TERASAKI
*Innovators in Protection Technology*

# TemBreak PRO

## New release




## IoT with SMART MCCB

**TERASAKI ELECTRIC CO., LTD.**
www.terasaki.co.jp
Catalogue No. '23-I68E

## Revised points

■ Revised the contents of “Product Warranty”.

■ Added the list of breakers for marine use and rated breaking capacities to Chapter 2 21.

■ Added the selection of breakers for protection of motor branch circuits approved by ship classification societies to Chapter 3 8.

■ Added the combination of breakers for cascade breaking approved by NK, LR, AB to Chapter 3 19.

■ The following models have been discontinued.

1) Molded Case Circuit Breaker for motor protection
   XM30PB, PS125-NM

2) TB series for distribution boards and control boards
   TB-5S (4poles), TB-5P (Single pole), TB-10S

3) Economical series of Earth Leakage Circuit Breakers
   TZD32-EA

■ Deleted the Plug-in for distribution boards (PMC).

# TABLE OF CONTENTS


## 1. General ····· 1-1

- Features ····· 1-2
- Series configuration/appearance ····· 1-8
- Selection Chart ····· 1-10

## 2. Ratings and Specifications ····· 2-1

**Moulded Case Circuit Breakers**

1 Economical series ····· 2-2
2 Standard series ····· 2-3
3 High-fault level series ····· 2-9
4 Current limiting standard series ····· 2-13
5 Current limiting High-fault level series ····· 2-15
6 Moulded Case Circuit Breakers for motor protection ····· 2-16
7 Switch-disconnectors ····· 2-17
8 Non-automatic trip breakers ····· 2-20
9 Circuit Breaker with earth leakage alarm ····· 2-21
10 Circuit Breaker with earth leakage alarm for distribution boards and control boards ··· 2-25
11 Single phase 3-wire circuit breaker with neutral phase open protection and earth leakage alarm ··· 2-26
12 Single phase 3-wire circuit breaker with neutral phase open protection ··· 2-28
13 TB series for distribution boards and control boards ····· 2-30

**Earth Leakage Circuit Breakers**

14 Economical series ····· 2-31
15 Standard series ····· 2-32
16 High-fault level series ····· 2-34
17 Earth Leakage Circuit Breakers for motor protection ····· 2-35
18 Single phase 3-wire earth leakage circuit breaker with neutral phase open protection ··· 2-36
19 Earth Leakage Circuit Breakers for distribution boards and control boards ··· 2-38

**Earth Leakage Relays**

20 TZS series ····· 2-39
21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies) ··· 2-40
22 List of breakers for CCC approved and rated breaking capacities ··· 2-52

## 3. Selection ····· 3-1

1 Characteristics and Performance ····· 3-2
2 Current-carrying capacity depending on ambient temperature and cable size ··· 3-3
3 Application of circuit breakers and earth leakage circuit breakers based on transformer capacity ··· 3-4
4 Application of circuit breakers based on breaking capacity ··· 3-6
5 Application of earth leakage circuit breakers based on breaking capacity ··· 3-7
6 Selection of earth leakage circuit breakers for the purpose of protection ··· 3-8
7 Selection of circuit breakers and earth leakage circuit breakers for motor circuit main lines ··· 3-9
8 Selection of breakers for protection of motor branch circuits ··· 3-10
9 Selection of earth leakage circuit breakers for motor branch circuits ··· 3-14
10 Selection of circuit breakers for lamps and electric heating circuits ··· 3-16
11 Selection of earth leakage circuit breakers for lamps and electric heating circuits ··· 3-17
12 Selection of motor protection breakers (for direct start) ··· 3-18
13 Selection of earth leakage circuit breakers for motor protection (for direct start) ··· 3-19
14 Selection of circuit breakers for transformer primary side ··· 3-20
15 Selection of circuit breakers for resistance welding machine circuits ··· 3-21
16 Selection of circuit breakers for capacitor circuits ····· 3-21
17 Selection of circuit breakers for inverter circuits ····· 3-21
18 Selection of circuit breakers and earth leakage circuit breakers for selectivity coordination ··· 3-22
19 Combination of breakers for cascade breaking ····· 3-24
20 Selection of rated operational voltage and number of poles ··· 3-29
21 Selection of single phase 3-wire circuit breakers with neutral phase open protection ··· 3-30
22 Application of single phase 3-wire circuit breakers/earth leakage circuit breakers with neutral phase open protection to parallel circuits ····· 3-31
23 Selection of single phase 3-wire earth leakage circuit breakers with neutral phase open protection for photovoltaic power generation systems ··· 3-32

## 4. Special Breakers ····· 4-1

1 Instantaneous trip only breakers ····· 4-2
2 Special instantaneous trip breakers ····· 4-4
3 Circuit Breaker For DC Special Voltage ····· 4-6
4 DC specification product instantaneous trip set current value ··· 4-7
5 Type 2 Heat Resistant Circuit Breaker for Emergency Power Supplies ··· 4-8
6 Thermal Adjustable Circuit Breaker for Overseas Plants ··· 4-9
7 690 V AC Circuit Breaker ····· 4-10
8 Special Mounting Dimensions 400 A Frame Circuit Breaker ····· 4-12
9 High-Performance Electronic Smart Circuit Breaker (TPOU type OCR) ··· 4-14
10 High-Performance Electronic Circuit Breaker (XOW type OCR) ····· 4-23
11 Circuit Breaker for Special Environments ····· 4-29

## 5. Mounting and Connection ····· 5-1

1 Type of connections and mountings ····· 5-2
List of connecting type ····· 5-2
Connecting parts ····· 5-6
Plug-in for switchboards (Plug-in) (PM) ····· 5-10
2 Compression terminals ····· 5-12
3 Terminal screw sizes and standard torques ····· 5-14
4 Insulation distance from the line side ····· 5-18
5 Lists of breaker mounting screws ····· 5-20
6 Effect of mounting angle ····· 5-21
7 Close fitting mounting ····· 5-22
8 Reverse connection ····· 5-23

## 6. Accessories ····· 6-1

1 OCR for electronic breakers ····· 6-2
1. TPOT type, TPOP type electronic OCR ····· 6-2
2. XOU type electronic OCR ····· 6-6
3. XOS type electronic OCR ····· 6-10
2 Internally mounted accessories ····· 6-14
1. Overview ····· 6-14
2. Connection diagrams and terminal numbers ····· 6-15
3. Possible combinations ····· 6-16
4. Ratings and operation data of auxiliary and alarm switches ··· 6-22
5. Shunt trip device (SH) ····· 6-23
6. Undervoltage trip device (UV) ····· 6-24
7. Shunt Trip for Circuit Breaker with Earth Leakage Alarm (SH) ····· 6-27
8. Circuit Breaker with Earth Leakage Alarm Option ····· 6-27
9. Remote reset voltage at both ends and current at closed path ····· 6-28
10. Test lead voltage at both ends and current at closed path ····· 6-28
3 Externally mounted accessories ····· 6-29
1. Overview ····· 6-29
2. Toggle extension ····· 6-30
3. Motor operators (MC) ····· 6-31
4. External operating handles ····· 6-36
Breaker-mounted (HB) ····· 6-36
Door-mounted (HP) ····· 6-51
5. Mechanical interlock ····· 6-63
Slide interlock (MS) ····· 6-63
Rear-connected interlock (MB) ····· 6-90
Link interlock (ML) ····· 6-91
Wire interlock (MW) ····· 6-102
6. Toggle holder (HH) and toggle lock (HL) ····· 6-117
7. Terminal covers CF/CR/CS ····· 6-119
8. Interpole barriers (BA) ····· 6-124
9. Terminal blocks (TF) ····· 6-125
10. Flush-mounted (flush plate) auxiliary circuit terminal block (TB) ··· 6-137
11. Plug-in auxiliary circuit terminal block ····· 6-147
12. DIN rail adapter ····· 6-152
13. Door Flange (DF) ····· 6-153

## 7. Characteristics and Outline Dimensions ····· 7-1

Moulded Case Circuit Breakers ····· 7-4
Moulded Case Circuit Breakers for motor protection ····· 7-88
Switch-disconnectors ····· 7-94
Non-automatic trip breakers ····· 7-116
Circuit Breaker with earth leakage alarm ····· 7-120
Circuit Breaker with earth leakage alarm for distribution boards and control boards ··· 7-140
Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm ··· 7-144
Single phase 3-wire circuit breakers with neutral phase open protection ··· 7-150
Circuit Breaker for distribution boards ····· 7-162
Earth Leakage Circuit Breakers ····· 7-174
Earth Leakage Circuit Breakers for motor protection ····· 7-198
Single phase 3-wire earth leakage circuit breakers with neutral phase open protection ··· 7-206
Earth Leakage Circuit Breaker for distribution boards and control boards ··· 7-214
Special Breakers ····· 7-220
Earth Leakage Relays ····· 7-243
Circuit Breaker with motor operators ····· 7-244

## 8. Handling and maintenance ····· 8-1

1 Transportation and storage ····· 8-2
2 Environmental operating conditions ····· 8-2
3 Installation and connection ····· 8-2
4 Maintenance and inspection ····· 8-4

## 9. Appendix ····· 9-1

1 Trip button, earth leakage indicator, test button, selector switch mounting position ··· 9-2
2 Handle operation and dimensions ····· 9-5
3 Maintenance and Inspection Checker ····· 9-6
4 Internal resistance and power consumptions ····· 9-7
5 Calculation and Reference Graphs of the Short Circuit Current ··· 9-10
6 Order Form ····· 9-19

## 10. *TemPlug* ····· 10-1

# Now our PRO series is launched.

## Ultratech for enhanced safety and usability.
## New product recommendation from TERASAKI

*User Friendly*

*Hi-Performance with Hi-Technology*

*Safety*









# It's the TemBreak PRO

# Product warranty

Please confirm the following product warranty before purchasing and using the product.

## 1. Warranty period and warranty coverage

If any failure found to be the responsibility of Teasaki Electric occurs during use of the product within the warranty period, the product shall be repaired at no cost via the sales representative or Terasaki Electric sales office. However, if repairs are required on-site at domestic or overseas locations, expenses to send an engineer will be charged.

**[Warranty period]**

The warranty period of the product shall be for 12 months after the date of purchase of delivery to the designated place. However, the maximum free warranty period is 18 months from the date of manufacture, with a maximum distribution period of 6 months after shipment.
The free-of-charge warranty period of the repaired product will not be extended beyond the free-of-charge warranty period before the repair.

**[Warranty coverage]**

1) The primary failure diagnosis should be performed by users. However, if required by users, Terasaki Electric or Terasaki Electric Sales office may be able to perform the diagnosis for a fee.
2) The coverage shall be limited to ordinary use within the usage state, usage methods, usage environment, and other conditions which follow the instructions and precautions given in the instruction manual, user's manual, and caution labels on the product.
3) Even within the warranty period, repair cost shall be charged for the following cases.

① Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by selection of hardware or software design on the user side.
② Failure caused by modifications, etc. to the product by the user without any approvals from Terasaki Electric.
③ In case Terasaki Electric product is assembled into a user's device, failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
④ Failure that could have been avoided if the maintenance described in the user's manual has been performed.
⑤ Failure caused by external irresistible forces such as fires or abnormal voltages, and failure caused by natural disasters such as earthquakes, lightning, wind and water damages.
⑥ Failure caused by reasons unpredictable based on scientific technology standards at the time of shipment from Terasaki Electric.
⑦ Any other failure found not to be the responsibility of Terasaki Electric or that admitted not to be so by the user.

＊In addition, the warranty applies only to the product delivered. It does not apply to the any damage that is caused by the failure of the product.

## 2. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the warranty period, Terasaki Electric shall not be liable for compensation to:

1) Damages caused by any cause found not to be the responsibility of Terasaki Electric.
2) Loss in opportunity, lost profits incurred to the user by failures of Terasaki Electric product.
3) Damages whether foreseeable or not, secondary damages, compensation for accidents, and compensation for damages to products other than Terasaki Electric products, caused by exceptional situations.
4) Compensation for cost occurring secondarily from replacement work by the user, maintenance of on-site equipment and start-up test run and other operations.

## 3. Product applications

1) When using the products listed in this catalogue, the following conditions must be confirmed and obeyed. The product must be used so that a failure that occurs to the product does not lead to a serious accident. When a damage or failure occurs, the external backup function or fail-safe function must be executed systematically.
2) The products listed in this catalogue are designed and manufactured as general-purpose products for application to the general industry field. When considering the use of our products for special applications such as the following equipment and systems, please contact Terasaki Electric sales office to confirm the specifications.

① The use that has a significant influence on the public facilities such as nuclear power plants and other power plants of power companies.
② The use for railway companies, government offices, etc. that require to build the special quality assurance system.
③ The use for aerospace equipment, medical equipment, railway equipment, combustion and fuel equipment, passenger vehicles, manned transportation equipment, recreational equipment, safety equipment, and air conditioner for servers and the cooling facilities that are expected to have a significant influence on life, body, and property.

## 4. Safety notice

Be sure to read these Instructions and other associated documents accompanying the product thoroughly to be familiarize yourself with the product handling, safety information, and all other precautions before mounting, using, servicing, or inspecting the product.


**[Meaning of indication]**

| | |
|---|---|
| ⚠ Warning | Warning notice with this symbol indicates that neglecting the suggested procedure or practice could result in lethal or serious personal injury. |
| ⚠ Caution | A caution notice with this symbol indicates that neglecting the suggested procedure or practice could result in moderate or slight personal injury and/or property damage. |

### ■Mounting precautions

**⚠ Caution**

- ●Electrical work should only be undertaken by suitably qualified persons.
- ●Do not place the product in an area that is subject to high temperature, high humidity, excessive dusty air, corrosive gas, strong vibration and shock, or other unusual conditions. Mounting in such areas could cause a fire or malfunction.
- ●Be careful to prevent foreign objects (debris, concrete powder, iron powder, etc.) and rainwater from entering product. These materials inside the product could cause a fire or malfunction.
- ●For 4-pole breakers, be sure to connect a neutral conductor to the N pole. Otherwise, an over-current may hinder the product from tripping, thus resulting in a fire.
- ●When connecting cable or busbar to the product, tighten terminal screws to the torque specified in this manual. Otherwise, a fire could result.
- ●For front-connected breakers, Insulate all bare conductors of the line side until the breaker end. If interpole barriers are packed, be sure to use the barriers; moreover, insulate all bare conductors by insulating tape or the like so that the tape overlaps with the barriers. Insufficient insulation may result in short-circuit.




- ●Do not block the arc gas vents of the product to ensure adequate arc space. Blocking these vents could result in failure of circuit interruption.


**[Earth leakage circuit breakers or Circuit breakers with earth leakage alarm]**

- ●When using a 3-pole breaker in a single -phase 2-wire circuit, connect the power source to the right and left poles. Do not connect it to the central pole. Otherwise, the earth leakage tripping or earth leakage alarm function will be inoperative.
- ●Using the test button, check the breaker for normal operation. Proceed as follows: After proper connection, move the handle to the I(ON) position and then (while applying voltage to the breaker) press the test button. The breaker will trip open. If pressing the test button for 2 or 3 seconds does not cause the breaker to trip open, the breaker is out of order. Please contact your local agent or our branch office immediately.

### ■Handling Precautions

**⚠ Warning**

- ●The earth leakage circuit breaker trips open just when the difference between outgoing current and incoming current exceeds a specified value. Never touch two or more bare live parts simultaneously. The breaker does not respond to electric shock.
- ●Never touch terminals. Otherwise, electric shock may result.




**⚠ Caution**

- ●When the breaker trips open automatically, remove the cause, then return the handle to the I(ON) position. Should a fault be interrupted, the breaker must be inspected. Otherwise, a fire may result.

**[Earth leakage circuit breakers or Circuit breakers with earth leakage alarm]**

- ●Be sure to connect the earth terminal of a load device to ground.
- ●Check the breaker for normal operation by pressing the test button once per month. (In case of leakage alarm, before testing the product, make sure that a leakage alarm from the product has no harmful effect on the electrical equipment or circuits.) If pressing the test button for 2 or 3 seconds does not cause the breaker to trip open, the breaker is out of order. Replace it by new one.

### ■Maintenance Precautions

**⚠ Caution**

- ●Service and/or inspection of the product must be done by persons having expert knowledge.
- ●Prior to commencing any work on the product, open an upstream circuit breaker or isolator to ensure that no voltage is applied to the product. Otherwise, electrical shock may result.
- ●When connecting cable or busbar to the product, tighten terminal screws to the torque specified in this manual. Otherwise, a fire could result.

## 5. Ordering information

Products and specifications appearing in this catalogue are subject to change (including discontinued sales) due to product improvements and other reasons, therefore contact TERASAKI or your local dealer prior to using, considering or ordering the shown products to confirm that the information in this catalogue is the up-to-date.

# 1 General

Features ····· 1-2
Series configuration/appearance ····· 1-8
Selection Chart ····· 1-10

## Based Standards

| | |
|---|---|
| **JIS C 8201-2-1 Ann.1 Ann.2**<br>**JIS C 8201-2-2 Ann.2** | Japanese Industrial Standard |
| **IEC 60947-2** | International Electrotechnical Commission |
| **EN 60947-2** | European Standard |

# Completely renewed electronic circuit breakers, ranging from

## Among the industry's smallest breakers

Models sizing 100AF or 125AF are the industry's smallest, measuring just 90 mm width, 130 mm height, and 68 mm depth for 3-pole types. 630AF models are of the same dimensions as 400AF versions: 140 mm width, 260 mm height, and 103 mm depth for 3-pole types. Their compactness helps space-saving in distribution switchboards.




## Smart MCCBs facilitating energy saving

Our new smart circuit breakers are capable of acquiring, displaying, and transmitting circuit information.
They help consolidate and reduce devices needed for energy management systems used at buildings and factories.

TemView PRO
Remote display




**★Remote display of circuit information**

The TemViewPRO Remote display (optional) can be connected to the smart circuit breakers using a single cable and easily attached to the switchboard panel. It has a back-lit LCD display that is highly visible even in dark places.

**★Centralized control of circuit information**

The TemComPRO Communication Module (optional) allows network communication of circuit information.
A system can be easily developed owing to the Modbus RTU communication protocol.
The TemComPRO can be mounted on a DIN rail with a snap-on mechanism and wired using connectors, so it is easy to install for additional installation.
With use of a support, the module can also be mounted on the side of the circuit breaker.




**★Zone interlock function mitigates circuit damage**

If an accidental short circuit or ground fault occurs in a selective coordinated circuit with short time-delay protection and ground fault protection, the circuit breaker in the immediate upstream of the accident spot can be protected by an instantaneous trip triggered as a result of deactivation of time delay settings, consequently alleviating thermal and mechanical damage to the circuit at the time of accidental short circuiting. Linkage can be established among smart circuit breakers ranging from 100AF to 630AF, as well as between the smart circuit breaker and the TemPower2 air circuit breaker.

# 100AF to 630AF, provide much improved user convenience.


## Advanced standard series electronic circuit breakers


★Protection settings of standard series can be adjusted using multiple dials in place of conventional two dials, enabling flexible configuration of protection to meet a wide variety of needs.

★The pre-trip alarm function, which was optional for the previous series, is now available as a standard feature. With this, the load current can be constantly monitored.

★Settings for long time-delay can be configured by conventional rated current adjustment; in addition, it can be set to 91% and 100% of the rated current, in 1% increments. This allows fine tuning to suit the load conditions to be applied.

★Also equipped with a temperature self-monitoring function.
When the temperature of the circuit board inside the over-current protective device exceeds 105°C, a LED lamp lights up in red to indicate an abnormal operating status of the breaker.







Smart AX/AL switch

### ★Versatile measurement functions

The following types of circuit information can be acquired. There is no need to install in-panel instruments and incidental connecting wires in the energy management system.

- Current • Voltage • Wattage • Watt-hour • Power factor
- Frequency • Total harmonic distortion • Demand current
- Demand wattage

### ★Precision measurement

Rogowski coils are used for current sensors.
Measurement is now possible with higher precision than previous series.
Reading errors complying with the international standard IEC 61557-12 were adopted to realize enhanced measurement accuracy: ±1% for electric current, ±0.5% for voltage, and ±2% for wattage.
This allows precise monitoring of energy use conditions.


### ★Great visibility

An OLED display panel is used for the display to indicate measurement values. Also, high visibility is ensured by use of symbols representing the items to be displayed.




### ★Excellent operability

A joystick is used for switching display screens and configuring settings.
User-friendliness improved in comparison with push-button operation adopted in conventional models.





### ★Status indication realized by smart AX/AL switch

With a special AX/AL switch installed, the number of times the auxiliary switch and alarm switch were activated can be indicated on the display of the circuit breaker, and it is also possible to transmit the activation count, along with the status of these switches, to the network including remote displays.

# Rated breaking capacity improved for 100AF - 630AF models

| | TemBreak2 | TemBreak PRO |
|---|---|---|
| 100AF<br>125AF |  **S100-GF**<br>415V AC<br>$I_{cu}/I_{cs}$=65kA/33kA |  **PS125-PF**<br>415V AC<br>$I_{cu}/I_{cs}$=70kA/50kA |
| 225AF<br>250AF |  **S225-GF**<br>415V AC<br>$I_{cu}/I_{cs}$=65kA/35kA |  **PS250-PF**<br>415V AC<br>$I_{cu}/I_{cs}$=70kA/50kA |
| 400AF |  **S400-PF**<br>415V AC<br>$I_{cu}/I_{cs}$=85kA/85kA |  **PH400-CF**<br>415V AC<br>$I_{cu}/I_{cs}$=110kA/110kA |
| 630AF |  **S630-PF**<br>415V AC<br>$I_{cu}/I_{cs}$=100kA/50kA |  **PH630-CF**<br>415V AC<br>$I_{cu}/I_{cs}$=110kA/110kA |

The 400AF/630AF models feature a pressure trip mechanism that leverages internal pressure generated at the time of a short-circuit trip, and a rotating double contact structure that has evolved from the world's first current-limiting circuit breaker technology developed by Terasaki. Owing to smooth contact separation realized by the rotating double throw contact, as well as speedy cut-off by the pressure trip mechanism, these new circuit breakers have excellent breaking performance: $I_{cu}/I_{cs}$ = 110kA/110kA (415V AC) .




# Safety inherited from *TemBreak2*

The safety-conscious functions and design features of the TemBreakPRO were taken over from the ***TemBreak2*** series.


## Isolation capability

The isolation capability means that, as long as the main contact is closed, the toggle is not in the OFF position and cannot be locked at the OFF position.
The toggle being in the OFF position hence shows the main contact is open and personnel are not exposed to electrical shock hazard when working in the load side.





## Direct Opening Action

As well as being a spring-based switching mechanism, with the forced OFF mechanism, the main contact is moved directly by the operating force from the toggle at the time of OFF operation.
It can be used as an emergency stop switch for machines which comply with IEC60204-1. Even if the internal spring mechanism is damaged, the plug-in base can be turned OFF, meaning that it is safe.




## Enhanced Insulation

The risk of touching live parts has been minimized by design. If the toggle is broken by accident or misuse, no live part is exposed.
Moreover, 400AF and 630AF models adopted a pole unit structure comprising contacts and arc chambers housed in plastic cases and allocated to each pole.
This helped improve insulation performance between poles.




## Easy-to-understand status indication

The indicator clearly shows Red when the circuit breaker is ON and Green when the breaker is OFF. No color indication means the device has tripped.
This design prevents misperception of breaker status when seen from any angle, thus ensuring safety.



# Global Standard

## Compatible with new JIS standards, IEC standards, and EN standards

TemBreak PRO moulded case circuit breakers comply with new JIS standards, IEC international standards and EN European standards.

**New JIS standard**
Moulded case circuit breakers
JIS C 8201-2-1
Earth leakage circuit breakers
JIS C 8201-2-2

**IEC standard**
Low-voltage switchgear and controlgear
Part2 Circuit-breakers
IEC 60947-2

**Electrical Appliances and Materials Safety Act**
PSE

**EN standard**
Low-voltage switchgear and controlgear
Part2 Circuit-breakers
EN 60947-2

They comply with the European safety EC Directive.

In addition to the models for overseas export, the standard products for domestic use comply with CE marking. (Excludes some models)

The products can be used both in Japan and overseas. (Earth leakage circuit breakers are for domestic use only.)

**CE marking**
☆Standard products compliance

**Isolation function Indication**




**New JIS standard:**
JIS C 8201-2-1
**IEC standard:** IEC60947-2
**EN standard:** EN60947-2

**Certified by the Japan Ship Technology Research Association**
NK, LR, ABS, BV, CCS, KR, RINA
(Excludes some models)

## Obtained CCC certification

TemBreak PRO moulded case circuit breakers comply with GB standards and are CCC certified.

**CCC certification**
GB standard:
GB/T 14048.2


中国国家强制性产品认证证书
证书编号：2019010307259638
委托人名称、地址
寺崎（中国）电气设备有限公司
广州增城区新塘镇太平洋五路1号
生产者（制造商）名称、地址
日本寺崎电气产业株式会社
日本大阪府大阪市平野区加美东6丁目13番47号
生产企业名称、地址
寺崎电气产业株式会社耶马溪制作所
日本大分県中津市耶马溪町大字戸原1073番地1
产品名称和系列、规格、型号
塑料外壳式断路器
PE400-NE,PS400-CE,PS400-SE,PS400-NE,PS400-GE,PS400-RE,PH400-CE,PE630-NE,PS630-CE,PS630-SE,PS630-NE,PS630-GE,PS630-RE,PH630-CE,PE400-NF,PE400-NJ,PS400-CF,PS400-CJ,PS400-SF,PS400-SJ,PS400-NF,PS400-NJ,PS400-GF,PS400-GJ,PS400-RF,PS400-RJ,PH400-CF,PH400-CJ,PE630-NF,PE630-NJ,PS630-CF,PS630-CJ,PS630-SF,PS630-SJ,PS630-NF,PS630-NJ,PS630-GF,PS630-GJ,PS630-RF,PS630-RJ,PH630-CF,PH630-CJ;详见附件
产品标准和技术要求
GB/T14048.2-2008
上述产品符合强制性产品认证实施规则 CNCA-C03-02:2014 的要求，特发此证。
发证日期：2019年12月16日　有效期至：2024年12月16日
证书有效期内本证书的有效性依据发证机构的定期监督获得保持。
本证书的相关信息可通过国家认监委网站 www.cnca.gov.cn 查询
经中国合格评定国家认可委员会认可 CNAS C001-P
主任：
中国质量认证中心
Q 2495926

## ●CCC certification system

The Chinese government enforces compulsory product certification covering areas such as safety and EMC for products that are distributed in China. It is prohibited to ship products that have not obtained CCC certification within China, import them into China, or sell them. TemBreak PRO products comply with GB/T 14048.2, the Chinese national standard, which is the technical standard for the CCC certification system. See page 2-52, 2-53 for details of CCC certified models.

## Obtained DEKRA certification

TemBreak PRO moulded case circuit breakers have obtained certification from DEKRA in Germany, an international certification body. We passed short circuit breaking test with DEKRA as a witness. DEKRA certification is recognised for its reliability not only in Europe but all over the world.

●KEMA, the Dutch standards association for electrical equipment, came under the umbrella of DEKRA in 2011. As such, the former KEMA certification is now called DEKRA certification.



IEC IECEE CB SCHEME

IEC SYSTEM FOR MUTUAL RECOGNITION OF TEST CERTIFICATES FOR ELECTRICAL EQUIPMENT (IECEE) CB SCHEME

CB TEST CERTIFICATE

| | |
|---|---|
| Product | Moulded Case Circuit-breakers |
| Name and address of the applicant | TERASAKI ELECTRIC CO., LTD.<br>6-13-47 Kamihigashi, Hirano-ku, Osaka 547-0002<br>Japan |
| Name and address of the manufacturer | TERASAKI ELECTRIC CO., LTD.<br>6-13-47 Kamihigashi, Hirano-ku, Osaka 547-0002<br>Japan |
| Name and address of the factory | Additional information on page 2<br>TERASAKI ELECTRIC CO., LTD.<br>Yabakei Factory<br>1073-1, Tobaru Yabakei-machi<br>Nakatsu-shi, Oita 871-0404<br>Japan |
| Ratings and principal characteristics | 3-pole, 4-pole (3-pole+N), with electronic release<br>In 250 A, 400 A, 630 A, Ue 220 Vac to 690 Vac, 50/60 Hz,<br>Uimp = 8 kV, Ui = 800 V, Suitable for isolation<br>See annex for details of rated currents, rated voltage and Ics / Icu ratings |
| Trademark (if any) | TERASAKI |
| Customer's Testing Facility (CTF) Stage used | CTF Stage 2 |
| Model / Type Ref. | PE...-N..., PS...-C..., PS...-S..., PS...-N...,<br>PS...-G..., PS...-R..., PH...-C... series |
| Additional information (if necessary may also be reported on page 2) | Additional information on page 2 |
| A sample of the product was tested and found to be in conformity with | IEC 60947-2:2016 |
| As shown in the Test Report Ref. No. which forms part of this Certificate | 2226199.52 |

This CB Test Certificate is issued by the National Certification Body

DEKRA Certification B.V.
Meander 1051, NL-6825 MJ Arnhem, Netherlands

DEKRA

Date: 2019-01-09

Signature: H.L. Schenstok


page 1 of 1

# Ecology

## Conforms to the RoHS2 Directive

We use environmentally-friendly materials and do not use harmful substances.
We use recyclable thermoplastic resin for plastic parts and indicate the names of the materials used on the main plastic parts.
(Excludes some models)

● **Indication of material name**



# Series configuration / appearance

## Moulded Case Circuit Breakers

| Economical series | Standard series | | Current limiting series | |
|---|---|---|---|---|
| | N Standard | G High-fault level | H Standard | L High-fault level |
|  |  |  |  |  |
| 30A Frame to 400A Frame<br>Breaking Capacity 1.5kA to 25kA/415V AC | 30A Frame to 3200A Frame<br>Breaking Capacity 2.5kA to 85kA/415V AC | 50A Frame to 1250A Frame<br>Breaking Capacity 50kA to 100kA/415V AC | 100A Frame to 1200A Frame<br>Breaking Capacity 110kA to 125kA/415V AC | 100A Frame to 800A Frame<br>Breaking Capacity 200kA/415V AC |
| See page 2-2 | See pages 2-3 to 2-8 | See pages 2-9 to 2-12 | See pages 2-13 to 2-14 | See page 2-15 |

| Moulded Case Circuit Breakers | | Earth Leakage Circuit Breakers | | |
|---|---|---|---|---|
| Switch-disconnectors | Non-automatic trip breakers | Economical series | Standard series | |
| | | | N Standard | G High-fault level |
|  |  |  |  |  |
| 30A Frame to 1600A Frame | 2000A Frame to 3200A Frame | 30A Frame to 400A Frame<br>Breaking Capacity 1.5kA to 25kA/415V AC | 30A Frame to 800A Frame<br>Breaking Capacity 2.5kA to 50kA/415V AC | 100A Frame to 400A Frame<br>Breaking Capacity65kA to 70kA/415V AC |
| See pages 2-17 to 2-19 | See page 2-20 | See pages 2-31 | See pages 2-32 to 2-33 | See page 2-34 |

| Motor protection series | | Single phase 3wire circuits | | |
|---|---|---|---|---|
| Moulded Case Circuit Breakers for motor protection | Earth Leakage Circuit Breakers for motor protection | Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm | Single phase 3-wire circuit breakers with neutral phase open protection | Single phase 3-wire earth leakage circuit breakers with neutral phase open protection |
|  |  |  |  |  |
| 30A Frame to 250A Frame<br>Breaking Capacity 1.5kA to 40kA/415V AC | 30A Frame to 250A Frame<br>Breaking Capacity 1.5kA to 40kA/415V AC | 125A Frame to 400A Frame<br>Breaking Capacity 35kA to 85kA/200V AC | 50A Frame to 800A Frame<br>Breaking Capacity 10kA to 85kA/200V AC | 50A Frame to 400A Frame<br>Breaking Capacity 10kA to 85kA/200V AC |
| See page 2-16 | See page 2-35 | See pages 2-26 to 2-27 | See pages 2-28 to 2-29 | See pages 2-36 to 2-37 |

## High-Performance Electronic Circuit Breaker

### TPOU type SMART



125A Frame to 630A Frame
Breaking Capacity 36kA to 110kA/415V AC

See pages 4-14 to 4-22

### XOW type



400A Frame to 1000A Frame
Breaking Capacity 50kA to 200kA/415V AC

See pages 4-23 to 4-28

## Circuit Breaker with Earth Leakage Alarm



50A Frame to 800A Frame
Breaking Capacity 2.5kA to 70kA/415V AC

See pages 2-21 to 2-24

## 690 V AC Circuit Breaker



125A Frame to 800A Frame
Breaking Capacity 70kA/690V AC

See page 4-10

## For distribution boards and control boards

### Circuit Breaker for Distribution Boards



30A Frame to 100A Frame
Breaking Capacity 2.5kA to 5kA/240V AC

See page 2-30

### Circuit Breaker with Earth Leakage Alarm for Distribution Boards and Control Boards



50A Frame to 100A Frame
Breaking Capacity 5kA/200V AC

See page 2-25

### Earth Leakage Circuit Breaker for Distribution Boards and Control Boards



30A Frame to 100A Frame
Breaking Capacity 2.5kA to 5kA/200V AC

See page 2-38

## Heat Resistant Circuit Breaker for Emergency Power Supplies



50A Frame to 400A Frame
Breaking Capacity 5kA to 30kA/415V AC

See page 4-8

## Earth Leakage Relays



Rated sensitivity current 30mA or 100/200/500/1000mA switching
Rated operating time 0.1s or less or 0.1 or less/0.3/0.5/1/2s selectable

See page 2-39

## For DC special voltage

### Moulded Case Circuit Breakers

#### For 1000V



125A Frame to 800A Frame
Breaking Capacity 5kA to 15kA/1000V DC

See Catalogue I73K

#### For 750V



125A Frame to 800A Frame
Breaking Capacity 3kA to 10kA/750V DC

See Catalogue I73K

#### For 600V



50A Frame to 3200A Frame
Breaking Capacity 5kA to 20kA/600V DC

See Catalogue I73K

### Switch-disconnectors

#### For 1000V



125A Frame to 800A Frame

See Catalogue I73K

#### For 750V




250A Frame to 800A Frame

See Catalogue I73K

# Selection Chart


| Moulded Case Circuit Breakers | Frame size (A) | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| | 30 | 50 | 60 | 100 | 125 | 225 | 250 | 400 |
| E Economical series | PE30-NF 1.5kA/2.5kA | PE50-NF 2.5kA/7.5kA | PE60-NF 2.5kA/7.5kA | PE125-NF 10kA/30kA | | E250-SF 25kA/35kA | | E400-NF 25kA/35kA |
| Standard series — N Standard | PS30-NF 2.5kA/7.5kA | PS50-NF 7.5kA/15kA | PS60-NF 10kA/30kA | S125-SF 30kA/50kA | | S250-SF 40kA/85kA | | PS400-CF 36kA/50kA |
| | | S50-SF 30kA/50kA | | PS125-NF 36kA/50kA | | | Electronic PS250-NE 36kA/50kA | PS400-NF 50kA/85kA |
| | | | | Electronic PS125-NE 36kA/— | | | | Electronic PS400-NE 50kA/85kA |
| Standard series — G High-fault level | | PS50-PF 70kA/85kA | | S100-GF 65kA/85kA | S125-GF 65kA/85kA | | | PS400-GF 70kA/100kA |
| | | | | PS125-PF 70kA/85kA | | PS250-PF 70kA/85kA | | Electronic PS400-GE 70kA/100kA |
| | | | | Electronic PS125-PE 70kA/— | | | Electronic PS250-PE 70kA/85kA | |
| Current limiting series — H Standard | | | | H100-NF 125kA/150kA | H125-NF 125kA/150kA | H225-NF 125kA/150kA | H250-NF 125kA/150kA | PH400-CF 110kA/125kA |
| | | | | | | Electronic H225-NE 125kA/150kA | | Electronic PH400-CE 110kA/125kA |
| | | | | | | | | Electronic H400-NE 125kA/150kA |
| Current limiting series — L High-fault level | | | | L100-NF 200kA/200kA | L125-NF 200kA/200kA | L225-NF 200kA/200kA | L250-NF 200kA/200kA | Electronic L400-NE 200kA/200kA |
| Moulded Case Circuit Breakers for motor protection | E30-NM 1.5kA/2.5kA | E50-NM 2.5kA/5kA | | E100-NM 10kA/25kA | | | | |
| | S30-NM 2.5kA/5kA | S50-NM 10kA/25kA | | | | S250-SM 40kA/85kA | | |
| Switch-disconnectors / Non-automatic trip breakers | PE30-NN | PE50-NN | | PE125-NN | | S250-SN | | PS400-NN |
| | | | | S125-SN | | PS250-NN | | |
| | | | | PS125-NN | | | | |
| Circuit Breaker with Earth Leakage Alarm | | PE50-NFZ 2.5kA/7.5kA | | PE125-NFZ 10kA/30kA | | ZAE250-SF 25kA/35kA | | ZAE400-NF 25kA/35kA |
| | | PS50-NFZ 7.5kA/15kA | | ZAS125-SF 30kA/50kA | | ZAS250-SF 40kA/85kA | | ZAS400-NF 50kA/85kA |
| | | ZAS50-GF 65kA/85kA | | ZAS100-GF 65kA/85kA | ZAS125-GF 65kA/85kA | ZAS225-GF 65kA/85kA | ZAS250-GF 65kA/85kA | ZAS400-GF 70kA/100kA |
| Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm | | | | NAE125-SF 35kA | | NAE250-SF 35kA | | NAE400-NF 35kA |
| | | | | NAS125-SF 50kA | | NAS250-SF 85kA | | NAS400-NF 85kA |
| Single phase 3-wire circuit breakers with neutral phase open protection | | PE50-NFN 10kA | | PE125-NFN 25kA | | NE250-SF 35kA | | NE400-NF 35kA |
| | | | | NS125-SF 50kA | | NS250-SF 85kA | | NS400-NF 85kA |
| Circuit Breaker for Distribution Boards | TB-52C —/2.5kA | TB-5S 2.5kA/5kA | | | | | | |
| | | TB-5P 2.5kA/5kA | | | | | | |
| | | TB-5D —/5kA | | | | | | |
| Circuit Breaker with Earth Leakage Alarm for Distribution Boards and Control Boards | | TB50KSL —/5kA | | TB100KSZ 2.5kA/5kA | | | | |
| | | TB50KSZ 2.5kA/5kA | | | | | | |





☆ For single phase 3-wire circuit breakers with neutral phase open protection, it indicates the breaking capacity at 100/200 V AC.

☆ For circuit breakers for distribution boards and control boards, it indicates the breaking capacity of 2 or 3 pole at 200 V AC.


# Selection Chart




☆ For single phase 3-wire earth leakage circuit breakers with neutral phase open protection, it indicates the breaking capacity at 100/200 V AC.

☆ For circuit breakers for distribution boards and control boards, it indicates the breaking capacity at 200 V AC.


600
630
800
ZS630-CF
36kA/50kA
ZS800-CF
36kA/50kA
ZS630-NF
50kA/85kA
ZS800-NF
50kA/85kA


# Selection Chart


**Breakers approved by NK ship classification society**

Frame size (A)

| | 30 | 50 | 60 | 100 | 125 | 225 | 250 | 400 |
|---|---|---|---|---|---|---|---|---|
| **E Economical series** | PE30-NF 1.5kA/1.5kA | PE50-NF 2.5kA/2.5kA | PE60-NF 2.5kA/2.5kA | PE125-NF 10kA/5kA | | E250-SF 15kA/12kA | | |
| **Standard series** N Standard | PS30-NF 2.5kA/2.5kA | PS50-NF 7.5kA/7.5kA | PS60-NF 10kA/5kA | S125-SF 25kA/13kA | | S250-SF 30kA/15kA | | PS400-CF 30kA/30kA |
| | | S50-SF 25kA/13kA | | PS125-NF 25kA/25kA | | | Electronic PS250-NE 25kA/25kA | PS400-NF 45kA/45kA |
| | | | | Electronic PS125-NE 25kA/25kA | | | | Electronic PS400-NE 45kA/45kA |
| **Standard series** G High-fault level | | PS50-PF 50kA/35kA | | S100-GF 50kA/25kA | S125-GF 50kA/25kA | | | PS400-GF 65kA/65kA |
| | | | | PS125-PF 50kA/35kA | | PS250-PF 50kA/35kA | | Electronic PS400-GE 65kA/65kA |
| | | | | Electronic PS125-PE 50kA/30kA | | | Electronic PS250-PE 50kA/35kA | |
| **Current limiting series** H Standard | | | | H100-NF 120kA/80kA | H125-NF 120kA/80kA | H225-NF 120kA/80kA | | PH400-CF 100kA/100kA |
| | | | | | | | | Electronic PH400-CE 100kA/100kA |
| | | | | | | | | Electronic H400-NE 120kA/80kA |
| **Current limiting series** L High-fault level | | | | L100-NF 180kA/135kA | L125-NF 180kA/135kA | L225-NF 180kA/135kA | | ElectronicS L400-NE 180kA/135kA |
| **Moulded Case Circuit Breakers for motor protection** | | | | PS125-NM 25kA/25kA | | | | |
| **Circuit Breaker for Distribution Boards** | | TB-5S 5kA/– *1 | | | | | | |
| | | TB-5P 5kA/– *1 | | | | | | |
| | | TB-5D 5kA/– *1 | | | | | | |

*1) at 250V AC
2.5kA/– for 10A




600
630
800
1000
1200
1250
S630-CF
30kA/30kA
S800-CF
30kA/30kA
PS630-CF
30kA/30kA
S630-NF
45kA/45kA
S800-NF
50kA/50kA
PS630-NF
45kA/45kA
Electronic
S630-NE
50kA/50kA
Electronic
S800-NE
50kA/50kA
Electronic
S1250-NE
65kA/50kA
PS630-GF
65kA/65kA
Electronic
S1250-GE
85kA/65kA
S800-PF
85kA/50kA
Electronic
S800-PE
85kA/50kA
PH630-CF
100kA/100kA
∗2) at 460V AC
∗2
∗2
Electronic
H630-NE
125kA/94kA
Electronic
H800-NE
125kA/94kA
Electronic
TL-1000NE
125kA/–
Electronic
TL-1200NE
125kA/–
Electronic
L630-NE
180kA/135kA
Electronic
L800-NE
180kA/135kA

# 2 Ratings and Specifications



Moulded Case Circuit Breakers
1 Economical series ····· 2-2
2 Standard series ····· 2-3
3 High-fault level series ····· 2-9
4 Current limiting standard series ····· 2-13
5 Current limiting High-fault level series ····· 2-15
6 Moulded Case Circuit Breakers for motor protection ····· 2-16
7 Switch-disconnectors ····· 2-17
8 Non-automatic trip breakers ····· 2-20
9 Circuit Breaker with earth leakage alarm ····· 2-21
10 Circuit Breaker with earth leakage alarm for distribution boards and control boards ··· 2-25
11 Single phase 3-wire circuit breaker with neutral phase open protection and earth leakage alarm ····· 2-26
12 Single phase 3-wire circuit breaker with neutral phase open protection ··· 2-28
13 TB series for distribution boards and control boards ····· 2-30

Earth Leakage Circuit Breakers
14 Economical series ····· 2-31
15 Standard series ····· 2-33
16 High-fault level series ····· 2-34
17 Earth Leakage Circuit Breakers for motor protection ····· 2-35
18 Single phase 3-wire earth leakage circuit breaker with neutral phase open protection ····· 2-36
19 Earth Leakage Circuit Breakers for distribution boards and control boards ····· 2-38


Earth Leakage Relays
20 TZS series ····· 2-39

21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies) ····· 2-40
22 List of breakers for CCC approved and rated breaking capacities··· 2-52

# 2 Ratings and Specifications

## Moulded Case Circuit Breakers

### 1 Economical series

| Frame size (A) | | | 30 | | 50 | | 60 | | 100 | | 125 | | 225 | | 250 | | 400 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | PE30-NF | | PE50-NF | | PE60-NF | | PE125-NF | | | | E250-SF | | | | E400-NF |
| Number of poles | | | 2 | 3 | 2 | 3 | 2 | 3 | 2 | 3 | 2 | 3 | 2＊ | 3 | 2＊ | 3 | 3 |
| **■Ratings** | | | | | | | | | | | | | | | | | |
| Rated current, A | | | 3 | | 15 | | 60 | | 60 | | 125 | | 125 | | 250 | | 250 |
| Calibrated at 40°C | | | 5 | | 20 | | | | 75 | | | | 150 | | | | 300 |
| 45°C | | | 10 | | 30 | | | | 100 | | | | 175 | | | | 350 |
| | | | 15 | | 40 | | | | | | | | 200 | | | | 400 |
| ＊2 poles breakers use the terminals of both ends of 3 poles breakers. | | | 20 | | 50 | | | | | | | | 225 | | | | |
| | | | 30 | | | | | | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | | 690 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | — | | — | | — | | — | | — | | — | | — | | — |
| Utilization Category | | | A | | A | | A | | A | | A | | A | | A | | A |
| **■Rated breaking capacity, kA** | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | — | | — | | — | | — | | — | | — | | — | | — |
| IEC 60947-2 | | 500V | — | | 2.5/2.5 | | 2.5/2.5 | | 7.5/4 | | 7.5/4 | | 10/7.5 | | 10/7.5 | | 15/15 |
| $I_{cu}/I_{cs}$(sym) | | 440V | 1.5/1.5 | | 2.5/2.5 | | 2.5/2.5 | | 10/5 | | 10/5 | | 15/12 | | 15/12 | | 22/22 |
| | | 415V | 1.5/1.5 | | 2.5/2.5 | | 2.5/2.5 | | 10/5 | | 10/5 | | 25/19 | | 25/19 | | 25/25 |
| | | 380V | 1.5/1.5 | | 5/5 | | 5/5 | | 10/5 | | 10/5 | | 25/19 | | 25/19 | | 25/25 |
| | | 240V | 2.5/2.5 | | 7.5/7.5 | | 7.5/7.5 | | 30/15 | | 30/15 | | 35/27 | | 35/27 | | 35/35 |
| | ① DC | 250V | — | | 2.5/2.5 ⑰ ㉗ | | 2.5/2.5 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 15/12 ㊽ | | 15/12 ㊽ | | 25/19 |
| | | 125V | — | | 2.5/2.5 ⑰ ㉗ | | 2.5/2.5 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 25/19 ㊽ | | 25/19 ㊽ | | 40/30 |
| NK | AC | 690V | — | | — | | — | | — | | — | | — | | — | | — |
| $I_{cu}/I_{cs}$(sym) | | 450V | 1.5/1.5 | | 2.5/2.5 | | 2.5/2.5 | | 10/5 | | 10/5 | | 15/12 | | 15/12 | | — |
| | | 240V | 2.5/2.5 | | 7.5/7.5 | | 7.5/7.5 | | 30/15 | | 30/15 | | 35/27 | | 35/27 | | — |
| | ① DC | 250V | — | | 2.5/2.5 ⑰ ㉗ | | 2.5/2.5 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | — | | — | | — |
| **■External dimensions, mm** | | | | | | | | | | | | | | | | | |
|  | | a | 50 | 75 | 50 | 75 | 50 | 75 | 50 | 75 | 50 | 75 | 105 | 105 | 105 | 105 | 140 |
| | | b | 130 | | 130 | | 130 | | 130 | | 130 | | 165 | | 165 | | 260 |
| | | c | 68 | | 68 | | 68 | | 68 | | 68 | | 68 | | 68 | | 103 |
| | | d | 90 | | 90 | | 90 | | 90 | | 90 | | 95 | | 95 | | 145 |
| Weight (◉ marked standard type) kg | | | 0.5 | 0.7 | 0.5 | 0.7 | 0.6 | 0.8 | 0.6 | 0.8 | 0.6 | 0.8 | 1.5 | 1.5 | 1.5 | 1.5 | 4.2 |
| **■Connections and Mountings** | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | | ◉ ㊺ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ |
| | With extension bars | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | — | | — | | — | | — | | — | | — |
| | Standard (PMC) | | — | ○ | — | ○ | — | ○ | — | ○ | — | ○ | ○ | | ○ | | — |
| For distribution boards (PMD) | | | ○ | | ○ | | ○ | | ○ | | ○ | | — | | — | | — |
| Flush-mounted (FP) With flat bar studs | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ |
| Draw-out type (DR) | | | — | | — | | — | | — | | — | | — | | — | | — |
| TemPlug70 (PG) | | | — | | — | | — | | — | | — | | — | ○ | — | ○ | ○ |
| DIN rail mount | | | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ | — | | — | | — |
| **■Accessories (optional)** | | Symbol | | | | | | | | | | | | | | | |
| Internally mounted: Auxiliary switch | | A X | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| Internally mounted: Alarm switch | | A L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| Internally mounted: Shunt trips | | S H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| Internally mounted: Undervoltage trips | | U V | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| Externally mounted: Motor operator | | M C | — | | — | | — | | — | | — | | ● | | ● | | ● |
| Externally mounted: External operating handle | Breaker-mounted | H B | — | ● | — | ● | — | ● | — | ● | — | ● | ● | | ● | | ● |
| | Door-mounted (variable depth) | H P | — | ● | — | ● | — | ● | — | ● | — | ● | ● | | ● | | ● |
| Externally mounted: Toggle extension | | H A | — | | — | | — | | — | | — | | — | | — | | ● |
| Externally mounted: Mechanical interlock | Slide type | M S | — | ● | — | ● | — | ● | — | ● | — | ● | ● | | ● | | ● |
| | Rear-connected type | M B | — | | — | | — | | — | | — | | — | | — | | — |
| | Link type | M L | — | | — | | — | | — | | — | | ● | | ● | | ● |
| | Wire type | M W | — | | — | | — | | — | | — | | ● | | ● | | ● |
| Externally mounted: Toggle holder | | H H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| Externally mounted: Toggle lock | | H L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | |
| Externally mounted: Terminal cover | For front-connected | C F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| | For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| Externally mounted: Terminal block for lead | | T F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| Externally mounted: Door flange | | D F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● |
| CE marking | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes |
| Overcurrent trip mechanism | | | Thermal-magnetic⑦ | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes |
| Reverse connection | | | Yes ⑫ | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes |
| Page of characteristics and outline dimensions | | | 7-4 | | 7-4 | | 7-8 | | 7-8 | | 7-8 | | 7-28 | | 7-28 | | 7-42 |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


● : "yes" or "available". — : "no" or "not available".

① : DC is a special specification. When ordering, please specify DC. ⑦ : Hydraulic-magnetic type for below 10A rating.

⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑰ : See page 4-7 for the instantaneous trip value when using with DC.


㉗ : Applicable to only 2 poles breakers. ㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts.

⑫ : There are some limitations. See page 5-23 for details. ㊽ : DC is a 2-pole product that uses both ends of a 3-pole circuit breaker.


| | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | | 30 | | | 50 | | | 50 | | | | 60 | | | | | | | | | |
| Type | | | | | PS30-NF | | | PS50-NF | | | S50-SF | | | | PS60-NF | | | | | | | | | |
| Number of poles | | | | | 2 | 3 | | 2 | 3 | | 2 | 3 | 4 | | 2 | 3 | | | | | | | | |
| ■Ratings | | | | | | | | | | | | | | | | | | | | | | | | |
| Rated current, A | | | | | 3 | | | 15 | | | 15 | | | | 60 | | | | | | | | | |
| Calibrated at 40°C | | | | | 5 | | | 20 | | | 20 | | | | | | | | | | | | | |
| 45°C | | | | | 10 | | | 30 | | | 30 | | | | | | | | | | | | | |
| | | | | | 15 | | | 40 | | | 40 | | | | | | | | | | | | | |
| | | | | | 20 | | | 50 | | | 50 | | | | | | | | | | | | | |
| | | | | | 30 | | | | | | | | | | | | | | | | | | | |
| Rated insulation voltage 〔$U_i$〕 V | | | | | 690 | | | 690 | | | 690 | | | | 690 | | | | | | | | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | | | 8 | | | 8 | | | 8 | | | | 8 | | | | | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | | — | | | — | | | — | | | | — | | | | | | | | | |
| Utilization Category | | | | | A | | | A | | | A | | | | A | | | | | | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | | — | | | — | | | 6/3 | | | | — | | | | | | | | | |
| IEC 60947-2 | | | 500V | | 2.5/2.5 | | | 7.5/7.5 | | | 12/6 | | | | 7.5/4 | | | | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | | 2.5/2.5 | | | 7.5/7.5 | | | 25/13 | | | | 10/5 | | | | | | | | | |
| | | | 415V | | 2.5/2.5 | | | 7.5/7.5 | | | 30/15 | | | | 10/5 | | | | | | | | | |
| | | | 380V | | 5/5 | | | 7.5/7.5 | | | 30/15 | | | | 10/5 | | | | | | | | | |
| | | | 240V | | 7.5/7.5 | | | 15/15 | | | 50/25 | | | | 30/15 | | | | | | | | | |
| | ① | DC | 250V | | 2.5/2.5 ⑰ ⑲ ㉗ | | | 7.5/7.5 ⑰ ㉗ | | | 25/13 ⑰ ㉗ | | | | 7.5/4 ⑰ ㉗ | | | | | | | | | |
| | | | 125V | | 2.5/2.5 ⑰ ⑲ ㉗ | | | 7.5/7.5 ⑰ ㉗ | | | 40/20 ⑰ ㉗ | | | | 7.5/4 ⑰ ㉗ | | | | | | | | | |
| NK | | AC | 690V | | — | | | — | | | — | | | | — | | | | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | | 2.5/2.5 | | | 7.5/7.5 | | | 25/13 | | | | 10/5 | | | | | | | | | |
| | | | 240V | | 7.5/7.5 | | | 15/15 | | | 50/25 | | | | 30/15 | | | | | | | | | |
| | ① | DC | 250V | | 2.5/2.5 ⑰ ⑲ ㉗ | | | 7.5/7.5 ⑰ ㉗ | | | 25/13 ⑰ ㉗ | | | | 7.5/4 ⑰ ㉗ | | | | | | | | | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | | | | | | | | | |
|  | | | a | | 50 | 75 | | 50 | 75 | | 50 | 75 | 100 | | 50 | 75 | | | | | | | | |
| | | | b | | 130 | | | 130 | | | 130 | | | | 130 | | | | | | | | | |
| | | | c | | 68 | | | 68 | | | 68 | | | | 68 | | | | | | | | | |
| | | | d | | 90 | | | 90 | | | 95 | | | | 90 | | | | | | | | | |
| Weight (◉ marked standard type) kg | | | | | 0.5 | 0.7 | | 0.5 | 0.7 | | 0.6 | 0.8 | 1.0 | | 0.6 | 0.8 | | | | | | | | |
| ■Connections and Mountings | | | | | | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | | Terminal screws | | | ◉ ㊺ | | | ◉ ㊺ | | | ◉ ㊺ | | | | ◉ | | | | | | | | | |
| | | With extension bars | | | ○ ㊸ | | | ○ ㊸ | | | ○ ㊸ | | | | ○ ㊸ | | | | | | | | | |
| Rear-connected (RC) | | Flat bar studs | | | ○ | | | ○ | | | ○ | | | | ○ | | | | | | | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | | — | | | — | | | — | | | | — | | | | | | | | | |
| | | Standard (PMC) | | | — | ○ | | — | ○ | | — | ○ | — | | — | ○ | | | | | | | | |
| | For distribution boards (PMD) | | | | ○ | | | ○ | | | ○ | | — | | ○ | | | | | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | | ○ | | | ○ | | | ○ | | — | | ○ | | | | | | | | | |
| Draw-out type (DR) | | | | | — | | | — | | | — | | | | — | | | | | | | | | |
| TemPlug70 (PG) | | | | | — | | | — | | | ○ | | — | | — | | | | | | | | | |
| DIN rail mount | | | | | — | ○ ⑪ | | — | ○ ⑪ | | — | ○ ⑪ | | | — | ○ ⑪ | | | | | | | | |
| ■Accessories (optional) | | | | Symbol | | | | | | | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | | | A X | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| | Alarm switch | | | A L | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| | Shunt trips | | | S H | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| | Undervoltage trips | | | U V | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| Externally mounted | Motor operator | | | M C | — | | | — | | | — | | | | — | | | | | | | | | |
| | External operating handle | Breaker-mounted | | H B | — | ● | | — | ● | | — | ● | | | — | ● | | | | | | | | |
| | | Door-mounted (variable depth) | | H P | — | ● | | — | ● | | — | ● | | | — | ● | | | | | | | | |
| | Toggle extension | | | H A | — | | | — | | | — | | | | — | | | | | | | | | |
| | Mechanical interlock | Slide type | | M S | — | ● | | — | ● | | — | ● | | | — | ● | | | | | | | | |
| | | Rear-connected type | | M B | — | | | — | | | — | | | | — | | | | | | | | | |
| | | Link type | | M L | — | | | — | | | — | | | | — | | | | | | | | | |
| | | Wire type | | M W | — | | | — | | | — | | | | — | | | | | | | | | |
| | Toggle holder | | | H H | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| | Toggle lock | | | H L | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| | Terminal cover | For front-connected | | C F | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| | | For rear-connected and plug-in | | C R | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| | Terminal block for lead | | | T F | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| | Door flange | | | D F | ● | | | ● | | | ● | | | | ● | | | | | | | | | |
| CE marking | | | | | Yes | | | Yes | | | Yes | | | | Yes | | | | | | | | | |
| Overcurrent trip mechanism | | | | | Thermal-magnetic⑦ | | | Thermal-magnetic | | | Thermal-magnetic | | | | Thermal-magnetic | | | | | | | | | |
| Colour of cover | | | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | | Grey Blue | | | | | | | | | |
| Trip button (Colour) | | | | | Yes (Red) | | | Yes (Red) | | | Yes (Red) | | | | Yes (Red) | | | | | | | | | |
| Suitability for isolation | | | | | Yes | | | Yes | | | Yes | | | | Yes | | | | | | | | | |
| Reverse connection | | | | | Yes ⑫ | | | Yes | | | Yes | | | | Yes | | | | | | | | | |
| Page of characteristics and outline dimensions | | | | | 7-4 | | | 7-4 | | | 7-6 | | | | 7-8 | | | | | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC. ⑦ : Hydraulic-magnetic type for below 10A rating.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ⑲ : Only applicable for 15 A and above. ㉗ : Applicable to only 2 poles breakers.
㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts. ⑫ : There are some limitations. See page 5-23 for details.

| Frame size (A) | | | | 100 | | | 125 | | | 100 | | | 125 | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | S125-SF | | | | | | PS125-NF | | | | | |
| Number of poles | | | | 2 | 3 | 4 | 2 | 3 | 4 | 2 | 3 | 4 | 2 | 3 | 4 |
| ■Ratings | | | | | | | | | | | | | | | |
| Rated current, A | | | | 15 | 60 | | 125 | | | 15 | 60 | | 125 | | |
| Calibrated at 40°C | | | | 20 | 75 | | | | | 20 | 75 | | | | |
| 45°C | | | | 30 | 100 | | | | | 30 | 100 | | | | |
| | | | | 40 | | | | | | 40 | | | | | |
| | | | | 50 | | | | | | 50 | | | | | |
| Rated insulation voltage 〔$U_i$〕 V | | | | 690 | | | 690 | | | 800 | | | 800 | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | | 8 | | | 8 | | | 8 | | | 8 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | — | | | — | | | — | | |
| Utilization Category | | | | A | | | A | | | A | | | A | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/3 | | | 6/3 | | | 6/6 | | | 6/6 | | |
| IEC 60947-2 | | | 500V | 12/6 | | | 12/6 | | | 22/22 | | | 22/22 | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 25/13 | | | 25/13 | | | 25/25 | | | 25/25 | | |
| | | | 415V | 30/15 | | | 30/15 | | | 36/36 | | | 36/36 | | |
| | | | 380V | 30/15 | | | 30/15 | | | 36/36 | | | 36/36 | | |
| | | | 240V | 50/25 | | | 50/25 | | | 50/50 | | | 50/50 | | |
| | ① | DC | 250V | 25/13 ⑰ ㉗ | | | 25/13 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | |
| | | | 125V | 40/20 ⑰ ㉗ | | | 40/20 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | |
| NK | | AC | 690V | — | | | — | | | 6/6 | | | 6/6 | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 25/13 | | | 25/13 | | | 25/25 | | | 25/25 | | |
| | | | 240V | 50/25 | | | 50/25 | | | 50/50 | | | 50/50 | | |
| | ① | DC | 250V | 25/13 ⑰ ㉗ | | | 25/13 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | |
| ■External dimensions, mm | | | | | | | | | | | | | | | |
|  | | | a | 50 | 75 | 100 | 50 | 75 | 100 | 60 | 90 | 120 | 60 | 90 | 120 |
| | | | b | 130 | | | 130 | | | 130 | | | 130 | | |
| | | | c | 68 | | | 68 | | | 68 | | | 68 | | |
| | | | d | 95 | | | 95 | | | 95.5 | | | 95.5 | | |
| Weight (◉ marked standard type) kg | | | | 0.6 | 0.8 | 1.0 | 0.6 | 0.8 | 1.0 | 0.7 | 1.0 | 1.3 | 0.7 | 1.0 | 1.3 |
| ■Connections and Mountings | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ ④ | | | ◉ | | | ◉ | | | ◉ | | |
| | With extension bars | | | ○ ㊸ | | | ○ ㊸ | | | ○ ㊸ | | | ○ ㊸ | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | ○ | | | ○ | | | ○ | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | | | — | | | — | ○ ㊿ | | — | ○ ㊿ | |
| | | Standard (PMC) | | — | ○ | — | — | ○ | — | ○ | | — | ○ | | — |
| | For distribution boards (PMD) | | | ○ | | — | ○ | | — | — | ○ | — | — | ○ | — |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | — | ○ | | — | ○ | | | ○ | | |
| Draw-out type (DR) | | | | — | | | — | | | — | | | — | | |
| TemPlug70 (PG) | | | | ○ | | — | ○ | | — | ○ | | — | ○ | | — |
| DIN rail mount | | | | — | ○ ⑪ | | — | ○ ⑪ | | — | ○ ⑪ | | — | ○ ⑪ | |
| ■Accessories (optional) | | | Symbol | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | | A X | ● | | | ● | | | ● | | | ● | | |
| | Alarm switch | | A L | ● | | | ● | | | ● | | | ● | | |
| | Shunt trips | | S H | ● | | | ● | | | ● | | | ● | | |
| | Undervoltage trips | | U V | ● | | | ● | | | ● | | | ● | | |
| Externally mounted | Motor operator | | M C | — | | | — | | | — | ● | | — | ● | |
| | External operating handle | Breaker-mounted | H B | — | ● | | — | ● | | — | ● | | — | ● | |
| | | Door-mounted (variable depth) | H P | — | ● | | — | ● | | — | ● | | — | ● | |
| | Toggle extension | | H A | — | | | — | | | — | | | — | | |
| | Mechanical interlock | Slide type | M S | — | ● | | — | ● | | — | ● | | — | ● | |
| | | Rear-connected type | M B | — | | | — | | | — | | | — | | |
| | | Link type | M L | — | | | — | | | — | ● | | — | ● | |
| | | Wire type | M W | — | | | — | | | — | ● | | — | ● | |
| | Toggle holder | | H H | ● | | | ● | | | ● | | | ● | | |
| | Toggle lock | | H L | ● | | | ● | | | ● | | | ● | | |
| | Terminal cover | For front-connected | C F | ● | | | ● | | | ● | | | ● | | |
| | | For rear-connected and plug-in | C R | ● | | | ● | | | ● | | | ● | | |
| | Terminal block for lead | | T F | ● | | | ● | | | ● | | | ● | | |
| | Door flange | | D F | ● | | | ● | | | ● | | | ● | | |
| CE marking | | | | Yes | | | Yes | | | Yes | | | Yes | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | Thermal-magnetic | | | Thermal-magnetic | | | Thermal-magnetic | | |
| Colour of cover | | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | | Yes (Red) | | | Yes (Red) | | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | | Yes | | | Yes | | | Yes | | |
| Reverse connection | | | | Yes | | | Yes | | | Yes | | | Yes | | |
| Page of characteristics and outline dimensions | | | | 7-10 | | | 7-10 | | | 7-12 | | | 7-12 | | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
④ : 50A or less is the M5 wire clamping terminal. ⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㉗ : Applicable to only 2 poles breakers.
㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts.

| Frame size (A) | | | 100 | | 125 | | 225 | | | 250 | | | 250 | | 400 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | PS125-NE | | | | S250-SF | | | | | | PS250-NE | | PS400-CF | |
| Number of poles | | | 3 | 4 | 3 | 4 | 2＊ | 3 | 4 | 2＊ | 3 | 4 | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | | | | | | | | | | |
| Rated current, A | | | Adjustable | | Adjustable | | 125 | | | 250 | | | Adjustable | | 225 | |
| Calibrated at 40°C | | | $I_n$=100 | | $I_n$=125 | | 150 | | | | | | $I_n$=250 | | 250 | |
| 45°C | | | 40 | 75 | 125 | | 175 | | | | | | 125 | 200 | 300 | |
| | | | 50 | 100 | | | 200 | | | | | | 150 | 225 | 350 | |
| ＊2 poles breakers use the terminals of both ends of 3 poles breakers. | | | 60 | | | | 225 | | | | | | 175 | 250 | 400 | |
| | | | 63 | ㊶ | | | | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 800 | | 800 | | 690 | | | 690 | | | 800 | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | | 8 | | | 8 | | 8 | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | — | | — | | — | | | — | | | — | | — | |
| Utilization Category | | | A | | A | | A | | | A | | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 6/6 | | 6/6 | | 4/4 | | | 4/4 | | | 6/6 | | 7/7 | |
| IEC 60947-2 | | 500V | 22/22 | | 22/22 | | 25/13 | | | 25/13 | | | 22/22 | | 25/25 | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 25/25 | | 25/25 | | 30/15 | | | 30/15 | | | 25/25 | | 30/30 | |
| | | 415V | 36/36 | | 36/36 | | 40/20 | | | 40/20 | | | 36/36 | | 36/36 | |
| | | 380V | 36/36 | | 36/36 | | 40/20 | | | 40/20 | | | 36/36 | | 36/36 | |
| | | 240V | — | | — | | 85/43 | | | 85/43 | | | 50/50 | | 50/50 | |
| | ① DC | 250V | — | | — | | 25/13 ㊽ | | | 25/13 ㊽ | | | — | | 25/25 ⑰ | |
| | | 125V | — | | — | | 40/20 ㊽ | | | 40/20 ㊽ | | | — | | 40/40 ⑰ | |
| NK | AC | 690V | 6/6 | | 6/6 | | — | | | — | | | 6/6 | | 7/7 | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 25/25 | | 25/25 | | 30/15 | | | 30/15 | | | 25/25 | | 30/30 | |
| | | 240V | 50/50 | | 50/50 | | 85/43 | | | 85/43 | | | 50/50 | | 50/50 | |
| | ① DC | 250V | 50/50 | | 50/50 | | 25/13 ㊽ | | | 25/13 ㊽ | | | — | | 25/25 ⑰ | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | |
|  | | a | 90 | 120 | 90 | 120 | 105 | 105 | 140 | 105 | 105 | 140 | 105 | 140 | 140 | 185 |
| | | b | 130 | | 130 | | 165 | | | 165 | | | 165 | | 260 | |
| | | c | 68 | | 68 | | 68 | | | 68 | | | 68 | | 103 | |
| | | d | 95.5 | | 95.5 | | 95 | | | 95 | | | 95.5 | | 151 | |
| Weight (◉ marked standard type) kg | | | 1.0 | 1.3 | 1.0 | 1.3 | 1.5 | 1.5 | 1.9 | 1.5 | 1.5 | 1.9 | 1.5 | 2.0 | 5.5 | 7.3 |
| ■Connections and Mountings | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | | ◉ | | | ◉ | | | ◉ | | ◉ | |
| | With extension bars | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | | ○ ㊸ | | | ○ ㊸ | | ○ | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | | ○ | | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㊿ | | ○ ㊿ | | — | | | — | | | ○ ㊿ | | ○ ㊿ | |
| | Standard (PMC) | | ○ | — | ○ | — | ○ | | | ○ | | | ○ | — | ○ | — |
| For distribution boards (PMD) | | | ○ | — | ○ | — | — | | | — | | | — | | — | |
| Flush-mounted (FP) With flat bar studs | | | ○ | | ○ | | ○ | | | ○ | | | ○ | | ○ | |
| Draw-out type (DR) | | | — | | — | | — | | | — | | | ▲ | | ▲ | |
| TemPlug70 (PG) | | | ○ | — | ○ | — | — | ○ | — | — | ○ | — | ○ | — | ○ | — |
| DIN rail mount | | | ○ ⑪ | | ○ ⑪ | | — | | | — | | | — | | — | |
| ■Accessories (optional) | | Symbol | | | | | | | | | | | | | | |
| Internally mounted: Auxiliary switch | | A X | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Internally mounted: Alarm switch | | A L | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Internally mounted: Shunt trips | | S H | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Internally mounted: Undervoltage trips | | U V | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Externally mounted: Motor operator | | M C | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Externally mounted: External operating handle | Breaker-mounted | H B | ● | | ● | | ● | | | ● | | | ● | | ● | |
| | Door-mounted (variable depth) | H P | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Externally mounted: Toggle extension | | H A | — | | — | | — | | | — | | | — | | ● | |
| Externally mounted: Mechanical interlock ⑨ | Slide type | M S | ● | | ● | | ● | | | ● | | | ● | | ● | |
| | Rear-connected type | M B | — | | — | | — | | | — | | | — | | — | |
| | Link type | M L | ● | | ● | | ● | | | ● | | | ● | | ● | |
| | Wire type | M W | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Externally mounted: Toggle holder | | H H | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Externally mounted: Toggle lock | | H L | ● | | ● | | ● | | | ● | | | ● | | | |
| Externally mounted: Terminal cover | For front-connected | C F | ● | | ● | | ● | | | ● | | | ● | | ● | |
| | For rear-connected and plug-in | C R | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Externally mounted: Terminal block for lead | | T F | ● | | ● | | ● | | | ● | | | ● | | ● | |
| Externally mounted: Door flange | | D F | ● | | ● | | ● | | | ● | | | ● | | ● | |
| CE marking | | | Yes | | Yes | | Yes | | | Yes | | | Yes | | Yes | |
| Overcurrent trip mechanism | | | Electronic | | Electronic | | Thermal-magnetic | | | Thermal-magnetic | | | Electronic | | Thermal-magnetic (adjustable) | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | | Grey Blue | | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | Yes (Red) | | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | | Yes | | | Yes | | Yes | |
| Reverse connection | | | Yes | | Yes | | Yes | | | Yes | | | Yes | | Yes | |
| Page of characteristics and outline dimensions | | | 7-16 | | 7-16 | | 7-30 | | | 7-30 | | | 7-34 | | 7-44 | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".


① : DC is a special specification. When ordering, please specify DC. ⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑰ : See page 4-7 for the instantaneous trip value when using with DC.


㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts.

㊶ : Does not comply with Electrical Appliances and Materials Safety Act at rated current 100 A or less because it is an adjustable product. Also, it cannot be used at voltages other than rated operational voltage 380 V to 690 V AC. Please contact us for details.

㊽ : DC is a 2-pole product that uses both ends of a 3-pole circuit breaker.

| Frame size (A) | | | | 400 | | 400 | | 600 | | 630 | | 600 | | 600 | | 630 | | 600 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | PS400-NF | | PS400-NE | | S630-CF | | | | PS630-CF | | S630-NF | | | | PS630-NF | |
| Number of poles | | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | | | | | | | | | | | | | |
| Rated current, A | | | | 225 | | Adjustable | | 500 | | 630 | | 500 | | 500 | | 630 | | 500 | |
| Calibrated at 40°C | | | | 250 | | $I_n$=250 | $I_n$=400 | 600 | | | | 600 | | 600 | | | | 600 | |
| 45°C | | | | 300 | | 125 | 175 | | | | | ⑱ | | | | | | ⑱ | |
| | | | | 350 | | 150 | 200 | | | | | | | | | | | | |
| | | | | 400 | | 175 | 225 | | | | | | | | | | | | |
| | | | | | | 200 | 250 | | | | | | | | | | | | |
| | | | | | | 225 | 300 | | | | | | | | | | | | |
| | | | | | | 250 | 350 | | | | | | | | | | | | |
| | | | | | | | 400 | | | | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | | 690 | | 690 | | 800 | | 690 | | 690 | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | — | | 5 (0.4sec.) | | — | | — | | — | | — | | — | | — | |
| Utilization Category | | | | A | | B | | A | | A | | A | | A | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 12/12 | | 12/12 | | 10/10 | | 10/10 | | 7/7 | | 20/20 | | 20/20 | | 12/12 | |
| IEC 60947-2 | | | 500V | 30/30 | | 30/30 | | 15/15 | | 15/15 | | 25/25 | | 30/30 | | 30/30 | | 30/30 | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 45/45 | | 45/45 | | 30/30 | | 30/30 | | 30/30 | | 50/50 | | 50/50 | | 45/45 | |
| | | | 415V | 50/50 | | 50/50 | | 36/36 | | 36/36 | | 36/36 | | 50/50 | | 50/50 | | 50/50 | |
| | | | 380V | 50/50 | | 50/50 | | 36/36 | | 36/36 | | 36/36 | | 50/50 | | 50/50 | | 50/50 | |
| | | | 240V | 85/85 | | 85/85 | | 50/50 | | 50/50 | | 50/50 | | 85/85 | | 85/85 | | 85/85 | |
| | ① | DC | 250V | 50/50 ⑰ | | — | | 50/50 | | 50/50 | | 25/25 ⑰ | | 50/50 | | 50/50 | | 50/50 ⑰ | |
| | | | 125V | 50/50 ⑰ | | — | | 50/50 | | 50/50 | | 40/40 ⑰ | | 50/50 | | 50/50 | | 50/50 ⑰ | |
| NK | | AC | 690V | 12/12 | | 12/12 | | 10/10 | | 10/10 | | 7/7 | | 20/20 | | 20/20 | | 12/12 | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 45/45 | | 45/45 | | 30/30 | | 30/30 | | 30/30 | | 50/50 | | 50/50 | | 45/45 | |
| | | | 240V | 85/85 | | 85/85 | | 50/50 | | 50/50 | | 50/50 | | 85/85 | | 85/85 | | 85/85 | |
| | ① | DC | 250V | 50/50 ⑰ | | — | | — | | — | | — | | — | | — | | — | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | | | | |
|  | | | a | 140 | 185 | 140 | 185 | 210 | 280 | 210 | 280 | 140 | 185 | 210 | 280 | 210 | 280 | 140 | 185 |
| | | | b | 260 | | 260 | | 273 | | 273 | | 260 | | 273 | | 273 | | 260 | |
| | | | c | 103 | | 103 | | 103 | | 103 | | 103 | | 103 | | 103 | | 103 | |
| | | | d | 151 | | 151 | | 145 | | 145 | | 151 | | 145 | | 145 | | 151 | |
| Weight (◉ marked standard type) kg | | | | 5.5 | 7.3 | 5.7 | 7.5 | 8.0 | 11.0 | 8.0 | 11.0 | 5.9 | 7.8 | 8.0 | 11.0 | 8.0 | 11.0 | 5.9 | 7.8 |
| ■Connections and Mountings | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | — | | — | | — | | — | | — | | — | |
| | With extension bars | | | ○ | | ○ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | ○ ⑤⓪ | | ○ ⑤⓪ | | ○ ⑤① | | ○ ⑤① | | ○ ⑤⓪ | | ○ ⑤① | | ○ ⑤① | | ○ ⑤⓪ | |
| | | Standard (PMC) | | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — |
| | For distribution boards | (PMD) | | — | | — | | — | | — | | — | | — | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | | ▲ | | ▲ | | ▲ | | ▲ | | ▲ | | ▲ | | ▲ | | ▲ | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — |
| DIN rail mount | | | | — | | — | | — | | — | | — | | — | | — | | — | |
| ■Accessories (optional) | | | Symbol | | | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | | A X | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Alarm switch | | A L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Shunt trips | | S H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Undervoltage trips | | U V | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted | Motor operator | | M C | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | External operating handle | Breaker-mounted | H B | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | | Door-mounted (variable depth) | H P | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Toggle extension | | H A | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Mechanical interlock ⑨ | Slide type | M S | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | | Rear-connected type | M B | — | | — | | — | | — | | — | | — | | — | | — | |
| | | Link type | M L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | | Wire type | M W | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Toggle holder | | H H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Toggle lock | | H L | | | | | | | | | | | | | | | | |
| | Terminal cover | For front-connected | C F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | | For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Terminal block for lead | | T F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Door flange | | D F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| CE marking | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Thermal-magnetic (adjustable) | | Electronic | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Page of characteristics and outline dimensions | | | | 7-44 | | 7-46 | | 7-54 | | 7-54 | | 7-58 | | 7-54 | | 7-54 | | 7-58 | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑰ : See page 4-7 for the instantaneous trip value when using with DC.
⑤⓪ : A safety trip function is provided. ⑤① : A safety lock function is provided.
⑱ : Plug-in type (PM), draw-out type (DR), and TemPlug70 (PG) are only 500A.

| Frame size (A) | | | | 630 | | 630 | | 800 | | 800 | | 800 | | 1000 | | 1250 | | 1600 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | S630-NE | | PS630-NE | | S800-CF | | S800-NF | | S800-NE | | S1000-CE | | S1250-NE | | S1600-NE | |
| Number of poles | | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | | | | | | | | | | | | | |
| Rated current, A | | | | Adjustable | | Adjustable | | 700 | | 700 | | Adjustable | | Adjustable | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | | $I_{CT}$=630 | | $I_n$=630 | | 800 | | 800 | | $I_{CT}$=800 | | $I_{CT}$=1000 | | $I_{CT}$=1250 | | $I_{CT}$=1600 | |
| 45°C | | | | 250 | | 250 | | | | | | 350 | 600 | 400 | 800 | 500 | 1000 | 700 | 1200 |
| | | | | 300 | | 300 | | | | | | 400 | 700 | 500 | 900 | 600 | 1200 | 800 | 1400 |
| | | | | 350 | | 350 | | | | | | 450 | 800 | 600 | 1000 | 700 | 1250 | 900 | 1500 |
| | | | | 400 | | 400 | | | | | | 500 | | 700 | | 800 | | 1000 | 1600 |
| | | | | 500 | | 500 | | | | | | | | | | | | | |
| | | | | 600 | | 600 | | | | | | | | | | | | | |
| | | | | 630 | | 630 | | | | | | | | | | | | | |
| Rated insulation voltage 〔$U_i$〕 V | | | | 690 | | 800 | | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | 10 (0.3sec.) | | — | | — | | — | | 10 (0.3sec.) | | — | | 15 (0.3sec.) | | 20 (0.3sec.) | |
| Utilization Category | | | | B | | A | | A | | A | | B | | A | | B | | B | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | | 20/20 | | 12/12 | | 10/10 | | 20/20 | | 20/20 | | 25/19 | | 25/20 | | 45/34 | |
| IEC 60947-2 | | 500V | | 30/30 | | 30/30 | | 15/15 | | 30/30 | | 30/30 | | 45/34 | | 45/34 | | 65/50 | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | | 50/50 | | 45/45 | | 30/30 | | 50/50 | | 50/50 | | 65/50 | | 65/50 | | 85/65 | |
| | | 415V | | 50/50 | | 50/50 | | 36/36 | | 50/50 | | 50/50 | | 65/50 | | 70/50 | | 85/65 | |
| | | 380V | | 50/50 | | 50/50 | | 36/36 | | 50/50 | | 50/50 | | 85/50 | | 85/65 | | 100/75 | |
| | | 240V | | 85/85 | | 85/85 | | 50/50 | | 85/85 | | 85/85 | | 100/75 | | 100/75 | | 125/94 | |
| | ① DC | 250V | | — | | — | | 50/50 | | 50/50 | | — | | — | | — | | — | |
| | | 125V | | — | | — | | 50/50 | | 50/50 | | — | | — | | — | | — | |
| NK | AC | 690V | | 20/20 | | — | | 10/10 | | 20/20 | | 20/20 | | — | | 25/20 | | — | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | | 50/50 | | — | | 30/30 | | 50/50 | | 50/50 | | — | | 65/50 | | — | |
| | | 240V | | 85/85 | | — | | 50/50 | | 85/85 | | 85/85 | | — | | 100/75 | | — | |
| | DC | 250V | | — | | — | | — | | — | | — | | — | | — | | — | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | | | | |
|  | | a | | 210 | 280 | 140 | 185 | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 |
| | | b | | 273 | | 260 | | 273 | | 273 | | 273 | | 273 | | 370 | | 370 | |
| | | c | | 103 | | 103 | | 103 | | 103 | | 103 | | 103 | | 120 | | 140 | |
| | | d | | 145 | | 151 | | 145 | | 145 | | 145 | | 145 | | 171 | | 191 | |
| Weight (◉ marked standard type) kg | | | | 8.7 | 11.9 | 6.0 | 8.0 | 8.5 | 11.5 | 8.5 | 11.5 | 9.1 | 12.3 | 11.0 | 14.8 | 19.8 | 25.0 | 27.0 | 35.0 |
| ■Connections and Mountings | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | | — | | — | | — | | — | | — | | — | |
| | With extension bars | | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ○ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ◉ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊶ | | — | | ○ ㊶ | | ○ ㊶ | | ○ ㊶ | | — | | — | | — | |
| | Standard (PMC) | | | ○ | — | — | | ○ | — | ○ | — | ○ | — | — | | ○ | | — | |
| For distribution boards (PMD) | | | | — | | — | | — | | — | | — | | — | | — | | — | |
| Flush-mounted (FP) With flat bar studs | | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | | ▲ | | — | | ▲ | | ▲ | | ▲ | | — | | ▲ | | ○ | |
| TemPlug70 (PG) | | | | ○ | — | — | | — | | — | | — | | — | | — | | — | |
| DIN rail mount | | | | — | | — | | — | | — | | — | | — | | — | | — | |
| ■Accessories (optional) | | | Symbol | | | | | | | | | | | | | | | | |
| Internally mounted: Auxiliary switch | | | A X | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Alarm switch | | | A L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Shunt trips | | | S H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Undervoltage trips | | | U V | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Motor operator | | | M C | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: External operating handle | Breaker-mounted | | H B | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Door-mounted (variable depth) | | H P | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle extension | | | H A | ● | | ● | | ● | | ● | | ● | | ● | | ● ㉔ | | ● ㉔ | |
| Externally mounted: Mechanical interlock ⑨ | Slide type | | M S | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Rear-connected type | | M B | — | | — | | — | | — | | — | | — | | ● | | ● | |
| | Link type | | M L | ● | | ● | | ● | | ● | | ● | | ● | | — | | — | |
| | Wire type | | M W | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle holder | | | H H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle lock | | | H L | | | | | | | | | | | | | | | | |
| Externally mounted: Terminal cover | For front-connected | | C F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | — | |
| | For rear-connected and plug-in | | C R | ● | | ● | | ● | | ● | | ● | | ● | | — | | — | |
| Externally mounted: Terminal block for lead | | | T F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Door flange | | | D F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| CE marking | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Electronic ⑯ | | Electronic | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Electronic ⑯ | | Electronic ⑯ | | Electronic ⑯ | | Electronic ⑯ | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Page of characteristics and outline dimensions | | | | 7-56 | | 7-60 | | 7-68 | | 7-68 | | 7-70 | | 7-74 | | 7-76 | | 7-80 | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

① : DC is a special specification. When ordering, please specify DC.


⑨ : Mechanical interlocks cannot be applied to draw-out type (DR). ⑯ : Optional preferential alarm or ground fault trip function available on request.

㉔ : One is supplied with every five breakers. Please specify if more are required.


㊶ : A safety lock function is provided.

| Frame size (A) | | | 2000 | | 2500 | | 3200 |
|---|---|---|---|---|---|---|---|
| Type | | | XS2000NE | | XS2500NE | | XS3200NE |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 |
| **■Ratings** | | | | | | | |
| Rated current, A | | | Adjustable | | Adjustable | | Adjustable |
| Calibrated at 40°C | | | $I_{CT}$=2000 | | $I_{CT}$=2500 | | $I_{CT}$=3200 |
| 45°C | | | 1000 1600<br>1200 1800<br>1400 2000 | | 1200 2000<br>1400 2500<br>1600<br>(40℃ only) | | 1600 2800<br>2000 3200<br>2500<br>(40℃ only) |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | 690 ⑦① |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | 42 (0.3sec.) | | 42 (0.3sec.) | | 38 (0.5sec.) |
| Utilization Category | | | B | | B | | B |
| **■Rated breaking capacity, kA** | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 45/42 | | 45/42 | | 45/42 |
| IEC 60947-2 | | 500V | 65/50 | | 65/50 | | 65/50 |
| $I_{cu}/I_{cs}$(sym) | | 440V | 85/65 | | 85/65 | | 85/65 |
| | | 415V | 85/65 | | 85/65 | | 85/65 |
| | | 380V | 100/75 | | 100/75 | | 100/75 |
| | | 240V | 125/94 | | 125/94 | | 125/94 |
| | DC | 250V | — | | — | | — |
| | | 125V | — | | — | | — |
| NK | AC | 690V | — | | — | | — |
| $I_{cu}/I_{cs}$(sym) | | 450V | 85/— ㉑ | | — | | — |
| | | 240V | — | | — | | — |
| | DC | 250V | — | | — | | — |
| **■External dimensions, mm** | | | | | | | |
|  | | a | 320 | 429 | 320 | 429 | 320 |
| | | b | 450 | | 450 | | 450 |
| | | c | 185 | | 185 | | 185 |
| | | d | 245 | | 245 | | 245 |
| Weight (◉ marked standard type) kg | | | 54.0 | 67.0 | 64 | 78.2 | 65 |
| **■Connections and Mountings** | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | — |
| | With extension bars | | ○ | | — | | — |
| Rear-connected (RC) | Flat bar studs | | ◉ | | ◉ | | ◉ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | — |
| | Standard (PMC) | | — | | — | | — |
| For distribution boards (PMD) | | | — | | — | | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ |
| Draw-out type (DR) | | | ○ | | — | | — |
| TemPlug70 (PG) | | | — | | — | | — |
| DIN rail mount | | | — | | — | | — |
| **■Accessories (optional)** | | Symbol | | | | | |
| Internally mounted: Auxiliary switch | | A X | ● | | ● | | ● |
| Alarm switch | | A L | ● | | ● | | ● |
| Shunt trips | | S H | ● | | ● | | ● |
| Undervoltage trips | | U V | ● ⑥ | | ● ⑥ | | ● ⑥ |
| Toggle extension | | H A | ● ② | | ● ② | | ● ② |
| Externally mounted: Mechanical interlock ⑨ | Slide type | M S | ● | | ● | | ● |
| | Rear-connected type | M B | ● | | ● | | ● |
| | Link type | M L | — | | — | | — |
| | Wire type | M W | — | | — | | — |
| Terminal cover | For front-connected | C F | — | | — | | — |
| | For rear-connected and plug-in | C R | — | | — | | — |
| Terminal block for lead | | T F | ● | | ● | | ● |
| Door flange | | D F | ● | | ● | | ● |
| CE marking | | | Non | | Non | | Non |
| Overcurrent trip mechanism | | | Electronic ⑯ | | Electronic ⑯ | | Electronic ⑯ |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) |
| Suitability for isolation | | | Yes | | Yes | | Yes |
| Reverse connection | | | Yes | | Yes | | Yes |
| Page of characteristics and outline dimensions | | | 7-82 | | 7-84 | | 7-86 |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available".
② : Supplied as standard. ⑥ : With AC UVT, the UVT controller is externally mounted. ⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑯ : Optional preferential alarm or ground fault trip function available on request. ㉑ : This is the value for 500V AC.
㊻ : Fixed depth, not adjustable. ⑦① : 3000A is also available as special.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 50 | | | 100 | | | 125 | | |
| Type | | | PS50-PF | | | S100-GF | | | S125-GF | | |
| Number of poles | | | 2 | 3 | 4 | 2 | 3 | 4 | 2 | 3 | 4 |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | 15 | | | 15 | 60 | | 125 | | |
| Calibrated at 40°C | | | 20 | | | 20 | 75 | | | | |
| 45°C | | | 30 | | | 30 | 100 | | | | |
| | | | 40 | | | 40 | | | | | |
| | | | 50 | | | 50 | | | | | |
| Rated insulation voltage 〔$U_i$〕 V | | | 800 | | | 690 | | | 690 | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | 8 | | | 8 | | | 8 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | | — | | | — | | |
| Utilization Category | | | A | | | A | | | A | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 6/6 | | | 6/6 | | | 6/6 | | |
| IEC 60947-2 | | 500V | 30/22 | | | 25/22 | | | 25/22 | | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 50/35 | | | 50/25 | | | 50/25 | | |
| | | 415V | 70/50 | | | 65/33 | | | 65/33 | | |
| | | 380V | 70/50 | | | 65/33 | | | 65/33 | | |
| | | 240V | 85/85 | | | 85/85 | | | 85/85 | | |
| | ① DC | 250V | 40/40 ⑰ ㉗ | | | 40/40 ㉗ | | | 40/40 ㉗ | | |
| | | 125V | 40/40 ⑰ ㉗ | | | 40/40 ㉗ | | | 40/40 ㉗ | | |
| NK | AC | 690V | 6/6 | | | 6/6 | | | 6/6 | | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 50/35 | | | 50/25 | | | 50/25 | | |
| | | 240V | 85/85 | | | 85/85 | | | 85/85 | | |
| | ① DC | 250V | 40/40 ⑰ ㉗ | | | 40/40 ㉗ | | | 40/40 ㉗ | | |
| ■External dimensions, mm | | | | | | | | | | | |
|  | | a | 60 | 90 | 120 | 60 | 90 | 120 | 60 | 90 | 120 |
| | | b | 130 | | | 155 | | | 155 | | |
| | | c | 68 | | | 68 | | | 68 | | |
| | | d | 95.5 | | | 92 | | | 92 | | |
| Weight (◉ marked standard type) kg | | | 0.7 | 1.0 | 1.3 | 0.7 | 1.1 | 1.4 | 0.7 | 1.1 | 1.4 |
| ■Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | ◉ | | | ◉ | | |
| | With extension bars | | ○ ㊸ | | | ○ ㊸ | | | ○ ㊸ | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | ○ | | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | ○ ㊿ | | ○ ㊶ | | | ○ ㊶ | | |
| | Standard (PMC) | | ○ | | — | — | ○ | — | — | ○ | — |
| For distribution boards | (PMD) | | — | ○ | — | — | | | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | ○ | | | ○ | | |
| Draw-out type (DR) | | | — | | | — | | | — | | |
| TemPlug70 (PG) | | | ○ | | — | ○ | | — | ○ | | — |
| DIN rail mount | | | — | ○ ⑪ | | — | ○ ⑪ | | — | ○ ⑪ | |
| ■Accessories (optional) | | Symbol | | | | | | | | | |
| Internally mounted: Auxiliary switch | | A X | ● | | | ● | | | ● | | |
| Internally mounted: Alarm switch | | A L | ● | | | ● | | | ● | | |
| Internally mounted: Shunt trips | | S H | ● | | | ● | | | ● | | |
| Internally mounted: Undervoltage trips | | U V | ● | | | ● | | | ● | | |
| Externally mounted: Motor operator | | M C | — | ● | | — | ● | | — | ● | |
| Externally mounted: External operating handle | Breaker-mounted | H B | — | ● | | — | ● | | — | ● | |
| | Door-mounted (variable depth) | H P | — | ● | | — | ● | | — | ● | |
| Externally mounted: Toggle extension | | H A | — | | | — | | | — | | |
| Externally mounted: Mechanical interlock | Slide type | M S | — | ● | | — | ● | | — | ● | |
| | Rear-connected type | M B | — | | | — | | | — | | |
| | Link type | M L | — | ● | | — | ● | | — | ● | |
| | Wire type | M W | — | ● | | — | ● | | — | ● | |
| Externally mounted: Toggle holder | | H H | ● | | | ● | | | ● | | |
| Externally mounted: Toggle lock | | H L | ● | | | ● | | | ● | | |
| Externally mounted: Terminal cover | For front-connected | C F | ● | | | ● | | | ● | | |
| | For rear-connected and plug-in | C R | ● | | | ● | | | ● | | |
| Externally mounted: Terminal block for lead | | T F | ● | | | ● | | | ● | | |
| Externally mounted: Door flange | | D F | ● | | | ● | | | ● | | |
| CE marking | | | Yes | | | Yes | | | Yes | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | | Thermal-magnetic | | | Thermal-magnetic | | |
| Colour of cover | | | Grey Blue | | | Grey Blue | | | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | | | Yes (Red) | | | Yes (Red) | | |
| Suitability for isolation | | | Yes | | | Yes | | | Yes | | |
| Reverse connection | | | Yes | | | Yes | | | Yes | | |
| Page of characteristics and outline dimensions | | | 7-14 | | | 7-20 | | | 7-22 | | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". ① : DC is a special specification. When ordering, please specify DC.
⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑰ : See page 4-7 for the instantaneous trip value when using with DC.
㉗ : Applicable to only 2 poles breakers. ㊿ : A safety trip function is provided. ㊶ : A safety lock function is provided. ㊸ : For the extension bars, please place the order separately in parts.

| Frame size (A) | | | | 100 | | | 125 | | | 100 | | 125 | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | PS125-PF | | | | | | PS125-PE | | | | | | | |
| Number of poles | | | | 2 | 3 | 4 | 2 | 3 | 4 | 3 | 4 | 3 | 4 | | | | |
| ■Ratings | | | | | | | | | | | | | | | | | |
| Rated current, A | | | | 15 | 60 | | 125 | | | Adjustable | | Adjustable | | | | | |
| Calibrated at 40°C | | | | 20 | 75 | | | | | $I_n$=100 | | $I_n$=125 | | | | | |
| 45°C | | | | 30 | 100 | | | | | 40 | 75 | 125 | | | | | |
| | | | | 40 | | | | | | 50 | 100 | | | | | | |
| | | | | 50 | | | | | | 60 | | | | | | | |
| | | | | | | | | | | 63 | ⑥① | | | | | | |
| Rated insulation voltage 〔$U_i$〕 V | | | | 800 | | | 800 | | | 800 | | 800 | | | | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | | 8 | | | 8 | | | 8 | | 8 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | — | | | — | | — | | | | | |
| Utilization Category | | | | A | | | A | | | A | | A | | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/6 | | | 6/6 | | | 6/6 | | 6/6 | | | | | |
| IEC 60947-2 | | | 500V | 30/22 | | | 30/22 | | | 30/22 | | 30/22 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 50/35 | | | 50/35 | | | 50/35 | | 50/35 | | | | | |
| | | | 415V | 70/50 | | | 70/50 | | | 70/50 | | 70/50 | | | | | |
| | | | 380V | 70/50 | | | 70/50 | | | 70/50 | | 70/50 | | | | | |
| | | | 240V | 85/85 | | | 85/85 | | | — | | — | | | | | |
| | ① | DC | 250V | 40/40 ⑰ ㉗ | | | 40/40 ⑰ ㉗ | | | — | | — | | | | | |
| | | | 125V | 40/40 ⑰ ㉗ | | | 40/40 ⑰ ㉗ | | | — | | — | | | | | |
| NK | | AC | 690V | 6/6 | | | 6/6 | | | 6/6 | | 6/6 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 50/35 | | | 50/35 | | | 50/35 | | 50/35 | | | | | |
| | | | 240V | 85/85 | | | 85/85 | | | 85/85 | | 85/85 | | | | | |
| | ① | DC | 250V | 40/40 ㉗ | | | 40/40 ㉗ | | | 85/85 | | 85/85 | | | | | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | | |
|  | | | a | 60 | 90 | 120 | 60 | 90 | 120 | 90 | 120 | 90 | 120 | | | | |
| | | | b | 130 | | | 130 | | | 130 | | 130 | | | | | |
| | | | c | 68 | | | 68 | | | 68 | | 68 | | | | | |
| | | | d | 95.5 | | | 95.5 | | | 95.5 | | 95.5 | | | | | |
| Weight (◉ marked standard type) kg | | | | 0.7 | 1.0 | 1.3 | 0.7 | 1.0 | 1.3 | 1.0 | 1.3 | 1.0 | 1.3 | | | | |
| ■Connections and Mountings | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | ◉ | | | ◉ | | ◉ | | | | | |
| | With extension bars | | | ○ ㊸ | | | ○ ㊸ | | | ○ ㊸ | | ○ ㊸ | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | ○ | | | ○ | | ○ | | | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | ○ ㊿ | | — | ○ ㊿ | | ○ ㊿ | | ○ ㊿ | | | | | |
| | | Standard (PMC) | | ○ | | — | ○ | | — | ○ | — | ○ | — | | | | |
| | For distribution boards | (PMD) | | — | ○ | — | — | ○ | — | ○ | — | ○ | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | ○ | | | ○ | | ○ | | | | | |
| Draw-out type (DR) | | | | — | | | — | | | — | | — | | | | | |
| TemPlug70 (PG) | | | | ○ | | — | ○ | | — | ○ | — | ○ | — | | | | |
| DIN rail mount | | | | — | ○ ⑪ | | — | ○ ⑪ | | ○ ⑪ | | ○ ⑪ | | | | | |
| ■Accessories (optional) | | | Symbol | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | | A X | ● | | | ● | | | ● | | ● | | | | | |
| | Alarm switch | | A L | ● | | | ● | | | ● | | ● | | | | | |
| | Shunt trips | | S H | ● | | | ● | | | ● | | ● | | | | | |
| | Undervoltage trips | | U V | ● | | | ● | | | ● | | ● | | | | | |
| Externally mounted | Motor operator | | M C | — | ● | | — | ● | | ● | | ● | | | | | |
| | External operating handle | Breaker-mounted | H B | — | ● | | — | ● | | ● | | ● | | | | | |
| | | Door-mounted (variable depth) | H P | — | ● | | — | ● | | ● | | ● | | | | | |
| | Toggle extension | | H A | — | | | — | | | — | | — | | | | | |
| | Mechanical interlock | Slide type | M S | — | ● | | — | ● | | ● | | ● | | | | | |
| | | Rear-connected type | M B | — | | | — | | | — | | — | | | | | |
| | | Link type | M L | — | ● | | — | ● | | ● | | ● | | | | | |
| | | Wire type | M W | — | ● | | — | ● | | ● | | ● | | | | | |
| | Toggle holder | | H H | ● | | | ● | | | ● | | ● | | | | | |
| | Toggle lock | | H L | ● | | | ● | | | ● | | ● | | | | | |
| | Terminal cover | For front-connected | C F | ● | | | ● | | | ● | | ● | | | | | |
| | | For rear-connected and plug-in | C R | ● | | | ● | | | ● | | ● | | | | | |
| | Terminal block for lead | | T F | ● | | | ● | | | ● | | ● | | | | | |
| | Door flange | | D F | ● | | | ● | | | ● | | ● | | | | | |
| CE marking | | | | Yes | | | Yes | | | Yes | | Yes | | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | Thermal-magnetic | | | Electronic | | Electronic | | | | | |
| Colour of cover | | | | Grey Blue | | | Grey Blue | | | Grey Blue | | Grey Blue | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | Yes (Red) | | | Yes (Red) | | Yes (Red) | | | | | |
| Suitability for isolation | | | | Yes | | | Yes | | | Yes | | Yes | | | | | |
| Reverse connection | | | | Yes | | | Yes | | | Yes | | Yes | | | | | |
| Page of characteristics and outline dimensions | | | | 7-14 | | | 7-14 | | | 7-18 | | 7-18 | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


● : "yes" or "available". — : "no" or "not available".

① : DC is a special specification. When ordering, please specify DC. ⑪ : Please order the DIN rail adapter separately. See page 6-152.

⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㉗ : Applicable to only 2 poles breakers.


㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts.

⑥① : Does not comply with Electrical Appliances and Materials Safety Act at rated current 100 A or less because it is an adjustable product. Also, it cannot be used at voltages other than rated operational voltage 380 V to 690 V AC. Please contact us for details.


| | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 225 | | | 250 | | | 250 | | 400 | | 400 | | |
| Type | | | | PS250-PF | | | | | | PS250-PE | | PS400-GF | | PS400-GE | | |
| Number of poles | | | | 2* | 3 | 4 | 2* | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | |
| ■Ratings | | | | | | | | | | | | | | | | |
| Rated current, A | | | | 125 | | | 250 | | | Adjustable | | 225 | | Adjustable | | |
| Calibrated at 40°C | | | | 150 | | | | | | $I_n$=250 | | 250 | | $I_n$=250 | $I_n$=400 | |
| 45°C | | | | 175 | | | | | | 125 | | 300 | | 125 | 175 | |
| | | | | 200 | | | | | | 150 | | 350 | | 150 | 200 | |
| *2 poles breakers use the terminals of both ends of 3 poles breakers. | | | | 225 | | | | | | 175 | | 400 | | 175 | 225 | |
| | | | | | | | | | | 200 | | | | 200 | 250 | |
| | | | | | | | | | | 225 | | | | 225 | 300 | |
| | | | | | | | | | | 250 | | | | 250 | 350 | |
| | | | | | | | | | | | | | | | 400 | |
| Rated insulation voltage 〔$U_i$〕 V | | | | 800 | | | 800 | | | 800 | | 800 | | 800 | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | | 8 | | | 8 | | | 8 | | 8 | | 8 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | — | | | — | | — | | 5 (0.4sec.) | | |
| Utilization Category | | | | A | | | A | | | A | | A | | B | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/6 | | | 6/6 | | | 6/6 | | 12/12 | | 12/12 | | |
| IEC 60947-2 | | | 500V | 35/30 | | | 35/30 | | | 35/30 | | 50/50 | | 50/50 | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 50/40 | | | 50/40 | | | 50/40 | | 65/65 | | 65/65 | | |
| | | | 415V | 70/50 | | | 70/50 | | | 70/50 | | 70/70 | | 70/70 | | |
| | | | 380V | 70/50 | | | 70/50 | | | 70/50 | | 70/70 | | 70/70 | | |
| | | | 240V | 85/85 | | | 85/85 | | | 85/85 | | 100/100 | | 100/100 | | |
| | ① | DC | 250V | 40/40 ⑰ ⑧⑨ | | | 40/40 ⑰ ⑧⑨ | | | — | | 50/50 ⑰ | | — | | |
| | | | 125V | 40/40 ⑰ ⑧⑨ | | | 40/40 ⑰ ⑧⑨ | | | — | | 50/50 ⑰ | | — | | |
| NK | | AC | 690V | 6/6 | | | 6/6 | | | 6/6 | | 12/12 | | 12/12 | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 50/35 | | | 50/35 | | | 50/35 | | 65/65 | | 65/65 | | |
| | | | 240V | 85/85 | | | 85/85 | | | 85/85 | | 100/100 | | 100/100 | | |
| | ① | DC | 250V | 40/40 ⑰ ⑧⑨ | | | 40/40 ⑰ ⑧⑨ | | | — | | 50/50 ⑰ | | — | | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | |
|  | | | a | 105 | 105 | 140 | 105 | 105 | 140 | 105 | 140 | 140 | 185 | 140 | 185 | |
| | | | b | 165 | | | 165 | | | 165 | | 260 | | 260 | | |
| | | | c | 68 | | | 68 | | | 68 | | 103 | | 103 | | |
| | | | d | 95.5 | | | 95.5 | | | 95.5 | | 151 | | 151 | | |
| Weight (◉ marked standard type) kg | | | | 1.5 | 1.5 | 2.0 | 1.5 | 1.5 | 2.0 | 1.5 | 2.0 | 5.5 | 7.3 | 5.7 | 7.5 | |
| ■Connections and Mountings | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | ◉ | | | ◉ | | ◉ | | ◉ | | |
| | With extension bars | | | ○ ㊸ | | | ○ ㊸ | | | ○ ㊸ | | ○ | | ○ | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | ○ | | | ○ | | ○ | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊿ | | | ○ ㊿ | | | ○ ㊿ | | ○ ㊿ | | ○ ㊿ | | |
| | Standard (PMC) | | | ○ | | — | ○ | | — | ○ | — | ○ | — | ○ | — | |
| For distribution boards (PMD) | | | | — | | | — | | | — | | — | | — | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | ○ | | | ○ | | ○ | | ○ | | |
| Draw-out type (DR) | | | | ▲ | | | ▲ | | | ▲ | | ▲ | | ▲ | | |
| TemPlug70 (PG) | | | | — | ○ | — | — | ○ | — | ○ | — | ○ | — | ○ | — | |
| DIN rail mount | | | | — | | | — | | | — | | — | | — | | |
| ■Accessories (optional) | | | Symbol | | | | | | | | | | | | | |
| Internally mounted: Auxiliary switch | | | A X | ● | | | ● | | | ● | | ● | | ● | | |
| Internally mounted: Alarm switch | | | A L | ● | | | ● | | | ● | | ● | | ● | | |
| Internally mounted: Shunt trips | | | S H | ● | | | ● | | | ● | | ● | | ● | | |
| Internally mounted: Undervoltage trips | | | U V | ● | | | ● | | | ● | | ● | | ● | | |
| Externally mounted: Motor operator | | | M C | ● | | | ● | | | ● | | ● | | ● | | |
| Externally mounted: External operating handle | Breaker-mounted | | H B | ● | | | ● | | | ● | | ● | | ● | | |
| | Door-mounted (variable depth) | | H P | ● | | | ● | | | ● | | ● | | ● | | |
| Externally mounted: Toggle extension | | | H A | — | | | — | | | — | | ● | | ● | | |
| Externally mounted: Mechanical interlock ⑨ | Slide type | | M S | ● | | | ● | | | ● | | ● | | ● | | |
| | Rear-connected type | | M B | — | | | — | | | — | | — | | — | | |
| | Link type | | M L | ● | | | ● | | | ● | | ● | | ● | | |
| | Wire type | | M W | ● | | | ● | | | ● | | ● | | ● | | |
| Externally mounted: Toggle holder | | | H H | ● | | | ● | | | ● | | ● | | ● | | |
| Externally mounted: Toggle lock | | | H L | ● | | | ● | | | ● | | ● | | ● | | |
| Externally mounted: Terminal cover | For front-connected | | C F | ● | | | ● | | | ● | | ● | | ● | | |
| | For rear-connected and plug-in | | C R | ● | | | ● | | | ● | | ● | | ● | | |
| Externally mounted: Terminal block for lead | | | T F | ● | | | ● | | | ● | | ● | | ● | | |
| Externally mounted: Door flange | | | D F | ● | | | ● | | | ● | | ● | | ● | | |
| CE marking | | | | Yes | | | Yes | | | Yes | | Yes | | Yes | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | Thermal-magnetic | | | Electronic | | Thermal-magnetic (adjustable) | | Electronic | | |
| Colour of cover | | | | Grey Blue | | | Grey Blue | | | Grey Blue | | Grey Blue | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | | Yes (Red) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | | Yes | | | Yes | | Yes | | Yes | | |
| Reverse connection | | | | Yes | | | Yes | | | Yes | | Yes | | Yes | | |
| Page of characteristics and outline dimensions | | | | 7-32 | | | 7-32 | | | 7-34 | | 7-44 | | 7-46 | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts.
⑧⑨ : DC is a 2-pole product that uses both ends of a 3-pole circuit breaker.

| Frame size (A) | | | | 600 | | 630 | | 800 | | 800 | | 800 | | 800 | | 1250 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | PS630-GF | | PS630-GE | | S800-RF | | S800-RE | | S800-PF | | S800-PE | | S1250-GE | |
| Number of poles | | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 |
| **■Ratings** | | | | | | | | | | | | | | | | | |
| Rated current, A | | | | 500 | | Adjustable | | 700 | | Adjustable | | 700 | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | | 600 | | $I_n$=630 | | 800 | | $I_{CT}$=800 | | 800 | | $I_{CT}$=800 | | $I_{CT}$=1250 | |
| 45°C | | | | ㉘ | | 250 | | | | 350 | 600 | | | 350 | 600 | 500 | 1000 |
| | | | | | | 300 | | | | 400 | 700 | | | 400 | 700 | 600 | 1200 |
| | | | | | | 350 | | | | 450 | 800 | | | 450 | 800 | 700 | 1250 |
| | | | | | | 400 | | | | 500 | | | | 500 | | 800 | |
| | | | | | | 500 | | | | | | | | | | | |
| | | | | | | 600 | | | | | | | | | | | |
| | | | | | | 630 | | | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | | 690 | | 690 | | 690 | | 690 | | 690 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | — | | — | | — | | 10(0.3sec.) | | — | | 10(0.3sec.) | | 15(0.3sec.) | |
| Utilization Category | | | | A | | A | | A | | B | | A | | B | | B | |
| **■Rated breaking capacity, kA** | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | | 12/12 | | 12/12 | | 25/20 | | 25/20 | | 25/20 | | 25/20 | | 45/34 | |
| IEC 60947-2 | | 500V | | 50/50 | | 50/50 | | 45/34 | | 45/34 | | 45/34 | | 45/34 | | 65/50 | |
| $I_{cu}/I_{cs}$(sym) | | 440V | | 65/65 | | 65/65 | | 65/50 | | 65/50 | | 85/50 | | 85/50 | | 85/65 | |
| | | 415V | | 70/70 | | 70/70 | | 70/50 | | 70/50 | | 100/50 | | 100/50 | | 85/65 | |
| | | 380V | | 70/70 | | 70/70 | | 70/50 | | 70/50 | | 100/50 | | 100/50 | | 100/75 | |
| | | 240V | | 100/100 | | 100/100 | | 100/75 | | 100/75 | | 125/125 | | 125/125 | | 125/94 | |
| | ① DC | 250V | | 50/50 ⑰ | | — | | 50/50 | | — | | 50/50 | | — | | — | |
| | | 125V | | 50/50 ⑰ | | — | | 50/50 | | — | | 50/50 | | — | | — | |
| NK | AC | 690V | | 12/12 | | — | | — | | — | | 25/20 | | 25/20 | | 45/34 | |
| $I_{cu}/I_{cs}$(sym) | | 450V | | 65/65 | | — | | — | | — | | 85/50 | | 85/50 | | 85/65 | |
| | | 240V | | 100/100 | | — | | — | | — | | 125/125 | | 125/125 | | 125/94 | |
| | ① DC | 250V | | — | | — | | — | | — | | — | | — | | — | |
| **■External dimensions, mm** | | | | | | | | | | | | | | | | | |
|  | | a | | 140 | 185 | 140 | 185 | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 |
| | | b | | 260 | | 260 | | 273 | | 273 | | 273 | | 273 | | 370 | |
| | | c | | 103 | | 103 | | 103 | | 103 | | 103 | | 103 | | 120 | |
| | | d | | 151 | | 151 | | 145 | | 145 | | 145 | | 145 | | 171 | |
| Weight (◉ marked standard type) kg | | | | 5.9 | 7.8 | 6.0 | 8.0 | 8.5 | 11.5 | 9.1 | 12.3 | 8.5 | 11.5 | 9.1 | 12.3 | 19.8 | 25.0 |
| **■Connections and Mountings** | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | | — | | — | | — | | — | | — | |
| | With extension bars | | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊿ | | — | | ○ ㊶ | | ○ ㊶ | | ○ ㊶ | | ○ ㊶ | | — | |
| | Standard (PMC) | | | ○ | — | — | | ○ | — | ○ | — | ○ | — | ○ | — | ○ | |
| For distribution boards (PMD) | | | | — | | — | | — | | — | | — | | — | | — | |
| Flush-mounted (FP) With flat bar studs | | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | | ▲ | | — | | ▲ | | ▲ | | ▲ | | ▲ | | ▲ | |
| TemPlug70 (PG) | | | | ○ | — | — | | — | | — | | — | | — | | — | |
| DIN rail mount | | | | — | | — | | — | | — | | — | | — | | — | |
| **■Accessories (optional)** | | | **Symbol** | | | | | | | | | | | | | | |
| Internally mounted: Auxiliary switch | | | A X | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Alarm switch | | | A L | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Shunt trips | | | S H | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Undervoltage trips | | | U V | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Motor operator | | | M C | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: External operating handle | Breaker-mounted | | H B | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Door-mounted (variable depth) | | H P | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle extension | | | H A | ● | | ● | | ● | | ● | | ● | | ● | | ● ㉔ | |
| Externally mounted: Mechanical interlock ⑨ | Slide type | | M S | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Rear-connected type | | M B | — | | — | | — | | — | | — | | — | | ● | |
| | Link type | | M L | ● | | ● | | ● | | ● | | ● | | ● | | — | |
| | Wire type | | M W | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle holder | | | H H | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle lock | | | H L | | | | | | | | | | | | | | |
| Externally mounted: Terminal cover | For front-connected | | C F | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | For rear-connected and plug-in | | C R | ● | | ● | | ● | | ● | | ● | | ● | | — | |
| Externally mounted: Terminal block for lead | | | T F | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Door flange | | | D F | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| CE marking | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Thermal-magnetic (adjustable) | | Electronic | | Thermal-magnetic (adjustable) | | Electronic ⑯ | | Thermal-magnetic (adjustable) | | Electronic ⑯ | | Electronic ⑯ | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Page of characteristics and outline dimensions | | | | 7-58 | | 7-60 | | 7-68 | | 7-70 | | 7-68 | | 7-70 | | 7-76 | |


**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR). ⑯ : Optional preferential alarm or ground fault trip function available on request.
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㉔ : One is supplied with every five breakers. Please specify if more are required.
㊿ : A safety trip function is provided.
㊶ : A safety lock function is provided. ㉘ : Plug-in type (PM), draw-out type (DR), and TemPlug70 (PG) are only 500A.

| Frame size (A) | | | | 100 | | 125 | | 225 | | 250 | | 225 | | 400 | | 400 | | 400 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | H100-NF | | H125-NF | | H225-NF | | H250-NF | | H225-NE | | PH400-CF | | PH400-CE | | H400-NE | |
| Number of poles | | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | | | | | | | | | | | | | |
| Rated current, A | | | | 15 | 60 | 125 | | 125 | | 250 | | (Adjustable) | | 225 | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | | 20 | 75 | | | 150 | | | | 125 | | 250 | | $I_n$=250 | $I_n$=400 | $I_{CT}$=250 | $I_{CT}$=400 |
| 45°C | | | | 30 | 100 | | | 175 | | | | 150 | | 300 | | 125 | 175 | 125 | 175 |
| | | | | 40 | | | | 200 | | | | 175 | | 350 | | 150 | 200 | 150 | 200 |
| | | | | 50 | | | | 225 | | | | 200 | | 400 | | 175 | 225 | 175 | 225 |
| | | | | | | | | | | | | 225 | | | | 200 | 250 | 200 | 250 |
| | | | | | | | | | | | | | | | | 225 | 300 | 225 | 300 |
| | | | | | | | | | | | | | | | | 250 | 350 | | 350 |
| | | | | | | | | | | | | | | | | | 400 | | 400 |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | 690 | | 690 | | 690 | | 800 | | 800 | | 690 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | — | | — | | — | | — | | — | | — | | 5(0.4sec.) | | 5(0.3sec.) | |
| Utilization Category | | | | A | | A | | A | | A | | A | | A | | B | | B | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 20/15 | | 20/15 | | 20/15 | | 20/15 | | 20/15 | | 12/12 | | 12/12 | | 35/35 | |
| IEC 60947-2 | | | 500V | 45/45 | | 45/45 | | 45/45 | | 45/45 | | 45/45 | | 65/65 | | 65/65 | | 45/45 | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 120/80 | | 120/80 | | 120/80 | | 120/80 | | 120/80 | | 100/100 | | 100/100 | | 120/80 | |
| | | | 415V | 125/85 | | 125/85 | | 125/85 | | 125/85 | | 125/85 | | 110/110 | | 110/110 | | 125/85 | |
| | | | 380V | 125/85 | | 125/85 | | 125/85 | | 125/85 | | 125/85 | | 110/110 | | 110/110 | | 125/85 | |
| | | | 240V | 150/150 | | 150/150 | | 150/150 | | 150/150 | | 150/150 | | 125/125 | | 125/125 | | 150/150 | |
| | ① | DC | 250V | 40/40 | | 40/40 | | 40/40 | | 40/40 | | — | | 50/50 ⑰ | | — | | — | |
| | | | 125V | 40/40 | | 40/40 | | 40/40 | | 40/40 | | — | | 50/50 ⑰ | | — | | — | |
| NK | | AC | 690V | 20/15 | | 20/15 | | 20/15 | | — | | — | | 12/12 | | 12/12 | | 35/35 | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 120/80 | | 120/80 | | 120/80 | | — | | — | | 100/100 | | 100/100 | | 120/80 | |
| | | | 240V | 150/150 | | 150/150 | | 150/150 | | — | | — | | 125/125 | | 125/125 | | 150/150 | |
| | ① | DC | 250V | — | | — | | — | | — | | — | | 50/50 ⑰ | | — | | — | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | | | | |
|  | | | a | 105 | 140 | 105 | 140 | 105 | 140 | 105 | 140 | 105 | 140 | 140 | 185 | 140 | 185 | 140 | 185 |
| | | | b | 165 | | 165 | | 165 | | 165 | | 165 | | 260 | | 260 | | 260 | |
| | | | c | 103 | | 103 | | 103 | | 103 | | 103 | | 103 | | 103 | | 140 | |
| | | | d | 127 | | 127 | | 127 | | 127 | | 127 | | 151 | | 151 | | 182 | |
| Weight (◉ marked standard type) kg | | | | 2.4 | 3.2 | 2.4 | 3.2 | 2.4 | 3.2 | 2.4 | 3.2 | 2.5 | 3.3 | 5.5 | 7.3 | 5.7 | 7.5 | 7.1 | 9.4 |
| ■Connections and Mountings | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ | | ○ | | ○ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | ○ ㊶ | | ○ ㊶ | | ○ ㊶ | | — | | — | | ○ ㊿ | | ○ ㊿ | | ○ ㊶ | |
| | | Standard (PMC) | | ○ | — | ○ | — | ○ | — | — | | — | | ○ | — | ○ | — | ○ | — |
| | For distribution boards (PMD) | | | — | | — | | — | | — | | — | | — | | — | | — | |
| lush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | | — | | — | | — | | — | | — | | ▲ | | ▲ | | — | |
| TemPlug70 (PG) | | | | ▲ ㊶ | — | ▲ ㊶ | — | ▲ ㊶ | — | — | | — | | ▲ ㊶ | — | ▲ ㊶ | — | — | |
| DIN rail mount | | | | — | | — | | — | | — | | — | | — | | — | | — | |
| ■Accessories (optional) | | | Symbol | | | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | | A X | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Alarm switch | | A L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Shunt trips | | S H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Undervoltage trips | | U V | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted | Motor operator | | M C | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | External operating handle | Breaker-mounted | H B | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | | Door-mounted (variable depth) | H P | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Toggle extension | | H A | — | | — | | — | | — | | — | | ● | | ● | | ● | |
| | Mechanical interlock ⑨ | Slide type | M S | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | | Rear-connected type | M B | — | | — | | — | | — | | — | | — | | — | | — | |
| | | Link type | M L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | | Wire type | M W | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Toggle holder | | H H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Toggle lock | | H L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Terminal cover | For front-connected | C F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | | For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Terminal block for lead | | T F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Door flange | | D F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| CE marking | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Electronic ⑳ | | Thermal-magnetic (adjustable) | | Electronic | | Electronic ⑯ | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | | Yes ⑫ | | Yes ⑫ | | Yes ⑫ | | Yes ⑫ | | Yes ⑫ | | Yes | | Yes | | Yes | |
| Page of characteristics and outline dimensions | | | | 7-24 | | 7-26 | | 7-36 | | 7-38 | | 7-40 | | 7-48 | | 7-50 | | 7-52 | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available". ① : DC is a special specification. When ordering, please specify DC.
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR). ⑯ : Optional preferential alarm or ground fault trip function available on request.
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ⑳ : Optional preferential trip alarm function available on request.
㊿ : A safety trip function is provided. ㊶ : A safety lock function is provided. ㊸ : For the extension bars, please place the order separately in parts.
⑫ : There are some limitations. See page 5-23 for details. ㊶ : They cannot be applied to circuits with a short circuit breaking current exceeding 85 kA.

| Frame size (A) | | | | 600 | | 630 | | 630 | | 800 | | 1000 | | 1200 | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | PH630-CF | | PH630-CE | | H630-NE | | H800-NE | | TL-1000NE | | TL-1200NE | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | | |
| ■Ratings | | | | | | | | | | | | | | | | | |
| Rated current, A | | | | 500 | | Adjustable | | Adjustable | | Adjustable | | Adjustable | | Adjustable | | | |
| Calibrated at 40°C | | | | 600 | | $I_n$=630 | | $I_{CT}$=630 | | $I_{CT}$=800 | | $I_{CT}$=1000 | | $I_{CT}$=1250 | | | |
| 45°C | | | | ㉘ | | 250 | | 250 | | 350 | 600 | 500 | 800 | 600 | 1000 | | |
| | | | | | | 300 | | 300 | | 400 | 700 | 600 | 900 | 700 | 1200 | | |
| | | | | | | 350 | | 350 | | 450 | 800 | 700 | 1000 | 800 | | | |
| | | | | | | 400 | | 400 | | 500 | | | | | | | |
| | | | | | | 500 | | 500 | | | | | | | | | |
| | | | | | | 600 | | 600 | | | | | | | | | |
| | | | | | | 630 | | 630 | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | | 690 | | 690 | | 690 | | 690 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | — | | — | | 10(0.3sec.) | | 10(0.3sec.) | | 15(0.3sec.) | | 15(0.3sec.) | | | |
| Utilization Category | | | | A | | A | | B | | B | | B | | B | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 ㊾ | AC | 690V | | 12/12 | | 12/12 | | 25/20 | | 25/20 | | 45/34 | | 45/34 | | | |
| IEC 60947-2 | | 500V | | 65/65 | | 65/65 | | 45/34 | | 45/34 | | 75/57 | | 75/57 | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | | 100/100 | | 100/100 | | 125/94 | | 125/94 | | 125/65 | | 125/65 | | | |
| | | 415V | | 110/110 | | 110/110 | | 125/94 | | 125/94 | | 125/65 | | 125/65 | | | |
| | | 380V | | 110/110 | | 110/110 | | 125/94 | | 125/94 | | 125/65 | | 125/65 | | | |
| | | 240V | | 125/125 | | 125/125 | | 150/150 | | 150/150 | | 150/113 | | 150/113 | | | |
| | ① DC | 250V | | 50/50 ⑰ | | — | | — | | — | | — | | — | | | |
| | | 125V | | 50/50 ⑰ | | — | | — | | — | | — | | — | | | |
| NK | AC | 690V | | 12/12 | | — | | 25/20 | | 25/20 | | — | | — | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | | 100/100 | | — | | 125/94 | | 125/94 | | 125/— ㉓ | | 125/— ㉓ | | | |
| | | 240V | | 125/125 | | — | | 150/150 | | 150/150 | | — | | — | | | |
| | ① DC | 250V | | — | | — | | — | | — | | — | | — | | | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | | |
|  | | a | | 140 | 185 | 140 | 185 | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 | | |
| | | b | | 260 | | 260 | | 273 | | 273 | | 370 | | 370 | | | |
| | | c | | 103 | | 103 | | 140 | | 140 | | 140 | | 140 | | | |
| | | d | | 151 | | 151 | | 182 | | 182 | | 191 | | 191 | | | |
| Weight (◉ marked standard type) kg | | | | 5.9 | 7.8 | 6.0 | 8.0 | 13.5 | 19.6 | 14.3 | 20.3 | 26.0 | 33.7 | 26.0 | 33.7 | | |
| ■Connections and Mountings | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | | — | | — | | — | | — | | | |
| | With extension bars | | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊿ | | — | | ○ ㊶ | | ○ ㊶ | | — | | — | | | |
| | Standard (PMC) | | | ○ | — | — | | ○ | — | ○ | — | ○ | | ○ | | | |
| For distribution boards (PMD) | | | | — | | — | | — | | — | | — | | — | | | |
| lush-mounted (FP) With flat bar studs | | | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | | |
| Draw-out type (DR) | | | | ▲ | | — | | — | | — | | ▲ | | ▲ | | | |
| TemPlug70 (PG) | | | | ▲ ㊶ | — | — | | — | | — | | — | | — | | | |
| DIN rail mount | | | | — | | — | | — | | — | | — | | — | | | |
| ■Accessories (optional) | | | Symbol | | | | | | | | | | | | | | |
| Internally mounted: Auxiliary switch | | | A X | ● | | ● | | ● | | ● | | ● | | ● | | | |
| Internally mounted: Alarm switch | | | A L | ● | | ● | | ● | | ● | | ● | | ● | | | |
| Internally mounted: Shunt trips | | | S H | ● | | ● | | ● | | ● | | ● | | ● | | | |
| Internally mounted: Undervoltage trips | | | U V | ● | | ● | | ● | | ● | | ● ⑥ | | ● ⑥ | | | |
| Externally mounted: Motor operator | | | M C | ● | | ● | | ● | | ● | | ● | | ● | | | |
| Externally mounted: External operating handle | Breaker-mounted | | H B | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Door-mounted (variable depth) | | H P | ● | | ● | | ● | | ● | | ● | | ● | | | |
| Externally mounted: Toggle extension | | | H A | ● | | ● | | ● | | ● | | ● ㉔ | | ● ㉔ | | | |
| Externally mounted: Mechanical interlock ⑨ | Slide type | | M S | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Rear-connected type | | M B | — | | — | | — | | — | | ● | | ● | | | |
| | Link type | | M L | ● | | ● | | ● | | ● | | — | | — | | | |
| | Wire type | | M W | ● | | ● | | ● | | ● | | — | | — | | | |
| Externally mounted: Toggle holder | | | H H | ● | | ● | | ● | | ● | | ● | | ● | | | |
| Externally mounted: Toggle lock | | | H L | | | | | | | | | | | | | | |
| Externally mounted: Terminal cover | For front-connected | | C F | ● | | ● | | ● | | ● | | — | | — | | | |
| | For rear-connected and plug-in | | C R | ● | | ● | | ● | | ● | | — | | — | | | |
| Externally mounted: Terminal block for lead | | | T F | ● | | ● | | ● | | ● | | ● | | ● | | | |
| Externally mounted: Door flange | | | D F | ● | | ● | | ● | | ● | | ● | | ● | | | |
| CE marking | | | | Yes | | Yes | | Yes | | Yes | | Non | | Non | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic (adjustable) | | Electronic | | Electronic ⑯ | | Electronic ⑯ | | Electronic ⑯ | | Electronic ⑯ | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Black | | Black | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Brown) | | Yes (Brown) | | | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | | Non | | Non | | | |
| Reverse connection | | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | |
| Page of characteristics and outline dimensions | | | | 7-62 | | 7-64 | | 7-66 | | 7-72 | | 7-78 | | 7-78 | | | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available". ① : DC is a special specification. When ordering, please specify DC.
⑥ : With AC UVT, the UVT controller is externally mounted. ⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑯ : Optional preferential alarm or ground fault trip function available on request. ⑰ : See page 4-7 for the instantaneous trip value when using with DC.
㉓ : This is the value for 460V AC. ㉔ : One is supplied with every five breakers. Please specify if more are required. ㊿ : A safety trip function is provided.
㊶ : A safety lock function is provided. ㊾ : TL-1000NE and TL-1200NE are JIS C 8201-2-1 Ann.2 compliant. ㉘ : Plug-in type (PM), draw-out type (DR), and TemPlug70 (PG) are only 500A.
㉛ : They cannot be applied to circuits with a short circuit breaking current exceeding 85kA.

| Frame size (A) | | | 100 | | 125 | | 225 | | 250 | | 400 | | 630 | | 800 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | L100-NF | | L125-NF | | L225-NF | | L250-NF | | L400-NE | | L630-NE | | L800-NE | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | | | | | | | | | | |
| Rated current, A | | | 15 | 60 | 125 | | 125 | | 250 | | Adjustable | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | 20 | 75 | | | 150 | | | | $I_{CT}$=250 | $I_{CT}$=400 | $I_{CT}$=630 | | $I_{CT}$=800 | |
| 45°C | | | 30 | 100 | | | 175 | | | | 125 | 175 | 250 | | 350 | 600 |
| | | | 40 | | | | 200 | | | | 150 | 200 | 300 | | 400 | 700 |
| | | | 50 | | | | 225 | | | | 175 | 225 | 350 | | 450 | 800 |
| | | | | | | | | | | | 200 | 250 | 400 | | 500 | |
| | | | | | | | | | | | 225 | 300 | 500 | | | |
| | | | | | | | | | | | | 350 | 600 | | | |
| | | | | | | | | | | | | 400 | 630 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | — | | — | | — | | — | | 5 (0.3sec.) | | 10 (0.3sec.) | | 10 (0.3sec.) | |
| Utilization Category | | | A | | A | | A | | A | | B | | B | | B | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 25/20 | | 25/20 | | 25/20 | | 25/20 | | 50/50 | | 25/20 | | 25/20 | |
| IEC 60947-2 | | 500V | 65/65 | | 65/65 | | 65/65 | | 65/65 | | 65/65 | | 45/34 | | 45/34 | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 180/135 | | 180/135 | | 180/135 | | 180/135 | | 180/135 | | 180/135 | | 180/135 | |
| | | 415V | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | |
| | | 380V | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | |
| | | 240V | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | | 200/150 | |
| | ① DC | 250V | 40/40 | | 40/40 | | 40/40 | | 40/40 | | — | | — | | — | |
| | | 125V | 40/40 | | 40/40 | | 40/40 | | 40/40 | | — | | — | | — | |
| NK | AC | 690V | 25/20 | | 25/20 | | 25/20 | | — | | 50/50 | | 25/20 | | 25/20 | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 180/135 | | 180/135 | | 180/135 | | — | | 180/135 | | 180/135 | | 180/135 | |
| | | 240V | 200/150 ㉛ | | 200/150 ㉛ | | 200/150 ㉛ | | — | | 200/150 ㉛ | | 200/150 | | 200/150 | |
| | ① DC | 250V | — | | — | | — | | — | | — | | — | | — | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | |
|  | | a | 105 | 140 | 105 | 140 | 105 | 140 | 105 | 140 | 140 | 185 | 210 | 280 | 210 | 280 |
| | | b | 165 | | 165 | | 165 | | 165 | | 260 | | 273 | | 273 | |
| | | c | 103 | | 103 | | 103 | | 103 | | 140 | | 140 | | 140 | |
| | | d | 127 | | 127 | | 127 | | 127 | | 182 | | 182 | | 182 | |
| Weight (◉ marked standard type) kg | | | 2.4 | 3.2 | 2.4 | 3.2 | 2.4 | 3.2 | 2.4 | 3.2 | 7.1 | 9.4 | 13.5 | 19.6 | 14.3 | 20.3 |
| ■Connections and Mountings | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | — | | — | |
| | With extension bars | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ | | ◉ | | ◉ | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㊶ | | ○ ㊶ | | ○ ㊶ | | — | | ○ ㊶ | | ○ ㊶ | | ○ ㊶ | |
| | Standard (PMC) | | ○ | — | ○ | — | ○ | — | — | | ○ | — | ○ | — | ○ | — |
| For distribution boards (PMD) | | | — | | — | | — | | — | | — | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | — | | — | | — | | — | | — | | — | | — | |
| TemPlug70 (PG) | | | — | | — | | — | | — | | — | | — | | — | |
| DIN rail mount | | | — | | — | | — | | — | | — | | — | | — | |
| ■Accessories (optional) | | Symbol | | | | | | | | | | | | | | |
| Internally mounted: Auxiliary switch | | A X | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Alarm switch | | A L | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Shunt trips | | S H | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Internally mounted: Undervoltage trips | | U V | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Motor operator | | M C | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: External operating handle | Breaker-mounted | H B | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Door-mounted (variable depth) | H P | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle extension | | H A | — | | — | | — | | — | | ● | | ● | | ● | |
| Externally mounted: Mechanical interlock | Slide type | M S | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Rear-connected type | M B | — | | — | | — | | — | | — | | — | | — | |
| | Link type | M L | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | Wire type | M W | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle holder | | H H | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Toggle lock | | H L | ● | | ● | | ● | | ● | | | | | | | |
| Externally mounted: Terminal cover | For front-connected | C F | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| | For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Terminal block for lead | | T F | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| Externally mounted: Door flange | | D F | ● | | ● | | ● | | ● | | ● | | ● | | ● | |
| CE marking | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Electronic ⑯ | | Electronic ⑯ | | Electronic ⑯ | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | Yes ⑫ | | Yes ⑫ | | Yes ⑫ | | Yes ⑫ | | Yes | | Yes | | Yes | |
| Page of characteristics and outline dimensions | | | 7-24 | | 7-26 | | 7-36 | | 7-38 | | 7-52 | | 7-66 | | 7-72 | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑯ : Optional preferential alarm or ground fault trip function available on request.
㉛ : Also applicable to 415V AC. ㊶ : A safety lock function is provided. ㊸ : For the extension bars, please place the order separately in parts.
⑫ : There are some limitations. See page 5-23 for details.

# 6 Moulded Case Circuit Breakers for motor protection

| Frame size (A) | 30 | 30 | 50 | 50 | 100 | 225 | | |
|---|---|---|---|---|---|---|---|---|
| Type | **E30-NM** | **S30-NM** | **E50-NM** | **S50-NM** | **E100-NM** | **S250-SM** | | |
| Number of poles | 3 | 3 | 3 | 3 | 3 | 3 | | |
| **■Ratings** | | | | | | | | |

Motor rated capacity (kW) and breaker rated current (A)
Calibrated at 40°C
45°C

| (A) | (kW) 200/220V | (kW) 400/440V |
|---|---|---|
| 1.4 | 0.2 | 0.4 |
| 2.6 | 0.4 | — |
| 4 | 0.75 | 1.5 |
| 8 | 1.5 | 3.7 |
| 10 | 2.2 | — |
| 16 | 3.7 | 7.5 |
| 24 | 5.5 | 11 |
| 32 | 7.5 | 15 |

(40℃ only)

| (A) | (kW) 200/220V | (kW) 400/440V |
|---|---|---|
| 0.7 | — | 0.2 |
| 1.4 | 0.2 | 0.4 |
| 2 | — | 0.75 |
| 2.6 | 0.4 | — |
| 4 | 0.75 | 1.5 |
| 5 | — | 2.2 |
| 8 | 1.5 | 3.7 |
| 10 | 2.2 | — |
| 12 | — | 5.5 |
| 16 | 3.7 | 7.5 |
| 24 | 5.5 | 11 |
| 32 | 7.5 | 15 |

(40℃ only)

| (A) | (kW) 200/220V | (kW) 400/440V |
|---|---|---|
| 24 | 5.5 | 11 |
| 32 | 7.5 | 15 |
| 40 | — | 18.5 |
| 45 | 11 | 22 |

(40℃ only)

| (A) | (kW) 200/220V | (kW) 400/440V |
|---|---|---|
| 10 | 2.2 | — |
| 12 | — | 5.5 |
| 16 | 3.7 | 7.5 |
| 24 | 5.5 | 11 |
| 32 | 7.5 | 15 |
| 40 | — | 18.5 |
| 45 | 11 | 22 |

(40℃ only)

| (A) | (kW) 200/220V | (kW) 400/440V |
|---|---|---|
| 60 | 15 | 30 |
| 75 | 18.5 | 37 |
| 90 | 22 | 45 |


(40℃ only)

| (A) | (kW) 200/220V | (kW) 400/440V |
|---|---|---|
| 125 | 30 | — |
| 150 | 37 | 75 |
| 175 | 45 | 90 |
| 225 | 55 | 110 |


Note: Select an appropriate one depending on the total load current of the motor operator.

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Rated insulation voltage 〔$U_i$〕 V | | | 500 | 690 | 690 | 690 | 690 | 690 |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | 6 | 6 | 6 | 6 | 6 | 8 |
| **■Rated breaking capacity, kA** | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 ㊻ | AC | 440V | 1.5/1 | 2.5/2 | 2.5/2 | 10/5 | 10/5 | 30/15 |
| IEC 60947-2 | | 415V | 1.5/1 | 2.5/2 | 2.5/2 | 10/5 | 10/5 | 40/20 |
| $I_{cu}/I_{cs}$(sym) | | 380V | 1.5/1 | 2.5/2 | 2.5/2 | 10/5 | 10/5 | 40/20 |
| | | 240V | 2.5/2 ㊾ | 5/3 ㊾ | 5/3 ㊾ | 25/13 ㊾ | 25/13 ㊾ | 85/43 |
| **■External dimensions, mm** | | | | | | | | |
| | | a | 75 | 75 | 75 | 75 | 75 | 105 |
| | | b | 100 | 100 | 100 | 100 | 100 | 165 |
| | | c | 60 | 60 | 60 | 60 | 60 | 68 |
| | | d | 84 | 84 | 84 | 84 | 84 | 95 |
| Weight (◉ marked standard type) kg | | | 0.5 | 0.5 | 0.5 | 0.5 | 0.5 | 1.5 |
| **■Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — | — | — |
| | Standard (PMC) | | — | — | — | — | — | — |
| For distribution boards | (PMC) | | — | — | — | — | — | — |
| | (PMD) | | — | — | — | — | — | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | | | — | — | — | — | — | — |
| TemPlug70 (PG) | | | — | — | — | — | — | ○ |
| DIN rail mount | | | ◉ | ◉ | ◉ | ◉ | ◉ | — |
| **■Accessories (optional)** | | Symbol | | | | | | |
| Internally mounted: Auxiliary switch | | A X | ● | ● | ● | ● | ● | ● |
| Internally mounted: Alarm switch | | A L | ● | ● | ● | ● | ● | ● |
| Internally mounted: Shunt trips | | S H | ● | ● | ● | ● | ● | ● |
| Internally mounted: Undervoltage trips | | U V | ● ㊽ | ● ㊽ | ● ㊽ | ● ㊽ | ● ㊽ | ● |
| Externally mounted: Motor operator | | M C | — | — | — | — | — | ● |
| Externally mounted: External operating handle | Breaker-mounted | H B | △ | △ | △ | △ | △ | ● |
| | Door-mounted (variable depth) | H P | △ | △ | △ | △ | △ | ● |
| Externally mounted: Toggle extension | | H A | — | — | — | — | — | — |
| Externally mounted: Mechanical interlock | Slide type | M S | ● | ● | ● | ● | ● | ● |
| | Rear-connected type | M B | — | — | — | — | — | — |
| | Link type | M L | — | — | — | — | — | ● |
| | Wire type | M W | — | — | — | — | — | ● |
| Externally mounted: Toggle holder | | H H | — | — | — | — | — | ● |
| Externally mounted: Toggle lock | | H L | ● | ● | ● | ● | ● | ● |
| Externally mounted: Terminal cover | For front-connected | C F | ● | ● | ● | ● | ● | ● |
| | For rear-connected and plug-in | C R | ● ② | ● ② | ● ② | ● ② | ● ② | ● |
| Externally mounted: Terminal block for lead | | T F | ● | ● | ● | ● | ● | ● |
| Externally mounted: Door flange | | D F | — | — | — | — | — | ● |
| CE marking | | | Yes | Yes | Yes | Yes | Yes | Yes |
| Overcurrent trip mechanism | | | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Thermal-magnetic |
| Colour of cover | | | Light Grey | Light Grey | Light Grey | Light Grey | Light Grey | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | Yes | Yes |
| Reverse connection | | | Yes ㉒ | Yes | Yes | Yes ㉒ | Yes ㉒ | Yes |
| Page of characteristics and outline dimensions | | | 7-88 | 7-88 | 7-88 | 7-88 | 7-90 | 7-92 |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.
② : Supplied as standard. ⑪ : Please order the DIN rail adapter separately. See page 6-152. ㊺ : A wire clamping terminal is provided.
㊸ : For the extension bars, please place the order separately in parts.
㊽ : It is mounted on the side of the circuit breaker. In the case of Flush-mounted type (FP), it cannot be installed.
㊾ : This is the value for 230V AC. ㉒ : There are some limitations. See page 5-23 for details.

| | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 30 | | 50 | | 100 | | 125 | | 100 | | 125 | | 100 | | 125 | | | |
| Type | | | PE30-NN | | PE50-NN | | PE125-NN | | | | S125-SN | | | | PS125-NN | | | | | |
| Number of poles | | | 2 | 3 | 2 | 3 | 2 | 3 | 2 | 3 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | | |
| **■Ratings** | | | | | | | | | | | | | | | | | | | | |
| Rated current, A | | | 30 | | 50 | | 100 | | 125 | | 100 | | 125 | | 100 | | 125 | | | |
| Rated insulation voltage 〔$U_i$〕 V | | | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | | 800 | | 800 | | | |
| Rated operational voltage V | | AC | 415 | | 500 | | 500 | | 500 | | 690 | | 690 | | 690 | | 690 | | | |
| | | DC | — | | 250 ㉗ | | 250 ㉗ | | 250 ㉗ | | 250 | | 250 | | 250 | | 250 | | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | | |
| Rated short circuit making capacity 〔$I_{cm}$〕 kA peak | | | 1.5 | | 1.5 | | 2.13 | | 2.13 | | 2.8 | | 2.8 | | 2.8 | | 2.8 | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 1 (1sec.) | | 1 (1sec.) | | 1.5 (0.3sec.) | | 1.5 (0.3sec.) | | 2 (0.3sec.) | | 2 (0.3sec.) | | 2 (1sec.) | | 2 (1sec.) | | | |
| **■Performance** | | | | | | | | | | | | | | | | | | | | |
| Utilization category | | AC | AC-23A | | AC-23A | | AC-23A | | AC-23A | | AC-23A | | AC-23A | | AC-23A | | AC-23A | | | |
| JIS C 8201-3 IEC 60947-3 | | DC | — | | DC-22A | | DC-22A | | DC-22A | | DC-22A | | DC-22A | | DC-22A | | DC-22A | | | |
| Upstream breaker (OCPD) ㉙ | | | PE30-NF | | PE50-NF | | PE125-NF | | PE125-NF | | S125-SF | | S125-SF | | PS125-NF | | PS125-NF | | | |
| **■External dimensions, mm** | | | | | | | | | | | | | | | | | | | | |
|  | | a | 50 | 75 | 50 | 75 | 50 | 75 | 50 | 75 | 75 | 100 | 75 | 100 | 90 | 120 | 90 | 120 | | |
| | | b | 130 | | 130 | | 130 | | 130 | | 130 | | 130 | | 130 | | 130 | | | |
| | | c | 68 | | 68 | | 68 | | 68 | | 68 | | 68 | | 68 | | 68 | | | |
| | | d | 90 | | 90 | | 90 | | 90 | | 95 | | 95 | | 95.5 | | 95.5 | | | |
| Weight (◉ marked standard type) kg | | | 0.5 | 0.7 | 0.5 | 0.7 | 0.5 | 0.7 | 0.5 | 0.7 | 0.7 | 0.9 | 0.7 | 0.9 | 1.0 | 1.3 | 1.0 | 1.3 | | |
| **■Connections and Mountings** | | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | | ◉ ㊺ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | | |
| | With extension bars | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | — | | — | | — | | — | | ○ ㊿ | | ○ ㊿ | | | |
| | Standard (PMC) | | — | ○ | — | ○ | — | ○ | — | ○ | ○ | — | ○ | — | ○ | — | ○ | — | | |
| For distribution boards (PMD) | | | ○ | | ○ | | ○ | | ○ | | ○ | — | ○ | — | ○ | — | ○ | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | — | ○ | — | ○ | | ○ | | | |
| Draw-out type (DR) | | | — | | — | | — | | — | | — | | — | | — | | — | | | |
| TemPlug70 (PG) | | | — | | — | | — | | — | | ○ | — | ○ | — | ○ | — | ○ | — | | |
| DIN rail mount | | | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ | ○ ⑪ | | ○ ⑪ | | ○ ⑪ | | ○ ⑪ | | | |
| **■Accessories (optional)** | | Symbol | | | | | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Alarm switch | A L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Shunt trips | S H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Undervoltage trips | U V | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| Externally mounted | Motor operator | M C | — | | — | | — | | — | | — | | — | | ● | | ● | | | |
| | External operating handle: Breaker-mounted | H B | — | ● | — | ● | — | ● | — | ● | ● | | ● | | ● | | ● | | | |
| | External operating handle: Door-mounted (variable depth) | H P | — | ● | — | ● | — | ● | — | ● | ● | | ● | | ● | | ● | | | |
| | Toggle extension | H A | — | | — | | — | | — | | — | | — | | — | | — | | | |
| | Mechanical interlock: Slide type | M S | — | ● | — | ● | — | ● | — | ● | ● | | ● | | ● | | ● | | | |
| | Mechanical interlock: Rear-connected type | M B | — | | — | | — | | — | | — | | — | | — | | — | | | |
| | Mechanical interlock: Link type | M L | — | | — | | — | | — | | — | | — | | ● | | ● | | | |
| | Mechanical interlock: Wire type | M W | — | | — | | — | | — | | — | | — | | ● | | ● | | | |
| | Toggle holder | H H | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Toggle lock | H L | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Terminal cover: For front-connected | C F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Terminal cover: For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Terminal block for lead | T F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| | Door flange | D F | ● | | ● | | ● | | ● | | ● | | ● | | ● | | ● | | | |
| CE marking | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | |
| Reverse connection | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | |
| Page of characteristics and outline dimensions | | | 7-94 | | 7-94 | | 7-96 | | 7-96 | | 7-98 | | 7-98 | | 7-100 | | 7-100 | | | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available".
⑪ : Please order the DIN rail adapter separately. See page 6-152. ㉗ : Applicable to only 2 poles breakers.
㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.
㊺ : A wire clamping terminal is provided.
㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts.

| | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 225 | | 250 | | 225 | | 250 | | 400 | | 600 | | | | | | | | | | | |
| Type | | | S250-SN | | | | PS250-NN | | | | PS400-NN | | PS630-NN | | | | | | | | | | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | | | | | | | | | | |
| ■Ratings | | | | | | | | | | | | | | | | | | | | | | | | |
| Rated current, A | | | 225 | | 250 | | 225 | | 250 | | 400 | | 600 ⑦⑨ | | | | | | | | | | | |
| Rated insulation voltage 〔$U_i$〕 V | | | 690 | | 690 | | 800 | | 800 | | 800 | | 800 | | | | | | | | | | | |
| Rated operational voltage V | | AC | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | | | | | | | | | | | |
| | | DC | 250 | | 250 | | 250 | | 250 | | 250 | | 250 | | | | | | | | | | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | | | | | | | | | | |
| Rated short circuit making capacity 〔$I_{cm}$〕 kA peak | | | 6 | | 6 | | 5 | | 5 | | 7.6 | | 13 | | | | | | | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 3 (0.3sec.) | | 3 (0.3sec.) | | 3.6 (1sec.) | | 3.6 (1sec.) | | 5 (1sec.) | | 7.6 (1sec.) | | | | | | | | | | | |
| ■Performance | | | | | | | | | | | | | | | | | | | | | | | | |
| Utilization category JIS C 8201-3 IEC 60947-3 | | AC | AC-23A | | AC-23A | | AC-23A | | AC-23A | | AC-23A | | AC-23A (500A) AC-22A (600A) | | | | | | | | | | | |
| | | DC | DC-22A | | DC-22A | | DC-22A | | DC-22A | | DC-22A | | DC-22A | | | | | | | | | | | |
| Upstream breaker (OCPD) ㉙ | | | S250-SF | | S250-SF | | PS250-PF | | PS250-PF | | PS400-NF | | PS630-NF | | | | | | | | | | | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | | | | | | | | | |
|  | | a | 105 | 140 | 105 | 140 | 105 | 140 | 105 | 140 | 140 | 185 | 140 | 185 | | | | | | | | | | |
| | | b | 165 | | 165 | | 165 | | 165 | | 260 | | 260 | | | | | | | | | | | |
| | | c | 68 | | 68 | | 68 | | 68 | | 103 | | 103 | | | | | | | | | | | |
| | | d | 95 | | 95 | | 95.5 | | 95.5 | | 151 | | 151 | | | | | | | | | | | |
| Weight (◉ marked standard type) kg | | | 1.5 | 1.9 | 1.5 | 1.9 | 1.5 | 2.0 | 1.5 | 2.0 | 5.4 | 7.2 | 5.7 | 7.7 | | | | | | | | | | |
| ■Connections and Mountings | | | | | | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | — | | | | | | | | | | | |
| | With extension bars | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ | | ◉ | | | | | | | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | | | | | | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | ○ ㊿ | | ○ ㊿ | | ○ ㊿ | | ○ ㊿ | | | | | | | | | | | |
| | Standard (PMC) | | ○ | | ○ | | ○ | — | ○ | — | ○ | — | ○ | — | | | | | | | | | | |
| For distribution boards (PMD) | | | — | | — | | — | | — | | — | | — | | | | | | | | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | | | | | | | | | | |
| Draw-out type (DR) | | | — | | — | | ▲ | | ▲ | | ▲ | | ▲ | | | | | | | | | | | |
| TemPlug70 (PG) | | | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | | | | | | | | | | |
| DIN rail mount | | | — | | — | | — | | — | | — | | — | | | | | | | | | | | |
| ■Accessories (optional) | | Symbol | | | | | | | | | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Alarm switch | A L | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Shunt trips | S H | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Undervoltage trips | U V | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| Externally mounted | Motor operator | M C | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | External operating handle — Breaker-mounted | H B | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | External operating handle — Door-mounted (variable depth) | H P | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Toggle extension | H A | — | | — | | — | | — | | ● | | ● | | | | | | | | | | | |
| | Mechanical interlock ⑨ — Slide type | M S | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Mechanical interlock ⑨ — Rear-connected type | M B | — | | — | | — | | — | | — | | — | | | | | | | | | | | |
| | Mechanical interlock ⑨ — Link type | M L | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Mechanical interlock ⑨ — Wire type | M W | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Toggle holder | H H | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Toggle lock | H L | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Terminal cover — For front-connected | C F | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Terminal cover — For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Terminal block for lead | T F | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Door flange | D F | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| CE marking | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | | | | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | | | | | | | | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | | | | | | | | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | | | | | | |
| Reverse connection | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | | | | | | |
| Page of characteristics and outline dimensions | | | 7-102 | | 7-102 | | 7-104 | | 7-104 | | 7-106 | | 7-108 | | | | | | | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).


㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts.

⑦⑨ : Plug-in type (PM), draw-out type (DR), and TemPlug70 (PG) are only rated current 500A.


| | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 600 | | 630 | | 800 | | 1000 | | 1250 | | 1600 | | | | | | | | | | | |
| Type | | | S630-GN | | | | S800-NN | | S1000-NN | | S1250-NN | | S1600-NN | | | | | | | | | | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | | | | | | | | | | |
| **■Ratings** | | | | | | | | | | | | | | | | | | | | | | | | |
| Rated current, A | | | 600 | | 630 | | 800 | | 1000 | | 1250 | | 1600 | | | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | | | | | | | | | | | |
| Rated operational voltage V | | AC | 690 | | 690 | | 690 | | 690 | | 690 | | 690 | | | | | | | | | | | |
| | | DC | 250 | | 250 | | 250 | | 250 | | 250 | | 250 | | | | | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | | | | | | | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | 17 | | 17 | | 17 | | 17 | | 32 | | 45 | | | | | | | | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | 10 (0.3sec.) | | 10 (0.3sec.) | | 10 (0.3sec.) | | 10 (0.3sec.) | | 15 (0.3sec.) | | 20 (0.3sec.) | | | | | | | | | | | |
| **■Performance** | | | | | | | | | | | | | | | | | | | | | | | | |
| Utilization category | | AC | AC-23A | | AC-23A | | AC-23A | | AC-23A | | AC-23A | | AC-23A | | | | | | | | | | | |
| JIS C 8201-3 IEC 60947-3 | | DC | DC-22A | | DC-22A | | DC-22A | | DC-22A | | DC-22A | | DC-22A | | | | | | | | | | | |
| Upstream breaker (OCPD) ㉙ | | | S630-NF | | S630-NF | | S800-NF | | S1000-CE | | S1250-NE | | S1600-NE | | | | | | | | | | | |
| **■External dimensions, mm** | | | | | | | | | | | | | | | | | | | | | | | | |
|  | | a | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 | 210 | 280 | | | | | | | | | | |
| | | b | 273 | | 273 | | 273 | | 273 | | 370 | | 370 | | | | | | | | | | | |
| | | c | 103 | | 103 | | 103 | | 103 | | 120 | | 140 | | | | | | | | | | | |
| | | d | 145 | | 145 | | 145 | | 145 | | 171 | | 191 | | | | | | | | | | | |
| Weight (◉ marked standard type) kg | | | 8.0 | 11.0 | 8.0 | 11.0 | 8.5 | 11.5 | 10.4 | 14.0 | 18.2 | 23.4 | 24.9 | 32.9 | | | | | | | | | | |
| **■Connections and Mountings** | | | | | | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | — | | — | | — | | — | | | | | | | | | | | |
| | With extension bars | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ○ | | | | | | | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ◉ | | | | | | | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㉛ | | ○ ㉛ | | ○ ㉛ | | — | | — | | — | | | | | | | | | | | |
| | Standard (PMC) | | ○ | — | ○ | — | ○ | — | — | | ○ | | — | | | | | | | | | | | |
| For distribution boards (PMD) | | | — | | — | | — | | — | | — | | — | | | | | | | | | | | |
| lush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | | | | | | | | | | |
| Draw-out type (DR) | | | ▲ | | ▲ | | ▲ | | — | | ▲ | | ○ | | | | | | | | | | | |
| TemPlug70 (PG) | | | ○ | — | ○ | — | — | | — | | — | | — | | | | | | | | | | | |
| DIN rail mount | | | — | | — | | — | | — | | — | | — | | | | | | | | | | | |
| **■Accessories (optional)** | | Symbol | | | | | | | | | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Alarm switch | A L | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Shunt trips | S H | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Undervoltage trips | U V | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| Externally mounted | Motor operator | M C | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | External operating handle: Breaker-mounted | H B | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | External operating handle: Door-mounted (variable depth) | H P | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Toggle extension | H A | ● | | ● | | ● | | ● | | ● ㉔ | | ● ㉔ | | | | | | | | | | | |
| | Mechanical interlock ⑨: Slide type | M S | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Mechanical interlock ⑨: Rear-connected type | M B | — | | — | | — | | — | | ● | | ● | | | | | | | | | | | |
| | Mechanical interlock ⑨: Link type | M L | ● | | ● | | ● | | ● | | — | | — | | | | | | | | | | | |
| | Mechanical interlock ⑨: Wire type | M W | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Toggle holder | H H | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Toggle lock | H L | | | | | | | | | | | | | | | | | | | | | | |
| | Terminal cover: For front-connected | C F | ● | | ● | | ● | | ● | | ● | | — | | | | | | | | | | | |
| | Terminal cover: For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | — | | — | | | | | | | | | | | |
| | Terminal block for lead | T F | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| | Door flange | D F | ● | | ● | | ● | | ● | | ● | | ● | | | | | | | | | | | |
| CE marking | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | | | | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | | | | | | | | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | | | | | | | | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | | | | | | |
| Reverse connection | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | | | | | | |
| Page of characteristics and outline dimensions | | | 7-110 | | 7-110 | | 7-110 | | 7-110 | | 7-112 | | 7-114 | | | | | | | | | | | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
㉔ : One is supplied with every five breakers. Please specify if more are required.
㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.
㉛ : A safety lock function is provided.

| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 2000 | | 2500 | | 3200 | | | | | |
| Type | | | XS2000NN | | XS2500NN | | XS3200NN | | | | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | | | | | |
| ■Ratings | | | | | | | | | | | | |
| Rated current, A | | | 2000 | | 2500 | | 3200 | | | | | |
| Rated insulation voltage 〔$U_i$〕 V | | | 690 | | 690 | | 690 | | | | | |
| Rated operational voltage V | | AC | 690 | | 690 | | 690 | | | | | |
| | | DC | 250 | | 250 | | 250 | | | | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | | | | |
| Rated short circuit making capacity 〔$I_{cm}$〕 kA peak | | | 90 | | 90 | | 90 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 35 (0.3sec.) | | 35 (0.3sec.) | | 38 (0.5sec.) | | | | | |
| ■Performance | | | | | | | | | | | | |
| Max switching current A | | AC | 12000 | | 15000 | | 15000 | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 ⑰ | | DC | 5000 | | 6250 | | 6250 | | | | | |
| IEC60947-2 | | | | | | | | | | | | |
| Ann.L CBI-Y | | | | | | | | | | | | |
| Endurance | Number of operating cycles with current | | 500 | | 500 | | 500 | | | | | |
| | Number of operating cycles without current | | 2500 | | 2500 | | 1500 | | | | | |
| Upstream breaker (OCPD) ㉙ | | | XS2000NE | | XS2500NE | | XS3200NE | | | | | |
| ■External dimensions, mm | | | | | | | | | | | | |
|  | | a | 320 | 429 | 320 | 429 | 320 | | | | | |
| | | b | 450 | | 450 | | 450 | | | | | |
| | | c | 185 | | 185 | | 185 | | | | | |
| | | d | 245 | | 245 | | 245 | | | | | |
| Weight (◉ marked standard type) kg | | | 51.8 | 64.8 | 60 | 75.7 | 60 | | | | | |
| ■Connections and Mountings | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | — | | | | | |
| | With extension bars | | ○ | | — | | — | | | | | |
| Rear-connected (RC) | Flat bar studs | | ◉ | | ◉ | | ◉ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | — | | | | | |
| | Standard (PMC) | | — | | — | | — | | | | | |
| For distribution boards | (PMD) | | — | | — | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | | | | |
| Draw-out type (DR) | | | ○ | | — | | — | | | | | |
| TemPlug70 (PG) | | | — | | — | | — | | | | | |
| DIN rail mount | | | — | | — | | — | | | | | |
| ■Accessories (optional) | | Symbol | | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | | ● | | ● | | | | | |
| | Alarm switch | A L | ● | | ● | | ● | | | | | |
| | Shunt trips | S H | ● | | ● | | ● | | | | | |
| | Undervoltage trips | U V | ● ⑥ | | ● ⑥ | | ● ⑥ | | | | | |
| Externally mounted | Toggle extension | H A | ● ② | | ● ② | | ● ② | | | | | |
| | Mechanical interlock ⑨ Slide type | M S | ● | | ● | | ● | | | | | |
| | Rear-connected type | M B | ● | | ● | | ● | | | | | |
| | Link type | M L | — | | — | | — | | | | | |
| | Wire type | M W | — | | — | | — | | | | | |
| | Terminal cover For front-connected | C F | — | | — | | — | | | | | |
| | For rear-connected and plug-in | C R | — | | — | | — | | | | | |
| | Terminal block for lead | T F | ● | | ● | | ● | | | | | |
| | Door flange | D F | ● | | ● | | ● | | | | | |
| CE marking | | | Non | | Non | | Non | | | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | | | |
| Suitability for isolation | | | Non | | Non | | Non | | | | | |
| Reverse connection | | | Yes | | Yes | | Yes | | | | | |
| Page of characteristics and outline dimensions | | | 7-116 | | 7-118 | | 7-118 | | | | | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available".
② : Supplied as standard. ⑥ : With AC UVT, the UVT controller is externally mounted. ⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.
㊻ : Fixed depth, not adjustable. ⑰ : XS2000NN, XS2500NN, and XS3200NN are JIS C 8201-2-1 Ann.2 compliant.

# 9 Circuit Breaker with earth leakage alarm (Harmonics/surge with countermeasure)

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 50 | 50 | 50 | | 100 | 125 | 100 | | 125 | | |
| Type | | | PE50-NFZ | PS50-NFZ | ZAS50-GF | | PE125-NFZ | | ZAS125-SF | | | | |
| Number of poles ⑭⑮ | | | 3 | 3 | 3 | 4 | 3 | 3 | 3 | | 3 | | |
| **■Ratings** | | | | | | | | | | | | | |
| Rated current, A | | | 15 | 15 | 15 | 50 | 60 | 125 | 15 | 50 | 125 | | |
| Calibrated at 40°C | | | 20 | 20 | 20 | | 75 | | 20 | 60 | | | |
| | | | 30 | 30 | 30 | | 100 | | 30 | 75 | | | |
| | | | 40 | 40 | 40 | | | | 40 | 100 | | | |
| | | | 50 | 50 | | | | | | | | | |
| Rated operational voltage V | | | 100-440 common | 100-440 common | 100-440 common | | 100-440 common | 100-440 common | 100-440 common | | 100-440 common | | |
| Applicable range V | | | 80～484 | 80～484 | 80～484 | | 80～484 | 80～484 | 80～484 | | 80～484 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | 6 | 8 | | 6 | 6 | 8 | | 8 | | |
| **■Rated breaking capacity, kA** | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 2.5 | 7.5 | 50 | | 10 | 10 | 25 | | 25 | | |
| $I_{cu}$(sym) | | 415V | 2.5 | 7.5 | 65 | | 10 | 10 | 30 | | 30 | | |
| | | 240V | 7.5 | 15 | 85 | | 30 | 30 | 50 | | 50 | | |
| **■Earth leakage alarm specifications** | | | | | | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | Electronic | | Electronic | Electronic | Electronic | | Electronic | | |
| Rated sensitivity current mA | | | 30/100/500 selectable | 30/100/500 selectable | 100/200/500 selectable | | 30/100/500 selectable | 30/100/500 selectable | 100/200/500 selectable | | 100/200/500 selectable | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | 1c | | 1c | 1c | 1c | | 1c | | |
| Alarm reset function (manual reset) ㊴ | | | Push button | Push button | Push button ⑧ | | Push button | Push button | Push button ⑧ | | Push button ⑧ | | |
| **■External dimensions, mm** | | | | | | | | | | | | | |
|  | | a | 75 | 75 | 90 | 120 | 75 | 75 | 75 | | 75 | | |
| | | b | 130 | 130 | 155 | | 130 | 130 | 130 | | 130 | | |
| | | c | 68 | 68 | 68 | | 68 | 68 | 68 | | 68 | | |
| | | d | 90 | 90 | 92 | | 90 | 90 | 95 | | 95 | | |
| Weight (◉ marked standard type) kg | | | 0.8 | 0.8 | 1.3 | 1.7 | 0.9 | 0.9 | 0.95 | | 0.95 | | |
| **■Connections and Mountings** | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ ㊺ | ◉ | | ◉ | ◉ | ◉ ④ | | ◉ | | |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | | ○ ㊸ | ○ ㊸ | ○ ㊸ | | ○ ㊸ | | |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | | ○ | ○ | ○ | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | | — | — | — | | — | | |
| | Standard (PMC) | | — | — | — | | — | — | — | | — | | |
| For distribution boards (PMD) | | | — | — | — | | — | — | — | | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | | ○ | ○ | ○ | | ○ | | |
| Draw-out type (DR) | | | — | — | — | | — | — | — | | — | | |
| TemPlug70 (PG) | | | — | — | ○ | — | — | — | ○ | | ○ | | |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ | | ○ ⑪ | ○ ⑪ | ○ ⑪ | | ○ ⑪ | | |
| **■Accessories (optional)** | | Symbol | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Alarm switch | A L | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Shunt trips | S H | — | — | △ ㊿㉜ | | — | — | △ ㊿㉜ | | △ ㊿㉜ | | |
| | Undervoltage trips | U V | — | — | — | | — | — | — | | — | | |
| | Test lead | T L | — | — | ● ㉜ | | — | — | — | | — | | |
| | Megger test switch | MG | — | — | ● | | — | — | ● | | ● | | |
| Externally mounted | Motor operator | M C | — | — | ● | | — | — | — | | — | | |
| | External operating handle — Breaker-mounted | H B | ● | ● | ● | | ● | ● | ● | | ● | | |
| | External operating handle — Door-mounted (variable depth) | H P | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Toggle extension | H A | — | — | — | | — | — | — | | — | | |
| | Mechanical interlock — Slide type | M S | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Mechanical interlock — Rear-connected type | M B | — | — | — | | — | — | — | | — | | |
| | Mechanical interlock — Link type | M L | — | — | — | | — | — | — | | — | | |
| | Mechanical interlock — Wire type | MW | — | — | — | | — | — | — | | — | | |
| | Toggle holder | H H | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Toggle lock | H L | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Terminal cover — For front-connected | C F | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Terminal cover — For rear-connected and plug-in | C R | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Terminal block for lead | T F | ● | ● | ● | | ● | ● | ● | | ● | | |
| | Door flange | D F | — | — | — | | — | — | — | | — | | |
| CE marking | | | Non | Non | Non | | Non | Non | Non | | Non | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | | Thermal-magnetic | | |
| Earth leakage indication | | | LED (Red) | LED (Red) | LED (Red) | | LED (Red) | LED (Red) | LED (Red) | | LED (Red) | | |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | | Grey Blue | Grey Blue | Grey Blue | | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | | Yes (Red) | Yes (Red) | Yes (Red) | | Yes (Red) | | |
| Suitability for isolation | | | Yes | Yes | Yes | | Yes | Yes | Yes | | Yes | | |
| Reverse connection | | | Non | Non | Yes | | Non | Non | Yes ㉒ | | Yes ㉒ | | |
| Page of characteristics and outline dimensions | | | 7-120 | 7-120 | 7-124 | | 7-120 | 7-120 | 7-122 | | 7-122 | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

④ : 50A or less is the M5 wire clamping terminal. ⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.


㉚ : See page 6-22 for the contact rating. ㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊺ : A wire clamping terminal is provided.

㊸ : For the extension bars, please place the order separately in parts.

㊿ : Flush-mounted type cannot be applied when a shunt trip device is mounted. ㉒ : There are some limitations. See page 5-23 for details. ㉜ : See page 6-27 for details.

Remarks: The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

# 9 Circuit Breaker with earth leakage alarm (Harmonics/surge with countermeasure)

| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | | 125 | | 225 | | 250 | | 225 | | 250 | | | | | | |
| Type | | | ZAS100-GF | | ZAS125-GF | | ZAE250-SF | | | | ZAS250-SF | | | | | | | | |
| Number of poles ⑭⑮ | | | 3 | 4 | 3 | 4 | 3 | | 3 | | 3 | | 3 | | | | | | |
| ■Ratings | | | | | | | | | | | | | | | | | | | |
| Rated current, A | | | 15 | 50 | 125 | | 125 | 225 | 250 | | 125 | 225 | 250 | | | | | | |
| Calibrated at 40°C | | | 20 | 60 | | | 150 | | | | 150 | | | | | | | | |
| | | | 30 | 75 | | | 175 | | | | 175 | | | | | | | | |
| | | | 40 | 100 | | | 200 | | | | 200 | | | | | | | | |
| Rated operational voltage V | | | 100-440 common | | 100-440 common | | 100-440 common | | 100-440 common | | 100-440 common | | 100-440 common | | | | | | |
| Applicable range V | | | 80～484 | | 80～484 | | 80～484 | | 80～484 | | 80～484 | | 80～484 | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | | 8 | | 8 | | | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 50 | | 50 | | 15 | | 15 | | 30 | | 30 | | | | | | |
| $I_{cu}$(sym) | | 415V | 65 | | 65 | | 25 | | 25 | | 40 | | 40 | | | | | | |
| | | 240V | 85 | | 85 | | 35 | | 35 | | 85 | | 85 | | | | | | |
| ■Earth leakage alarm specifications | | | | | | | | | | | | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | | Electronic | | Electronic | | Electronic | | Electronic | | Electronic | | | | | | |
| Rated sensitivity current mA | | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | | | | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | | | | | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | | 1c | | 1c | | 1c | | 1c | | 1c | | | | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | | Push button ⑧ | | Push button ⑧ | | Push button ⑧ | | Push button ⑧ | | Push button ⑧ | | | | | | |
| ■External dimensions, mm | | | | | | | | | | | | | | | | | | | |
|  | | a | 90 | 120 | 90 | 120 | 105 | | 105 | | 105 | | 105 | | | | | | |
| | | b | 155 | | 155 | | 165 | | 165 | | 165 | | 165 | | | | | | |
| | | c | 68 | | 68 | | 68 | | 68 | | 68 | | 68 | | | | | | |
| | | d | 92 | | 92 | | 95 | | 95 | | 95 | | 95 | | | | | | |
| Weight (◉ marked standard type) kg | | | 1.3 | 1.7 | 1.3 | 1.7 | 1.7 | | 1.7 | | 1.7 | | 1.7 | | | | | | |
| ■Connections and Mountings | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | | | | | |
| | With extension bars | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | — | | — | | — | | — | | | | | | |
| | Standard (PMC) | | — | | — | | — | | — | | — | | — | | | | | | |
| For distribution boards (PMD) | | | — | | — | | — | | — | | — | | — | | | | | | |
| lush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | ○ | | | | | | |
| Draw-out type (DR) | | | — | | — | | — | | — | | — | | — | | | | | | |
| TemPlug70 (PG) | | | ○ | — | ○ | — | ○ | | ○ | | ○ | | ○ | | | | | | |
| DIN rail mount | | | ○ ⑪ | | ○ ⑪ | | — | | — | | — | | — | | | | | | |
| ■Accessories (optional) | | Symbol | | | | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Alarm switch | A L | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Shunt trips | S H | △ ⑦⑧② | | △ ⑦⑧② | | △ ⑦⑧② | | △ ⑦⑧② | | △ ⑦⑧② | | △ ⑦⑧② | | | | | | |
| | Undervoltage trips | U V | — | | — | | — | | — | | — | | — | | | | | | |
| | Test lead | T L | ● ⑧② | | ● ⑧② | | ● ⑧② | | ● ⑧② | | ● ⑧② | | ● ⑧② | | | | | | |
| | Megger test switch | M G | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| Externally mounted | Motor operator | M C | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | External operating handle: Breaker-mounted | H B | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | External operating handle: Door-mounted (variable depth) | H P | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Toggle extension | H A | — | | — | | — | | — | | — | | — | | | | | | |
| | Mechanical interlock: Slide type | M S | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Mechanical interlock: Rear-connected type | M B | — | | — | | — | | — | | — | | — | | | | | | |
| | Mechanical interlock: Link type | M L | — | | — | | — | | — | | — | | — | | | | | | |
| | Mechanical interlock: Wire type | M W | — | | — | | — | | — | | — | | — | | | | | | |
| | Toggle holder | H H | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Toggle lock | H L | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Terminal cover: For front-connected | C F | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Terminal cover: For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Terminal block for lead | T F | ● | | ● | | ● | | ● | | ● | | ● | | | | | | |
| | Door flange | D F | — | | — | | — | | — | | — | | — | | | | | | |
| CE marking | | | Non | | Non | | Non | | Non | | Non | | Non | | | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | | | | | |
| Earth leakage indication | | | LED (Red) | | LED (Red) | | LED (Red) | | LED (Red) | | LED (Red) | | LED (Red) | | | | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | | | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | | | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | |
| Reverse connection | | | Yes | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | |
| Page of characteristics and outline dimensions | | | 7-124 | | 7-126 | | 7-128 | | 7-128 | | 7-128 | | 7-128 | | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating.

㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊸ : For the extension bars, please place the order separately in parts.


⑦⓪ : Flush-mounted type cannot be applied when a shunt trip device is mounted. ⑧② : See page 6-27 for details.

Remarks: The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

# 9 Circuit Breaker with earth leakage alarm (Harmonics/surge with countermeasure)


| | | |

# 9 Circuit Breaker with earth leakage alarm (Harmonics/surge with countermeasure)

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 600 | 630 | 800 | 800 | | | | |
| Type | | | ZAS630-NF | | ZAS800-CF | ZAS800-NF | | | | |
| Number of poles ⑭⑮ | | | 3 | 3 | 3 | 3 | | | | |
| **■Ratings** | | | | | | | | | | |
| Rated current, A | | | 500 | 630 | 700 | 700 | | | | |
| Calibrated at 40°C | | | 600 | | 800 | 800 | | | | |
| Rated operational voltage V | | | 100-440 common | 100-440 common | 100-440 common | 100-440 common | | | | |
| Applicable range V | | | 80～484 | 80～484 | 80～484 | 80～484 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | 8 | 8 | | | | |
| **■Rated breaking capacity, kA** | | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 45 | 45 | 30 | 45 | | | | |
| $I_{cu}$(sym) | | 415V | 50 | 50 | 36 | 50 | | | | |
| | | 240V | 85 | 85 | 50 | 85 | | | | |
| **■Earth leakage alarm specifications** | | | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | Electronic | Electronic | | | | |
| Rated sensitivity current mA | | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | | | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | | | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | 1c | 1c | | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | Push button ⑧ | Push button ⑧ | Push button ⑧ | | | | |
| **■External dimensions, mm** | | | | | | | | | | |
|  | | a | 210 | 210 | 210 | 210 | | | | |
| | | b | 273 | 273 | 273 | 273 | | | | |
| | | c | 103 | 103 | 103 | 103 | | | | |
| | | d | 145 | 145 | 145 | 145 | | | | |
| Weight (◉ marked standard type) kg | | | 10.0 | 10.0 | 11.0 | 11.0 | | | | |
| **■Connections and Mountings** | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | — | — | — | | | | |
| | With extension bars | | ◉ | ◉ | ◉ | ◉ | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — | | | | |
| | Standard (PMC) | | — | — | — | — | | | | |
| For distribution boards (PMD) | | | — | — | — | — | | | | |
| lush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ | | | | |
| Draw-out type (DR) | | | — | — | — | — | | | | |
| TemPlug70 (PG) | | | ○ | ○ | — | — | | | | |
| DIN rail mount | | | — | — | — | — | | | | |
| **■Accessories (optional)** | | **Symbol** | | | | | | | | |
| Internally mounted: Auxiliary switch | | A X | ● | ● | ● | ● | | | | |
| Alarm switch | | A L | ● | ● | ● | ● | | | | |
| Shunt trips | | S H | ● ㊷ | ● ㊷ | ● ㊷ | ● ㊷ | | | | |
| Undervoltage trips | | U V | — | — | — | — | | | | |
| Test lead | | T L | ● ㉜ | ● ㉜ | ● ㉜ | ● ㉜ | | | | |
| Megger test switch | | M G | ● | ● | ● | ● | | | | |
| Externally mounted: Motor operator | | M C | ● | ● | ● | ● | | | | |
| External operating handle: Breaker-mounted | | H B | ● | ● | ● | ● | | | | |
| Door-mounted (variable depth) | | H P | ● | ● | ● | ● | | | | |
| Toggle extension | | H A | ● | ● | ● | ● | | | | |
| Mechanical interlock: Slide type | | M S | ● | ● | ● | ● | | | | |
| Rear-connected type | | M B | — | — | — | — | | | | |
| Link type | | M L | — | — | — | — | | | | |
| Wire type | | M W | — | — | — | — | | | | |
| Toggle holder | | H H | ● | ● | ● | ● | | | | |
| Toggle lock | | H L | | | | | | | | |
| Terminal cover: For front-connected | | C F | ● | ● | ● | ● | | | | |
| For rear-connected and plug-in | | C R | ● | ● | ● | ● | | | | |
| Terminal block for lead | | T F | ● | ● | ● | ● | | | | |
| Door flange | | D F | — | — | — | — | | | | |
| CE marking | | | Non | Non | Non | Non | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | | | | |
| Earth leakage indication | | | LED (Red) | LED (Red) | LED (Red) | LED (Red) | | | | |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | | | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | | | | |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | | | | |
| Reverse connection | | | Yes | Yes | Yes | Yes | | | | |
| Page of characteristics and outline dimensions | | | 7-136 | 7-136 | 7-138 | 7-138 | | | | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available".
⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.
⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating.
㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊷ : Factory-installed. ㉜ : See page 6-27 for details.
Remarks: The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

# 10 Circuit Breaker with earth leakage alarm for distribution boards and control boards

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 50 | 50 | 100 | | | | | |
| Type | | | TB50KSL | TB50KSZ | TB100KSZ | | | | | |
| Number of poles ⑭⑮ | | | 2 | 3 | 3 | | | | | |
| ■Ratings | | | | | | | | | | |
| Rated current, A | | | 15 50 | 15 50 | 60 | | | | | |
| Calibrated at 40°C | | | 20 | 20 | 75 | | | | | |
| | | | 30 | 30 | 100 | | | | | |
| | | | 40 | 40 | | | | | | |
| Rated operational voltage AC V | | | 100-240 common | 200-415 common | 200-415 common | | | | | |
| Applicable range V | | | 80～264 | 160～484 | 160～484 | | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 415V | — | 2.5 | 2.5 | | | | | |
| $I_{cu}$(sym) | | 200V | 5(240V) | 5 | 5 | | | | | |
| | | 100/200V | — | 5 | 5 | | | | | |
| | | 100V | 5 | — | — | | | | | |
| ■Earth leakage alarm specifications | | | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | Electronic | | | | | |
| Rated sensitivity current mA | | | 30/100 selectable | 30/100/500 selectable | 30/100/500 selectable | | | | | |
| Max. operating time sec | | | 0.1 | 0.1 | 0.1 | | | | | |
| Earth leakage alarm output contact configuration ㉚ | | | — ㊱ | 1c | 1c | | | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button | Push button ㉞ | Push button ㉞ | | | | | |
| ■External dimensions, mm | | | | | | | | | | |
|  | | a | 50 | 75 | 75 | | | | | |
| | | b | 96 | 96 | 96 | | | | | |
| | | c | 60 | 60 | 60 | | | | | |
| | | d | 75 | 75 | 75 | | | | | |
| Weight (◉ marked standard type) kg | | | 0.3 | 0.5 | 0.6 | | | | | |
| ■Connections and Mountings | | | | | | | | | | |
| Front-connected (FC) Terminal screws | | | ◉ ㊺ | ◉ ㊺ | ◉ | | | | | |
| Rear-connected (RC) | | | — | — | — | | | | | |
| Flush-mounted (FP) | | | — | — | — | | | | | |
| DIN rail mount | | | ○ ㊷ | ○ ㊷ | ○ ㊷ | | | | | |
| Clip-in chassis mount | | | ◉ | ◉ | ◉ | | | | | |
| ■Accessories (optional) | | Symbol | | | | | | | | |
| Internally mounted: Auxiliary switch | | A X | ● | ● | ● | | | | | |
| Internally mounted: Alarm switch | | A L | ● | ● | ● | | | | | |
| Internally mounted: Shunt trips | | S H | — | ● | ● | | | | | |
| Internally mounted: Undervoltage trips | | U V | — | — | — | | | | | |
| Internally mounted: Test lead | | T L | — | — | — | | | | | |
| Internally mounted: Megger test switch | | M G | ● ㊲ | ● ㊲ | ● ㊲ | | | | | |
| Externally mounted: Toggle holder | | H H | ● | ● | ● | | | | | |
| Externally mounted: Toggle lock | | H L | — | — | — | | | | | |
| Externally mounted: Terminal cover For front-connected | | C F | ● | ● | ● | | | | | |
| Externally mounted: Terminal block for lead | | T F | ● | ● | ● | | | | | |
| CE marking | | | Non | Non | Non | | | | | |
| Overcurrent trip mechanism | | | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | | | | | |
| Earth leakage indication | | | LED (Red) | LED (Red) | LED (Red) | | | | | |
| Colour of cover | | | Grey | Grey | Grey | | | | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | | | | | |
| Reverse connection | | | Non | Non | Non | | | | | |
| Page of characteristics and outline dimensions | | | 7-140 | 7-142 | 7-142 | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available".

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.

⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating.


㉞ : Optional lead wire draw-in for remote reset available on request. Please specify "with MRA" when ordering. The external switch should be a self-resetting a-contact (NO) switch (for 24V DC 10mA microload circuit), and do not apply voltage.

㊱ : The earth leakage alarm of TB50KSL type is LED indication only. ㊲ : If the megger test switch is mounted, the auxiliary switch cannot be mounted.

㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

㊺ : A wire clamping terminal is provided. ㊷ : Please order the DIN rail mounting bracket separately. (Order type: 50EE-RAIL, 1 set per unit)

## 11 Single phase 3-wire circuit breaker with neutral phase open protection and earth leakage alarm (Harmonics/surge with countermeasure)

| Frame size (A) | | | 100 | 125 | 100 | 125 | 225 | 250 | 225 | 250 |
|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | NAE125-SF | | NAS125-SF | | NAE250-SF | | NAS250-SF | |
| Number of poles / Elements | | | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ |
| Phase and wires | | | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W |
| ■Ratings | | | | | | | | | | |
| Rated current, A<br>Calibrated at 40°C | | | 15 50<br>20 60<br>30 75<br>40 100 | 125 | 15 50<br>20 60<br>30 75<br>40 100 | 125 | 125 225<br>150<br>175<br>200 | 250 | 125 225<br>150<br>175<br>200 | 250 |
| Rated operational voltage AC V | | | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 |
| Rated impulse withstand voltage ($U_{imp}$) kV | | | 8 | 8 | 8 | 8 | 8 | 8 | 8 | 8 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | 135 | 135 | 135 | 135 | 135 | 135 |
| | Rated non-operating overvoltage AC V | | 120 | 120 | 120 | 120 | 120 | 120 | 120 | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less |
| ■Rated breaking capacity, kA | | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 35 | 35 | 50 | 50 | 35 | 35 | 85 | 85 |
| ■External dimensions, mm | | | | | | | | | | |
|  | a | | 100 | 100 | 100 | 100 | 130 | 130 | 130 | 130 |
| | b | | 130 | 130 | 130 | 130 | 165 | 165 | 165 | 165 |
| | c | | 68 | 68 | 68 | 68 | 68 | 68 | 68 | 68 |
| | d | | 95 | 95 | 95 | 95 | 95 | 95 | 95 | 95 |
| Weight (◉ marked standard type) kg | | | 1.15 | 1.15 | 1.15 | 1.15 | 1.8 | 1.8 | 1.8 | 1.8 |
| ■Earth leakage alarm specifications | | | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic |
| Rated sensitivity current mA | | | 30/100/500 selectable<br>100/200/500 selectable | 30/100/500 selectable<br>100/200/500 selectable | 30/100/500 selectable<br>100/200/500 selectable | 30/100/500 selectable<br>100/200/500 selectable | 30/100/500 selectable<br>100/200/500 selectable | 30/100/500 selectable<br>100/200/500 selectable | 30/100/500 selectable<br>100/200/500 selectable | 30/100/500 selectable<br>100/200/500 selectable |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | 1c | 1c | 1c | 1c | 1c | 1c |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | Push button ⑧ | Push button ⑧ | Push button ⑧ | Push button ⑧ | Push button ⑧ | Push button ⑧ | Push button ⑧ |
| Earth leakage indication | | | LED (Red) | LED (Red) | LED (Red) | LED (Red) | LED (Red) | LED (Red) | LED (Red) | LED (Red) |
| ■Connections and Mountings | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ④ | ◉ | ◉ ④ | ◉ | ◉ | ◉ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | △ | △ | △ | △ | △ | △ | △ | △ |
| ■Accessories (optional) | | Symbol | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | ● | ● | ● | ● | ● | ● |
| | Alarm switch | A L | ● | ● | ● | ● | ● | ● | ● | ● |
| | Shunt trips | S H | — | — | — | — | — | — | — | — |
| | Undervoltage trips | U V | — | — | — | — | — | — | — | — |
| | Test lead | T L | — | — | — | — | — | — | — | — |
| | Megger test switch | M G | ● | ● | ● | ● | ● | ● | ● | ● |
| Externally mounted | Motor operator | M C | — | — | — | — | ● | ● | ● | ● |
| | External operating handle — Breaker-mounted | H B | ● | ● | ● | ● | ● | ● | ● | ● |
| | External operating handle — Door-mounted (variable depth) | H P | ● | ● | ● | ● | ● | ● | ● | ● |
| | Toggle extension | H A | — | — | — | — | — | — | — | — |
| | Mechanical interlock — Slide type | M S | — | — | — | — | — | — | — | — |
| | Mechanical interlock — Link type | M L | — | — | — | — | — | — | — | — |
| | Mechanical interlock — Wire type | M W | — | — | — | — | — | — | — | — |
| | Toggle holder | H H | ● | ● | ● | ● | ● | ● | ● | ● |
| | Toggle lock | H L | ● | ● | ● | ● | ● | ● | ● | ● |
| | Terminal cover — For front-connected | C F | ● | ● | ● | ● | ● | ● | ● | ● |
| | Terminal cover — For rear-connected | C R | ● | ● | ● | ● | ● | ● | ● | ● |
| | Terminal block for lead | T F | ● | ● | ● | ● | ● | ● | ● | ● |
| | Door flange | D F | — | — | — | — | — | — | — | — |
| CE marking | | | Non | Non | Non | Non | Non | Non | Non | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Yes |
| Reverse power flow circuit | | | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ |
| Page of characteristics and outline dimensions | | | 7-144 | 7-144 | 7-144 | 7-144 | 7-146 | 7-146 | 7-146 | 7-146 |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

④ : 50A or less is the M5 wire clamping terminal.

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details.

⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.

㉚ : See page 6-22 for the contact rating.

㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.


㊸ : For the extension bars, please place the order separately in parts.

㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

Remarks: See pages 3-25 and 3-26 for connection details.

# Moulded Case Circuit Breakers

## 11 Single phase 3-wire circuit breaker with neutral phase open protection and earth leakage alarm (Harmonics/surge with countermeasure)

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | 400 | | | | | | |
| Type | | | **NAE400-NF** | **NAS400-NF** | | | | | | |
| Number of poles / Elements | | | 3P2E ⑱ | 3P2E ⑱ | | | | | | |
| Phase and wires | | | 1ø3W | 1ø3W | | | | | | |
| **■Ratings** | | | | | | | | | | |
| Rated current, A | | | 250 | 250 | | | | | | |
| Calibrated at 40°C | | | 300 | 300 | | | | | | |
| | | | 350 | 350 | | | | | | |
| | | | 400 | 400 | | | | | | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | | | | | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | 8 | 8 | | | | | | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | | | | | | |
| | Rated non-operating overvoltage AC V | | 120 | 120 | | | | | | |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | | | | | | |
| **■Rated breaking capacity, kA** | | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 35 | 85 | | | | | | |
| **■External dimensions, mm** | | | | | | | | | | |
|  | | a | 170 | 170 | | | | | | |
| | | b | 260 | 260 | | | | | | |
| | | c | 103 | 103 | | | | | | |
| | | d | 145 | 145 | | | | | | |
| Weight (◉ marked standard type) kg | | | 4.9 | 4.9 | | | | | | |
| **■Earth leakage alarm specifications** | | | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | | | | | | |
| Rated sensitivity current mA | | | 30/100/500 selectable | 30/100/500 selectable | | | | | | |
| | | | 100/200/500 selectable | 100/200/500 selectable | | | | | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | | | | | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | | | | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | Push button ⑧ | | | | | | |
| Earth leakage indication | | | LED (Red) | LED (Red) | | | | | | |
| **■Connections and Mountings** | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | | | | | | |
| | With extension bars | | ○ | ○ | | | | | | |
| Rear-connected (RC) | Flat bar studs | | △ | △ | | | | | | |
| **■Accessories (optional)** | | **Symbol** | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | | | | | | |
| | Alarm switch | A L | ● | ● | | | | | | |
| | Shunt trips | S H | — | — | | | | | | |
| | Undervoltage trips | U V | — | — | | | | | | |
| | Test lead | T L | — | — | | | | | | |
| | Megger test switch | MG | ● | ● | | | | | | |
| Externally mounted | Motor operator | M C | ● | ● | | | | | | |
| | External operating handle — Breaker-mounted | H B | ● | ● | | | | | | |
| | External operating handle — Door-mounted (variable depth) | H P | ● | ● | | | | | | |
| | Toggle extension | H A | ● | ● | | | | | | |
| | Mechanical interlock — Slide type | M S | — | — | | | | | | |
| | Mechanical interlock — Link type | M L | — | — | | | | | | |
| | Mechanical interlock — Wire type | MW | — | — | | | | | | |
| | Toggle holder | H H | ● | ● | | | | | | |
| | Toggle lock | H L | | | | | | | | |
| | Terminal cover — For front-connected | C F | ● | ● | | | | | | |
| | Terminal cover — For rear-connected | C R | ● | ● | | | | | | |
| | Terminal block for lead | T F | ● | ● | | | | | | |
| | Door flange | D F | — | — | | | | | | |
| CE marking | | | Non | Non | | | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic (adjustable) | | | | | | |
| Colour of cover | | | Grey Blue | Grey Blue | | | | | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | | | | | | |
| Suitability for isolation | | | Yes | Yes | | | | | | |
| Reverse power flow circuit | | | Yes ㉕ | Yes ㉕ | | | | | | |
| Page of characteristics and outline dimensions | | | 7-148 | 7-148 | | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details.

⑱ : Do not apply to circuits where overcurrent flows in the neutral wire.


㉚ : See page 6-22 for the contact rating.

㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

Remarks: See pages 3-25 and 3-26 for connection details.

# 12 Single phase 3-wire circuit breaker with neutral phase open protection


| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | 50 | 100 | 125 | 100 | 125 | 225 | 250 | |
| Type | | PE50-NFN | PE125-NFN | | NS125-SF | | NE250-SF | | |
| Number of poles / Elements | | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | |
| Phase and wires | | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | |
| **■Ratings** | | | | | | | | | |
| Rated current, A | | 15 | 60 | 125 | 15 50 | 125 | 125 225 | 250 | |
| Calibrated at 40°C | | 20 | 75 | | 20 60 | | 150 | | |
| | | 30 | 100 | | 30 75 | | 175 | | |
| | | 40 | | | 40 100 | | 200 | | |
| | | 50 | | | | | | | |
| Rated operational voltage AC V | | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | |
| Rated impulse withstand voltage ($U_{imp}$) kV | | 6 | 6 | 6 | 8 | 8 | 8 | 8 | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | 135 | 135 | 135 | 135 | 135 | 135 | 135 | |
| | Rated non-operating overvoltage AC V | 120 | 120 | 120 | 120 | 120 | 120 | 120 | |
| | Rated overvoltage operating time (sec) | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | |
| **■Rated breaking capacity, kA** | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) AC 100/200V | | 10 | 25 | 25 | 50 | 50 | 35 | 35 | |
| **■External dimensions, mm** | | | | | | | | | |
|  | a | 75 | 75 | 75 | 75 | 75 | 105 | 105 | |
| | b | 130 | 130 | 130 | 130 | 130 | 165 | 165 | |
| | c | 68 | 68 | 68 | 68 | 68 | 68 | 68 | |
| | d | 90 | 90 | 90 | 95 | 95 | 95 | 95 | |
| Weight (◉ marked standard type) kg | | 0.8 | 0.8 | 0.8 | 0.95 | 0.95 | 1.6 | 1.6 | |
| **■Connections and Mountings** | | | | | | | | | |
| Front-connected (FC) | Terminal screws | ◉ ㊺ | ◉ | ◉ | ◉ ④ | ◉ | ◉ | ◉ | |
| | With extension bars | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | △ | △ | △ | △ | △ | △ | △ | |
| DIN rail mount | | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | — | — | |
| **■Accessories (optional)** | | Symbol | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | ● | ● | ● | ● | ● | |
| | Alarm switch | A L | ● | ● | ● | ● | ● | ● | ● | |
| | Shunt trips | S H | — | — | — | — | — | — | — | |
| | Undervoltage trips | U V | — | — | — | — | — | — | — | |
| | Test lead | T L | — | — | — | ● | ● | ● | ● | |
| | Megger test switch | M G | — | — | — | ● | ● | ● | ● | |
| Externally mounted | Motor operator | M C | — | — | — | — | — | ● | ● | |
| | External operating handle — Breaker-mounted | H B | ● | ● | ● | ● | ● | ● | ● | |
| | External operating handle — Door-mounted (variable depth) | H P | ● | ● | ● | ● | ● | ● | ● | |
| | Toggle extension | H A | — | — | — | — | — | — | — | |
| | Mechanical interlock — Slide type | M S | ● | ● | ● | ● | ● | ● | ● | |
| | Mechanical interlock — Link type | M L | — | — | — | — | — | — | — | |
| | Mechanical interlock — Wire type | M W | — | — | — | — | — | — | — | |
| | Toggle holder | H H | ● | ● | ● | ● | ● | ● | ● | |
| | Toggle lock | H L | ● | ● | ● | ● | ● | ● | ● | |
| | Terminal cover — For front-connected | C F | ● | ● | ● | ● | ● | ● | ● | |
| | Terminal cover — For rear-connected | C R | ● | ● | ● | ● | ● | ● | ● | |
| | Terminal block for lead | T F | ● | ● | ● | ● | ● | ● | ● | |
| | Door flange | D F | — | — | — | — | — | — | — | |
| CE marking | | | Non | Non | Non | Non | Non | Non | Non | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | |
| Overvoltage operation indication function | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | Yes | Yes | Yes | |
| Reverse power flow circuit | | | Non | Non | Non | Yes ㉞ | Yes ㉞ | Yes ㉞ | Yes ㉞ | |
| Page of characteristics and outline dimensions | | | 7-150 | 7-150 | 7-150 | 7-152 | 7-152 | 7-154 | 7-154 | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.
④ : 50A or less is the M5 wire clamping terminal.
⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
㊺ : A wire clamping terminal is provided.
㊸ : For the extension bars, please place the order separately in parts.
㉞ : Since the overvoltage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

Remarks: See pages 3-25 and 3-26 for connection details.

# 12 Single phase 3-wire circuit breaker with neutral phase open protection

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | 225 | 250 | 400 | 400 | 600 | 630 | 800 | |
| Type | | NS250-SF | | NE400-NF | NS400-NF | NS630-NF | | NS800-NF | |
| Number of poles / Elements | | 3P3E ⑩ | 3P3E ⑩ | 3P2E ⑱ | 3P2E ⑱ | 3P2E ⑱ | 3P2E ⑱ | 3P2E ⑱ | |
| Phase and wires | | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | |
| **■Ratings** | | | | | | | | | |
| Rated current, A | | 125 225 | 250 | 250 | 250 | 500 | 630 | 700 | |
| Calibrated at 40°C | | 150 | | 300 | 300 | 600 | | 800 | |
| | | 175 | | 350 | 350 | | | | |
| | | 200 | | 400 | 400 | | | | |
| Rated operational voltage AC V | | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | 8 | 8 | 8 | 8 | 8 | 8 | 8 | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | 135 | 135 | 135 | 135 | 135 | 135 | 135 | |
| | Rated non-operating overvoltage AC V | 120 | 120 | 120 | 120 | 120 | 120 | 120 | |
| | Rated overvoltage operating time (sec) | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | |
| **■Rated breaking capacity, kA** | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) AC 100/200V | | 85 | 85 | 35 | 85 | 85 | 85 | 85 | |
| **■External dimensions, mm** | | | | | | | | | |
|  | a | 105 | 105 | 140 | 140 | 210 | 210 | 210 | |
| | b | 165 | 165 | 260 | 260 | 273 | 273 | 273 | |
| | c | 68 | 68 | 103 | 103 | 103 | 103 | 103 | |
| | d | 95 | 95 | 145 | 145 | 145 | 145 | 145 | |
| Weight (◉ marked standard type) kg | | 1.6 | 1.6 | 4.8 | 4.8 | 10.0 | 10.0 | 11.0 | |
| **■Connections and Mountings** | | | | | | | | | |
| Front-connected (FC) | Terminal screws | ◉ | ◉ | ◉ | ◉ | — | — | — | |
| | With extension bars | ○ ⑤③ | ○ ⑤③ | ○ | ○ | ◉ | ◉ | ◉ | |
| Rear-connected (RC) | Flat bar studs | △ | △ | △ | △ | △ | △ | △ | |
| DIN rail mount | | — | — | — | — | — | — | — | |
| **■Accessories (optional)** | | Symbol | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | ● | ● | ● | ● | ● | |
| | Alarm switch | A L | ● | ● | ● | ● | ● | ● | ● | |
| | Shunt trips | S H | — | — | — | — | — | — | — | |
| | Undervoltage trips | U V | — | — | — | — | — | — | — | |
| | Test lead | T L | ● | ● | ● | ● | ● | ● | ● | |
| | Megger test switch | M G | ● | ● | ● | ● | ● | ● | ● | |
| Externally mounted | Motor operator | M C | ● | ● | ● | ● | ● | ● | ● | |
| | External operating handle: Breaker-mounted | H B | ● | ● | ● | ● | ● | ● | ● | |
| | External operating handle: Door-mounted (variable depth) | H P | ● | ● | ● | ● | ● | ● | ● | |
| | Toggle extension | H A | — | — | ● | ● | ● | ● | ● | |
| | Mechanical interlock: Slide type | M S | ● | ● | ● | ● | ● | ● | ● | |
| | Mechanical interlock: Link type | M L | — | — | — | — | — | — | — | |
| | Mechanical interlock: Wire type | M W | — | — | — | — | — | — | — | |
| | Toggle holder | H H | ● | ● | ● | ● | ● | ● | ● | |
| | Toggle lock | H L | ● | ● | | | | | | |
| | Terminal cover: For front-connected | C F | ● | ● | ● | ● | ● | ● | ● | |
| | Terminal cover: For rear-connected | C R | ● | ● | ● | ● | ● | ● | ● | |
| | Terminal block for lead | T F | ● | ● | ● | ● | ● | ● | ● | |
| | Door flange | D F | — | — | — | — | — | — | — | |
| CE marking | | | Non | Non | Non | Non | Non | Non | Non | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | |
| Overvoltage operation indication function | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | Yes | Yes | Yes | |
| Reverse power flow circuit | | | Yes ⑦④ | Yes ⑦④ | Yes ⑦④ | Yes ⑦④ | Yes ⑦④ | Yes ⑦④ | Yes ⑦④ | |
| Page of characteristics and outline dimensions | | | 7-154 | 7-154 | 7-156 | 7-156 | 7-158 | 7-158 | 7-160 | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.


● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire. ⑱ : Do not apply to circuits where overcurrent flows in the neutral wire.


⑤③ : For the extension bars, please place the order separately in parts.

⑦④ : Since the overvoltage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

Remarks: See pages 3-25 and 3-26 for connection details.


| Category | | | Compatibility circuit breaker | | | Line side Plug-in | | Plug-in | | TB mini size | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 50 | | | 50 | | 50 | | 50 | 50 |
| Type | | | TB-5S | | | TB-5P | | TB-5D | | TB-51C | TB-52C |
| Number of poles | | | 1 | 2 | 3 | 2 | | 2 | | 2 ㊸ | 2 |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | 10 | 30 | | 10 | 30 | 10 | 30 | 15 | 15 |
| Calibrated at 40°C | | | 15 | 40 | | 15 | 40 | 15 | 40 | 20 | 20 |
| 45°C | | | 20 | 50 | | 20 | 50 | 20 | 50 | 30 | 30 |
| Rated operational voltage V | AC | | 240 | 415 | 415 | 415 | | 250 | | 100 | 240 |
| | DC | | 125 | 125 | — | 125 | | 125 | | — | — |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 415 V | — | 2.5 | 2.5 | 2.5 | | — | | — | — |
| $I_{cu}$ (sym) | | 240 V | 2.5 | 5 | — | 5 | | — | | — | 2.5 |
| | | 200 V | 2.5 | 5 | 5 | 5 | | — | | — | 2.5 |
| | | 100 / 200 V | — | — | — | — | | — | | — | 5 |
| | | 100 V | 5 | — | — | — | | — | | 5 | — |
| | DC | 110 V | 1 | 5 | — | 5 | | — | | — | — |
| NK | AC | 250 V | — | 5 ㊹ | — | 5 ㊹ | | 5 ㊹ | | — | — |
| (sym) | | 125 V | — | 42 | — | 42 | | 42 | | — | — |
| | DC | 125 V | — | 5 | — | 5 | | 5 | | — | — |
| ■External dimensions, mm | | | | | | | | | | | |
|  | | a | 25 | 50 | 75 | 50 | | 50 | | 25 | 25 |
| | | b | 95 | | | 74.5 | | 74.5 | | 95 | 95 |
| | | c | 60 | | | 60 | | 60 | | 60 | 60 |
| | | d | 77 | 79 | | 79 | | 79 | | 77 | 77 |
| Weight kg | | | 0.16 | 0.34 | 0.5 | 0.28 | | 0.28 | | 0.15 | 0.16 |
| ■Connections | | | | | | | | | | | |
| Front-connected type on both line side and load side | | | ● ㊺ | | | — | | — | | ● ㊽ | ● ㊽ |
| Line side plug-in type, load side front-connected type | | | — | | | ● | | — | | — | — |
| Plug-in type on both line side and load side | | | — | | | — | | ● | | — | — |
| ■Mountings (optional) | | | | | | | | | | | |
| Clip-in chassis | | | ● | | | — | | — | | ● | ● |
| Mounting base for single-row installation | | | — | | | ● ㊼ | | ● ㊼ | | — | — |
| Mounting base for branched-into-dual-rows | | | — | | | ● ㊼ | | ● ㊼ | | — | — |
| ■Accessories (optional) | | Symbol | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | — | | | — | | — | | ● ㊽ | ● ㊽ |
| | Alarm switch | A L | — | | | — | | — | | ● ㊽ | ● ㊽ |
| Externally mounted | Toggle holder | H H | ● | | | ● | | ● | | ● | ● |
| | Toggle lock | H L | ● | — | | — | | — | | — | — |
| | Toggle cap | H C | ● | — | | — | | — | | ● | ● |
| CE marking | | | Non | | | Non | | Non | | Non | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic | | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | Thermal-magnetic |
| Colour of cover | | | Black | | | Black | | Black | | Black | Black |
| Reverse connection | | | Yes | | | Yes | | Yes | | Yes | Yes |
| Page of characteristics and outline dimensions | | | 7-162 | | | 7-164 | | 7-166 | | 7-168 | 7-168 |

**Notes:**
● : "yes" or "available". — : "no" or "not available".
㊸ : This is 2-pole 1-element. ㊹ : 2.5kA for 10A. ㊺ : A wire clamping terminal is provided. ㊼ : Specify the branch bars when ordering.
㊽ : Distribution board branch conductors and busbar conductor supports are available. (Optional)
㊽ : The auxiliary switch and alarm switch cannot be applied at the same time.

| Frame size (A) | | | 30 | 50 | 60 | 100 | 125 | 225 | 250 | 400 |
|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | PZE30-NF | PZE50-NF | PZE60-NF | PZE125-NF | | ZE250-SF | | ZE400-NF |
| Number of poles | | | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| Phase and wires | 1ø2W | ⑭ | ● | ● | ● | ● | ● | ● | ● | ● |
| | 3ø3W, 1ø3W | ⑮ | ● | ● | ● | ● | ● | ● | ● | ● |
| | 3ø4W | | — | — | — | — | — | — | — | — |
| **■Ratings** | | | | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | 6 | 6 | 6 | 6 | 8 | 8 | 8 |
| Rated current, A Calibrated at 40°C | | | 5 20<br>10 30<br>15 | 15 40<br>20 50<br>30 | 60 | 60<br>75<br>100 | 125 | 125 200<br>150 225<br>175 | 250 | 250 400<br>300<br>350 |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common |
| | Operable voltage fluctuation range V | | 80-484 | 80-484 | 80-484 | 80-484 | 80-484 | 80-484 | 80-484 | 80～484 |
| | Time delay tripping type | | — | — | — | — | — | 100-440 common | 100-440 common | 100-440 common |
| | Operable voltage fluctuation range V | | — | — | — | — | — | 80-484 | 80-484 | 80～484 |
| Rated sensitivity current mA | Instantaneous tripping type | | 15<br>30<br>— | 15 ㉝<br>30<br>100/200/500 selectable ㊶ | 30<br>100/200/500 selectable<br>— | 30<br>100/200/500 selectable<br>— | 30<br>100/200/500 selectable<br>— | 30<br>100/200/500 selectable<br>— | 30<br>100/200/500 selectable<br>— | 30<br>100/200/500 selectable<br>— |
| | Max. operating time sec | | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 |
| | Time delay tripping type | | — | — | — | — | — | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable |
| | Max. operating time sec | | — | — | — | — | — | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable |
| | Non-operating time sec | | — | — | — | — | — | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more |
| **■Rated breaking capacity, kA** | | | | | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | AC | 440V | 1.5 | 2.5 | 2.5 | 10 | 10 | 15 | 15 | 22 |
| | | 415V | 1.5 | 2.5 | 2.5 | 10 | 10 | 25 | 25 | 25 |
| | | 240V | 2.5 | 7.5 | 7.5 | 30 | 30 | 35 | 35 | 35 |
| | | 100V | 2.5 | 7.5 | 7.5 | 30 | 30 | 35 | 35 | 35 |
| **■External dimensions, mm** | | | | | | | | | | |
|  | | a | 75 | 75 | 75 | 75 | 75 | 105 | 105 | 140 |
| | | b | 130 | 130 | 130 | 130 | 130 | 165 | 165 | 260 |
| | | c | 68 | 68 | 68 | 68 | 68 | 68 | 68 | 103 |
| | | d | 90 | 90 | 90 | 90 | 90 | 95 | 95 | 145 |
| Weight (◉ marked standard type) kg | | | 0.8 | 0.8 | 0.9 | 0.9 | 0.9 | 1.7 | 1.7 | 5.2 |
| **■Connections and Mountings** | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ ㊺ | ◉ | ◉ | ◉ | ◉ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — | — | — | — | — |
| | Standard (PMC) | | — | — | — | — | — | — | — | — |
| For distribution boards (PMD) | | | — | — | — | — | — | — | — | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | | | — | — | — | — | — | — | — | — |
| TemPlug70 (PG) | | | — | — | — | — | — | ○ | ○ | ○ |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | — | — | — |
| **■Accessories (optional)** | | Symbol | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | ● | ● | ● | ● | ● | ● |
| | Alarm switch | A L | ● | ● | ● | ● | ● | ● | ● | ● |
| | Shunt trips | S H | — | — | — | — | — | — | — | — |
| | Undervoltage trips | U V | — | — | — | — | — | — | — | — |
| | Test lead | T L | — | — | — | — | — | ● | ● | ● |
| | Leakage alarm switch | L A | — | — | — | — | — | — | — | — |
| | Megger test switch | M G | — | — | — | — | — | ● | ● | ● |
| Externally mounted | Motor operator | M C | — | — | — | — | — | ● | ● | ● |
| | External operating handle: Breaker-mounted | H B | ● | ● | ● | ● | ● | ● | ● | ● |
| | External operating handle: Door-mounted (variable depth) | H P | ● | ● | ● | ● | ● | ● | ● | ● |
| | Toggle extension | H A | — | — | — | — | — | — | — | ● |
| | Mechanical interlock: Slide type | M S | ● | ● | ● | ● | ● | ● | ● | ● |
| | Mechanical interlock: Link type | M L | — | — | — | — | — | — | — | — |
| | Mechanical interlock: Wire type | M W | — | — | — | — | — | — | — | — |
| | Toggle holder | H H | ● | ● | ● | ● | ● | ● | ● | |
| | Toggle lock | H L | ● | ● | ● | ● | ● | ● | ● | ● |
| | Terminal cover: For front-connected | C F | ● | ● | ● | ● | ● | ● | ● | ● |
| | Terminal cover: For rear-connected and plug-in | C R | ● | ● | ● | ● | ● | ● | ● | ● |
| | Terminal block for lead | T F | ● | ● | ● | ● | ● | ● | ● | ● |
| | Door flange | D F | — | — | — | — | — | — | — | — |
| CE marking | | | Non | Non | Non | Non | Non | Non | Non | Non |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic |
| Overcurrent trip mechanism | | | Thermal-magnetic ⑦ | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Yes |
| Reverse connection | | | Non | Non | Non | Non | Non | Yes | Yes | Yes ⑫ |
| Page of characteristics and outline dimensions | | | 7-174 | 7-174 | 7-178 | 7-178 | 7-178 | 7-186 | 7-186 | 7-192 |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering. ● : "yes" or "available".
— : "no" or "not available". ⑦ : Hydraulic-magnetic type for below 10A rating. ⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.
⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉝ : Applicable to 15A to 30A.
㊲ : If the megger test switch is mounted, the auxiliary switch cannot be mounted. ㊶ : Not applicable to 20 A or less. ㊺ : A wire clamping terminal is provided.
㊾ : If an earth leakage alarm switch is mounted, the megger test switch cannot be mounted. ㊸ : For the extension bars, please place the order separately in parts.
Remarks: The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 30 | 50 | 50 | 60 | 100 | 125 | 225 | 250 | |
| Type | | | PZS30-NF | PZS50-NF | ZS50-SF | PZS60-NF | ZS125-SF | | ZS250-SF | | |
| Number of poles | | | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 | |
| Phase and wires | 1ø2W | ⑭ | ● | ● | ● | ● | ● | ● | ● | ● | |
| | 3ø3W, 1ø3W | ⑮ | ● | ● | ● | ● | ● | ● | ● | ● | |
| | 3ø4W | | — | — | — | — | — | — | — | — | |
| **■Ratings** | | | | | | | | | | | |
| Rated impulse withstand voltage ($U_{imp}$) kV | | | 6 | 6 | 8 | 6 | 8 | 8 | 8 | 8 | |
| Rated current, A | | | 5 20 | 15 40 | 15 40 | 60 | 15 40 75 | 125 | 125 200 | 250 | |
| Calibrated at 40°C | | | 10 30 | 20 50 | 20 50 | | 20 50 100 | | 150 225 | | |
| | | | 15 | 30 | 30 | | 30 60 | | 175 | | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | |
| | Operable voltage fluctuation range V | | 80-484 | 80-484 | 80～484 | 80-484 | 80～484 | 80～484 | 80～484 | 80～484 | |
| | Time delay tripping type | | — | — | 100-440 common | — | 100-440 common | 100-440 common | 100-440 common | 100-440 common | |
| | Operable voltage fluctuation range V | | — | — | 80～484 | — | 80～484 | 80～484 | 80～484 | 80～484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 15 | 15 ㉝ | 30 | 30 | 30 | 30 | 30 | 30 | |
| | | | 30 | 30 | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | |
| | | | 100/200/500 selectable ㊶ | 100/200/500 selectable ㊶ | — | — | — | — | — | — | |
| | Max. operating time sec | | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | |
| | Time delay tripping type | | — | — | 100/200/500 selectable | — | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | |
| | Max. operating time sec | | — | — | 0.45/1.0/2.0 selectable | — | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | — | — | 0.1/0.5/1.2 or more | — | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | |
| **■Rated breaking capacity, kA** | | | | | | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | AC | 440V | 2.5 | 7.5 | 25 | 10 | 25 | 25 | 30 | 30 | |
| | | 415V | 2.5 | 7.5 | 30 | 10 | 30 | 30 | 40 | 40 | |
| | | 240V | 7.5 | 15 | 50 | 30 | 50 | 50 | 85 | 85 | |
| | | 100V | 7.5 | 15 | 50 | 30 | 50 | 50 | 85 | 85 | |
| **■External dimensions, mm** | | | | | | | | | | | |
|  | | a | 75 | 75 | 75 | 75 | 75 | 75 | 105 | 105 | |
| | | b | 130 | 130 | 130 | 130 | 130 | 130 | 165 | 165 | |
| | | c | 68 | 68 | 68 | 68 | 68 | 68 | 68 | 68 | |
| | | d | 90 | 90 | 95 | 90 | 95 | 95 | 95 | 95 | |
| Weight (◉ marked standard type) kg | | | 0.8 | 0.8 | 0.95 | 0.9 | 0.95 | 0.95 | 1.7 | 1.7 | |
| **■Connections and Mountings** | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ | ◉ | ◉ ④ | ◉ | ◉ | ◉ | |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — | — | — | — | — | |
| | Standard (PMC) | | — | — | — | — | — | — | — | — | |
| For distribution boards (PMD) | | | — | — | — | — | — | — | — | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| Draw-out type (DR) | | | — | — | — | — | — | — | — | — | |
| TemPlug70 (PG) | | | — | — | ○ | — | ○ | ○ | ○ | ○ | |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | — | — | |
| **■Accessories (optional)** | | Symbol | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Alarm switch | A L | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Shunt trips | S H | — | — | — | — | — | — | — | — | |
| | Undervoltage trips | U V | — | — | — | — | — | — | — | — | |
| | Test lead | T L | — | — | ● | — | ● | ● | ● | ● | |
| | Leakage alarm switch | L A | — | — | — | — | — | — | — | — | |
| | Megger test switch | M G | — | — | ● | — | ● | ● | ● | ● | |
| Externally mounted | Motor operator | M C | — | — | — | — | — | — | ● | ● | |
| | External operating handle: Breaker-mounted | H B | ● | ● | ● | ● | ● | ● | ● | ● | |
| | External operating handle: Door-mounted (variable depth) | H P | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Toggle extension | H A | — | — | — | — | — | — | — | — | |
| | Mechanical interlock: Slide type | M S | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Mechanical interlock: Link type | M L | — | — | — | — | — | — | — | — | |
| | Mechanical interlock: Wire type | M W | — | — | — | — | — | — | — | — | |
| | Toggle holder | H H | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Toggle lock | H L | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Terminal cover: For front-connected | C F | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Terminal cover: For rear-connected and plug-in | C R | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Terminal block for lead | T F | ● | ● | ● | ● | ● | ● | ● | ● | |
| | Door flange | D F | — | — | — | — | — | — | — | — | |
| CE marking | | | Non | Non | Non | Non | Non | Non | Non | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic ⑦ | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | |
| Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | Yes | Yes | Yes | Yes | |
| Reverse connection | | | Non | Non | Yes ⑫ | Non | Yes ⑫ | Yes ⑫ | Yes | Yes | |
| Page of characteristics and outline dimensions | | | 7-174 | 7-174 | 7-176 | 7-178 | 7-180 | 7-180 | 7-186 | 7-186 | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". ④ : 50A or less is the M5 wire clamping terminal.

⑦ : Hydraulic-magnetic type for below 10A rating. ⑪ : Please order the DIN rail adapter separately. See page 6-152.

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.


⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.

㉝ : Applicable to 15A to 30A. ㊶ : Not applicable to 20 A or less.

㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts. ⑫ : There are some limitations. See page 5-23 for details.


Remarks: The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

# 15 Standard series (Harmonics/surge with countermeasure)

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | | 600 | 630 | 600 | 630 | 800 | 800 | |
| Type | | | ZS400-NF | | ZS630-CF | | ZS630-NF | | ZS800-CF | ZS800-NF | |
| Number of poles | | | 3 | 4 | 3 | 3 | 3 | 3 | 3 | 3 | |
| Phase and wires | 1ø2W | ⑭ | ● | — | ● | ● | ● | ● | ● | ● | |
| | 3ø3W, 1ø3W | ⑮ | ● | — | ● | ● | ● | ● | ● | ● | |
| | 3ø4W | | — | ● | — | — | — | — | — | — | |
| **■Ratings** | | | | | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | 8 | 8 | 8 | 8 | 8 | |
| Rated current, A | | | 250 | 400 | 500 | 630 | 500 | 630 | 700 | 700 | |
| Calibrated at 40°C | | | 300 | | 600 | | 600 | | 800 | 800 | |
| | | | 350 | | | | | | | | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | |
| | Operable voltage fluctuation range V | | 80～484 | | 80～484 | 80～484 | 80～484 | 80～484 | 80～484 | 80～484 | |
| | Time delay tripping type | | 100-440 common | | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | |
| | Operable voltage fluctuation range V | | 80～484 | | 80～484 | 80～484 | 80～484 | 80～484 | 80～484 | 80～484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | | 30 | 30 | 30 | 30 | 30 | 30 | |
| | | | 100/200/500 selectable | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | |
| | | | — | | — | — | — | — | — | — | |
| | Max. operating time sec | | 0.1 | | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | |
| **■Rated breaking capacity, kA** | | | | | | | | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 45 | | 30 | 30 | 45 | 45 | 30 | 45 | |
| $I_{cu}$(sym) | | 415V | 50 | | 36 | 36 | 50 | 50 | 36 | 50 | |
| | | 240V | 85 | | 50 | 50 | 85 | 85 | 50 | 85 | |
| | | 100V | 85 | | 50 | 50 | 85 | 85 | 50 | 85 | |
| **■External dimensions, mm** | | | | | | | | | | | |
|  | | a | 140 | 185 | 210 | 210 | 210 | 210 | 210 | 210 | |
| | | b | 260 | | 273 | 273 | 273 | 273 | 273 | 273 | |
| | | c | 103 | | 103 | 103 | 103 | 103 | 103 | 103 | |
| | | d | 145 | | 145 | 145 | 145 | 145 | 145 | 145 | |
| Weight (◉ marked standard type) kg | | | 5.2 | 6.6 | 10.0 | 10.0 | 10.0 | 10.0 | 11.0 | 11.0 | |
| **■Connections and Mountings** | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | — | — | — | — | — | — | |
| | With extension bars | | ○ | | ◉ | ◉ | ◉ | ◉ | ◉ | ◉ | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | ○ | ○ | ○ | ○ | ○ | |
| Plug-in (PM) | For switchboards High-performance (PMB) | | — | | — | — | — | — | — | — | |
| | Standard (PMC) | | — | | — | — | — | — | — | — | |
| | For distribution boards (PMD) | | — | | — | — | — | — | — | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | ○ | ○ | ○ | ○ | ○ | |
| Draw-out type (DR) | | | — | | — | — | — | — | — | — | |
| TemPlug70 (PG) | | | ○ | — | ○ | ○ | ○ | ○ | — | — | |
| DIN rail mount | | | — | | — | — | — | — | — | — | |
| **■Accessories (optional)** | | **Symbol** | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | | ● | ● | ● | ● | ● | ● | |
| | Alarm switch | A L | ● | | ● | ● | ● | ● | ● | ● | |
| | Shunt trips | S H | — | | — | — | — | — | — | — | |
| | Undervoltage trips | U V | — | | — | — | — | — | — | — | |
| | Test lead | T L | ● | | ● | ● | ● | ● | ● | ● | |
| | Leakage alarm switch | L A | — | | — | — | — | — | — | — | |
| | Megger test switch | M G | ● | | ● | ● | ● | ● | ● | ● | |
| Externally mounted | Motor operator | M C | ● | | ● | ● | ● | ● | ● | ● | |
| | External operating handle Breaker-mounted | H B | ● | | ● | ● | ● | ● | ● | ● | |
| | Door-mounted (variable depth) | H P | ● | | ● | ● | ● | ● | ● | ● | |
| | Toggle extension | H A | ● | | ● | ● | ● | ● | ● | ● | |
| | Mechanical interlock Slide type | M S | ● | | ● | ● | ● | ● | ● | ● | |
| | Link type | M L | — | | — | — | — | — | — | — | |
| | Wire type | M W | — | | — | — | — | — | — | — | |
| | Toggle holder | H H | ● | | ● | ● | ● | ● | ● | ● | |
| | Toggle lock | H L | | | | | | | | | |
| | Terminal cover For front-connected | C F | ● | | ● | ● | ● | ● | ● | ● | |
| | For rear-connected and plug-in | C R | ● | | ● | ● | ● | ● | ● | ● | |
| | Terminal block for lead | T F | ● | | ● | ● | ● | ● | ● | ● | |
| | Door flange | D F | — | | — | — | — | — | — | — | |
| CE marking | | | Non | | Non | Non | Non | Non | Non | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | |
| Earth leakage indication | | | Mechanical button | | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | |
| Colour of cover | | | Grey Blue | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | |
| Suitability for isolation | | | Yes | | Yes | Yes | Yes | Yes | Yes | Yes | |
| Reverse connection | | | Yes ⑫ | | Yes ⑫ | Yes ⑫ | Yes ⑫ | Yes ⑫ | Yes ⑫ | Yes ⑫ | |
| Page of characteristics and outline dimensions | | | 7-192 | | 7-194 | 7-194 | 7-194 | 7-194 | 7-196 | 7-196 | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available".
⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.
⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ⑫ : There are some limitations. See page 5-23 for details.
Remarks: The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

# 16 High-fault level series (Harmonics/surge with countermeasure)

| | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | | 125 | | 225 | | 250 | | 400 | | | | | | | | | | |
| Type | | | ZS100-GF | | ZS125-GF | | ZS225-GF | | ZS250-GF | | ZS400-GF | | | | | | | | | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | | | | | | | | | |
| Phase and wires | 1ø2W | ⑭ | ● | — | ● | — | ● | — | ● | — | ● | — | | | | | | | | | |
| | 3ø3W, 1ø3W | ⑮ | ● | — | ● | — | ● | — | ● | — | ● | — | | | | | | | | | |
| | 3ø4W | | — | ● | — | ● | — | ● | — | ● | — | ● | | | | | | | | | |
| **■Ratings** | | | | | | | | | | | | | | | | | | | | | |
| Rated impulse withstand voltage ($U_{imp}$) kV | | | 8 | | 8 | | 8 | | 8 | | 8 | | | | | | | | | | |
| Rated current, A Calibrated at 40°C | | | 15 | 50 | 125 | | 125 | 225 | 250 | | 250 | | | | | | | | | | |
| | | | 20 | 60 | | | 150 | | | | 300 | | | | | | | | | | |
| | | | 30 | 75 | | | 175 | | | | 350 | | | | | | | | | | |
| Rated operational voltage AC V | Instantaneous tripping type | | 40 | 100 | | | 200 | | | | 400 | | | | | | | | | | |
| | Operable voltage fluctuation range V | | 100-440 common | | 100-440 common | | 100-440 common | | 100-440 common | | 100-440 common | | | | | | | | | | |
| | Time delay tripping type | | 80～484 | | 80～484 | | 80～484 | | 80～484 | | 80～484 | | | | | | | | | | |
| | Operable voltage fluctuation range V | | 100-440 common | | 100-440 common | | 100-440 common | | 100-440 common | | 100-440 common | | | | | | | | | | |
| Rated sensitivity current mA | Instantaneous tripping type | | 80～484 | | 80～484 | | 80～484 | | 80～484 | | 80～484 | | | | | | | | | | |
| | | | 30 | | 30 | | 30 | | 30 | | 30 | | | | | | | | | | |
| | | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | | | | | | | | | |
| | Max. operating time sec | | 0.1 | | 0.1 | | 0.1 | | 0.1 | | 0.1 | | | | | | | | | | |
| | Time delay tripping type | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | | | | | | | | | | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | | 0.45/1.0/2.0 selectable | | 0.45/1.0/2.0 selectable | | 0.45/1.0/2.0 selectable | | 0.45/1.0/2.0 selectable | | | | | | | | | | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | | 0.1/0.5/1.2 or more | | 0.1/0.5/1.2 or more | | 0.1/0.5/1.2 or more | | 0.1/0.5/1.2 or more | | | | | | | | | | |
| **■Rated breaking capacity, kA** | | | | | | | | | | | | | | | | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | AC | 440V | 50 | | 50 | | 50 | | 50 | | 65 | | | | | | | | | | |
| | | 415V | 65 | | 65 | | 65 | | 65 | | 70 | | | | | | | | | | |
| | | 240V | 85 | | 85 | | 85 | | 85 | | 100 | | | | | | | | | | |
| | | 100V | 85 | | 85 | | 85 | | 85 | | 100 | | | | | | | | | | |
| **■External dimensions, mm** | | | | | | | | | | | | | | | | | | | | | |
|  | | a | 90 | 120 | 90 | 120 | 105 | 140 | 105 | 140 | 140 | 185 | | | | | | | | | |
| | | b | 155 | | 155 | | 165 | | 165 | | 260 | | | | | | | | | | |
| | | c | 68 | | 68 | | 68 | | 68 | | 103 | | | | | | | | | | |
| | | d | 92 | | 92 | | 92 | | 92 | | 145 | | | | | | | | | | |
| Weight (◉ marked standard type) kg | | | 1.3 | 1.7 | 1.3 | 1.7 | 1.7 | 2.1 | 1.7 | 2.1 | 5.2 | 6.6 | | | | | | | | | |
| **■Connections and Mountings** | | | | | | | | | | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | | ◉ | | ◉ | | ◉ | | | | | | | | | | |
| | With extension bars | | ○ ⑬ | | ○ ⑬ | | ○ ⑬ | | ○ ⑬ | | ○ | | | | | | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | | | | | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | — | | — | | — | | | | | | | | | | |
| | Standard (PMC) | | — | | — | | — | | — | | — | | | | | | | | | | |
| For distribution boards (PMD) | | | — | | — | | — | | — | | — | | | | | | | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | ○ | | ○ | | | | | | | | | | |
| Draw-out type (DR) | | | — | | — | | — | | — | | — | | | | | | | | | | |
| TemPlug70 (PG) | | | ○ | — | ○ | — | ○ | — | ○ | — | ○ | — | | | | | | | | | |
| DIN rail mount | | | ○ ⑪ | | ○ ⑪ | | — | | — | | — | | | | | | | | | | |
| **■Accessories (optional)** | | Symbol | | | | | | | | | | | | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Alarm switch | A L | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Shunt trips | S H | — | | — | | — | | — | | — | | | | | | | | | | |
| | Undervoltage trips | U V | — | | — | | — | | — | | — | | | | | | | | | | |
| | Test lead | T L | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Leakage alarm switch | L A | — | | — | | — | | — | | — | | | | | | | | | | |
| | Megger test switch | M G | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| Externally mounted | Motor operator | M C | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | External operating handle — Breaker-mounted | H B | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | External operating handle — Door-mounted (variable depth) | H P | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Toggle extension | H A | — | | — | | — | | — | | ● | | | | | | | | | | |
| | Mechanical interlock — Slide type | M S | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Mechanical interlock — Link type | M L | — | | — | | — | | — | | — | | | | | | | | | | |
| | Mechanical interlock — Wire type | M W | — | | — | | — | | — | | — | | | | | | | | | | |
| | Toggle holder | H H | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Toggle lock | H L | ● | | ● | | ● | | ● | | — | | | | | | | | | | |
| | Terminal cover — For front-connected | C F | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Terminal cover — For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Terminal block for lead | T F | ● | | ● | | ● | | ● | | ● | | | | | | | | | | |
| | Door flange | D F | — | | — | | — | | — | | — | | | | | | | | | | |
| CE marking | | | Non | | Non | | Non | | Non | | Non | | | | | | | | | | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | | Electronic | | Electronic | | Electronic | | Electronic | | | | | | | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic (adjustable) | | | | | | | | | | |
| Earth leakage indication | | | Mechanical button | | Mechanical button | | Mechanical button | | Mechanical button | | Mechanical button | | | | | | | | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | | | | | | | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | | | | | | | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | Yes | | | | | | | | | | |
| Reverse connection | | | Yes ⑫ | | Yes ⑫ | | Yes ⑫ | | Yes ⑫ | | Non | | | | | | | | | | |
| Page of characteristics and outline dimensions | | | 7-182 | | 7-184 | | 7-188 | | 7-190 | | 7-192 | | | | | | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering. ● : "yes" or "available".

— : "no" or "not available". ⑪ : Please order the DIN rail adapter separately. See page 6-152.

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.


⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.

⑬ : For the extension bars, please place the order separately in parts.

⑫ : There are some limitations. See page 5-23 for details.

Remarks: The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

# 17 Earth Leakage Circuit Breakers for motor protection (Harmonics/surge with countermeasure)


| Frame size (A) | 30 | 30 | 50 | 50 | 100 | 100 | 225 |
|---|---|---|---|---|---|---|---|
| Type | ZE30-NM | ZS30-NM | ZE50-NM | ZS50-CM | ZE100-NM | ZS100-SM | ZS250-SM |
| Number of poles | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| **■Ratings** | | | | | | | |
| Rated capacity of motor and rated current of circuit breaker Calibrated at 40°C | (A) (kW) 200V 415V<br>1.4 0.2 0.4<br>2.6 0.4 —<br>4 0.75 1.5<br>5 1 2.2<br>8 1.5 3.7<br>10 2.2 —<br>16 3.7 7.5<br>24 5.5 11<br>32 7.5 15 | (A) (kW) 200V 415V<br>0.7 — 0.2<br>1.4 0.2 0.4<br>2 — 0.75<br>2.6 0.4 —<br>4 0.75 1.5<br>5 1 2.2<br>8 1.5 3.7<br>10 2.2 —<br>12 — 5.5<br>16 3.7 7.5<br>24 5.5 11<br>32 7.5 15 | (A) (kW) 200V 415V<br>45 11 22 | (A) (kW) 200V 415V<br>0.7 — 0.2<br>1.4 0.2 0.4<br>2 — 0.75<br>2.6 0.4 —<br>4 0.75 1.5<br>5 1 2.2<br>8 1.5 3.7<br>(A) (kW) 200V 415V<br>10 2.2 —<br>12 — 5.5<br>16 3.7 7.5<br>24 5.5 11<br>32 7.5 15<br>40 — 18.5<br>45 11 22 | (A) (kW) 200V 415V<br>60 15 30<br>75 18.5 37<br>90 22 45 | (A) (kW) 200V 415V<br>16 3.7 7.5<br>24 5.5 11<br>32 7.5 15<br>40 — 18.5<br>45 11 22<br>60 15 30<br>75 18.5 37<br>90 22 45<br>100 — 55 | (A) (kW) 200V 415V<br>125 30 —<br>150 37 75<br>175 45 90<br>225 55 110 |
| Remarks: Select according to the full load current of the motor. | | | | | | | |
| Rated impulse withstand voltage $(U_{imp})$ kV | 6 | 6 | 6 | 6 | 6 | 8 | 8 |
| Rated operational voltage AC V — Instantaneous tripping type | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common | 100-440 common |
| Rated operational voltage AC V — Operable voltage fluctuation range V | 80～484 | 80～484 | 80～484 | 80～484 | 80～484 | 80～484 | 80～484 |
| Rated sensitivity current mA — Instantaneous tripping type | 30 | 30 | 30 | 30 | 30 | 30 | 30 |
| Rated sensitivity current mA | 100 | 100/200/500 selectable | 100/200 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable |
| Max. operating time sec | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 |
| **■Rated breaking capacity, kA** | | | | | | | |
| JIS C 8201-2-2 Ann.2 AC 440V | 1.5 | 2.5 | 2.5 | 7.5 | 10 | 25 | 30 |
| $I_{cu}$(sym) 415V | 1.5 | 2.5 | 2.5 | 7.5 | 10 | 30 | 40 |
| 240V | 2.5 ㊾ | 5 ㊾ | 5 ㊾ | 10 ㊾ | 25 ㊾ | 50 | 85 |
| 100V | 5 | 5 | 5 | 10 | 25 | 50 | 85 |
| **■External dimensions, mm** | | | | | | | |
|  a | 75 | 75 | 75 | 75 | 75 | 75 | 105 |
| b | 100 | 100 | 100 | 100 | 100 | 130 | 165 |
| c | 60 | 60 | 60 | 60 | 60 | 68 | 68 |
| d | 84 | 84 | 84 | 84 | 84 | 95 | 95 |
| Weight (◉ marked standard type) kg | 0.5 | 0.5 | 0.5 | 0.5 | 0.5 | 0.95 | 1.7 |
| **■Connections and Mountings** | | | | | | | |
| Front-connected (FC) — Terminal screws | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ | ◉ | ◉ ④ | ◉ |
| Front-connected (FC) — With extension bars | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) — Flat bar studs | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards — High-performance (PMB) | — | — | — | — | — | — | — |
| Plug-in (PM) For switchboards — Standard (PMC) | — | — | — | — | — | — | — |
| Plug-in (PM) For distribution boards (PMD) | — | — | — | — | — | — | — |
| Flush-mounted (FP) — With flat bar studs | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | — | — | — | — | — | — | — |
| TemPlug70 (PG) | — | — | — | — | — | ○ | ○ |
| DIN rail mount | ◉ | ◉ | ◉ | ◉ | ◉ | ○ ⑪ | — |
| **■Accessories (optional)** Symbol | | | | | | | |
| Internally mounted — Auxiliary switch AX | ● | ● | ● | ● | ● | ● | ● |
| Internally mounted — Alarm switch AL | ● | ● | ● | ● | ● | ● | ● |
| Internally mounted — Shunt trips SH | ● ㊽ | ● ㊽ | ● ㊽ | ● ㊽ | ● ㊽ | — | — |
| Internally mounted — Undervoltage trips UV | ● ㊽ | ● ㊽ | ● ㊽ | ● ㊽ | ● ㊽ | — | — |
| Internally mounted — Test lead TL | ● | ● | ● | ● | ● | ● | ● |
| Internally mounted — Megger test switch MG | ● | ● | ● | ● | ● | ● | ● |
| Externally mounted — Motor operator MC | — | — | — | — | — | — | ● |
| Externally mounted — External operating handle — Breaker-mounted HB | △ | △ | △ | △ | △ | ● | ● |
| Externally mounted — External operating handle — Door-mounted (variable depth) HP | △ | △ | △ | △ | △ | ● | ● |
| Externally mounted — Toggle extension HA | — | — | — | — | — | — | — |
| Externally mounted — Mechanical interlock — Slide type MS | ● | ● | ● | ● | ● | ● | ● |
| Externally mounted — Mechanical interlock — Rear-connected type MB | — | — | — | — | — | — | — |
| Externally mounted — Mechanical interlock — Link type ML | — | — | — | — | — | — | — |
| Externally mounted — Mechanical interlock — Wire type MW | — | — | — | — | — | — | — |
| Externally mounted — Toggle holder HH | — | — | — | — | — | ● | ● |
| Externally mounted — Toggle lock HL | ● | ● | ● | ● | ● | ● | ● |
| Externally mounted — Terminal cover — For front-connected CF | ● | ● | ● | ● | ● | ● | ● |
| Externally mounted — Terminal cover — For rear-connected and plug-in CR | ● ② | ● ② | ● ② | ● ② | ● ② | ● | ● |
| Externally mounted — Terminal block for lead TF | ● | ● | ● | ● | ● | ● | ● |
| Externally mounted — Door flange DF | — | — | — | — | — | — | — |
| CE marking | Non | Non | Non | Non | Non | Non | Non |
| Earth leakage trip mechanism (Current operation type) | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic |
| Overcurrent trip mechanism | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Thermal-magnetic | Thermal-magnetic |
| Earth leakage indication | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | Light Grey | Light Grey | Light Grey | Light Grey | Light Grey | Grey Blue | Grey Blue |
| Trip button (Colour) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | Yes | Yes | Yes | Yes | Yes | Yes | Yes |
| Reverse connection | Non | Non | Non | Non | Non | Yes ㉒ | Yes |
| Page of characteristics and outline dimensions | 7-198 | 7-198 | 7-198 | 7-198 | 7-200 | 7-202 | 7-204 |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".
△ : Custom-built product. Please contact us for details. ② : Supplied as standard. ④ : 50A or less is the M5 wire clamping terminal.
⑪ : Please order the DIN rail adapter separately. See page 6-152. ㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts.
㊽ : It is mounted on the side of the circuit breaker. In the case of Flush-mounted type (FP), it cannot be installed. ㊾ : This is the value for 230V AC.
㉒ : There are some limitations. See page 5-23 for details.
Remarks: The rated sensitivity current is set to 100mA before delivery.

# Earth Leakage Circuit Breakers

## 18 Single phase 3-wire earth leakage circuit breaker with neutral phase open protection (Harmonics/surge with countermeasure)

| Frame size (A) | | | 50 | 100 | 125 | 100 | 125 | 225 | 250 |
|---|---|---|---|---|---|---|---|---|---|
| Type | | | PZE50-NFN | PZE125-NFN | | ZNS125-SF | | ZNE250-SF | |
| Number of poles / Elements | | | 3P3E ㊵ | 3P3E ㊵ | 3P3E ㊵ | 3P3E ㊵ | 3P3E ㊵ | 3P3E ㊵ | 3P3E ㊵ |
| Phase and wires | | | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W | 1ø3W |
| **■Ratings** | | | | | | | | | |
| Rated current, A | | | 15 40 | 60 | 125 | 15 40 75 | 125 | 125 225 | 250 |
| Calibrated at 40°C | | | 20 50 | 75 | | 20 50 100 | | 150 | |
| | | | 30 | 100 | | 30 60 | | 175 | |
| | | | | | | | | 200 | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 | 100/200 |
| Rated impulse withstand voltage ($U_{imp}$) kV | | | 6 | 6 | 6 | 8 | 8 | 8 | 8 |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | 30 | 30 | 30 | 30 | 30 | 30 |
| | | | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable |
| | | Max. operating time sec | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 |
| | Time delay tripping type | | — | — | — | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable |
| | | Max. operating time sec | — | — | — | 0.45 | 0.45 | 0.45 | 0.45 |
| | | Non-operating time sec | — | — | — | 0.1 | 0.1 | 0.1 | 0.1 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | 135 | 135 | 135 | 135 | 135 |
| | Rated non-operating overvoltage AC V | | 120 | 120 | 120 | 120 | 120 | 120 | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less | 1 or less |
| **■Rated breaking capacity, kA** | | | | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 10 | 25 | 25 | 50 | 50 | 35 | 35 |
| **■External dimensions, mm** | | | | | | | | | |
|  | | a | 75 | 75 | 75 | 75 | 75 | 105 | 105 |
| | | b | 130 | 130 | 130 | 130 | 130 | 165 | 165 |
| | | c | 68 | 68 | 68 | 68 | 68 | 68 | 68 |
| | | d | 90 | 90 | 90 | 95 | 95 | 95 | 95 |
| Weight (◉ marked standard type) kg | | | 0.8 | 0.9 | 0.9 | 0.95 | 0.95 | 1.7 | 1.7 |
| **■Connections and Mountings** | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ | ◉ | ◉ ④ | ◉ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | △ | △ | △ | △ | △ | △ | △ |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ | — | — |
| **■Accessories (optional)** | | Symbol | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | ● | ● | ● | ● | ● |
| | Alarm switch | A L | ● | ● | ● | ● | ● | ● | ● |
| | Shunt trips | S H | — | — | — | — | — | — | — |
| | Undervoltage trips | U V | — | — | — | — | — | — | — |
| | Test lead | T L | — | — | — | ● | ● | ● | ● |
| | Megger test switch | M G | — | — | — | ● | ● | ● | ● |
| Externally mounted | Motor operator | M C | — | — | — | — | — | ● | ● |
| | External operating handle — Breaker-mounted | H B | ● | ● | ● | ● | ● | ● | ● |
| | External operating handle — Door-mounted (variable depth) | H P | ● | ● | ● | ● | ● | ● | ● |
| | Toggle extension | H A | — | — | — | — | — | — | — |
| | Mechanical interlock — Slide type | M S | ● | ● | ● | ● | ● | ● | ● |
| | Mechanical interlock — Link type | M L | — | — | — | — | — | — | — |
| | Mechanical interlock — Wire type | M W | — | — | — | — | — | — | — |
| | Toggle holder | H H | ● | ● | ● | ● | ● | ● | ● |
| | Toggle lock | H L | ● | ● | ● | ● | ● | ● | ● |
| | Terminal cover — For front-connected | C F | ● | ● | ● | ● | ● | ● | ● |
| | Terminal cover — For rear-connected | C R | ● | ● | ● | ● | ● | ● | ● |
| | Terminal block for lead | T F | ● | ● | ● | ● | ● | ● | ● |
| | Door flange | D F | — | — | — | — | — | — | — |
| CE marking | | | Non | Non | Non | Non | Non | Non | Non |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic | Electronic |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Overvoltage / Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | Yes | Yes | Yes |
| Reverse power flow circuit | | | Non | Non | Non | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ |
| Page of characteristics and outline dimensions | | | 7-206 | 7-206 | 7-206 | 7-208 | 7-208 | 7-210 | 7-210 |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

④ : 50A or less is the M5 wire clamping terminal.

⑪ : Please order the DIN rail adapter separately. See page 6-152.

㊵ : They can also be applied to circuits where overcurrent flows in the neutral wire. Can be used as a main circuit breaker for photovoltaic power generation systems. See page 3-27 for details.

㊺ : A wire clamping terminal is provided.


㊸ : For the extension bars, please place the order separately in parts.

㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

Remarks: See pages 3-25 and 3-26 for connection details.

# Earth Leakage Circuit Breakers

## 18 Single phase 3-wire earth leakage circuit breaker with neutral phase open protection (Harmonics/surge with countermeasure)

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 225 | 250 | 400 | 400 | | | | |
| Type | | | ZNS250-SF | | ZNE400-NF | ZNS400-NF | | | | |
| Number of poles / Elements | | | 3P3E ㊵ | 3P3E ㊵ | 3P2E ⑱ | 3P2E ⑱ | | | | |
| Phase and wires | | | 1ø3W | 1ø3W | 1ø3W | 1ø3W | | | | |
| **■Ratings** | | | | | | | | | | |
| Rated current, A | | | 125 225 | 250 | 250 | 250 | | | | |
| Calibrated at 40°C | | | 150 | | 300 | 300 | | | | |
| | | | 175 | | 350 | 350 | | | | |
| | | | 200 | | 400 | 400 | | | | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | 100/200 | 100/200 | | | | |
| Rated impulse withstand voltage [$U_{imp}$] kV | | | 8 | 8 | 8 | 8 | | | | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | 30 | 30 | 30 | | | | |
| | | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | | | | |
| | | Max. operating time sec | 0.1 | 0.1 | 0.1 | 0.1 | | | | |
| | Time delay tripping type | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | | | | |
| | | Max. operating time sec | 0.45 | 0.45 | 0.45 | 0.45 | | | | |
| | | Non-operating time sec | 0.1 | 0.1 | 0.1 | 0.1 | | | | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | 135 | 135 | | | | |
| | Rated non-operating overvoltage AC V | | 120 | 120 | 120 | 120 | | | | |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | 1 or less | 1 or less | | | | |
| **■Rated breaking capacity, kA** | | | | | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 85 | 85 | 35 | 85 | | | | |
| **■External dimensions, mm** | | | | | | | | | | |
|  | | a | 105 | 105 | 140 | 140 | | | | |
| | | b | 165 | 165 | 260 | 260 | | | | |
| | | c | 68 | 68 | 103 | 103 | | | | |
| | | d | 95 | 95 | 145 | 145 | | | | |
| Weight (◉ marked standard type) kg | | | 1.7 | 1.7 | 5.2 | 5.2 | | | | |
| **■Connections and Mountings** | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | ◉ | ◉ | | | | |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ | ○ | | | | |
| Rear-connected (RC) | Flat bar studs | | △ | △ | △ | △ | | | | |
| DIN rail mount | | | — | — | — | — | | | | |
| **■Accessories (optional)** | | Symbol | | | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● | ● | ● | ● | | | | |
| | Alarm switch | A L | ● | ● | ● | ● | | | | |
| | Shunt trips | S H | — | — | — | — | | | | |
| | Undervoltage trips | U V | — | — | — | — | | | | |
| | Test lead | T L | ● | ● | ● | ● | | | | |
| | Megger test switch | M G | ● | ● | ● | ● | | | | |
| Externally mounted | Motor operator | M C | ● | ● | ● | ● | | | | |
| | External operating handle — Breaker-mounted | H B | ● | ● | ● | ● | | | | |
| | External operating handle — Door-mounted (variable depth) | H P | ● | ● | ● | ● | | | | |
| | Toggle extension | H A | — | — | ● | ● | | | | |
| | Mechanical interlock — Slide type | M S | ● | ● | ● | ● | | | | |
| | Mechanical interlock — Link type | M L | — | — | — | — | | | | |
| | Mechanical interlock — Wire type | M W | — | — | — | — | | | | |
| | Toggle holder | H H | ● | ● | ● | ● | | | | |
| | Toggle lock | H L | ● | ● | | | | | | |
| | Terminal cover — For front-connected | C F | ● | ● | ● | ● | | | | |
| | Terminal cover — For rear-connected | C R | ● | ● | ● | ● | | | | |
| | Terminal block for lead | T F | ● | ● | ● | ● | | | | |
| | Door flange | D F | — | — | — | — | | | | |
| CE marking | | | Non | Non | Non | Non | | | | |
| Earth leakage trip mechanism | | | Electronic | Electronic | Electronic | Electronic | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic (adjustable) | | | | |
| Overvoltage / Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button | | | | |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | | | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | | | | |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | | | | |
| Reverse power flow circuit | | | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ | | | | |
| Page of characteristics and outline dimensions | | | 7-210 | 7-210 | 7-212 | 7-212 | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑱ : Do not apply to circuits where overcurrent flows in the neutral wire.

㊵ : They can also be applied to circuits where overcurrent flows in the neutral wire. Can be used as a main circuit breaker for photovoltaic power generation systems. See page 3-27 for details.

㊸ : For the extension bars, please place the order separately in parts.

㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

Remarks: See pages 3-25 and 3-26 for connection details.

# 19 Earth Leakage Circuit Breakers for distribution boards and control boards (Harmonics/surge with countermeasure)

| | | |

| Category | | Separate type | |
|---|---|---|---|
| | | High-sensitivity Instantaneous tripping type | Medium sensitivity Instantaneous tripping / time delay tripping type |
| Type | | TZS-15HD ⑧<br>TZS-24HD<br>TZS-40HD<br>TZS-68HD<br>TZS-100HD | TZS-15MD ⑨<br>TZS-24MD<br>TZS-40MD<br>TZS-68MD<br>TZS-100MD |
| Phase and wires ① | 1ø2W, 1ø3W | ● | ● |
| | 3ø3W, 3ø4W | ● | ● |
| Outside view<br>The monitor (ZCT) is shown in the table below. | |  |  |
| ■Ratings | | | |
| Rated control voltage, V AC② | | 100 selectable ③④<br>200 | 100 selectable ③④<br>200 |
| Applicable range V | AC100 | 80～132 | 80～132 |
| | AC200 | 160～264 | 160～264 |
| Rated sensitivity current [mA] | | 30 | 100<br>200<br>500<br>1000<br>selectable |
| Rated operating time (sec) | | 0.1 or less | 0.1 or less<br>0.3<br>0.5 selectable ⑤<br>1<br>2 |
| External dimensions mm Width × Height × Depth | | 60×78×100 | 60×78×100 |
| Weight (FC) kg | | 0.22 | 0.22 |
| ■Connections and Mountings | | | |
| Front-connected (FC) | | ◉ | ◉ |
| Flush-mounted (FP) | | ○ | ○ |
| ■Standard features | | | |
| Earth leakage detection (Current operation type) | | Electronic | Electronic |
| Output contact ⑥ | | 1C | 1C |
| Earth leakage indication | | LED (Red) | LED (Red) |
| Reset function | | Push button ⑦ | Push button ⑦ |
| Power source required | | 1VA or more | 1VA or more |
| CE marking | | Non ⑩ | Non ⑩ |
| Page of characteristics and outline dimensions | | 7-243 | 7-243 |

**Notes:**

◉: Standard. This configuration used unless otherwise specified.

○: Specify when ordering.

●: "yes" or "available".

①: Can also be applied to the ground wire.

②: Applicable rated voltage For 100V: 100 to 120V, For 200V: 200 to 240V

③: Terminals for 100V AC and 200V AC are provided.

**Caution: do not apply 100V AC to the 200V AC terminal., burnout can result.**

④: For 415V AC or 440V AC, please contact TERASAKI.

⑤: Operating time range and Non-operating time range.

| Rated operating time (sec) | Operating time range (sec) | Non-operating time range (sec) |
|---|---|---|
| 0.1 or less | 0.1 or less | — |
| 0.3 | 0.2～0.36 | 0.15 |
| 0.5 | 0.4～0.6 | 0.38 |
| 1 | 0.8～1.2 | 0.7 |
| 2 | 1.3～2 | 1.25 |

⑥: Ratings of output contact.

| Voltage | COSø=1 | COSø=0.4 (L/R=7ms) | Minimum load |
|---|---|---|---|
| 120V AC | 6A | 3.5A | 5V DC 10mA |
| 240V AC | 6A | 3.5A | |
| 30V DC | 6A | 3A | |

⑦: The output contacts remain operational until the RESET button is pressed. If the control power supply fails, the contacts automatically reset.

⑧: Type of the relay displayed is TZS-HD.

⑨: Type of the relay displayed is TZS-MD.

⑩: The earth leakage relay TZS-AD for overseas with CE marking is available. Please contact us for details.

Remarks (1): With the medium sensitivity instantaneous tripping / time delay tripping type, you can switch the rated sensitivity current to 100mA, 200mA, 500mA, or 1000mA, and switch the operating time to 5 stages of 0.1 seconds or less, 0.3, 0.5, 1, or 2 seconds with the DIP switch. The rated sensitivity current is set to 100 mA and the operating time is set to 0.1 seconds before delivery.

## Ratings of ZCT

| Type | | TZS-15 | TZS-24 | TZS-40 | TZS-68 | TZS-100 |
|---|---|---|---|---|---|---|
| Outside view | |  |  |  |  |  |
| Diameter of transit part [mm] | | ø15 | ø24 | ø40 | ø68 | ø100 |
| Weight [kg] | | 0.2 | 0.3 | 0.7 | 1.1 | 2.0 |
| Applicable numbers, size and continuous current of wires (IV cable wires) | | | | | | |
| 2 wires | max. continuous current A | 61 | 139 | 298 | 650 | 1185 |
| | max. wire size mm² | 8 | 30 | 100 | 325 | 850 |
| | max.diameter of wire mm | 6.0 | 10.5 | 17 | 29 | 45 |
| 3 wires | max. continuous current A | 61 | 139 | 298 | 650 | 1185 |
| | max. wire size mm² | 8 | 30 | 100 | 325 | 850 |
| | max.diameter of wire mm | 6.0 | 10.5 | 17 | 29 | 45 |
| 4 wires | max. continuous current A | 49 | 115 | 257 | 556 | 992 |
| | max. wire size mm² | 5.5 | 22 | 80 | 250 | 600 |
| | max.diameter of wire mm | 5.0 | 9.5 | 15.5 | 26 | 38 |

# 21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies)

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | N K | | L R | | A B S | | B V | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 30 | **PE30-NF** | 3,5,10,15,20,30 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 1.5[2.1] | 1.5[2.1] | 1.5[2.1] | 1.5[2.1] | 1.5[2.1] | 1.5[2.1] | 1.5[2.1] | 1.5[2.1] |
| | | | | AC240 | 2.5[3.55] | 2.5[3.55] | 2.5[3.55] | 2.5[3.55] | 2.5[3.55] | 2.5[3.55] | 2.5[3.55] | 2.5[3.55] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **PS30-NF** | 3,5,10,15,20,30 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] |
| | | | | AC240 | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] |
| | | | | DC250 | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] |
| 50 | **PE50-NF** | 15,20,30,40,50 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] |
| | | | | AC240 | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] |
| | | | | DC250 | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] |
| | **PS50-NF** | 15,20,30,40,50 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 7.5[13.4] | 7.5[13.4] | 7.5[13.4] | 7.5[13.4] | 7.5[13.4] | 7.5[13.4] | 7.5[13.4] | 7.5[13.4] |
| | | | | AC240 | 15[31.0] | 15[31.0] | 15[31.0] | 15[31.0] | 15[31.0] | 15[31.0] | 15[31.0] | 15[31.0] |
| | | | | DC250 | 7.5[7.5] | 7.5[7.5] | 7.5[7.5] | 7.5[7.5] | 7.5[7.5] | 7.5[7.5] | 7.5[7.5] | 7.5[7.5] |
| | **S50-SF** | 15,20,30,40,50 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 25[54.4] | 13[29.6] | 25[54.4] | 13[29.6] | 25[54.4] | 13[29.6] | 25[54.4] | 13[29.6] |
| | | | | AC240 | 50[117] | 25[56.9] | 50[117] | 25[56.9] | 50[117] | 25[56.9] | 50[117] | 25[56.9] |
| | | | | DC250 | 25[25] | 13[13] | 25[25] | 13[13] | 25[25] | 13[13] | 25[25] | 13[13] |
| | **PS50-PF** | 15,20,30,40,50 | 2 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] |
| | | | 3 | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] |
| | | | 4 | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] |
| 60 | **PE60-NF** | 60 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] |
| | | | | AC240 | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] |
| | | | | DC250 | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] |
| | **PS60-NF** | 60 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 10[21.3] | 5[7.74] | 10[21.3] | 5[7.74] | 10[21.3] | 5[7.74] | 10[21.3] | 5[7.74] |
| | | | | AC240 | 30[61.9] | 15[31.0] | 30[61.9] | 15[31.0] | 30[61.9] | 15[31.0] | 30[61.9] | 15[31.0] |
| | | | | DC250 | 7.5[7.5] | 4[4] | 7.5[7.5] | 4[4] | 7.5[7.5] | 4[4] | 7.5[7.5] | 4[4] |
| 100 | **S100-GF** | 15,20,30, 40,50,60, 75,100 | 2 | AC690 | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] |
| | | | 3 | AC500 | — | — | 25[52.5] | 22[46.2] | 25[52.5] | 22[46.2] | 25[52.5] | 22[46.2] |
| | | | | AC450 | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[112] | 25[54.4] |
| | | | | AC415 | — | — | 65[143] | 33[69.3] | 65[143] | 33[69.3] | 65[143] | 33[69.3] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] |
| | **S100-GFL** | 15,20,30, 40,50,60, 75,100 | 2 | AC690 | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] |
| | | | 3 | AC500 | — | — | 25[52.5] | 22[46.2] | 25[52.5] | 22[46.2] | 25[52.5] | 22[46.2] |
| | | | | AC450 | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[112] | 25[54.4] |
| | | | | AC415 | — | — | 65[143] | 33[69.3] | 65[143] | 33[69.3] | 65[143] | 33[69.3] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] |
| | **S100-GFH** | 15,20,30, 40,50,60, 75,100 | 2 | AC690 | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] |
| | | | 3 | AC500 | — | — | 25[52.5] | 22[46.2] | 25[52.5] | 22[46.2] | 25[52.5] | 22[46.2] |
| | | | | AC450 | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[112] | 25[54.4] |
| | | | | AC415 | — | — | 65[143] | 33[69.3] | 65[143] | 33[69.3] | 65[143] | 33[69.3] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] |
| | **H100-NF** | 15,20,30,40,50, 60,75,100 | 3 | AC690 | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] |
| | | | | AC500 | — | — | 45[94.5]① | 45[94.5]① | 45[94.5] | 45[94.5] | 45[94.5]① | 45[94.5]① |
| | | | | AC450 | 120[283] | 80[191] | 120[283] | 80[191] | 120[283] | 80[191] | 120[283] | 80[191] |
| | | | | AC415 | — | — | 125[275] | 85[187] | 125[275] | 85[187] | 125[275] | 85[187] |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] |
| | **L100-NF** | 15,20,30,40,50, 60,75,100 | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC500 | — | — | 65[143]① | 65[143]① | 65[143] | 65[143] | 65[143]① | 65[143]① |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] |
| | | | | AC415 | 200[484] | 150[345] | 200[484] | 150[345] | 200[484] | 150[345] | 200[484] | 150[345] |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] |
| 125 | **PE125-NF** | 60,75,100,125 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 10[21.3] | 5[7.74] | 10[21.3] | 5[7.74] | 10[21.3] | 5[7.74] | 10[21.3] | 5[7.74] |
| | | | | AC240 | 30[61.9] | 15[31.0] | 30[61.9] | 15[31.0] | 30[61.9] | 15[31.0] | 30[61.9] | 15[31.0] |
| | | | | DC250 | 7.5[7.5] | 4[4] | 7.5[7.5] | 4[4] | 7.5[7.5] | 4[4] | 7.5[7.5] | 4[4] |
| | **S125-SF** | 15,20,30,40,50, 60,75,100,125 | 2 | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 25[54.4] | 13[29.6] | 25[54.4] | 13[29.6] | 25[54.4] | 13[29.6] | 25[54.4] | 13[29.6] |
| | | | | AC240 | 50[117] | 25[56.9] | 50[117] | 25[56.9] | 50[117] | 25[56.9] | 50[117] | 25[56.9] |
| | | | | DC250 | 25[25] | 13[13] | 25[25] | 13[13] | 25[25] | 13[13] | 25[25] | 13[13] |

**Note** ① : at 525V AC.

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | C C S | | K R | | R I N A | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 30 | **PE30-NF** | 3,5,10,15,20,30 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 1.5[2.1] | 1.5[2.1] | 1.5[2.1] | 1.5[2.1] | — | — |
| | | | | AC240 | 2.5[3.55] | 2.5[3.55] | 2.5[3.55] | 2.5[3.55] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **PS30-NF** | 3,5,10,15,20,30 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | — | — |
| | | | | AC240 | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | — | — |
| | | | | DC250 | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | — | — |
| 50 | **PE50-NF** | 15,20,30,40,50 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | — | — |
| | | | | AC240 | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | — | — |
| | | | | DC250 | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | — | — |
| | **PS50-NF** | 15,20,30,40,50 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 7.5[13.4] | 7.5[13.4] | 7.5[13.4] | 7.5[13.4] | — | — |
| | | | | AC240 | 15[31.0] | 15[31.0] | 15[31.0] | 15[31.0] | — | — |
| | | | | DC250 | 7.5[7.5] | 7.5[7.5] | 7.5[7.5] | 7.5[7.5] | — | — |
| | **S50-SF** | 15,20,30,40,50 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 25[54.4] | 13[29.6] | 25[54.4] | 13[29.6] | — | — |
| | | | | AC240 | 50[117] | 25[56.9] | 50[117] | 25[56.9] | — | — |
| | | | | DC250 | 25[25] | 13[13] | 25[25] | 13[13] | — | — |
| | **PS50-PF** | 15,20,30,40,50 | 2 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | — | — |
| | | | 3 | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | — | — |
| | | | 4 | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | — | — |
| 60 | **PE60-NF** | 60 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | 2.5[3.60] | — | — |
| | | | | AC240 | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | 7.5[13.1] | — | — |
| | | | | DC250 | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | 2.5[2.5] | — | — |
| | **PS60-NF** | 60 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 10[21.3] | 5[7.74] | 10[21.3] | 5[7.74] | — | — |
| | | | | AC240 | 30[61.9] | 15[31.0] | 30[61.9] | 15[31.0] | — | — |
| | | | | DC250 | 7.5[7.5] | 4[4] | 7.5[7.5] | 4[4] | — | — |
| 100 | **S100-GF** | 15,20,30, 40,50,60, 75,100 | 2 | AC690 | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9] | 6[9] |
| | | | 3 | AC500 | — | — | 25[52.5] | 22[46.2] | — | — |
| | | | | AC450 | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[105] | 25[52.5] |
| | | | | AC415 | — | — | 65[143] | 33[69.3] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[187] | 85[187] |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] |
| | **S100-GFL** | 15,20,30, 40,50,60, 75,100 | 2 | AC690 | — | — | 6[9.29] | 6[9.29] | — | — |
| | | | 3 | AC500 | — | — | 25[52.5] | 22[46.2] | — | — |
| | | | | AC450 | — | — | 50[112] | 25[54.4] | — | — |
| | | | | AC415 | — | — | 65[143] | 33[69.3] | — | — |
| | | | | AC240 | — | — | 85[201] | 85[201] | — | — |
| | | | | DC250 | — | — | 40[40] | 40[40] | — | — |
| | **S100-GFH** | 15,20,30, 40,50,60, 75,100 | 2 | AC690 | — | — | 6[9.29] | 6[9.29] | — | — |
| | | | 3 | AC500 | — | — | 25[52.5] | 22[46.2] | — | — |
| | | | | AC450 | — | — | 50[112] | 25[54.4] | — | — |
| | | | | AC415 | — | — | 65[143] | 33[69.3] | — | — |
| | | | | AC240 | — | — | 85[201] | 85[201] | — | — |
| | | | | DC250 | — | — | 40[40] | 40[40] | — | — |
| | **H100-NF** | 15,20,30,40,50, 60,75,100 | 3 | AC690 | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | 20[40] | 15[30] |
| | | | | AC500 | — | — | 45[94.5] | 45[94.5] | — | — |
| | | | | AC450 | 120[283] | 80[191] | 120[283] | 80[191] | 120[264] | 80[176] |
| | | | | AC415 | — | — | 125[275] | 85[187] | — | — |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | 150[330] | 150[330] |
| | **L100-NF** | 15,20,30,40,50, 60,75,100 | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[52.5] | 19[38] |
| | | | | AC500 | — | — | 65[143] | 65[143] | — | — |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | 180[396] | 135[297] |
| | | | | AC415 | 200[484] | 150[345] | 200[484] | 150[345] | — | — |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | 200[440] | 150[330] |
| 125 | **PE125-NF** | 60,75,100,125 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 10[21.3] | 5[7.74] | 10[21.3] | 5[7.74] | — | — |
| | | | | AC240 | 30[61.9] | 15[31.0] | 30[61.9] | 15[31.0] | — | — |
| | | | | DC250 | 7.5[7.5] | 4[4] | 7.5[7.5] | 4[4] | — | — |
| | **S125-SF** | 15,20,30,40,50, 60,75,100,125 | 2 | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 25[54.4] | 13[29.6] | 25[54.4] | 13[29.6] | — | — |
| | | | | AC240 | 50[117] | 25[56.9] | 50[117] | 25[56.9] | — | — |
| | | | | DC250 | 25[25] | 13[13] | 25[25] | 13[13] | — | — |

# 21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies)

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | N K | | L R | | A B S | | B V | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 125 | **PS125-NF** | 15,20,30,40,50, 60,75,100,125 | 2 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] |
| | | | 3 | AC450 | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] |
| | | | | DC250 | 25[25] | 19[19] | 25[25] | 19[19] | 25[25] | 19[19] | 25[25] | 19[19] |
| | **PS125-NE** | 40～125 (40,50,60,63 75,100,125) | 3 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] |
| | | | | AC450 | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **PS125-PF** | 15,20,30,40,50, 60,75,100,125 | 2 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] |
| | | | 3 | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] |
| | **PS125-PE** | 40～125 (40,50,60,63 75,100,125) | 3 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] |
| | | | | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **S125-GF** | 125 | 2 | AC690 | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] |
| | | | 3 | AC500 | — | — | 25[52.5] | 22[46.2] | 25[52.5] | 22[46.2] | 25[52.5] | 22[46.2] |
| | | | | AC450 | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[112] | 25[54.4] | 50[112] | 25[54.4] |
| | | | | AC415 | — | — | 65[143] | 33[69.3] | 65[143] | 33[69.3] | 65[143] | 33[69.3] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] |
| | **H125-NF** | 125 | 3 | AC690 | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] |
| | | | | AC500 | — | — | 45[94.5]① | 45[94.5]① | 45[94.5] | 45[94.5] | 45[94.5]① | 45[94.5]① |
| | | | | AC450 | 120[283] | 80[191] | 120[283] | 80[191] | 120[283] | 80[191] | 120[283] | 80[191] |
| | | | | AC415 | — | — | 125[275] | 85[187] | 125[275] | 85[187] | 125[275] | 85[187] |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] |
| | **L125-NF** | 125 | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC500 | — | — | 65[143]① | 65[143]① | 65[143] | 65[143] | 65[143]① | 65[143]① |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] |
| | | | | AC415 | 200[484] | 150[345] | 200[484] | 150[345] | 200[484] | 150[345] | 200[484] | 150[345] |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] |
| 225 | **H225-NF** | 125,150,175, 200,225 | 3 | AC690 | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] |
| | | | | AC500 | — | — | 45[94.5]① | 45[94.5]① | 45[94.5] | 45[94.5] | 45[94.5]① | 45[94.5]① |
| | | | | AC450 | 120[283] | 80[191] | 120[283] | 80[191] | 120[283] | 80[191] | 120[283] | 80[191] |
| | | | | AC415 | — | — | 125[275] | 85[187] | 125[275] | 85[187] | 125[275] | 85[187] |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] |
| | **L225-NF** | 125,150,175, 200,225 | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC500 | — | — | 65[143]① | 65[143]① | 65[143] | 65[143] | 65[143]① | 65[143]① |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] |
| | | | | AC415 | 200[484] | 150[345] | 200[484] | 150[345] | 200[484] | 150[345] | 200[484] | 150[345] |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] |
| 250 | **E250-SF** | 125,150,175, 200,225 | 2＊ | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 15[32.6] | 12[27.3] | 15[32.6] | 12[27.3] | 15[32.6] | 12[27.3] | 15[32.6] | 12[27.3] |
| | | | | AC240 | 35[83.6] | 27[62.2] | 35[83.6] | 27[62.2] | 35[83.6] | 27[62.2] | 35[83.6] | 27[62.2] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **S250-SF** | 125,150,175, 200,225,250 | 2＊ | AC690 | — | — | — | — | — | — | — | — |
| | | | 3 | AC450 | 30[70.8] | 15[32.6] | 30[70.8] | 15[32.6] | 30[70.8] | 15[32.6] | 30[70.8] | 15[32.6] |
| | | | | AC240 | 85[211] | 43[103] | 85[211] | 43[103] | 85[211] | 43[103] | 85[211] | 43[103] |
| | | | | DC250 | 25[25] | 13[13] | 25[25] | 13[13] | 25[25] | 13[13] | 25[25] | 13[13] |
| | **PS250-NE** | 125～250 (125,150,175, 200,225,250) | 3 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] |
| | | | | AC450 | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **PS250-PF** | 125,150,175, 200,225,250 | 2＊ | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] |
| | | | 3 | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] | 40[40] |
| | **PS250-PE** | 125～250 (125,150,175, 200,225,250) | 3 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] |
| | | | | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] | 50[112] | 35[81.6] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | — | — | — | — | — | — | — | — |

**Notes** ① : at 525V AC.
＊ : 2 poles breakers use the terminals of both ends of 3 poles breakers.

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | C C S | | K R | | R I N A | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 125 | **PS125-NF** | 15,20,30,40,50, 60,75,100,125 | 2 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | — | — |
| | | | 3 | AC450 | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | — | — |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | — | — |
| | | | | DC250 | 25[25] | 19[19] | 25[25] | 19[19] | — | — |
| | **PS125-NE** | 40～125 (40,50,60,63 75,100,125) | 3 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | — | — |
| | | | | AC450 | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | — | — |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **PS125-PF** | 15,20,30,40,50, 60,75,100,125 | 2 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | — | — |
| | | | 3 | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | — | — |
| | **PS125-PE** | 40～125 (40,50,60,63 75,100,125) | 3 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | — | — |
| | | | | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **S125-GF** | 125 | 2 | AC690 | 6[9.29] | 6[9.29] | 6[9.29] | 6[9.29] | — | — |
| | | | 3 | AC500 | — | — | 25[52.5] | 22[46.2] | — | — |
| | | | | AC450 | 50[112] | 25[54.4] | 50[112] | 25[54.4] | — | — |
| | | | | AC415 | — | — | 65[143] | 33[69.3] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | — | — |
| | **H125-NF** | 125 | 3 | AC690 | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | — | — |
| | | | | AC500 | — | — | 45[94.5] | 45[94.5] | — | — |
| | | | | AC450 | 120[283] | 80[191] | 120[283] | 80[191] | — | — |
| | | | | AC415 | — | — | 125[275] | 85[187] | — | — |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | — | — |
| | **L125-NF** | 125 | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | — | — |
| | | | | AC500 | — | — | 65[143] | 65[143] | — | — |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | — | — |
| | | | | AC415 | 200[484] | 150[345] | 200[484] | 150[345] | — | — |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | — | — |
| 225 | **H225-NF** | 125,150,175, 200,225 | 3 | AC690 | 20[43.0] | 15[32.6] | 20[43.0] | 15[32.6] | 20[40] | 15[30] |
| | | | | AC500 | — | — | 45[94.5] | 45[94.5] | — | — |
| | | | | AC450 | 120[283] | 80[191] | 120[283] | 80[191] | 120[264] | 80[176] |
| | | | | AC415 | — | — | 125[275] | 85[187] | — | — |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | 150[330] | 150[330] |
| | **L225-NF** | 125,150,175, 200,225 | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[52.5] | 19[38] |
| | | | | AC500 | — | — | 65[143] | 65[143] | — | — |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | 180[396] | 135[297] |
| | | | | AC415 | 200[484] | 150[345] | 200[484] | 150[345] | — | — |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | 200[440] | 150[330] |
| 250 | **E250-SF** | 125,150,175, 200,225 | 2* | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 15[32.6] | 12[27.3] | 15[32.6] | 12[27.3] | — | — |
| | | | | AC240 | 35[83.6] | 27[62.2] | 35[83.6] | 27[62.2] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **S250-SF** | 125,150,175, 200,225,250 | 2* | AC690 | — | — | — | — | — | — |
| | | | 3 | AC450 | 30[70.8] | 15[32.6] | 30[70.8] | 15[32.6] | — | — |
| | | | | AC240 | 85[211] | 43[103] | 85[211] | 43[103] | — | — |
| | | | | DC250 | 25[25] | 13[13] | 25[25] | 13[13] | — | — |
| | **PS250-NE** | 125～250 (125,150,175, 200,225,250) | 3 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | — | — |
| | | | | AC450 | 25[54.4] | 25[54.4] | 25[54.4] | 25[54.4] | — | — |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **PS250-PF** | 125,150,175, 200,225,250 | 2* | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | — | — |
| | | | 3 | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | | | | DC250 | 40[40] | 40[40] | 40[40] | 40[40] | — | — |
| | **PS250-PE** | 125～250 (125,150,175, 200,225,250) | 3 | AC690 | 6[11.2] | 6[11.2] | 6[11.2] | 6[11.2] | — | — |
| | | | | AC450 | 50[112] | 35[81.6] | 50[112] | 35[81.6] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | | | | DC250 | — | — | — | — | — | — |

# 21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies)

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | N K | | L R | | A B S | | B V | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 400 | **PS400-CF** | 225,250,300, 350,400 | 3 | AC690 | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] |
| | | | | AC450 | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] |
| | | | | DC250 | 25[25] | 25[25] | 25[25] | 25[25] | 25[25] | 25[25] | 25[25] | 25[25] |
| | **PS400-NF** | 225,250,300, 350,400 | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] |
| | **PS400-NE** | 125～250 (125,150,175, 200,225,250) 175～400 (175,200,225,250, 300,350,400) | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **PS400-GF** | 225,250,300, 350,400 | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 65[157 ] | 65[157] | 65[157 ] | 65[157] | 65[157 ] | 65[157] | 65[157 ] | 65[157] |
| | | | | AC240 | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] |
| | | | | DC250 | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] |
| | **PS400-GE** | 125～250 (125,150,175, 200,225,250) 175～400 (175,200,225,250, 300,350,400) | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 65[157] | 65[157] | 65[157] | 65[157] | 65[157] | 65[157] | 65[157] | 65[157] |
| | | | | AC240 | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **PH400-CF** | 225,250,300, 350,400 | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] |
| | | | | AC240 | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] |
| | | | | DC250 | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] | 50[50] |
| | **PH400-CE** | 125～250 (125,150,175, 200,225,250) 175～400 (175,200,225,250, 300,350,400) | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] |
| | | | | AC240 | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **H400-NE** | 100～400 (125,150,175, 200,225,250, 300,350,400) | 3 | AC690 | 35[77.8] | 35[77.8] | 35[77.8] | 35[77.8] | 35[77.8] | 35[77.8] | 35[77.8] | 35[77.8] |
| | | | | AC525 | — | — | 45[94.5] | 45[94.5] | 45[94.5] | 45[94.5] | 45[94.5] | 45[94.5] |
| | | | | AC450 | 120[283] | 80[191] | 120[283] | 80[191] | 120[283] | 80[191] | 120[283] | 80[191] |
| | | | | AC415 | — | — | 125[275] | 85[187] | 125[275] | 85[187] | 125[275] | 85[187] |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] |
| | **L400-NE** | 100～400 (125,150,175, 200,225,250, 300,350,400) | 3 | AC690 | 50[115] | 50[115] | 50[115] | 50[115] | 50[115] | 50[115] | 50[115] | 50[115] |
| | | | | AC525 | — | — | 65[143] | 65[143] | 65[143] | 65[143] | 65[143] | 65[143] |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] |
| | | | | AC415 | 200[484] | 150[345] | 200[484] | 150[345] | 200[484] | 150[345] | 200[484] | 150[345] |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] |

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | C C S | | K R | | R I N A | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 400 | **PS400-CF** | 225,250,300, 350,400 | 3 | AC690 | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | — | — |
| | | | | AC450 | 100[230] | 100[230] | 30[70.8] | 30[70.8] | — | — |
| | | | | AC240 | 125[306] | 125[306] | 50[117] | 50[117] | — | — |
| | | | | DC250 | 25[25] | 25[25] | 25[25] | 25[25] | — | — |
| | **PS400-NF** | 225,250,300, 350,400 | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 45[109] | 45[109] | 45[109] | 45[109] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | | | | DC250 | 50[50] | 50[50] | 50[50] | 50[50] | — | — |
| | **PS400-NE** | 125～250 (125,150,175, 200,225,250) 175～400 (175,200,225,250, 300,350,400) | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 45[109] | 45[109] | 45[109] | 45[109] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **PS400-GF** | 225,250,300, 350,400 | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 65[157 ] | 65[157] | 65[157 ] | 65[157] | — | — |
| | | | | AC240 | 100[233] | 100[233] | 100[233] | 100[233] | — | — |
| | | | | DC250 | 50[50] | 50[50] | 50[50] | 50[50] | — | — |
| | **PS400-GE** | 125～250 (125,150,175, 200,225,250) 175～400 (175,200,225,250, 300,350,400) | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 65[157] | 65[157] | 65[157] | 65[157] | — | — |
| | | | | AC240 | 100[233] | 100[233] | 100[233] | 100[233] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **PH400-CF** | 225,250,300, 350,400 | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 100[230] | 100[230] | 100[230] | 100[230] | — | — |
| | | | | AC240 | 125[306] | 125[306] | 125[306] | 125[306] | — | — |
| | | | | DC250 | 50[50] | 50[50] | 50[50] | 50[50] | — | — |
| | **PH400-CE** | 125～250 (125,150,175, 200,225,250) 175～400 (175,200,225,250, 300,350,400) | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 100[230] | 100[230] | 100[230] | 100[230] | — | — |
| | | | | AC240 | 125[306] | 125[306] | 125[306] | 125[306] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **H400-NE** | 100～400 (125,150,175, 200,225,250, 300,350,400) | 3 | AC690 | 35[77.8] | 35[77.8] | 35[77.8] | 35[77.8] | — | — |
| | | | | AC525 | — | — | — | — | — | — |
| | | | | AC450 | 120[283] | 80[191] | 120[283] | 80[191] | — | — |
| | | | | AC415 | — | — | — | — | — | — |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | — | — |
| | **L400-NE** | 100～400 (125,150,175, 200,225,250, 300,350,400) | 3 | AC690 | 50[115] | 50[115] | 50[115] | 50[115] | — | — |
| | | | | AC525 | — | — | — | — | — | — |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | — | — |
| | | | | AC415 | 200[484] | 150[345] | 200[484] | 150[345] | — | — |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | — | — |

# 21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies)

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | N K | | L R | | A B S | | B V | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 630 | **S630-CF** | 500,600,630 | 3 | AC690 | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] |
| | | | | AC525 | — | — | 15[30] | 15[30] | 15[30] | 15[30] | 15[30] | 15[30] |
| | | | | AC450 | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] |
| | | | | AC415 | — | — | 36[75.6] | 36[75.6] | 36[75.6] | 36[75.6] | 36[75.6] | 36[75.6] |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **S630-NF** | 500,600,630 | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] |
| | | | | AC525 | — | — | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] |
| | | | | AC415 | — | — | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **S630-NE** | 250～630 (250,300,350, 400,500,600,630) | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] |
| | | | | AC525 | — | — | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] |
| | | | | AC415 | — | — | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] |
| | **S630-NEH** | 250～630 (250,300,350, 400,500,600,630) | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] |
| | | | | AC525 | — | — | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] |
| | | | | AC415 | — | — | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] |
| | **PS630-CF** | 500,600 ① | 3 | AC690 | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] |
| | | | | AC450 | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] |
| | **PS630-NF** | 500,600 ① | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] | 45[109] |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] | 85[201] |
| | **PS630-GF** | 500,600 ① | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 65[157] | 65[157] | 65[157] | 65[157] | 65[157] | 65[157] | 65[157] | 65[157] |
| | | | | AC240 | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] | 100[233] |
| | **PH630-CF** | 500,600 ① | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] |
| | | | | AC450 | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] | 100[230] |
| | | | | AC240 | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] |
| | **H630-NE** | 250～630 (250,300,350, 400,500,600,630) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC525 | — | — | 45[94.5] | 34[71.4] | 45[94.5] | 34[71.4] | 45[94.5] | 34[71.4] |
| | | | | AC450 | 125[295] | 94[225] | 125[295] | 94[225] | 125[295] | 94[225] | 125[295] | 94[225] |
| | | | | AC415 | — | — | 125[275] | 94[206.8] | 125[275] | 94[206.8] | 125[275] | 94[206.8] |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] |
| | **L630-NE** | 250～630 (250,300,350, 400,500,600,630) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC525 | — | — | 45[94.5] | 34[71.4] | 45[94.5] | 34[71.4] | 45[94.5] | 34[71.4] |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] |
| | | | | AC415 | — | — | 200[440] | 150[330] | 200[440] | 150[330] | 200[440] | 150[330] |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] |

**Note** ① : Front-conn. type (FC) and Rear-conn. type (RC) are available for 500A and 600A. Plug-in type (PM) is available for only 500A.

# 21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies)

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | C C S | | K R | | R I N A | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 630 | **S630-CF** | 500,600,630 | 3 | AC690 | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | — | — |
| | | | | AC525 | — | — | 15[30] | 15[30] | — | — |
| | | | | AC450 | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | — | — |
| | | | | AC415 | — | — | 36[75.6] | 36[75.6] | — | — |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **S630-NF** | 500,600,630 | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 30[63] | 30[63] | — | — |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | — | — |
| | | | | AC415 | — | — | 50[105] | 50[105] | — | — |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **S630-NE** | 250～630 (250,300,350, 400,500,600,630) | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 30[63] | 30[63] | — | — |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | — | — |
| | | | | AC415 | — | — | 50[105] | 50[105] | — | — |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | — | — |
| | **S630-NEH** | 250～630 (250,300,350, 400,500,600,630) | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 30[63] | 30[63] | — | — |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | — | — |
| | | | | AC415 | — | — | 50[105] | 50[105] | — | — |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | — | — |
| | **PS630-CF** | 500,600 ① | 3 | AC690 | 7[13.1] | 7[13.1] | 7[13.1] | 7[13.1] | — | — |
| | | | | AC450 | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | — | — |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | — | — |
| | **PS630-NF** | 500,600 ① | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 45[109] | 45[109] | 45[109] | 45[109] | — | — |
| | | | | AC240 | 85[201] | 85[201] | 85[201] | 85[201] | — | — |
| | **PS630-GF** | 500,600 ① | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 65[157] | 65[157] | 65[157] | 65[157] | — | — |
| | | | | AC240 | 100[233] | 100[233] | 100[233] | 100[233] | — | — |
| | **PH630-CF** | 500,600 ① | 3 | AC690 | 12[24.3] | 12[24.3] | 12[24.3] | 12[24.3] | — | — |
| | | | | AC450 | 100[230] | 100[230] | 100[230] | 100[230] | — | — |
| | | | | AC240 | 125[306] | 125[306] | 125[306] | 125[306] | — | — |
| | **H630-NE** | 250～630 (250,300,350, 400,500,600,630) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 45[94.5] | 34[71.4] | — | — |
| | | | | AC450 | 125[295] | 94[225] | 125[295] | 94[225] | — | — |
| | | | | AC415 | — | — | 125[275] | 94[206.8] | — | — |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | — | — |
| | **L630-NE** | 250～630 (250,300,350, 400,500,600,630) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 45[94.5] | 34[71.4] | — | — |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | — | — |
| | | | | AC415 | — | — | 200[440] | 150[330] | — | — |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | — | — |

# 21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies)

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | N K | | L R | | A B S | | B V | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 800 | **S800-CF** | 700,800 | 3 | AC690 | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] |
| | | | | AC525 | — | — | 15[30] | 15[30] | 15[30] | 15[30] | 15[30] | 15[30] |
| | | | | AC450 | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] |
| | | | | AC415 | — | — | 36[75.6] | 36[75.6] | 36[75.6] | 36[75.6] | 36[75.6] | 36[75.6] |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] | 50[117] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **S800-NF** | 700,800 | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] |
| | | | | AC525 | — | — | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] |
| | | | | AC415 | — | — | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **S800-NE** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] |
| | | | | AC525 | — | — | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] |
| | | | | AC415 | — | — | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] |
| | **S800-NEH** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] |
| | | | | AC525 | — | — | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] | 30[63] |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] | 50[121] |
| | | | | AC415 | — | — | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] | 50[105] |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] | 85[211] |
| | **S800-PF** | 700,800 | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC450 | 85[203] | 50[121] | 85[203] | 50[121] | 85[203] | 50[121] | 85[203] | 50[121] |
| | | | | AC240 | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **S800-PE** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC450 | 85[203] | 50[121] | 85[203] | 50[121] | 85[203] | 50[121] | 85[203] | 50[121] |
| | | | | AC240 | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] | 125[306] |
| | | | | DC250 | — | — | — | — | — | — | — | — |
| | **H800-NE** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC525 | — | — | 45[94.5] | 34[71.4] | 45[94.5] | 34[71.4] | 45[94.5] | 34[71.4] |
| | | | | AC450 | 125[295] | 94[225] | 125[295] | 94[225] | 125[295] | 94[225] | 125[295] | 94[225] |
| | | | | AC415 | — | — | 125[275] | 94[206.8] | 125[275] | 94[206.8] | 125[275] | 94[206.8] |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] | 150[350] |
| | **L800-NE** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC525 | — | — | 45[94.5] | 34[71.4] | 45[94.5] | 34[71.4] | 45[94.5] | 34[71.4] |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] | 180[430] | 135[315] |
| | | | | AC415 | — | — | 200[440] | 150[330] | 200[440] | 150[330] | 200[440] | 150[330] |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] | 200[484] | 150[350] |
| 1250 | **S1250-NE** | 500～1250 (500,600,700,800, 1000,1200,1250) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC450 | 65[157] | 50[121] | 65[157] | 50[121] | 65[157] | 50[121] | 65[157] | 50[121] |
| | | | | AC240 | 100[233] | 75[181] | 100[233] | 75[181] | 100[233] | 75[181] | 100[233] | 75[181] |
| | **S1250-NEH** | 500～1250 (500,600,700,800, 1000,1200,1250) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] |
| | | | | AC450 | 65[157] | 50[121] | 65[157] | 50[121] | 65[157] | 50[121] | 65[157] | 50[121] |
| | | | | AC240 | 100[233] | 75[181] | 100[233] | 75[181] | 100[233] | 75[181] | 100[233] | 75[181] |
| | **S1250-GE** | 500～1250 (500,600,700,800, 1000,1200,1250) | 3 | AC690 | 45[100] | 34[75.6] | 45[100] | 34[75.6] | 45[100] | 34[75.6] | 45[100] | 34[75.6] |
| | | | | AC450 | 85[203] | 65[157] | 85[203] | 65[157] | 85[203] | 65[157] | 85[203] | 65[157] |
| | | | | AC240 | 125[306] | 94[227] | 125[306] | 94[227] | 125[306] | 94[227] | 125[306] | 94[227] |

# 21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies)

## Domestic Circuit Breakers

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | C C S | | K R | | R I N A | |
| | | | | | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ | $I_{cu}$ | $I_{cs}$ |
| 800 | **S800-CF** | 700,800 | 3 | AC690 | 10[21.1] | 10[21.1] | 10[21.1] | 10[21.1] | — | — |
| | | | | AC525 | — | — | 15[30] | 15[30] | — | — |
| | | | | AC450 | 30[70.8] | 30[70.8] | 30[70.8] | 30[70.8] | — | — |
| | | | | AC415 | — | — | 36[75.6] | 36[75.6] | — | — |
| | | | | AC240 | 50[117] | 50[117] | 50[117] | 50[117] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **S800-NF** | 700,800 | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 30[63] | 30[63] | — | — |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | — | — |
| | | | | AC415 | — | — | 50[105] | 50[105] | — | — |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **S800-NE** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 30[63] | 30[63] | — | — |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | — | — |
| | | | | AC415 | — | — | 50[105] | 50[105] | — | — |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | — | — |
| | **S800-NEH** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 20[43.0] | 20[43.0] | 20[43.0] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 30[63] | 30[63] | — | — |
| | | | | AC450 | 50[121] | 50[121] | 50[121] | 50[121] | — | — |
| | | | | AC415 | — | — | 50[105] | 50[105] | — | — |
| | | | | AC240 | 85[211] | 85[211] | 85[211] | 85[211] | — | — |
| | **S800-PF** | 700,800 | 3 | AC690 | — | — | — | — | — | — |
| | | | | AC450 | — | — | — | — | — | — |
| | | | | AC240 | — | — | — | — | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **S800-PE** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | — | — | — | — | — | — |
| | | | | AC450 | — | — | — | — | — | — |
| | | | | AC240 | — | — | — | — | — | — |
| | | | | DC250 | — | — | — | — | — | — |
| | **H800-NE** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 45[94.5] | 34[71.4] | — | — |
| | | | | AC450 | 125[295] | 94[225] | 125[295] | 94[225] | — | — |
| | | | | AC415 | — | — | 125[275] | 94[206.8] | — | — |
| | | | | AC240 | 150[350] | 150[350] | 150[350] | 150[350] | — | — |
| | **L800-NE** | 350～800 (350,400,450,500, 600,700,800) | 3 | AC690 | 25[53.8] | 20[43.0] | 25[53.8] | 20[43.0] | — | — |
| | | | | AC525 | — | — | 45[94.5] | 34[71.4] | — | — |
| | | | | AC450 | 180[430] | 135[315] | 180[430] | 135[315] | — | — |
| | | | | AC415 | — | — | 200[440] | 150[330] | — | — |
| | | | | AC240 | 200[484] | 150[350] | 200[484] | 150[350] | — | — |
| 1250 | **S1250-NE** | 500～1250 (500,600,700,800, 1000,1200,1250) | 3 | AC690 | 25[53.8] | 20[43.0] | — | — | — | — |
| | | | | AC450 | 65[157] | 50[121] | — | — | — | — |
| | | | | AC240 | 100[233] | 75[181] | — | — | — | — |
| | **S1250-NEH** | 500～1250 (500,600,700,800, 1000,1200,1250) | 3 | AC690 | 25[53.8] | 20[43.0] | — | — | — | — |
| | | | | AC450 | 65[157] | 50[121] | — | — | — | — |
| | | | | AC240 | 100[233] | 75[181] | — | — | — | — |
| | **S1250-GE** | 500～1250 (500,600,700,800, 1000,1200,1250) | 3 | AC690 | 45[100] | 34[75.6] | — | — | — | — |
| | | | | AC450 | 85[203] | 65[157] | — | — | — | — |
| | | | | AC240 | 125[306] | 94[227] | — | — | — | — |

## 21 List of breakers for marine use and rated breaking capacities (approved by ship classification societies)

### TemBreak

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | N K | | L R | | A B S | | B V | |
| | | | | | O-CO | O-CO-CO | O-CO | O-CO-CO | O-CO | O-CO-CO | O-CO | O-CO-CO |
| 50 | **TB-5S** | 10 | 2 | AC250 | 2.5[4.1] | — | 2.5[4.1] | — | — | — | — | — |
| | | | | AC125 | 42[99.3] | — | 43.5[101.6] | — | — | — | — | — |
| | | | | DC125 | 5.0[5.0] | — | 5.0[5.0] | — | — | — | — | — |
| | | 15,20,30, 40,50 | 2 | AC250 | 5.0[8.0] | — | 5.0[8.0] | — | — | — | — | — |
| | | | | AC125 | 42[99.3] | — | 43.5[101.6] | — | — | — | — | — |
| | | | | DC125 | 5.0[5.0] | — | 5.0[5.0] | — | — | — | — | — |
| | **TB-5P** | 10 | 2 | AC250 | 2.5[4.1] | — | 2.5[4.1] | — | 2.5[4.1] | — | 2.5[3.57]③ | — |
| | | | | AC125 | 42[99.3] | — | 43.5[101.6] | — | 42[99.3] | — | 42[102]② | — |
| | | | | DC125 | 5.0[5.0] | — | 5.0[5.0] | — | 5.0[5.0] | — | — | — |
| | | 15,20,30, 40,50 | 2 | AC250 | 5.0[8.0] | — | 5.0[8.0] | — | 5.0[8.0] | — | 5[7.98]③ | — |
| | | | | AC125 | 42[99.3] | — | 43.5[101.6] | — | 42[99.3] | — | 42[102]② | — |
| | | | | DC125 | 5.0[5.0] | — | 5.0[5.0] | — | 5.0[5.0] | — | — | — |
| | **TB-5D** | 10 | 2 | AC250 | 2.5[4.1] | — | 2.5[4.1] | — | 2.5[4.1] | — | 2.5[3.57]③ | — |
| | | | | AC125 | 42[99.3] | — | 43.5[101.6] | — | 42[99.3] | — | 42[102]② | — |
| | | | | DC125 | 5.0[5.0] | — | 5.0[5.0] | — | 5.0[5.0] | — | — | — |
| | | 15,20,30, 40,50 | 2 | AC250 | 5.0[8.0] | — | 5.0[8.0] | — | 5.0[8.0] | — | 5[7.98]③ | — |
| | | | | AC125 | 42[99.3] | — | 43.5[101.6] | — | 42[99.3] | — | 42[102]② | — |
| | | | | DC125 | 5.0[5.0] | — | 5.0[5.0] | — | 5.0[5.0] | — | — | — |
| 1000 | **TL-1000NE** | 500～1000 (500,600, 700,800, 900,1000) | 3 | AC690 | — | — | 45[93.8] | 34[71.6] | — | — | 45[93.8] | 34[71.6] |
| | | | | AC500 | — | — | 75[163] | 57[124] | — | — | — | — |
| | | | | AC460 | 125[295] | — | 125[295]① | 65[153]① | 125[295] | — | 125[295]① | 65[153]① |
| | | | | AC240 | — | — | 150[345] | 113[263] | — | — | — | — |
| 1200 | **TL-1200NE** | 600～1200 (600,700, 800,1000, 1200) | 3 | AC690 | — | — | 45[93.8] | 34[71.6] | — | — | 45[93.8] | 34[71.6] |
| | | | | AC500 | — | — | 75[163] | 57[124] | — | — | — | — |
| | | | | AC460 | 125[295] | — | 125[295]① | 65[153]① | 125[295] | — | 125[295]① | 65[153]① |
| | | | | AC240 | — | — | 150[345] | 113[263] | — | — | — | — |
| 2000 | **XS2000NE** | 1000～2000 (1000,1200,1400, 1600,1800,2000) | 3 | AC500 | — | — | 87.1[194.9] | — | 85[195] | — | — | — |

**Notes** ① : at 450V AC. ② : at 100V AC. ③ : at 225V AC.

## TemBreak

| Frame size | Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities, kA (sym.) Values enclosed in square brackets "[ ]" represent the making current, kA. | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | C C S | | K R | | R I N A | |
| | | | | | O-CO | O-CO-CO | O-CO | O-CO-CO | O-CO | O-CO-CO |
| 50 | **TB-5S** | 10 | 2 | AC250 | — | — | 2.5[4.1] | — | — | — |
| | | | | AC125 | — | — | 42[99.3] | — | — | — |
| | | | | DC125 | — | — | 5.0[5.0] | — | — | — |
| | | 15,20,30, 40,50 | 2 | AC250 | — | — | 5.0[8.0] | — | — | — |
| | | | | AC125 | — | — | 42[99.3] | — | — | — |
| | | | | DC125 | — | — | 5.0[5.0] | — | — | — |
| | **TB-5P** | 10 | 2 | AC250 | 2.5[4.1] | — | 2.5[4.1] | — | — | — |
| | | | | AC125 | 42[99.3] | — | 42[99.3] | — | — | — |
| | | | | DC125 | 5.0[5.0] | — | 5.0[5.0] | — | — | — |
| | | 15,20,30, 40,50 | 2 | AC250 | 5.0[8.0] | — | 5.0[8.0] | — | — | — |
| | | | | AC125 | 42[99.3] | — | 42[99.3] | — | — | — |
| | | | | DC125 | 5.0[5.0] | — | 5.0[5.0] | — | — | — |
| | **TB-5D** | 10 | 2 | AC250 | — | — | 2.5[4.1] | — | — | — |
| | | | | AC125 | — | — | 42[99.3] | — | — | — |
| | | | | DC125 | — | — | 5.0[5.0] | — | — | — |
| | | 15,20,30, 40,50 | 2 | AC250 | — | — | 5.0[8.0] | — | — | — |
| | | | | AC125 | — | — | 42[99.3] | — | — | — |
| | | | | DC125 | — | — | 5.0[5.0] | — | — | — |
| 1000 | **TL-1000NE** | 500～1000 (500,600, 700,800, 900,1000) | 3 | AC690 | — | — | — | — | 45[94.5] | 34[71.4] |
| | | | | AC500 | — | — | — | — | — | — |
| | | | | AC460 | — | — | — | — | 125[275]① | 63[138.6]① |
| | | | | AC240 | — | — | — | — | — | — |
| 1200 | **TL-1200NE** | 600～1200 (600,700, 800,1000, 1200) | 3 | AC690 | — | — | — | — | 45[94.5] | 34[71.4] |
| | | | | AC500 | — | — | — | — | — | — |
| | | | | AC460 | — | — | — | — | 125[275]① | 63[138.6]① |
| | | | | AC240 | — | — | — | — | — | — |
| 2000 | **XS2000NE** | 1000～2000 (1000,1200,1400, 1600,1800,2000) | 3 | AC500 | — | — | 85[195] | — | — | — |

# 22 List of breakers for CCC approved and rated breaking capacities

## Domestic Circuit Breakers

| Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities (kA) (sym.) | | Rated short time withstand current (kA) |
|---|---|---|---|---|---|---|
| | | | | $I_{cu}$ | $I_{cs}$ | $I_{cw}$ |
| **E250-SF** | 125～250 | 3,4 | AC 415 | 25 | 19 | — |
| **S50-SF** | 15～50 | 2,3 | AC 415 | 30 | 15 | — |
| | | | AC 240 | 30 | 15 | — |
| **S125-SF** | 15～125 | 2,3,4 | AC 415 | 30 | 15 | — |
| | | | AC 240 | 30 | 15 | — |
| **PS125-NF** | 15～125 | 2,3,4 | AC 690 | 6 | 6 | — |
| | | | AC 415 | 36 | 36 | — |
| | | | AC 240 | 50 | 50 | — |
| **PS125-NE** | 40～125 | 3,4 | AC 690 | 6 | 6 | 1.6 (0.4s) |
| | | | AC 415 | 36 | 36 | 1.6 (0.4s) |
| | | | AC 240 | 50 | 50 | 1.6 (0.4s) |
| **PS125-PF** | 15～125 | 2,3,4 | AC 690 | 6 | 6 | — |
| | | | AC 415 | 70 | 50 | — |
| | | | AC 240 | 85 | 85 | — |
| **PS125-PE** | 40～125 | 3,4 | AC 690 | 6 | 6 | 1.6 (0.4s) |
| | | | AC 415 | 70 | 50 | 1.6 (0.4s) |
| | | | AC 240 | 85 | 85 | 1.6 (0.4s) |
| **PS250-NE** | 125～250 | 3,4 | AC 690 | 6 | 6 | 2.5 (0.4s) |
| | | | AC 415 | 36 | 36 | 2.5 (0.4s) |
| | | | AC 240 | 50 | 50 | 2.5 (0.4s) |
| **S250-SF** | 125～250 | 3,4 | AC 415 | 40 | 20 | — |
| **PS250-PF** | 125～250 | 3,4 | AC 690 | 6 | 6 | — |
| | | | AC 415 | 70 | 50 | — |
| | | | AC 240 | 85 | 85 | — |
| **PS250-PE** | 125～250 | 3,4 | AC 690 | 6 | 6 | 2.5 (0.4s) |
| | | | AC 415 | 70 | 50 | 2.5 (0.4s) |
| | | | AC 240 | 85 | 85 | 2.5 (0.4s) |
| **PS400-CF** | 225～400 | 3,4 | AC 690 | 7 | 7 | — |
| | | | AC 415 | 36 | 36 | — |
| | | | AC 240 | 50 | 50 | — |
| **PS400-NF** | 225～400 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 50 | 50 | — |
| | | | AC 240 | 85 | 85 | — |
| **PS400-NE** | 125～400 | 3,4 | AC 690 | 12 | 12 | 5 (0.4s) |
| | | | AC 415 | 50 | 50 | 5 (0.4s) |
| | | | AC 240 | 85 | 85 | 5 (0.4s) |
| **PS400-GF** | 225～400 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 70 | 70 | — |
| | | | AC 240 | 100 | 100 | — |
| **PS400-GE** | 125～400 | 3,4 | AC 690 | 12 | 12 | 5 (0.4s) |
| | | | AC 415 | 70 | 70 | 5 (0.4s) |
| | | | AC 240 | 100 | 100 | 5 (0.4s) |
| **S630-CF** | 500～630 | 3,4 | AC 415 | 36 | 36 | — |
| | | | AC 240 | 50 | 50 | — |
| **PS630-CF** | 500～600 | 3,4 | AC 690 | 7 | 7 | — |
| | | | AC 415 | 36 | 36 | — |
| | | | AC 240 | 50 | 50 | — |
| **S630-NF** | 500～630 | 3,4 | AC 415 | 50 | 50 | — |
| | | | AC 240 | 85 | 85 | — |
| **S630-NE** | 250～630 | 3,4 | AC 415 | 50 | 50 | 10 (0.3s) |
| | | | AC 240 | 85 | 85 | 10 (0.3s) |
| **S630-NEH** | 250～630 | 3,4 | AC 415 | 50 | 50 | 10 (0.3s) |
| | | | AC 240 | 85 | 85 | 10 (0.3s) |
| **PS630-NF** | 500～600 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 50 | 50 | — |
| | | | AC 240 | 85 | 85 | — |
| **PS630-NE** | 250～630 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 50 | 50 | — |
| | | | AC 240 | 85 | 85 | — |
| **PS630-GF** | 500～600 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 70 | 70 | — |
| | | | AC 240 | 100 | 100 | — |
| **PS630-GE** | 250～630 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 70 | 70 | — |
| | | | AC 240 | 100 | 100 | — |
| **S800-CF** | 700, 800 | 3,4 | AC 415 | 36 | 36 | — |
| | | | AC 240 | 50 | 50 | — |
| **S800-NF** | 700, 800 | 3,4 | AC 415 | 50 | 50 | — |
| | | | AC 240 | 85 | 85 | — |
| **S800-NE** | 350～800 | 3,4 | AC 415 | 50 | 50 | 10 (0.3s) |
| | | | AC 240 | 85 | 85 | 10 (0.3s) |
| **S800-NEH** | 350～800 | 3,4 | AC 415 | 50 | 50 | 10 (0.3s) |
| | | | AC 240 | 85 | 85 | 10 (0.3s) |
| **S800-RF** | 700, 800 | 3,4 | AC 415 | 70 | 50 | — |
| | | | AC 240 | 100 | 75 | — |
| **S800-RE** | 350～800 | 3,4 | AC 415 | 70 | 50 | 10 (0.3s) |
| | | | AC 240 | 100 | 75 | 10 (0.3s) |
| **S800-REH** | 350～800 | 3,4 | AC 415 | 70 | 50 | 10 (0.3s) |
| | | | AC 240 | 100 | 75 | 10 (0.3s) |

| Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities (kA) (sym.) | | Rated short time withstand current (kA) |
|---|---|---|---|---|---|---|
| | | | | $I_{cu}$ | $I_{cs}$ | $I_{cw}$ |
| **S1000-CE** | 400～1000 | 3,4 | AC 415 | 65 | 50 | — |
| | | | AC 240 | 100 | 75 | — |
| **S1250-NE** | 500～1250 | 3,4 | AC 415 | 70 | 50 | 15 (0.3s) |
| | | | AC 240 | 100 | 75 | 15 (0.3s) |
| **S1250-NEH** | 500～1250 | 3,4 | AC 415 | 70 | 50 | 15 (0.3s) |
| | | | AC 240 | 100 | 75 | 15 (0.3s) |
| **S1250-GE** | 500～1250 | 3,4 | AC 415 | 85 | 65 | 15 (0.3s) |
| | | | AC 240 | 125 | 94 | 15 (0.3s) |
| **S1600-NE** | 700～1600 | 3,4 | AC 415 | 85 | 65 | 20 (0.3s) |
| | | | AC 240 | 125 | 94 | 20 (0.3s) |
| **S1600-NEH** | 700～1600 | 3,4 | AC 415 | 85 | 65 | 20 (0.3s) |
| | | | AC 240 | 125 | 94 | 20 (0.3s) |
| **H100-NF** | 15～100 | 3,4 | AC 415 | 125 | 85 | — |
| | | | AC 240 | 150 | 150 | — |
| **H125-NF** | 125 | 3,4 | AC 415 | 125 | 85 | — |
| | | | AC 240 | 150 | 150 | — |
| **H225-NF** | 125～225 | 3,4 | AC 415 | 125 | 85 | — |
| | | | AC 240 | 150 | 150 | — |
| **H225-NE** | 125～225 | 3,4 | AC 415 | 85 | 85 | — |
| | | | AC 240 | 150 | 150 | — |
| **H250-NF** | 250 | 3,4 | AC 415 | 125 | 85 | — |
| | | | AC 240 | 150 | 150 | — |
| **PH400-CF** | 225～400 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 110 | 110 | — |
| | | | AC 240 | 125 | 125 | — |
| **PH400-CE** | 125～400 | 3,4 | AC 690 | 12 | 12 | 5 (0.4s) |
| | | | AC 415 | 110 | 110 | 5 (0.4s) |
| | | | AC 240 | 125 | 125 | 5 (0.4s) |
| **H400-NE** | 125～400 | 3,4 | AC 415 | 125 | 85 | 5 (0.3s) |
| | | | AC 240 | 150 | 150 | 5 (0.3s) |
| **PH630-CF** | 500～600 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 110 | 110 | — |
| | | | AC 240 | 125 | 125 | — |
| **PH630-CE** | 250～630 | 3,4 | AC 690 | 12 | 12 | — |
| | | | AC 415 | 110 | 110 | — |
| | | | AC 240 | 125 | 125 | — |
| **H630-NE** | 250～630 | 3 | AC 415 | 125 | 94 | 10 (0.3s) |
| | | | AC 240 | 150 | 150 | 10 (0.3s) |
| **H800-NE** | 350～800 | 3 | AC 415 | 125 | 94 | 10 (0.3s) |
| | | | AC 240 | 150 | 150 | 10 (0.3s) |
| **L100-NF** | 15～100 | 3,4 | AC 415 | 200 | 150 | — |
| | | | AC 240 | 200 | 150 | — |
| **L125-NF** | 125 | 3,4 | AC 415 | 200 | 150 | — |
| | | | AC 240 | 200 | 150 | — |
| **L225-NF** | 125～225 | 3,4 | AC 415 | 200 | 150 | — |
| | | | AC 240 | 200 | 150 | — |
| **L250-NF** | 250 | 3,4 | AC 415 | 200 | 150 | — |
| | | | AC 240 | 200 | 150 | — |
| **L400-NE** | 125～400 | 3,4 | AC 415 | 200 | 150 | 5 (0.3s) |
| | | | AC 240 | 200 | 150 | 5 (0.3s) |
| **L630-NE** | 250～630 | 3 | AC 415 | 200 | 150 | 10 (0.3s) |
| | | | AC 240 | 200 | 150 | 10 (0.3s) |
| **L800-NE** | 350～800 | 3 | AC 415 | 200 | 150 | 10 (0.3s) |
| | | | AC 240 | 200 | 150 | 10 (0.3s) |
| **TB-5D** | 10 | 2 | AC 240 | 2.5 | — | — |
| | 15～50 | | AC 240 | 5 | — | — |
| **TB-5P** | 10 | 2 | AC 240 | 2.5 | — | — |
| | 15～50 | | AC 240 | 5 | — | — |
| **TL-1000NE** | 500～1000 | 3,4 | AC 440 | 125 | 65 | — |
| | | | AC 240 | 150 | 113 | — |
| **TL-1200NE** | 600～1200 | 3,4 | AC 440 | 125 | 65 | — |
| | | | AC 240 | 150 | 113 | — |

**Note:** Specify CCC certified product when ordering.

# 22 List of breakers for CCC approved and rated breaking capacities

## Overseas Circuit Breakers

| Type | Rated current (A) | Poles | Rated voltage (V) | Rated breaking capacities (kA) (sym.) | | Rated short time withstand current (kA) |
|---|---|---|---|---|---|---|
| | | | | $I_{cu}$ | $I_{cs}$ | $I_{cw}$ |
| **E250-SJ** | 100～250 | 3,4 | AC 415 | 25 | 19 | — |
| **S160-SCJ** | 25～160 | 3,4 | AC 415 | 25 | 13 | — |
| **S160-SJ** | 25～160 | 3,4 | AC 415 | 40 | 20 | — |
| **S800-NJ** | 630～800 | 3,4 | AC 415 | 50 | 50 | — |
| | | | AC 240 | 85 | 85 | — |

**Note:** Specify CCC certified product when ordering.


# 3 Selection


1 Characteristics and Performance ····· 3-2
2 Current-carrying capacity depending on ambient temperature and cable size ··· 3-3
3 Application of circuit breakers and earth leakage circuit breakers based on transformer capacity ····· 3-4
4 Application of circuit breakers based on breaking capacity ····· 3-6
5 Application of earth leakage circuit breakers based on breaking capacity ····· 3-7
6 Selection of earth leakage circuit breakers for the purpose of protection ····· 3-8
7 Selection of circuit breakers and earth leakage circuit breakers for motor circuit main lines ··· 3-9
8 Selection of breakers for protection of motor branch circuits ····· 3-10
9 Selection of earth leakage circuit breakers for motor branch circuits ····· 3-14
10 Selection of circuit breakers for lamps and electric heating circuits ····· 3-16
11 Selection of earth leakage circuit breakers for lamps and electric heating circuits ··· 3-17
12 Selection of motor protection breakers (for direct start) ····· 3-18
13 Selection of earth leakage circuit breakers for motor protection (for direct start) ··· 3-19
14 Selection of circuit breakers for transformer primary side ····· 3-20
15 Selection of circuit breakers for resistance welding machine circuits ····· 3-21
16 Selection of circuit breakers for capacitor circuits ····· 3-21
17 Selection of circuit breakers for inverter circuits ····· 3-21
18 Selection of circuit breakers and earth leakage circuit breakers for selectivity coordination ····· 3-22
19 Combination of breakers for cascade breaking ····· 3-24
20 Selection of rated operational voltage and number of poles ····· 3-29
21 Selection of single phase 3-wire circuit breakers with neutral phase open protection ··· 3-30
22 Application of single phase 3-wire circuit breakers/earth leakage circuit breakers with neutral phase open protection to parallel circuits ····· 3-31
23 Selection of single phase 3-wire earth leakage circuit breakers with neutral phase open protection for photovoltaic power generation systems ··· 3-32

## Overcurrent and Operating Time

The operating characteristic curves show a graph of overcurrent and the corresponding operating time. The device operates within the range of the maximum and minimum curves.

Also, the operating characteristics are based on the operating time at 125% and 200% of the rated current specified in Appendix 2, JIS C 8201-2-1.




Thermal-Magnetic Type Operating Characteristic Curve

**Trip Operating Characteristics**

| Rated current $I_n$ (A) | Tripping Time (min) | |
|---|---|---|
| | Rated current ×125% | Rated current × 200% |
| $I_n \leq 30$ | 60 or less | 2 or less |
| $30 < I_n \leq 50$ | 60 or less | 4 or less |
| $50 < I_n \leq 100$ | 120 or less | 6 or less |
| $100 < I_n \leq 225$ | 120 or less | 8 or less |
| $225 < I_n \leq 400$ | 120 or less | 10 or less |
| $400 < I_n \leq 600$ | 120 or less | 12 or less |
| $600 < I_n \leq 800$ | 120 or less | 14 or less |
| $800 < I_n \leq 1000$ | 120 or less | 16 or less |
| $1000 < I_n \leq 1200$ | 120 or less | 18 or less |
| $1200 < I_n \leq 1600$ | 120 or less | 20 or less |
| $1600 < I_n \leq 2000$ | 120 or less | 22 or less |
| $2000 < I_n$ | 120 or less | 24 or less |

## Short circuit breaking performance

Short circuit breaking performance refers to the ability to break a short-circuit current that flows when a short-circuit accident occurs. It is indicated by two types of rated breaking capacity (kA), $I_{cu}$ and $I_{cs}$.

$I_{cu}$ : It indicates the ability to break directly under the breaker, and is called the rated ultimate short-circuit breaking capacity. In terms of breaking operation duty, it must have twice the breaking performance of O-t-CO.

$I_{cs}$ : It indicates the ability to break at the wiring end of the circuit breaker load, and is called the rated service short-circuit breaking capacity. In terms of breaking operation duty, it must have three times the breaking performance of O-t-CO-t-CO.

# 2 Current-carrying capacity depending on ambient temperature and cable size

## Correction of conduction current depending on ambient temperature


For rated current of thermal-magnetic type and hydraulic-magnetic circuit breakers, electrical adjustment is performed at a calibrated temperature of 40˚C as specified by JIS standards. And, when the ambient temperature of the circuit breaker installation location is other than 40˚C, the operating characteristics will change. Therefore, it is necessary to correct the load current based on the ambient compensating curve.

**Thermal-Magnetic Type Circuit Breakers** : If the ambient temperature becomes higher than the calibrated temperature, the trip current decreases, and the circuit breaker will trip even when the rated current flows. Therefore, it is necessary to reduce the load current in accordance with the ambient compensating curve so that the circuit breaker does not trip. If the ambient temperature becomes lower than the calibrated temperature, the circuit breaker can be used up to the load current corrected by the ambient compensating curve, but select a circuit breaker with a margin of error in consideration of fluctuations in the power supply voltage and load current.


**Hydraulic-Magnetic Type Circuit Breakers** : The trip current does not vary depending on the ambient temperature, but the tripping time will change.

**Electronic Circuit Breakers** : The trip current and tripping time do not vary depending on the ambient temperature. However, if the ambient temperature rises above the calibrated temperature, it may affect the service life of the electronic components.

Thermal-magnetic type temperature correction curve




Hydraulic-magnetic type temperature correction curve




## Precautions when using heat-resistant wires with thermal-magnetic circuit breakers

Appendix 2 of the JIS standard defines the test copper conductor according to the rated current for the circuit breaker trip test and temperature rise test as shown in the table below. If a conductor that is thinner than this test copper conductor is used, the terminal temperature of the circuit breaker may rise or the circuit breaker may operate with a current lower than the rated current.

Therefore, when using a thin conductor such as a heat-resistant wire, it is necessary to select the circuit breaker rated current with a margin of safety in terms of the load current.

**Test copper conductor**

| Circuit breaker rated current (A) | Thickness of 600 V Vinyl insulated wire ($mm^2$) |
|---|---|
| 15 or less | ø 1.6mm |
| 20 | ø 2mm |
| 30 | 5.5 |
| 40 | 8 |
| 50 | 14 |
| 60 | 14 |
| 75 | 22 |
| 100 | 38 |
| 125 | 60 |
| 150 | 60 |
| 175 | 100 |
| 200 | 100 |
| 225 | 150 |
| 250 | 150 |
| 300 | 200 |
| 350 | 250 |
| 400 | 2×100 |
| 500 | 2×150 |
| 600 | 2×200 |

The table below shows the size of the test copper bars. (Reference)

**Test copper bars**

| Circuit breaker rated current (A) | Copper strip | |
|---|---|---|
| | Number | Dimensions mm |
| 500 | 2 | 30 × 5 |
| 600 | 2 | 40 × 5 |
| 800 | 2 | 50 × 5 |
| 1000 | 2 | 60 × 5 |
| 1250 | 2 | 80 × 5 |
| 1600 | 2 | 50 × 10 |
| 2000 | 2 | 75 × 10 |
| 2500 | 2 | 100 × 10 |
| 3000 | 2 | 150 × 10 |

## 3 Application of circuit breakers and earth leakage circuit breakers based on transformer capacity

The graph below is a table to calculate the short-circuit current from the capacity of the transformer and the thickness and length of the wire, and simply select a circuit breaker/earth leakage circuit breaker that satisfies the breaking capacity.

**How to read the graph**


(1) Select the transformer capacity (kVA) on the vertical axis.
(2) Select the length (m) of the wire from the transformer to the circuit breaker on the horizontal axis.
(3) The intersection of (1) and (2) shows the circuit breaker that can be applied.

The breaking capacity is calculated based on the symmetrical value (sym.).
The calculation conditions are based on the calculation of short-circuit current on page 9-10 onward, but the wire is single core, closed (50 Hz).

**Example**

| | |
|---|---|
| Voltage 3-phase | 420 V |
| Transformer capacity | 75kVA |
| Wire thickness | 14mm² |
| Wire length | 20m |


In this case, based on the graph below, the intersection is A, and the applicable circuit breakers are PS50-NF or PZS50-NF.





### ■ In the case of a 3-phase circuit

Secondary voltage 420V AC


● 50A・60A Frame — Wire thickness 14mm²





● 400A Frame — Wire thickness 325mm²





● 100A・125A Frame — Wire thickness 38mm²





● 630A・800A Frame — 1500A Busduct




● 225A・250A Frame — Wire thickness 100mm²





● 1000A・1250A Frame — 1500A Busduct




## ■ In the case of a 3-phase circuit

Secondary voltage 210V AC


● 50A・60A Frame — Wire thickness 14mm²





● 100A・125A Frame — Wire thickness 38mm²





● 225A・250A Frame — Wire thickness 100mm²




● 400A Frame — Wire thickness 325mm²





● 630A・800A Frame — 1500A Busduct





## ■ In the case of a single-phase 3-wire circuit

Between external cables 210V AC


● 30A Frame — Wire thickness 8mm²





● 50A・60A Frame — Wire thickness 14mm²





● 100A・125A Frame — Wire thickness 38mm²




● 225A・250A Frame — Wire thickness 100mm²




● 400A Frame — Wire thickness 325mm²



## 240V AC

| Transformer capacity kVA | 20 or less | 30 | 50 | 75 | 100 | 150 | 200 | 300 | 500 | 750 | 1000 | 1500 | 2000 | 3000 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Percent impedance of the transformer % | 2.5 | 2.5 | 2.5 | 2.85 | 2.9 | 3.1 | 3.1 | 3.5 | 4.0 | 4.8 | 5.3 | 6.1 | 6.1 | 6.1 |

| Circuit breaker breaking capacity kA sym. | 2.5 | 7.5 | 15 | 30 | 35 | 50 | 85 | 100 | 125 | 130 | 150 | 200 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 30A Frame | PE30-NF | PS30-NF | | | | | | | | | | |
| 50A | | PE50-NF | PS50-NF | | S50-SF | PS50-PF | | | | | | |
| 60A | | PE60-NF | | PS60-NF | | | | | | | | |
| 100/125A | | | | PE125-NF | S125-SF, PS125-NF | PS125-PF | | | H100-NF, H125-NF | | | L100-NF, L125-NF |
| 225/250A | | | | E250-SF | S250-SF, PS250PF, PS250-PE | | | | H225-NF, H250-NF | | | L225-NF, L250-NF |
| 400A | | | | E400-NF | PS400-CF | PS400-NF<br>PS400-NE | PS400-GF<br>PS400-GE | PH400-CF<br>PH400-CE | H400-NE | | | L400-NE |
| 600/630A | | | | | S630-CF<br>PS630-CF | S630-NF<br>S630-NE<br>PS630-NF<br>PS630-NE | PS630-GF<br>PS630-GE | PH630-CF<br>PH630-CE | H630-NE | | | L630-NE |
| 800A | | | | | S800-CF | S800-NF<br>S800-NE | S800-RF<br>S800-RE | S800-PF<br>S800-PE | H800-NE | | | L800-NE |
| 1000A | | | | | | | S1000-CE | S1250-GE | TL-1000NE | | | |
| 1200A | | | | | | | S1250-NE | S1250-GE | TL-1200NE | | | |
| 1600A | | | | | | | S1600-NE | | | | | |
| 2000A | | | | | | | XS2000NE | | | | | |
| 2500A | | | | | | | XS2500NE | | | | | |
| 3200A | | | | | | | XS3200NE | | | | | |

1. The average value was used for the percent impedance of the transformer.
2. The ratio between the transformer and the breaking capacity assumes a short-circuit directly under the secondary voltage of 240V for a 3-phase transformer.

## 415V AC

| Transformer capacity kVA | 30 or less | 50 | 75<br>100 | 150 | 200 | 300 | 500 | 750 | 1000 | 1500 | 2000 | 3000 | 4000—5000 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Percent impedance of the transformer % | 2.5 | 2.5 | 2.85 | 3.1 | 3.1 | 3.5 | 4.0 | 4.8 | 5.3 | 6.1 | 6.1 | 6.1 | 6.1 |

| Circuit breaker breaking capacity kA sym. | 2.5 | 7.5 | 10 | 25 | 30 | 36 | 50 | 65 | 70 | 85 | 100 | 110 | 125 | 150 | 200 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 30A Frame | PS30-NF | | | | | | | | | | | | | | |
| 50A | PE50-NF | PS50-NF | | | S50-SF | | | PS50-PF | | | | | | | |
| 60A | PE60-NF | | PS60-NF | | | | | | | | | | | | |
| 100/125A | | PE125-NF | | | S125-SF | PS125-NF<br>PS125-NE | S100-GF<br>S125-GF | PS125-PF<br>PS125-PE | | H100-NF<br>H125-NF | | | L100-NF<br>L125-NF | | |
| 225/250A | | | | E250-SF | PS250-NE | | PS250-PF<br>PS250-PE | | | H225-NF<br>H250-NF | | | L225-NF<br>L250-NF | | |
| 400A | | | | E400-NF | PS400-CF | PS400-NF<br>PS400-NE | PS400-GF<br>PS400-GE | | PH400-CF<br>PH400-CE | H400-NE | | | L400-NE | | |
| 600/630A | | | | | S630-CF<br>PS630-CF | S630-NF<br>PS630-NF<br>S630-NE<br>PS630-NE | PS630-GF<br>PS630-GE | | PH630-CF<br>PH630-CE | H630-NE | | | L630-NE | | |
| 800A | | | | | S800-CF | S800-NF<br>S800-NE | S800-RF<br>S800-RE | | S800-PF<br>S800-PE | H800-NE | | | L800-NE | | |
| 1000A | | | | | | | S1000-CE | | S1250-GE | | TL-1000NE | | | | |
| 1200A | | | | | | | S1250-NE | | S1250-GE | | TL-1200NE | | | | |
| 1600A | | | | | | | S1600-NE | | | | | | | | |
| 2000A | | | | | | | XS2000NE | | | | | | | | |
| 2500A | | | | | | | XS2500NE | | | | | | | | |
| 3200A | | | | | | | XS3200NE | | | | | | | | |

1. The average value was used for the percent impedance of the transformer.
2. The ratio between the transformer and the breaking capacity assumes a short-circuit directly under the secondary voltage of 415V for a 3-phase transformer.

## 240V AC

| Transformer capacity kVA | 20 or less | 30 | 50 | 75 | 100 | 150 | 200 | 300 | 500 | 750 | 1000 | 1500 | 2000 | 3000 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Percent impedance of the transformer % | 2.5 | 2.5 | 2.5 | 2.85 | 2.9 | 3.1 | 3.1 | 3.5 | 4.0 | 4.8 | 5.3 | 6.1 | 6.1 | 6.1 |
| Circuit breaker breaking capacity kA sym. | 2.5 | | | 7.5 | | 15 | | 30 | 35 | | 50 | 85 | 100 | 130 |
| 30A Frame | PZE30-NF | PZS30-NF | | | | | | | | | | | | |
| 50A | | PZE50-NF | | PZS50-NF | | | | ZS50-SF | | | | | | |
| 60A | | PZE60-NF | | | | PZS60-NF | | | | | | | | |
| 100/125A | | | | | | PZE125-NF | | | ZS125-SF | | ZS100-GF ZS125-GF | | | |
| 225/250A | | | | | | ZE250-SF | | | ZS250-SF, ZS225/250-GF | | | | | |
| 400A | | | | | | ZE400-NF | | | | | ZS400-NF | ZS400-GF | | |
| 600/630A | | | | | | | | | | ZS630-CF | ZS630-NF | | | |
| 800A | | | | | | | | | | ZS800-CF | ZS800-NF | | | |

1. The average value was used for the percent impedance of the transformer.
2. The ratio between the transformer and the breaking capacity assumes a short-circuit directly under the secondary voltage of 240V for a 3-phase transformer.

## 415V AC

| Transformer capacity kVA | 30 or less | 50 | 75 100 | 150 | 200 | 300 | 500 | 750 | 1000 | 1500 | 2000 | 3000 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Percent impedance of the transformer % | 2.5 | 2.5 | 2.85 | 3.1 | 3.1 | 3.5 | 4.0 | 4.8 | 5.3 | 6.1 | 6.1 | 6.1 |
| Circuit breaker breaking capacity kA sym. | 2.5 | | 7.5 | | 10 | | | 25 | 30 | 36 40 | 50 | 65 70 85 |
| 30A Frame | PZS30-NF | | | | | | | | | | | |
| 50A | PZE50-NF | | PZS50-NF | | | | ZS50-SF | | | | | |
| 60A | PZE60-NF | | | PZS60-NF | | | | | | | | |
| 100/125A | | | | PZE125-NF | | | ZS125-SF | | | ZS100/125-GF | | |
| 225/250A | | | | | | ZE250-SF | | | ZS250-SF | ZS225/250-GF | | |
| 400A | | | | | | ZE400-NF | | | | ZS400-NF | ZS400-GF | |
| 600/630A | | | | | | | | | ZS630-CF | ZS630-NF | | |
| 800A | | | | | | | | | ZS800-CF | ZS800-NF | | |

1. The average value was used for the percent impedance of the transformer.
2. The ratio between the transformer and the breaking capacity assumes a short-circuit directly under the secondary voltage of 415V for a 3-phase transformer.

# 6 Selection of earth leakage circuit breakers for the purpose of protection


If the purpose of protection, load equipment, and installation location, etc. are not considered when selecting the earth leakage circuit breaker, an electric shock accident may occur or unnecessary trips may occur, which may hinder the smooth progress of work at the site.

## Selection for the purpose of protection


<table>
<tr><th>Purpose</th><th>Type</th><th>Sensitivity current</th><th>Usage conditions</th></tr>
<tr><td rowspan="2">For electric shock prevention</td><td>High-sensitivity instantaneous tripping type</td><td>15mA<br>30mA</td><td>Cases that specify the use of high-sensitivity instantaneous tripping type in the technical standards and interior wiring regulations of electrical equipment.<br>Cases subject to occupational safety and health regulations.</td></tr>
<tr><td>Medium sensitivity instantaneous tripping type</td><td>100mA<br>200mA<br>500mA</td><td>When the circuit of the equipment is securely grounded to prevent electric shock in the event of earth leakage.<br>In this case, the grounding resistance value of the equipment should be as follows.
<table>
<tr><th rowspan="2">Sensitivity current (mA)</th><th colspan="2">Allowable contact voltage</th></tr>
<tr><th>25 V</th><th>50 V</th></tr>
<tr><td>100</td><td>250Ω or less</td><td>500Ω or less</td></tr>
<tr><td>200</td><td>125Ω or less</td><td>250Ω or less</td></tr>
<tr><td>500</td><td>50Ω or less</td><td>100Ω or less</td></tr>
</table>
⇩ ⇩<br>
A state in which the user’ s body is significantly wet. A state in which the user's body is in constant contact with metallic electrical equipment or a part of it due to its structure. (Type 2 contact voltage)<br>
In cases other than types 1 and 2, there is a high risk if a contact voltage is applied when the user's body is in a normal state. (Type 3 contact state)</td></tr>
<tr><td>Earth leakage fire / ground fault arc For protection</td><td>Medium sensitivity time delay tripping type<br>.<br>Medium sensitivity instantaneous tripping type</td><td>100mA<br>200mA<br>500mA</td><td>When coordinating ground fault protection between the main line and branch circuit against ground fault accidents.</td></tr>
</table>

## Ground fault protection cooperation

When selective protection is coordinated against ground faults, the time delay tripping type is used for the main line and the instantaneous tripping type is used for the branch circuit. (Figure b)
If the time delay tripping type is not used for the main line, depending on the magnitude of the ground fault current due to the ground fault in one branch circuit, the earth leakage circuit breakers for the main line and the branch circuit may trip at the same time, and power failure will occur in other non-faulty circuits. (Figure a) shows the operating characteristic curve in this case.




（Figure a）



（Figure b）


## Earth leakage trip characteristics




• The non-operating time range is an example for ZS125-SF type.

## 7 Selection of circuit breakers and earth leakage circuit breakers for motor circuit main lines

To select the circuit breaker for the main line of circuits that include loads such as electric motors, follow the procedure below.

| Load type | Conditions | Allowable current of wire $I_W$ | Rated capacity of circuit breaker $I_N$ |
|---|---|---|---|
|  | $\Sigma I_M \leq \Sigma I_L$ | $I_W \geq \Sigma I_M + \Sigma I_L$ | $I_N \leq 3 \Sigma I_M + \Sigma I_L$ or $I_N \leq 2.5 I_W$ whichever is smaller. However, when $I_W > 100$ A and does not correspond to the standard rated current value of the circuit breaker, the latest higher rating may be used. |
| | $50A \geq \Sigma I_M > \Sigma I_L$ | $I_W \geq 1.25 \Sigma I_M + \Sigma I_L$ | |
| | $50A < \Sigma I_M > \Sigma I_L$ | $I_W \geq 1.1 \Sigma I_M + \Sigma I_L$ | |

$I_M$ : Load current of electric motor, etc.
$I_L$ : Load current other than electric motor, etc.

### Rated current (A) of circuit breakers/earth leakage circuit breakers for main lines of 200/220V AC 3-phase induction motors

| Total motor kW (kW or less) | Max. operational current (A or less) | Largest motor (kW) : Motor capacity (A) : Full-load current | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 |
| | | 4.8 | 8 | 11.1 | 17.4 | 26 | 34 | 48 | 65 | 79 | 93 | 124 | 152 | 190 | 230 | 310 | 360 | 440 | 500 |
| 3 | 15 | 20 | 30 | | | | | | | | | | | | | | | | |
| 4.5 | 20 | 30 | | | 50 | | | | | | | | | | | | | | |
| 6.3 | 30 | 40 | | | 50 | 60 | | | | | | | | | | | | | |
| 8.2 | 40 | 50 | | | 60 | 75 | 100 | | | | | | | | | | | | |
| 12 | 50 | 60 | | | 75 | | 100 | 125 | | | | | | | | | | | |
| 15.7 | 75 | 100 | | | | | | 125 | 150 | | | | | | | | | | |
| 19.5 | 90 | 100 | | | | | | 125 | | 150 | | | | | | | | | |
| 23.2 | 100 | 125 | | | | | | | 150 | | 200 | | | | | | | | |
| 30 | 125 | 150 | | | | | | | | | 200 | | | | | | | | |
| 37.5 | 150 | 200 | | | | | | | | | | 225 | | | | | | | |
| 45 | 175 | 200 | | | | | | | | | | 225 | 300 | | | | | | |
| 52.5 | 200 | 225 | | | | | | | | | | 225 | 300 | 400 | | | | | |
| 63.7 | 250 | 300 | | | | | | | | | | | 400 | | 500 | | | | |
| 75 | 300 | 400 | | | | | | | | | | | | | 500 | | | | |
| 86.2 | 350 | 400 | | | | | | | | | | | | | 500 | 600 | | | |
| 97.5 | 400 | 500 | | | | | | | | | | | | | | 600 | 700 | | |
| 112.5 | 450 | 500 | | | | | | | | | | | | | | 700 | | | |
| 125 | 500 | 600 | | | | | | | | | | | | | | 700 | | 1000 | |
| 150 | 600 | 700 | | | | | | | | | | | | | | | 800 | 1000 | |
| 175 | 700 | 800 | | | | | | | | | | | | | | | | 1000 | |
| 200 | 800 | 1000 | | | | | | | | | | | | | | | | | |

### Rated current (A) of circuit breakers/earth leakage circuit breakers for main lines of 400/440V AC 3-phase induction motors

| Total motor kW (kW or less) | Max. operational current (A or less) | Largest motor (kW) : Motor capacity (A) : Full-load current | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 | 11 | 15 | 18.5 | 22 | 30 | 37 | 45 | 55 | 75 | 90 | 110 | 132 |
| | | 2.4 | 4 | 5.5 | 8.7 | 13 | 17 | 24 | 32 | 39 | 46 | 62 | 76 | 95 | 115 | 155 | 180 | 220 | 250 |
| 3 | 7.5 | 15 | | | | | | | | | | | | | | | | | |
| 4.5 | 10 | 15 | | | 30 | | | | | | | | | | | | | | |
| 6.3 | 15 | 20 | | | 30 | 40 | | | | | | | | | | | | | |
| 8.2 | 20 | 30 | | | | 40 | 50 | | | | | | | | | | | | |
| 12 | 25 | 30 | | | | 40 | 50 | 75 | | | | | | | | | | | |
| 15.7 | 38 | 50 | | | | | 60 | 75 | 100 | | | | | | | | | | |
| 19.5 | 45 | 50 | | | | | 60 | 75 | 100 | | | | | | | | | | |
| 23.2 | 50 | 60 | | | | | 75 | | 100 | | 100 | | | | | | | | |
| 30 | 63 | 75 | | | | | | 100 | | | 100 | | | | | | | | |
| 37.5 | 75 | 100 | | | | | | | | 125 | | | | | | | | | |
| 45 | 88 | 100 | | | | | | | | 125 | | | 150 | | | | | | |
| 52.5 | 100 | 125 | | | | | | | | | | | 150 | 200 | | | | | |
| 63.7 | 125 | 150 | | | | | | | | | | | | 200 | 225 | | | | |
| 75 | 150 | 200 | | | | | | | | | | | | | 225 | | | | |
| 86.2 | 175 | 200 | | | | | | | | | | | | | 225 | 300 | | | |
| 97.5 | 200 | 225 | | | | | | | | | | | | | 225 | 300 | 400 | | |
| 112.5/125 | 225/250 | 300 | | | | | | | | | | | | | | 400 | | 500 | |
| 150/175 | 300/350 | 400 | | | | | | | | | | | | | | | | 500 | |
| 200 | 400 | 500 | | | | | | | | | | | | | | | | | |
| 250 | 500 | 600 | | | | | | | | | | | | | | | | | |
| 300/350 | 600/700 | 800 | | | | | | | | | | | | | | | | | |
| 400/450 | 800/900 | 1000 | | | | | | | | | | | | | | | | | |
| 500 | 1000 | 1200 | | | | | | | | | | | | | | | | | |

Remarks :
1. The total load current of the motor is based on the specified current of the motor in Document 3-7-3 of the interior wiring regulations.
2. The starting condition of the motor is selected to be within 10 seconds at 600% of the total load current, and the inrush current is selected to be within 1700% of the total load current.
3. The value of the largest motor (kW) can also be applied to the total capacity of the motors that start at the same time.

# 8 Selection of breakers for protection of motor branch circuits

This table assumes that the motor branch circuit is protected against overcurrent by an electromagnetic relay and against short-circuit current by a moulded case circuit breaker.

## For protection of 200/220V AC 3-phase induction motors

| Rated breaking capacity (kA) 230V AC $I_{cu}$ (sym) | | | 2.5 | | 7.5 | | 15 | | 30 | | 35 | | 50 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Output (kW) | Full-load current(A) | Max. starting current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) |
| 0.75 | 3.71 | 28.4 | **PE30-NF** | 15 | **PS30-NF** | 15 | | | | | | | **PS125-NF** | 15 |
| 1.5 | 6.74 | 56 | **PE30-NF** | 15 | **PS30-NF** | 15 | **PS50-NF** | 15 | | | | | **PS125-NF** | 20 |
| 2.2 | 10.4 | 96 | **PE30-NF** | 30 | **PS30-NF** | 30 | **PS50-NF** | 30 | | | | | **PS125-NF** | 30 ※ |
| 3.7 | 15.6 | 139 | | | **PE50-NF** | 40 | **PS50-NF** | 40 | | | | | **PS125-NF** | 40 |
| 5.5 | 22.8 | 203 | | | **PE60-NF** | 60 | | | **PS60-NF** | 60 | | | **PS125-NF** | 60 |
| 7.5 | 30.2 | 264 | | | | | | | **PE125-NF** | 75 | | | **PS125-NF** | 75 |
| 11 | 44.9 | 380 | | | | | | | **PE125-NF** | 100 | | | **PS125-NF** | 125 ※※ |
| 15 | 60 | 540 | | | | | | | | | **E250-SF** | 125 | | |
| 18.5 | 72 | 668 | | | | | | | | | **E250-SF** | 150 | | |
| 22 | 81.9 | 744 | | | | | | | | | **E250-SF** | 175 | | |
| 30 | 112 | 1090 | | | | | | | | | **E250-SF** | 200 | | |
| 37 | 141 | 1500 | | | | | | | | | **E250-SFH** | 225 ※ | | |
| 45 | 168 | 1780 | | | | | | | | | **E400-NF** | 350 | **PS400-CF** | 350 ⑯ |
| 55 | 211 | 1960 | | | | | | | | | | | **S630-CF** | 500 |
| 75 | 272 | 2080 | | | | | | | | | | | **S630-CF** | 630 |
| 90 | 332 | 2600 | | | | | | | | | | | **S800-CF** | 800 |
| 110 | 380 | 2980 | | | | | | | | | | | | |
| 132 | 450 | 3460 | | | | | | | | | | | | |

## For protection of 400/440V AC 3-phase induction motors

| Rated breaking capacity (kA) 415V AC $I_{cu}$ (sym) | | | 2.5 | | 7.5 | | 10 | | 25 | | 36 | | 40 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Output (kW) | Full-load current(A) | Max. starting current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) |
| 0.75 | 1.9 | 14.2 | **PS30-NF** | 10 | | | | | | | **PS125-NF** | 15 | | |
| 1.5 | 3.4 | 28 | **PS30-NF** | 15 | | | | | | | **PS125-NF** | 15 | | |
| 2.2 | 5.2 | 48 | **PS30-NF** | 15 | **PS50-NF** | 15 | | | | | **PS125-NF** | 20 | | |
| 3.7 | 7.8 | 70 | **PS30-NF** | 20 | **PS50-NF** | 20 | | | | | **PS125-NF** | 30 | | |
| 5.5 | 11.4 | 102 | **PS30-NF** | 30 | **PS50-NF** | 30 | | | | | **PS125-NF** | 40 | | |
| 7.5 | 15.1 | 132 | **PE50-NF** | 40 | **PS50-NF** | 40 | | | | | **PS125-NF** | 40 | | |
| 11 | 22.5 | 190 | **PE60-NF** | 60 | | | **PE125-NF** | 60 | | | **PS125-NF** | 50 | | |
| 15 | 30 | 270 | | | | | **PE125-NF** | 75 | | | **PS125-NF** | 75 | | |
| 18.5 | 36 | 334 | | | | | **PE125-NF** | 100 | | | **PS125-NF** | 100 | | |
| 22 | 41 | 372 | | | | | **PE125-NF** | 125 | | | **PS125-NF** | 125 ※※ | | |
| 30 | 56 | 545 | | | | | | | **E250-SF** | 125 | | | **S250-SF** | 125 |
| 37 | 70.5 | 750 | | | | | | | **E250-SF** | 150 | | | **S250-SF** | 150 |
| 45 | 84 | 890 | | | | | | | **E250-SF** | 175 | | | **S250-SF** | 175 |
| 55 | 105 | 980 | | | | | | | **E250-SF** | 200 | | | **S250-SF** | 200 |
| 75 | 136 | 1040 | | | | | | | **E250-SFH** | 225 | **PS400-CF** | 300 ⑰ | **S250-SFH** | 225 |
| 90 | 166 | 1300 | | | | | | | **E400-NF** | 350 | **PS400-CF** | 350 ⑯ | | |
| 110 | 190 | 1490 | | | | | | | | | **PS400-CF** | 400 ⑯ | | |
| 132 | 225 | 1730 | | | | | | | | | | | | |
| 160 | 273 | 2170 | | | | | | | | | | | | |

Remark 1.
Motor starting conditions
The inrush current is assumed to be as follows:

| Motor output | Inrush current |
|---|---|
| 0.75 ~ 7.5kW | Full-load current x1600% max. |
| 11 ~ 45kW | Full-load current x1700% max. |
| 55 ~ 160kW | Full-load current x1800% max. |

Exceptions:
Note ⑯ : Full-load x 1600% max.
Note ⑰ : Full-load x 1700% max.
When the inrush current exceeds the above values, the breaker may trip.
The starting time is assumed to be 6 seconds max. at the max. starting current.
Exceptions:
Note ※ : 5 seconds max. at the max. starting current. When the max. starting current flows through the breaker for a period of time exceeding the above max. starting time, the breaker may trip.

Remark 2.
The full-load current and the max. starting current are determined with reference to those of highly efficient 3-phase induction motors (4 poles) from individual manufacturers. Please consult us if the full-load current or the max. starting current of your motor is different significantly from the values shown in the table.

Note ※※ : Operates at 500% of rated current for a minimum of 2 seconds and a maximum of 20 seconds.
Does not comply with the following regulations of interior wiring regulations JEAC 8001. Document number 3-7-5
In the case of rated current of 125A or more 6 seconds or more at 500% of rated current.

Remark 3.
- In regard to electronic breakers, it is assumed that the protection characteristic setting dial is set so that the long time delay tripping time is the longest.
- In regard to breakers with the instantaneous trip current being adjustable, it is assumed that the instantaneous trip current is set to the max. value.
- Protective coordination with the motor is analyzed for on the basis of 40℃ cold start characteristics of the breaker.

| 85 | | 100 | | 125 | | 150 | | 200 | | Rated breaking capacity (kA) 230V AC $I_{cu}$ (sym) | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Output (kW) | Full-load current(A) | Max. starting current(A) |
| **PS125-PF** | 15 | | | | | **H100-NF** | 15 | **L100-NF** | 15 | 0.75 | 3.71 | 28.4 |
| **PS125-PF** | 20 | | | | | **H100-NF** | 15 | **L100-NF** | 15 | 1.5 | 6.74 | 56 |
| **PS125-PF** | 30 ※ | | | | | **H100-NF** | 20 | **L100-NF** | 20 | 2.2 | 10.4 | 96 |
| **PS125-PF** | 40 | | | | | **H100-NF** | 30 | **L100-NF** | 30 | 3.7 | 15.6 | 139 |
| **PS125-PF** | 60 | | | | | **H100-NF** | 50 | **L100-NF** | 50 | 5.5 | 22.8 | 203 |
| **PS125-PF** | 75 | | | | | **H100-NF** | 60 | **L100-NF** | 60 | 7.5 | 30.2 | 264 |
| **PS125-PF** | 100 | | | | | **H100-NF** | 100 | **L100-NF** | 100 | 11 | 44.9 | 380 |
| **PS125-PF** | 125 ※※ | | | | | **H125-NF** | 125 | **L125-NF** | 125 | 15 | 60 | 540 |
| **PS250-PF** | 125 | | | | | **H225-NF** | 150 | **L225-NF** | 150 | 18.5 | 72 | 668 |
| **PS250-PF** | 150 | | | | | **H225-NF** | 175 | **L225-NF** | 175 | 22 | 81.9 | 744 |
| **S250-SF** | 200 | | | | | **H225-NF** | 200 | **L225-NF** | 200 | 30 | 112 | 1090 |
| **S250-SFH** | 225 ※ | | | | | **H400-NE** | 250 | **L400-NE** | 250 | 37 | 141 | 1500 |
| **PS400-NEH** | 250 | **PS400-GEH** | 250 | **PH400-CEH** | 250 | **H400-NE** | 300 | **L400-NE** | 300 | 45 | 168 | 1780 |
| **PS400-NEH** | 300 | **PS400-GEH** | 300 | **PH400-CEH** | 300 | **H400-NE** | 350 | **L400-NE** | 350 | 55 | 211 | 1960 |
| **PS400-NEH** | 350 | **PS400-GEH** | 350 | **PH400-CEH** | 350 | **H630-NE** | 500 | **L630-NE** | 500 | 75 | 272 | 2080 |
| **S630-NE** | 600 | **S800-RE** | 600 | **S800-PE** | 600 | **H630-NE** | 630 | **L630-NE** | 630 | 90 | 332 | 2600 |
| **S800-NE** | 700 | **S800-RE** | 700 | **S800-PE** | 700 | **H800-NE** | 700 | **L800-NE** | 700 | 110 | 380 | 2980 |
| **S800-NE** | 800 ⑰ | **S800-RE** | 800 ⑰ | **S800-PE** | 800 ⑰ | **H800-NE** | 800 ⑰ | **L800-NE** | 800 ⑰ | 132 | 450 | 3460 |

| 50 | | 65 | | 70 | | 110 | | 125 | | 200 | | Rated breaking capacity (kA) 415V AC $I_{cu}$ (sym) | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Output (kW) | Full-load current(A) | Max. starting current(A) |
| | | **S100-GF** | 15 | **PS125-PF** | 15 | | | **H100-NF** | 15 | **L100-NF** | 15 | 0.75 | 1.9 | 14.2 |
| | | **S100-GF** | 15 | **PS125-PF** | 15 | | | **H100-NF** | 15 | **L100-NF** | 15 | 1.5 | 3.4 | 28 |
| | | **S100-GF** | 15 | **PS125-PF** | 20 | | | **H100-NF** | 15 | **L100-NF** | 15 | 2.2 | 5.2 | 48 |
| | | **S100-GF** | 15 | **PS125-PF** | 30 | | | **H100-NF** | 15 | **L100-NF** | 15 | 3.7 | 7.8 | 70 |
| | | **S100-GF** | 30 | **PS125-PF** | 40 | | | **H100-NF** | 30 | **L100-NF** | 30 | 5.5 | 11.4 | 102 |
| | | **S100-GF** | 40 | **PS125-PF** | 40 | | | **H100-NF** | 30 | **L100-NF** | 30 | 7.5 | 15.1 | 132 |
| | | **S100-GFH** | 40 | **PS125-PF** | 50 | | | **H100-NF** | 50 | **L100-NF** | 50 | 11 | 22.5 | 190 |
| | | **S100-GFH** | 50 | **PS125-PF** | 75 | | | **H100-NF** | 60 | **L100-NF** | 60 | 15 | 30 | 270 |
| | | **S100-GFH** | 60 | **PS125-PF** | 75 | | | **H100-NF** | 75 | **L100-NF** | 75 | 18.5 | 36 | 334 |
| | | **S100-GFH** | 75 | **PS125-PF** | 100 | | | **H100-NF** | 100 | **L100-NF** | 100 | 22 | 41 | 372 |
| | | **S100-GFH** | 100 | **PS125-PF** | 125 ※※ | | | **H100-NF** | 100 | **L100-NF** | 100 | 30 | 56 | 545 |
| | | | | **PS250-PF** | 150 | | | **H225-NF** | 125 | **L225-NF** | 125 | 37 | 70.5 | 750 |
| | | | | **PS250-PF** | 175 | | | **H225-NF** | 150 | **L225-NF** | 150 | 45 | 84 | 890 |
| | | | | **PS250-PF** | 200 | **PH400-CEH** | **175** | **H225-NF** | 175 ⑰ | **L225-NF** | 175 ⑰ | 55 | 105 | 980 |
| **PS400-NEH** | 200 | | | **PS400-GEH** | 200 | **PH400-CEH** | **200** | **H225-NF** | 225 ⑰ | **L225-NF** | 225 ⑰ | 75 | 136 | 1040 |
| **PS400-NEH** | 250 | | | **PS400-GEH** | 250 | **PH400-CEH** | **250** | **H400-NE** | 300 | **L400-NE** | 300 | 90 | 166 | 1300 |
| **PS400-NEH** | 250 | | | **PS400-GEH** | 250 | **PH400-CEH** | **250** | **H400-NE** | 350 | **L400-NE** | 350 | 110 | 190 | 1490 |
| **PS400-NEH** | 300 | | | **PS400-GEH** | 300 | **PH400-CEH** | **300** | **H400-NE** | 400 | **L400-NE** | 400 | 132 | 225 | 1730 |
| **PS400-NEH** | 350 | | | **PS400-GEH** | 350 | **PH400-CEH** | **350** | **H630-NE** | 500 | **L630-NE** | 500 | 160 | 273 | 2170 |

# 8 Selection of breakers for protection of motor branch circuits [approved by ship classification societies]

This table assumes that the motor branch circuit is protected against overcurrent by an electromagnetic relay and against short-circuit current by a moulded case circuit breaker.

## For protection of 200/220V AC 3-phase induction motors

| Rated breaking capacity (kA) 230V AC $I_{cu}$ (sym) | | | 2.5 | | 7.5 | | 15 | | 30 | | 35 | | 50 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Output (kW) | Full-load current(A) | Max. starting current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) |
| 0.75 | 3.71 | 28.4 | **PE30-NF** | 15 | **PS30-NF** | 15 | | | | | | | **PS125-NF** | 15 |
| 1.5 | 6.74 | 56 | **PE30-NF** | 15 | **PS30-NF** | 15 | **PS50-NF** | 15 | | | | | **PS125-NF** | 20 |
| 2.2 | 10.4 | 96 | **PE30-NF** | 30 | **PS30-NF** | 30 | **PS50-NF** | 30 | | | | | **PS125-NF** | 30 ※ |
| 3.7 | 15.6 | 139 | | | **PE50-NF** | 40 | **PS50-NF** | 40 | | | | | **PS125-NF** | 40 |
| 5.5 | 22.8 | 203 | | | **PE60-NF** | 60 | | | **PS60-NF** | 60 | | | **PS125-NF** | 60 |
| 7.5 | 30.2 | 264 | | | | | | | **PE125-NF** | 75 | | | **PS125-NF** | 75 |
| 11 | 44.9 | 380 | | | | | | | **PE125-NF** | 100 | | | **PS125-NF** | 125 ※※ |
| 15 | 60 | 540 | | | | | | | | | **E250-SF** | 125 | | |
| 18.5 | 72 | 668 | | | | | | | | | **E250-SF** | 150 | | |
| 22 | 81.9 | 744 | | | | | | | | | **E250-SF** | 175 | | |
| 30 | 112 | 1090 | | | | | | | | | **E250-SF** | 200 | | |
| 37 | 141 | 1500 | | | | | | | | | **E400-NF** | 300 | | |
| 45 | 168 | 1780 | | | | | | | | | **E400-NF** | 350 | **PS400-CF** | 350 ⑯ |
| 55 | 211 | 1960 | | | | | | | | | | | **S630-CF** | 500 |
| 75 | 272 | 2080 | | | | | | | | | | | **S630-CF** | 630 |
| 90 | 332 | 2600 | | | | | | | | | | | **S800-CF** | 800 |
| 110 | 380 | 2980 | | | | | | | | | | | | |
| 132 | 450 | 3460 | | | | | | | | | | | | |

## For protection of 400/440V AC 3-phase induction motors

| Rated breaking capacity (kA) 440V AC $I_{cu}$ (sym) | | | 2.5 | | 7.5 | | 10 | | 15 | | 25 | | 30 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Output (kW) | Full-load current(A) | Max. starting current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) |
| 0.75 | 1.9 | 14.2 | **PS30-NF** | 10 | | | | | | | **PS125-NF** | 15 | | |
| 1.5 | 3.4 | 28 | **PS30-NF** | 15 | | | | | | | **PS125-NF** | 15 | | |
| 2.2 | 5.2 | 48 | **PS30-NF** | 15 | **PS50-NF** | 15 | | | | | **PS125-NF** | 20 | | |
| 3.7 | 7.8 | 70 | **PS30-NF** | 20 | **PS50-NF** | 20 | | | | | **PS125-NF** | 30 | | |
| 5.5 | 11.4 | 102 | **PS30-NF** | 30 | **PS50-NF** | 30 | | | | | **PS125-NF** | 40 | | |
| 7.5 | 15.1 | 132 | **PE50-NF** | 40 | **PS50-NF** | 40 | | | | | **PS125-NF** | 40 | | |
| 11 | 22.5 | 190 | **PE60-NF** | 60 | | | **PE125-NF** | 60 | | | **PS125-NF** | 50 | | |
| 15 | 30 | 270 | | | | | **PE125-NF** | 75 | | | **PS125-NF** | 75 | | |
| 18.5 | 36 | 334 | | | | | **PE125-NF** | 100 | | | **PS125-NF** | 100 | | |
| 22 | 41 | 372 | | | | | **PE125-NF** | 125 | | | **PS125-NF** | 125 ※※ | | |
| 30 | 56 | 545 | | | | | | | **E250-SF** | 125 | | | **S250-SF** | 125 |
| 37 | 70.5 | 750 | | | | | | | **E250-SF** | 150 | | | **S250-SF** | 150 |
| 45 | 84 | 890 | | | | | | | **E250-SF** | 175 | | | **S250-SF** | 175 |
| 55 | 105 | 980 | | | | | | | **E250-SF** | 200 | | | **S250-SF** | 200 |
| 75 | 136 | 1040 | | | | | | | | | | | **PS400-CF** | 300 ⑰ |
| 90 | 166 | 1300 | | | | | | | | | | | **PS400-CF** | 350 ⑯ |
| 110 | 190 | 1490 | | | | | | | | | | | **PS400-CF** | 400 ⑯ |
| 132 | 225 | 1730 | | | | | | | | | | | | |
| 160 | 273 | 2170 | | | | | | | | | | | | |

Remark 1.
Motor starting conditions
The inrush current is assumed to be as follows:

| Motor output | Inrush current |
|---|---|
| 0.75 ~ 7.5kW | Full-load current x1600% max. |
| 11 ~ 45kW | Full-load current x1700% max. |
| 55 ~ 160kW | Full-load current x1800% max. |

Exceptions:
Note ⑯ : Full-load x 1600% max.
Note ⑰ : Full-load x 1700% max.
When the inrush current exceeds the above values, the breaker may trip.
The starting time is assumed to be 6 seconds max. at the max. starting current.
Exceptions:
Note ※ : 5 seconds max. at the max. starting current. When the max. starting current flows through the breaker for a period of time exceeding the above max. starting time, the breaker may trip.

Remark 2.
The full-load current and the max. starting current are determined with reference to those of highly efficient 3-phase induction motors (4 poles) from individual manufacturers. Please consult us if the full-load current or the max. starting current of your motor is different significantly from the values shown in the table.

Note ※※ : Operates at 500% of rated current for a minimum of 2 seconds and a maximum of 20 seconds.
Does not comply with the following regulations of interior wiring regulations JEAC 8001. Document number 3-7-5
In the case of rated current of 125A or more 6 seconds or more at 500% of rated current.

Remark 3.
- In regard to electronic breakers, it is assumed that the protection characteristic setting dial is set so that the long time delay tripping time is the longest.
- In regard to breakers with the instantaneous trip current being adjustable, it is assumed that the instantaneous trip current is set to the max. value.
- Protective coordination with the motor is analyzed for on the basis of 40℃ cold start characteristics of the breaker.

| 85 | | 100 | | 125 | | 150 | | 200 | | Rated breaking capacity (kA) 230V AC $I_{cu}$ (sym) | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Output (kW) | Full-load current(A) | Max. starting current(A) |
| **PS125-PF** | 15 | | | | | **H100-NF** | 15 | **L100-NF** | 15 | 0.75 | 3.71 | 28.4 |
| **PS125-PF** | 20 | | | | | **H100-NF** | 15 | **L100-NF** | 15 | 1.5 | 6.74 | 56 |
| **PS125-PF** | 30 ※ | | | | | **H100-NF** | 20 | **L100-NF** | 20 | 2.2 | 10.4 | 96 |
| **PS125-PF** | 40 | | | | | **H100-NF** | 30 | **L100-NF** | 30 | 3.7 | 15.6 | 139 |
| **PS125-PF** | 60 | | | | | **H100-NF** | 50 | **L100-NF** | 50 | 5.5 | 22.8 | 203 |
| **PS125-PF** | 75 | | | | | **H100-NF** | 60 | **L100-NF** | 60 | 7.5 | 30.2 | 264 |
| **PS125-PF** | 125 ※※ | | | | | **H100-NF** | 100 | **L100-NF** | 100 | 11 | 44.9 | 380 |
| **PS250-PF** | 125 | | | | | **H125-NF** | 125 | **L125-NF** | 125 | 15 | 60 | 540 |
| **PS250-PF** | 125 | | | | | **H225-NF** | 150 | **L225-NF** | 150 | 18.5 | 72 | 668 |
| **PS250-PF** | 150 | | | | | **H225-NF** | 175 | **L225-NF** | 175 | 22 | 81.9 | 744 |
| **S250-SF** | 200 | | | | | **H225-NF** | 200 | **L225-NF** | 200 | 30 | 112 | 1090 |
| **S250-SFH** | 225 ※ | | | | | **H400-NE** | 250 | **L400-NE** | 250 | 37 | 141 | 1500 |
| **PS400-NEH** | 250 | **PS400-GEH** | 250 | **PH400-CE** | 250 ① | **H400-NE** | 300 | **L400-NE** | 300 | 45 | 168 | 1780 |
| **PS400-NEH** | 300 | **PS400-GEH** | 300 | **PH400-CE** | 300 | **H400-NE** | 350 | **L400-NE** | 350 | 55 | 211 | 1960 |
| **PS400-NEH** | 350 | **PS400-GEH** | 350 | **S800-PE** | 500 | **H630-NE** | 500 | **L630-NE** | 500 | 75 | 272 | 2080 |
| **S630-NE** | 600 | **S800-RE** | 600 | **S800-PE** | 600 | **H630-NE** | 630 | **L630-NE** | 630 | 90 | 332 | 2600 |
| **S800-NE** | 700 | **S800-RE** | 700 | **S800-PE** | 700 | **H800-NE** | 700 | **L800-NE** | 700 | 110 | 380 | 2980 |
| **S800-NE** | 800 ⑰ | **S800-RE** | 800 ⑰ | **S800-PE** | 800 ⑰ | **H800-NE** | 800 ⑰ | **L800-NE** | 800 ⑰ | 132 | 450 | 3460 |

| 45 | | 50 | | 65 | | 100 | | 120 | | 180 | | Rated breaking capacity (kA) 440V AC $I_{cu}$ (sym) | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Output (kW) | Full-load current(A) | Max. starting current(A) |
| | | **S100-GF** | 15 | | | | | **H100-NF** | 15 | **L100-NF** | 15 | 0.75 | 1.9 | 14.2 |
| | | **S100-GF** | 15 | | | | | **H100-NF** | 15 | **L100-NF** | 15 | 1.5 | 3.4 | 28 |
| | | **S100-GF** | 15 | | | | | **H100-NF** | 15 | **L100-NF** | 15 | 2.2 | 5.2 | 48 |
| | | **S100-GF** | 15 | | | | | **H100-NF** | 15 | **L100-NF** | 15 | 3.7 | 7.8 | 70 |
| | | **S100-GF** | 30 | | | | | **H100-NF** | 30 | **L100-NF** | 30 | 5.5 | 11.4 | 102 |
| | | **S100-GF** | 40 | | | | | **H100-NF** | 30 | **L100-NF** | 30 | 7.5 | 15.1 | 132 |
| | | **S100-GFH** | 40 | | | | | **H100-NF** | 50 | **L100-NF** | 50 | 11 | 22.5 | 190 |
| | | **S100-GFH** | 50 | | | | | **H100-NF** | 60 | **L100-NF** | 60 | 15 | 30 | 270 |
| | | **S100-GFH** | 60 | | | | | **H100-NF** | 75 | **L100-NF** | 75 | 18.5 | 36 | 334 |
| | | **S100-GFH** | 75 | | | | | **H100-NF** | 100 | **L100-NF** | 100 | 22 | 41 | 372 |
| | | **S100-GFH** | 100 | | | | | **H100-NF** | 100 | **L100-NF** | 100 | 30 | 56 | 545 |
| | | **PS250-PF** | 150 | | | | | **H225-NF** | 125 | **L225-NF** | 125 | 37 | 70.5 | 750 |
| | | **PS250-PF** | 175 | | | | | **H225-NF** | 150 | **L225-NF** | 150 | 45 | 84 | 890 |
| | | **PS250-PF** | 200 | | | **PH400-CE** | **175** | **H225-NF** | 175 ⑰ | **L225-NF** | 175 ⑰ | 55 | 105 | 980 |
| **PS400-NEH** | 200 | | | **PS400-GEH** | 200 | **PH400-CE** | **200** ① | **H225-NF** | 225 ⑰ | **L225-NF** | 225 ⑰ | 75 | 136 | 1040 |
| **PS400-NEH** | 250 | | | **PS400-GEH** | 250 | **PH400-CE** | **250** ① | **H400-NE** | 300 | **L400-NE** | 300 | 90 | 166 | 1300 |
| **PS400-NEH** | 250 | | | **PS400-GEH** | 250 | **PH400-CE** | **250** ① | **H400-NE** | 350 | **L400-NE** | 350 | 110 | 190 | 1490 |
| **PS400-NEH** | 300 | | | **PS400-GEH** | 300 | **PH400-CE** | **300** ⑰ | **H400-NE** | 400 | **L400-NE** | 400 | 132 | 225 | 1730 |
| **PS400-NEH** | 350 | | | **PS400-GEH** | 350 | | | **H630-NE** | 500 ② | **L630-NE** | 500 | 160 | 273 | 2170 |

Note ①: For PH400-CE, use a breaker with $I_n$ = 400A.

Note ②: $I_{cu}$ of H630-NE is 125kA.

# 9 Selection of earth leakage circuit breakers for motor branch circuits

This table assumes that the motor branch circuit is protected against overcurrent by an electromagnetic switch and against short-circuit current by an earth leakage circuit breaker.

## For protection of 200/220V AC 3-phase induction motors

| Rated breaking capacity (kA) 230V AC $I_{cu}$ (sym) | | | 2.5 | | 7.5 | | 15 | | 30 | | 35 | | 50 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Output (kW) | Full-load current (A) | Max. starting current (A) | Type | Rated current(A) | Type | Rated current (A) | Type | Rated current (A) | Type | Rated current (A) | Type | Rated current (A) | Type | Rated current (A) |
| 0.75 | 3.71 | 28.4 | **PZE30-NF** | 10 | **PZE50-NF** | 15 | **PZS50-NF** | 15 | | | | | **ZS50-SF** | 15 |
| 1.5 | 6.74 | 56 | **PZE30-NF** | 20 | **PZE50-NF** | 20 | **PZS50-NF** | 20 | | | | | **ZS50-SF** | 20 |
| 2.2 | 10.4 | 96 | **PZE30-NF** | 30 | **PZE50-NF** | 30 | **PZS50-NF** | 30 | | | | | **ZS50-SF** | 30 |
| 3.7 | 15.6 | 139 | | | **PZE50-NF** | 50 | **PZS50-NF** | 50 | | | | | **ZS50-SF** | 40 |
| 5.5 | 22.8 | 203 | | | **PZE60-NF** | 60 | | | **PZS60-NF** | 60 | | | **ZS50-SF** | 40 |
| 7.5 | 30.2 | 264 | | | | | | | **PZE125-NF** | 75 | | | **ZS50-SF** | 50 |
| 11 | 44.9 | 380 | | | | | | | **PZE125-NF** | 100 | | | **ZS125-SF** | 75 |
| 15 | 60 | 540 | | | | | | | | | **ZE250-SF** | 125 | **ZS125-SF** | 100 |
| 18.5 | 72 | 668 | | | | | | | | | **ZE250-SF** | 150 | **ZS125-SF** | 125 ⑯ |
| 22 | 81.9 | 744 | | | | | | | | | **ZE250-SF** | 175 | | |
| 30 | 112 | 1090 | | | | | | | | | **ZE250-SF** | 200 | | |
| 37 | 141 | 1500 | | | | | | | | | **ZE250-SF** | 225 ⑯ | | |
| 45 | 168 | 1780 | | | | | | | | | **ZE400-NF** | 350 | | |
| 55 | 211 | 1960 | | | | | | | | | | | | |
| 75 | 272 | 2080 | | | | | | | | | | | **ZS630-CF** | 630 |
| 90 | 332 | 2600 | | | | | | | | | | | **ZS800-CF** | 800 |
| 110 | 380 | 2980 | | | | | | | | | | | | |
| 132 | 450 | 3460 | | | | | | | | | | | | |

## For protection of 400/440V AC 3-phase induction motors

| Rated breaking capacity (kA) 415V AC $I_{cu}$ (sym) | | | 1.5 | | 2.5 | | 7.5 | | 10 | | 25 | | 30 | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Output (kW) | Full-load current(A) | Max. starting current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) |
| 0.75 | 1.9 | 14.2 | **PZE30-NF** | 5 | **PZS30-NF** | 5 | **PZS50-NF** | 15 | | | | | **ZS50-SF** | 15 |
| 1.5 | 3.4 | 28 | **PZE30-NF** | 10 | **PZS30-NF** | 10 | **PZS50-NF** | 15 | | | | | **ZS50-SF** | 15 |
| 2.2 | 5.2 | 48 | **PZE30-NF** | 15 | **PZS30-NF** | 15 | **PZS50-NF** | 15 | | | | | **ZS50-SF** | 15 |
| 3.7 | 7.8 | 70 | **PZE30-NF** | 20 ※ | **PZS30-NF** | 20 ※ | **PZS50-NF** | 20 ※ | | | | | **ZS50-SF** | 20 |
| 5.5 | 11.4 | 102 | **PZE30-NF** | 30 ※ | **PZS30-NF** | 30 ※ | **PZS50-NF** | 30 ※ | | | | | **ZS50-SF** | 30 |
| 7.5 | 15.1 | 132 | | | **PZE50-NF** | 40 | **PZS50-NF** | 40 | | | | | **ZS50-SF** | 40 |
| 11 | 22.5 | 190 | | | **PZE60-NF** | 60 | | | **PZE125-NF** | 60 | | | **ZS50-SF** | 40 |
| 15 | 30 | 270 | | | **PZE60-NF** | 60 | | | **PZE125-NF** | 60 | | | **ZS50-SF** | 50 |
| 18.5 | 36 | 334 | | | | | | | **PZE125-NF** | 75 | | | **ZS125-SF** | 60 |
| 22 | 41 | 372 | | | | | | | **PZE125-NF** | 100 | | | **ZS125-SF** | 75 |
| 30 | 56 | 545 | | | | | | | **PZE125-NF** | 125 | **ZE250-SF** | 125 | **ZS125-SF** | 100 |
| 37 | 70.5 | 750 | | | | | | | | | **ZE250-SF** | 150 | **ZS125-SF** | 125 |
| 45 | 84 | 890 | | | | | | | | | **ZE250-SF** | 175 | | |
| 55 | 105 | 980 | | | | | | | | | **ZE250-SF** | 200 | | |
| 75 | 136 | 1040 | | | | | | | | | **ZE250-SF** | 225 ⑰ | | |
| 90 | 166 | 1300 | | | | | | | | | **ZE400-NF** | 350 | | |
| 110 | 190 | 1490 | | | | | | | | | | | | |
| 132 | 225 | 1730 | | | | | | | | | | | | |
| 160 | 273 | 2170 | | | | | | | | | | | | |

Remark 1.
Motor starting conditions
The inrush current is assumed to be as follows:

| Motor output | Inrush current |
|---|---|
| 0.75 ~ 7.5kW | Full-load current x1600% max. |
| 11 ~ 45kW | Full-load current x1700% max. |
| 55 ~ 160kW | Full-load current x1800% max. |

Exceptions:
⑯ : Full-load x 1600% max.
⑰ : Full-load x 1700% max.
When the inrush current exceeds the above values, the earth leakage circuit breaker may trip.
The starting time is assumed to be 6 seconds max. at the max. starting current.
Exceptions:
Note ※ : 5 seconds max. at the max. starting current. When the max. starting current flows through the breaker for a period of time exceeding the above max. starting time, the earth leakage circuit breaker may trip.

Remark 2.
The full-load current and the max. starting current are determined with reference to those of highly efficient 3-phase induction motors (4 poles) from individual manufacturers. Please consult us if the full-load current or the max. starting current of your motor is different significantly from the values shown in the table.

Remark 3.
- In regard to breakers with the instantaneous trip current being adjustable, it is assumed that the instantaneous trip current is set to the max. value.
- Protective coordination with the motor is analyzed for on the basis of 40℃ cold start characteristics of the earth leakage circuit breaker.

| 85 | | 100 | | Rated breaking capacity (kA) 230V AC $I_{cu}$ (sym) | | |
|---|---|---|---|---|---|---|
| Type | Rated current (A) | Type | Rated current (A) | Output (kW) | Full-load current (A) | Max. starting current (A) |
| **ZS100-GF** | 15 | | | 0.75 | 3.71 | 28.4 |
| **ZS100-GF** | 15 | | | 1.5 | 6.74 | 56 |
| **ZS100-GF** | 30 | | | 2.2 | 10.4 | 96 |
| **ZS100-GF** | 40 | | | 3.7 | 15.6 | 139 |
| **ZS100-GF** | 40 | | | 5.5 | 22.8 | 203 |
| **ZS100-GF** | 50 | | | 7.5 | 30.2 | 264 |
| **ZS100-GF** | 75 | | | 11 | 44.9 | 380 |
| **ZS100-GF** | 100 | | | 15 | 60 | 540 |
| **ZS250-SF** | 150 | | | 18.5 | 72 | 668 |
| **ZS250-SF** | 175 | | | 22 | 81.9 | 744 |
| **ZS250-SF** | 200 | | | 30 | 112 | 1090 |
| **ZS250-SF** | 225 ⑯ | **ZS400-GF** | 250 | 37 | 141 | 1500 |
| **ZS400-NF** | 300 | **ZS400-GF** | 300 | 45 | 168 | 1780 |
| **ZS400-NF** | 400 | **ZS400-GF** | 400 | 55 | 211 | 1960 |
| **ZS630-NF** | 630 | | | 75 | 272 | 2080 |
| **ZS800-NF** | 800 | | | 90 | 332 | 2600 |
| | | | | 110 | 380 | 2980 |
| | | | | 132 | 450 | 3460 |

| 36 | | 40 | | 50 | | 65 | | 70 | | Rated breaking capacity (kA) 415V AC $I_{cu}$ (sym) | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Type | Rated current(A) | Output (kW) | Full-load current(A) | Max. starting current(A) |
| | | | | | | **ZS100-GF** | 15 | | | 0.75 | 1.9 | 14.2 |
| | | | | | | **ZS100-GF** | 15 | | | 1.5 | 3.4 | 28 |
| | | | | | | **ZS100-GF** | 15 | | | 2.2 | 5.2 | 48 |
| | | | | | | **ZS100-GF** | 15 | | | 3.7 | 7.8 | 70 |
| | | | | | | **ZS100-GF** | 20 | | | 5.5 | 11.4 | 102 |
| | | | | | | **ZS100-GF** | 40 | | | 7.5 | 15.1 | 132 |
| | | | | | | **ZS100-GF** | 40 | | | 11 | 22.5 | 190 |
| | | | | | | **ZS100-GF** | 50 | | | 15 | 30 | 270 |
| | | | | | | **ZS100-GF** | 60 | | | 18.5 | 36 | 334 |
| | | | | | | **ZS100-GF** | 75 | | | 22 | 41 | 372 |
| | | **ZS250-SF** | 125 | | | **ZS100-GF** | 100 | | | 30 | 56 | 545 |
| | | **ZS250-SF** | 150 | | | **ZS225-GF** | 125 | | | 37 | 70.5 | 750 |
| | | **ZS250-SF** | 175 | | | **ZS225-GF** | 150 | | | 45 | 84 | 890 |
| | | **ZS250-SF** | 200 | **ZS400-NF** | 250 | **ZS225-GF** | 200 | | | 55 | 105 | 980 |
| | | **ZS250-SF** | 225 ⑰ | **ZS400-NF** | 300 | | | **ZS400-GF** | 300 | 75 | 136 | 1040 |
| | | | | **ZS400-NF** | 350 | | | **ZS400-GF** | 350 | 90 | 166 | 1300 |
| **ZS630-CF** | 500 | | | **ZS400-NF** | 400 | | | **ZS400-GF** | 400 | 110 | 190 | 1490 |
| **ZS630-CF** | 600 | | | **ZS400-NF** | 400 ⑰ | | | **ZS400-GF** | 400 ⑰ | 132 | 225 | 1730 |
| **ZS630-CF** | 630 | | | **ZS630-NF** | 630 | | | | | 160 | 273 | 2170 |

# 10 Selection of circuit breakers for lamps and electric heating circuits

Select a circuit breaker with a rated current of 1.25 times or more of the max. operational current.
(Interior wiring regulation JEAC8001 3605-3 Article 3 specifies, "The load capacity of a branch circuit with a continuous load shall not exceed 80% of the rated current of the overcurrent circuit breaker that protects the branch circuit. [Recommendation]".

## 200V AC circuit

| Rated breaking capacity (kA) 240V AC $I_{cu}$ (sym) | | 2.5 | 5 | 7.5 | 15 | 30 | 35 | 50 | 85 | 100 | 125 | 150 | 200 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Max. operational current (A) | Rated current of circuit breaker(A) | | | | | | | | | | | | |
| 12 | 15 | TB-5S TB-5P TB-52C PE30-NF | TB-5S① TB-5P | PS30-NF | PS50-NF | S50-SF | | PS50-PF | H100-NF H125-NF | | | L100-NF | |
| 16 | 20 | | | | | | | | | | | | |
| 24 | 30 | | | | | | | | | | | | |
| 32 | 40 | TB-5S①, TB-5P | | PE50-NF | | | | | | | | | |
| 40 | 50 | | | | | | | | | | | | |
| 48 | 60 | | | PE60-NF | PS60-NF | | S125-SF PS125-NF | PS125-PF | | | | | |
| 60 | 75 | | | | | | | | | | | | |
| 80 | 100 | | | PE125-NF | | | | | | | | | |
| 100 | 125 | | | | | | | | | | | L125-NF | |
| 120 | 150 | E250-SF | | | | | PS250-NE | PS250-PF PS250-PE | H225-NF | | | L225-NF | |
| 140 | 175 | | | | | | | | | | | | |
| 160 | 200 | | | | | | | | | | | | |
| 180 | 225 | | | | | | | | | | | | |
| 200 | 250 | | | | | | | | H250-NF | | | L250-NF | |
| 240 | 300 | E400-NF | | | | | PS400-CF | PS400-NF PS400-NE | PS400-GF PS400-GE | PH400-CF PH400-CE | H400-NE | L400-NE | |
| 280 | 350 | | | | | | | | | | | | |
| 320 | 400 | | | | | | | | | | | | |
| 400 | 500 | S630-NF | | | | | S630-CF PS630-CF | S630-NF S630-NE PS630-NF PS630-NE | PS630-GF PS630-GE | PH630-CF PH630-CE | H630-NE | L630-NE | |
| 480 | 600/630 | | | | | | | | | | | | |
| 560 | 700 | S800-CF | | | | | | S800-NF S800-NE | S800-RF S800-RE | S800-PF S800-PE | H800-NE | L800-NE | |
| 640 | 800 | | | | | | | | | | | | |
| 800 | 1000 | S1000-CE | | | | | | | | S1250-GE | TL-1000NE | | |
| 960 | 1200 | S1250-NE | | | | | | | | | TL-1200NE | | |
| 1120 | 1400 | S1600-NE | | | | | | | | | | | |
| 1280 | 1600 | | | | | | | | | | | | |
| 1440 | 1800 | XS2000NE | | | | | | | | | | | |
| 1600 | 2000 | | | | | | | | | | | | |
| 2000 | 2500 | XS2500NE | | | | | | | | | | | |
| 2240 | 2800 | XS3200NE | | | | | | | | | | | |
| 2560 | 3200 | | | | | | | | | | | | |

## 400V AC circuit

| Rated breaking capacity (kA) 415V AC $I_{cu}$ (sym) | | 1.5 | 2.5 | 5 | 7.5 | 10 | 25 | 30 | 36 | 50 | 65 | 70 | 85 | 100 | 110 | 125 | 200 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Max. operational current (A) | Rated current of circuit breaker(A) | | | | | | | | | | | | | | | | |
| 12 | 15 | PE30-NF | TB-5S② TB-5P PS30-NF | PS50-NF | | S50-SF | | PS125-NF PS125-NE | S100-GF | | PS50-PF | H100-NF H125-NF | | | | L100-NF | |
| 16 | 20 | | | | | | | | | | | | | | | | |
| 24 | 30 | | | | | | | | | | | | | | | | |
| 32 | 40 | TB-5S②, TB-5P, PE50-NF | | | | | | | | | | | | | | | |
| 40 | 50 | | | | | | | | | | | | | | | | |
| 48 | 60 | PE60-NF | | PS60-NF | | | S125-SF | | | | PS125-PF PS125-PE | | | | | | |
| 60 | 75 | | | | | | | | | | | | | | | | |
| 80 | 100 | | | | | | | | | | | | | | | | |
| 100 | 125 | PE125-NF | | | | | | | S125-GF | | | | | | | L125-NF | |
| 120 | 150 | E250-SF | | | | | PS250-NE | | PS250-PF PS250-PE | | | H225-NF H250-NF | | | | L225-NF | |
| 140 | 175 | | | | | | | | | | | | | | | | |
| 160 | 200 | | | | | | | | | | | | | | | | |
| 180 | 225 | | | | | | | | | | | | | | | | |
| 200 | 250 | | | | | | | | | | | | | | | L250-NF | |
| 240 | 300 | E400-NF | | | | | PS400-CF | | PS400-NF PS400-NE | PS400-GF PS400-GE | | PH400-CF PH400-CE | | | H400-NE | L400-NE | |
| 280 | 350 | | | | | | | | | | | | | | | | |
| 320 | 400 | | | | | | | | | | | | | | | | |
| 400 | 500 | PS630-CF S630-CF | | | | | | | S630-NF S630-NE PS630-NF PS630-NE | PS630-GF PS630-GE | | PH630-CF PH630-CE | | | H630-NE | L630-NE | |
| 480 | 600/630 | | | | | | | | | | | | | | | | |
| 560 | 700 | S800-CF | | | | | | | S800-NF S800-NE | S800-RF S800-RE | | S800-PF S800-PE | H800-NE | | | L800-NE | |
| 640 | 800 | | | | | | | | | | | | | | | | |
| 800 | 1000 | S1000-CE | | | | | | | | | S1250-GE | | | TL-1000NE | | | |
| 960 | 1200 | S1250-NE | | | | | | | | | | | | TL-1200NE | | | |
| 1120 | 1400 | S1600-NE | | | | | | | | | | | | | | | |
| 1280 | 1600 | | | | | | | | | | | | | | | | |
| 1440 | 1800 | XS2000NE | | | | | | | | | | | | | | | |
| 1600 | 2000 | | | | | | | | | | | | | | | | |
| 2000 | 2500 | XS2500NE | | | | | | | | | | | | | | | |
| 2240 | 2800 | XS3200NE | | | | | | | | | | | | | | | |
| 2560 | 3200 | | | | | | | | | | | | | | | | |

Note ① : 1P is 2.5 kA. ② : 1P cannot be applied.

# 11 Selection of earth leakage circuit breakers for lamps and electric heating circuits

Select a circuit breaker with a rated current of 1.25 times or more of the max. operational current.
(Interior wiring regulation JEAC8001 3605-3 Article 3 specifies, "The load capacity of a branch circuit with a continuous load shall not exceed 80% of the rated current of the overcurrent circuit breaker that protects the branch circuit. [Recommendation]".

## 200V AC circuit

| Rated breaking capacity (kA) 240V AC $I_{cu}$ (sym) | | 2.5 | 5 | 7.5 | 15 | 30 | 35 | 50 | 85 | 100 | 125 |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Max. operational current (A) | Rated current of circuit breaker(A) | | | | | | | | | | |
| 12 | 15 | PZE30-NF TZ30EC | TZ50EE | PZS30-NF | PZS50-NF | ZS50-SF | | ZS100-GF | | | |
| 16 | 20 | | | | | | | | | | |
| 24 | 30 | | | | | | | | | | |
| 32 | 40 | TZ-52C | | PZE50-NF | | | | | | | |
| 40 | 50 | | | | | | | | | | |
| 48 | 60 | PZE60-NF | | | PZS60-NF | | ZS125-SF | | | | |
| 60 | 75 | PZE125-NF | | | | | | | | | |
| 80 | 100 | | | | | | | | | | |
| 100 | 125 | ZS125-SF | | | | | | ZS125-GF | | | |
| 120 | 150 | ZE250-SF | | | | | ZS225-GF | | | | |
| 140 | 175 | | | | | | | | | | |
| 160 | 200 | | | | | | | | | | |
| 180 | 225 | | | | | | | | | | |
| 200 | 250 | | | | | | ZS250-SF, ZS250-GF | | | ZS400-GF | |
| 240 | 300 | ZE400-NF | | | | | ZS400-NF | | | | |
| 280 | 350 | | | | | | | | | | |
| 320 | 400 | | | | | | | | | | |
| 400 | 500 | ZS630-CF | | | | | | ZS630-NF | | | |
| 480 | 600/630 | | | | | | | | | | |
| 560 | 700 | ZS800-CF | | | | | | ZS800-NF | | | |
| 640 | 800 | | | | | | | | | | |

## 400V AC circuit

| Rated breaking capacity (kA) 415V AC $I_{cu}$ (sym) | | 1.5 | 2.5 | 7.5 | 10 | 25 | 30 | 36 | 40 | 50 | 65 | 70 | 100 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Max. operational current (A) | Rated current of circuit breaker(A) | | | | | | | | | | | | |
| 12 | 15 | PZE30-NF | PZS30-NF | PZS50-NF | | ZS50-SF | | | ZS100-GF | | | | |
| 16 | 20 | | | | | | | | | | | | |
| 24 | 30 | | | | | | | | | | | | |
| 32 | 40 | PZE50-NF | | | | | | | | | | | |
| 40 | 50 | | | | | | | | | | | | |
| 48 | 60 | PZE60-NF | | PZS60-NF | | ZS125-SF | | | | | | | |
| 60 | 75 | PZE125-NF | | | | | | | | | | | |
| 80 | 100 | | | | | | | | | | | | |
| 100 | 125 | | | | | | ZS125-GF | | | | | | |
| 120 | 150 | ZE250-SF | | | | ZS250-SF | | | ZS225-GF | | | | |
| 140 | 175 | | | | | | | | | | | | |
| 160 | 200 | | | | | | | | | | | | |
| 180 | 225 | | | | | | | | | | | | |
| 200 | 250 | | | | | | | | ZS250-GF | | | | |
| 240 | 300 | ZE400-NF | | | | ZS400-NF | | | | ZS400-GF | | | |
| 280 | 350 | | | | | | | | | | | | |
| 320 | 400 | | | | | | | | | | | | |
| 400 | 500 | ZS630-CF | | | | | | ZS630-NF | | | | | |
| 480 | 600/630 | | | | | | | | | | | | |
| 560 | 700 | ZS800-CF | | | | | | ZS800-NF | | | | | |
| 640 | 800 | | | | | | | | | | | | |

# 12 Selection of motor protection breakers (for direct start)

## For protection of 200/220V AC 3-phase induction motors

| Rated capacity of motor (kW) | Rated current of motor protection breaker(A) | Motor protection breaker type<br>Rated breaking capacity (sym.) 240V AC<br>2.5kA | 5 kA | 25kA | 50kA | 65kA | 85kA | 125kA |
|---|---|---|---|---|---|---|---|---|
| 0.2 | 1.4 | **E30-NM** | **S30-NM** | | | | | |
| 0.4 | 2.6 | | | | | | | |
| 0.75 | 4 | | | | | | | |
| 1.5 | 8 | | | | | | | |
| 2.2 | 10 | | | **S50-NM** | | | | |
| 3.7 | 16 | | | | **PS125-NM** (Comming soon) | | | |
| 5.5 | 24 | | | | | | | |
| 7.5 | 32 | | | | | | | |
| 11 | 45 | **E50-NM** | | | | | | |
| 15 | 60 | **E100-NM** | | | | | | |
| 18.5 | 75 | | | | | | | |
| 22 | 90 | | | | | | | |
| 30 | 125 | **S250-SM** | | | | | | |
| 37 | 150 | | | | | | | |
| 45 | 175 | | | | | | | |
| 55 | 225 | | | | | | | |

## For protection of 400/440V AC 3-phase induction motors

| Rated capacity of motor (kW) | Rated current of motor protection breaker(A) | Motor protection breaker type<br>Rated breaking capacity (sym.) 415V AC<br>2.5kA | 7.5kA | 10kA | 30kA | 36kA | 40kA | 85kA |
|---|---|---|---|---|---|---|---|---|
| 0.2 | 0.7 | **S30-NM** | | | | | | |
| 0.4 | 1.4 | | | | | | | |
| 0.75 | 2.0 | | | | | | | |
| 1.5 | 4 | | | | | | | |
| 2.2 | 5 | | | | | | | |
| 3.7 | 8 | | | | | | | |
| 5.5 | 12 | | **S50-NM** | | | | | |
| 7.5 | 16 | | | | | | | |
| 11 | 24 | | | | | | | |
| 15 | 32 | | | | | | | |
| 18.5 | 40 | **E50-NM** | | | | | | |
| 22 | 45 | | | | | | | |
| 30 | 60 | **E100-NM** | | | | | | |
| 37 | 75 | | | | | | | |
| 45 | 90 | | | | | | | |
| 55 | 100 | | | | | | | |
| 75 | 150 | **S250-SM** | | | | | | |
| 90 | 175 | | | | | | | |
| 110 | 225 | | | | | | | |

Note (1) : A motor protection breaker with a hydraulic-magnetic overcurrent trip mechanism cannot be used in an inverter circuit.

Remark 1. Applies to direct on line starting. Please consider the starting conditions. When applying to Y- △ circuits, refer to "Selection of breakers for protection of motor branch circuits" on page 3-10.

Starting conditions

| Frame | Motor protection breaker type | Start time (600%) | Inrush current (percentage of total load current) |
|---|---|---|---|
| 30A | **E30-NM**<br>**S30-NM** | 2 sec max. | 960% max. |
| 50A | **E50-NM**<br>**S50-NM** | 2 sec max. | 960% max. |
| 100A | **E100-NM** | 2 sec max. | 960% max. |
| 225A | **S250-SM** | 4 sec max. | 1040% max. |

**Warning**

If the starting current (600% of the total motor load current), starting time, or inrush current exceeds the starting conditions shown in the table, the circuit breaker may trip. In particular, note that in the case of a high-efficiency motor, the starting current and inrush current are generally larger than for a general-purpose motor, and the motor protection breaker may not be applicable.

# 13 Selection of earth leakage circuit breakers for motor protection (for direct start)

## For protection of 200/220V AC 3-phase induction motors

| Rated capacity of motor (kW) | Circuit breaker rated current (A) | Circuit breaker type<br>Rated breaking capacity (sym.) 240V AC<br>2.5kA | 5 kA | 10kA | 25kA | 50kA | 85kA |
|---|---|---|---|---|---|---|---|
| 0.2 | 1.4 | ZE30-NM | ZS30-NM | ZS50-CM | | | |
| 0.4 | 2.6 | | | | | | |
| 0.75 | 4 | | | | | | |
| 1.5 | 8 | | | | | | |
| 2.2 | 10 | | | | | | |
| 3.7 | 16 | | | | ZS100-SM | | |
| 5.5 | 24 | | | | | | |
| 7.5 | 32 | | | | | | |
| 11 | 45 | ZE50-NM | | | | | |
| 15 | 60 | ZE100-NM | | | | | |
| 18.5 | 75 | | | | | | |
| 22 | 90 | | | | | | |
| 30 | 125 | ZS250-SM | | | | | |
| 37 | 150 | | | | | | |
| 45 | 175 | | | | | | |
| 55 | 225 | | | | | | |

## For protection of 400/440V AC 3-phase induction motors

| Rated capacity of motor (kW) | Circuit breaker rated current (A) | Circuit breaker type<br>Rated breaking capacity (sym.) 415V AC<br>2.5kA | 7.5kA | 10kA | 15kA | 30kA | 40kA |
|---|---|---|---|---|---|---|---|
| 0.2 | 0.7 | ZS30-NM | ZS50-CM | | | | |
| 0.4 | 1.4 | | | | | | |
| 0.75 | 2.0 | | | | | | |
| 1.5 | 4 | | | | | | |
| 2.2 | 5 | | | | | | |
| 3.7 | 8 | | | | | | |
| 5.5 | 12 | | | | | | |
| 7.5 | 16 | | ZS100-SM | | | | |
| 11 | 24 | | | | | | |
| 15 | 32 | | | | | | |
| 18.5 | 40 | | | | | | |
| 22 | 45 | ZE50-NM | | | | | |
| 30 | 60 | ZE100-NM | | | | | |
| 37 | 75 | | | | | | |
| 45 | 90 | | | | | | |
| 55 | 100 | | | | | | |
| 75 | 150 | ZS250-SM | | | | | |
| 90 | 175 | | | | | | |
| 110 | 225 | | | | | | |

Note (1) : An earth leakage circuit breaker for motor protection with a hydraulic-magnetic overcurrent trip mechanism cannot be used in an inverter circuit.
Remark 1. Applies to direct on line starting. Please consider the starting conditions. When applying to Y- △ starting circuits, refer to "Selection of earth leakage circuit breakers for motor branch circuits" on page 3-12.

**Starting conditions**

| Frame | Circuit breaker type | Start time (600%) | Inrush current (percentage of total load current) |
|---|---|---|---|
| 30 A | **ZE30-NM** | 2 sec max. | 960% max. |
| | **ZS30-NM** | | |
| 50 A | **ZE50-NM** | 2 sec max. | 960% max. |
| | **ZS50-CM** | | |
| 100 A | **ZE100-NM** | 2 sec max. | 960% max. |
| 225 A | **ZS250-SM** | 6 sec max. | 1040% max. |

| Frame | Circuit breaker type | Rated current | Start time (600%) | Inrush current |
|---|---|---|---|---|
| 100 A | **ZS100-SM** | 16～32 A | 2 sec max. | 360 A |
| | | 40～45 A | 6 sec max. | 480 A |
| | | 60 A | 4 sec max. | 720 A |
| | | 75 A | 4 sec max. | 900 A |
| | | 90 A | 4 sec max. | 1080 A |
| | | 100 A | 4 sec max. | 1200 A |

**Warning**

If the starting current (600% of the total motor load current), starting time, or inrush current exceeds the starting conditions shown in the table, the earth leakage circuit breaker may trip.
In particular, note that in the case of a high-efficiency motor, the starting current and inrush current are generally larger than for a general-purpose motor, and the earth leakage circuit breaker for motor protection may not be applicable.

# 14 Selection of circuit breakers for transformer primary side

The circuit breaker for transformer primary side is selected that has an instantaneous trip pickup current value slightly larger than the excitation inrush current value so that it will not malfunction due to the excitation inrush current of the transformer. The magnitude of the excitation inrush current is based on Table 1.

| Transformer capacity (kVA) | Single-phase 210V Type / breaking capacity (kA) | | Rated current (A) | Single-phase 420V Type / breaking capacity (kA) | | Rated current (A) | 3-phase 210V Type / breaking capacity (kA) | | Rated current (A) | 3-phase 420V Type / breaking capacity (kA) | | Rated current (A) |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 5 | **PS125-NFH** | /50 | 50 | **PS125-NFH** | /36 | 30 | **PS125-NFH** | /50 | 30 | **PS125-NFH** | /36 | 15 |
| 7.5 | **PS125-NFH** | /50 | 75 | **PS125-NFH** | /36 | 40 | **PS125-NFH** | /50 | 40 | **PS125-NFH** | /36 | 20 |
| 10 | **PS125-NFH** | /50 | 100 | **PS125-NFH** | /36 | 50 | **PS125-NFH** | /50 | 50 | **PS125-NFH** | /36 | 30 |
| 15 | **E250-SFH** | /35 | 150 | **PS125-NFH** | /36 | 75 | **PS125-NFH** | /50 | 75 | **PS125-NFH** | /36 | 40 |
| | **S250-SFH** | /85 | 150 | | | | | | | | | |
| 20 | **S250-SFH** | /85 | 200 | **PS125-NFH** | /36 | 100 | **PS125-NFH** | /50 | 125 | **PS125-NFH** | /36 | 50 |
| 30 | **PS400-NEH** | /85 | 175 ($I_{CT}$=400A) | **E250-SFH** | /25 | 150 | **E250-SFH** | /35 | 150 | **PS125-NFH** | /36 | 60 |
| | | | | **S250-SFH** | /40 | 150 | **S250-SF** | /85 | 225 | | | |
| | | | | | | | **S250-SFH** | /85 | 150 | | | |
| 50 | **S630-NEH** | /85 | 300 | **PS400-NEH** | /50 | 175 ($I_{CT}$=400A) | **PS400-NEH** | /85 | 200 ($I_{CT}$=400A) | **PS125-NFH** | /36 | 125 |
| | | | | | | | **E250-SFH** | /35 | 225 | | | |
| | | | | | | | **S250-SFH** | /85 | 225 | | | |
| 75 | **S1250-NEH** | /100 | 500 | **PS400-NEH** | /50 | 200 ($I_{CT}$=400A) | **PS400-NEH** | /85 | 250 ($I_{CT}$=400A) | **E250-SFH** | /25 | 150 |
| | | | | | | | | | | **E250-SF** | /25 | 200 |
| | | | | | | | | | | **S250-SF** | /40 | 200 |
| | | | | | | | | | | **S250-SFH** | /40 | 150 |
| 100 | **S1250-NEH** | /100 | 600 | **S630-NEH** | /50 | 300 | **PS400-NEH** | /85 | 350 ($I_{CT}$=400A) | **E250-SFH** | /25 | 175 |
| | | | | | | | | | | **S250-SFH** | /40 | 175 |
| 150 | **S1600-NEH** | /125 | 800 | **S630-NEH** | /50 | 400 | **S630-NEH** | /85 | 500 | **PS400-NEH** | /50 | 225 ($I_{CT}$=400A) |
| 200 | **XS2000NE** | /125 | 1000 | **S1250-NEH** | /70 | 500 | **S800-NEH** | /85 | 700 | **PS400-NEH** | /50 | 350 ($I_{CT}$=400A) |
| 300 | **XS2000NE** | /125 | 1600 | **S1250-NEH** | /70 | 800 | **S1250-NEH** | /100 | 1000 | **S630-NEH** | /50 | 500 |

Note: Do not use a circuit breaker for transformer primary side as a switch. The switching durability will be greatly reduced due to the excitation inrush current. Please install a separate switch.

**Table 1**

| Transformer capacity (kVA) | Single-phase transformer First wave peak value (multiple) | Attenuation time constant (cycle) | 3-phase transformer First wave peak value (multiple) | Attenuation time constant (cycle) |
|---|---|---|---|---|
| 5～10 | 34 | 3～6 | 32 | 3～6 |
| 15～20 | 33 | 3～6 | 30 | 3～6 |
| 30 | 32 | 4～7 | 26 | 3～6 |
| 50 | 30 | 4～7 | 24 | 4～7 |
| 75 | 25 | 6～10 | 20 | 4～7 |
| 100 | 24 | 6～10 | 18 | 6～10 |
| 150 | 21 | 6～10 | 16 | 6～10 |
| 200 | 19 | 7～12 | 14 | 6～10 |
| 300 | 16 | 9～14 | 12 | 6～10 |

Remarks :

1. The above value is larger than the actual excitation inrush current because the current limiting due to the impedance of the electric circuit is not considered.
2. The multiple indicates the first wave peak value of the excitation inrush current with respect to the rated current peak value.

## 15 Selection of circuit breakers for resistance welding machine circuits

| Welding machine | | Single-phase 200V | | | Single-phase 400V | | |
|---|---|---|---|---|---|---|---|
| | | Circuit breaker with instantaneous trip only | | | Circuit breaker with instantaneous trip only | | |
| Rated capacity (kVA) | Standard max. input example (kVA) | Circuit breaker type | Rated current (A) | Instantaneous trip pickup current (A) | Circuit breaker type | Rated current (A) | Instantaneous trip pickup current (A) |
| 12.5 | 40 | **PS50-NF** | 50I | 600±120 | **PS50-NF** | 50I | 600±120 |
| | | **S125-SF** | 125I | 600±120 | **S125-SF** | 125I | 600±120 |
| 25 | 79 | **PE125-NF** | 125I | 1500±300 | **PE125-NF** | 60I | 750±150 |
| | | **S125-SF** | 125I | 1000±200 | **S125-SF** | 125I | 600±120 |
| 50 | 158 | **E250-SF** | 250I | 1950±390 | **PE125-NF** | 125I | 1500±300 |
| | | **S250-SF** | 250I | 1950±390 | **S125-SF** | 125I | 1000±200 |
| 75 | 237 | **E400-NF** | 400I | 3000±600 | **E250-SF** | 250I | 1625±325 |
| | | **PS400-CF** | 400I | 3000±600 | **S250-SF** | 250I | 1625±325 |
| 100 | 316 | **E400-NF** | 400I | 4000±800 | **E250-SF** | 250I | 1950±390 |
| | | **PS400-CF** | 400I | 4000±800 | **S250-SF** | 250I | 1950±390 |

Remarks :
1. The welding machine is for the case of the synchronous closing method.
2. Select the applicable circuit breaker type according to the required rated breaking capacity.



## 16 Selection of circuit breakers for capacitor circuits

| Capacitor capacity | Circuit breaker rated current (A) | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| | 200 V 50Hz | | 400 V 50Hz | | 220 V 60Hz | | 440 V 60Hz | |
| (kvar) | Single-phase | 3-phase | Single-phase | 3-phase | Single-phase | 3-phase | Single-phase | 3-phase |
| 5 | 40 | 30 | 20 | 15 | 40 | 20 | 20 | 15 |
| 10 | 100 | 50 | 40 | 30 | 75 | 40 | 40 | 20 |
| 15 | 100 | 75 | 60 | 40 | 100 | 60 | 50 | 30 |
| 20 | 150 | 100 | 100 | 50 | 150 | 100 | 75 | 40 |
| 25 | 200 | 100 | 100 | 60 | 175 | 100 | 100 | 50 |
| 30 | 225 | 125 | 100 | 75 | 200 | 125 | 100 | 60 |
| 40 | 300 | 175 | 150 | 100 | 300 | 175 | 150 | 100 |
| 50 | 400 | 225 | 200 | 100 | 350 | 200 | 175 | 100 |
| 75 | 600 | 350 | 300 | 175 | 500 | 300 | 250 | 150 |
| 100 | 800 | 400 | 400 | 225 | 700 | 400 | 350 | 200 |
| 150 | 1000 | 600 | 600 | 350 | 1000 | 600 | 500 | 300 |
| 200 | 1400 | 800 | 800 | 400 | 1200 | 800 | 700 | 400 |
| 300 | 2500 | 1400 | 1000 | 600 | 2000 | 1200 | 1000 | 600 |
| 400 | 3000 | 1800 | 1400 | 800 | 2800 | 1600 | 1200 | 800 |


Remark : The rated current of the circuit breaker is selected to be approximately 150% of the rated current of the capacitor.



## 17 Selection of circuit breakers for inverter circuits

The circuit breaker is for overload/short-circuit protection of the wiring on the primary side of the inverter. Select the rated current ($I_n$) of the circuit breaker with respect to the inverter input current ($I_i$) including harmonic components as follows in consideration of the effects of temperature rise, etc. due to harmonic components.

$$I_n \geq 1.4 \times I_i$$





Inverter circuit

Note 1: The circuit breaker is for commercial frequencies of 50 and 60 Hz. It cannot be installed on the secondary side of the inverter.
Note 2: A circuit breaker with a hydraulic-magnetic overcurrent trip mechanism cannot be used in an inverter circuit due to the problem of temperature rise.

# 18 Selection of circuit breakers and earth leakage circuit breakers for selectivity coordination

The following table shows possible combinations of main circuit breakers and branch circuit breakers capable of selectivity coordination with the main circuit breakers as well as the breaking capacity $I_{cu}$ sym.（kA）of each combination at the points where the branch circuit breaker is installed.




## Breaker combination table for selectivity coordination for 240V AC circuit

| | Main circuit breaker | | PS250-NE | PS400-NE | PS400-GE | PH400-CE | H400-NE | L400-NE | S630-NE | S630-NEH | PS630-NE | PS630-GE | PH630-CE |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | Rated current $I_r$ | | 250A | 400A | 400A | 400A | 400A | 400A | 630A | 630A | 630A | 630A | 630A |
| | Rated breaking capacity $I_{cu}$ sym.（kA） / Branch circuit breaker | | 50 | 85 | 100 | 125 | 150 | 200 | 85 | 85 | 85 | 100 | 125 |
| MCCB | PS30-NF, PE50-NF, PE60-NF | 7.5 | 2.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 |
| MCCB | PS50-NF | 15 | 2.5 | 10 | 10 | 10 | 10 | 10 | 15 | 15 | 15 | 15 | 15 |
| MCCB | PS60-NF, PE125-NF | 30 | 2.5 | 10 | 10 | 10 | 10 | 10 | 30 | 30 | 30 | 30 | 30 |
| MCCB | S50-SF, S125-SF | 50 | 30 | 25 | 25 | 25 | 6 | 6 | 36 | 50 | 36 | 36 | 36 |
| MCCB | PS125-NF | 50 | 30 | 36 | 36 | 36 | 6 | 6 | 36 | 50 | 36 | 36 | 36 |
| MCCB | S100-GF, S125-GF | 85 | — | 6 | 6 | 6 | 6 | 6 | 42 | 65 | 36 | 36 | 36 |
| MCCB | PS50-PF, PS125-PF | 85 | 30 | 50 | 50 | 50 | 6 | 6 | 36 | 65 | 50 | 70 | 70 |
| MCCB | H100-NF, H125-NF | 150 | — | 25 | 25 | 25 | 6 | 6 | 65 | 85 | 65 | 65 | 65 |
| MCCB | E250-SF | 35 | — | 5 | 5 | 5 | 5 | 5 | 35 | 35 | 35 | 35 | 35 |
| MCCB | PS250-NE | 50 | — | 5 | 5 | 5 | 5 | 5 | 36 | 50 | 36 | 36 | 36 |
| MCCB | S250-SF | 85 | — | 5 | 5 | 5 | 5 | 5 | 36 | 65 | 36 | 36 | 36 |
| MCCB | PS250-PF, PS250-PE | 85 | — | 5 | 5 | 5 | 5 | 5 | 36 | 65 | 50 | 70 | 70 |
| MCCB | H225-NF, H250-NF | 150 | — | 5 | 5 | 5 | 5 | 5 | 65 | 85 | 65 | 65 | 65 |
| MCCB | E400-NF | 35 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | PS400-CF | 50 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | PS400-NF, PS400-NE | 85 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | PS400-GF, PS400-GE | 100 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | PH400-CF, PH400-CE | 125 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | H400-NE | 150 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | S630-CF | 50 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | PS630-CF | 50 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | S630-NF, S630-NE | 85 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | PS630-NF, PS630-NE | 85 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | PS630-GF, PS630-GE | 100 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | PH630-CF, PH630-CE | 125 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | S800-CF | 50 | — | — | — | — | — | — | — | — | — | — | — |
| MCCB | S800-NF, S800-NE | 85 | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | PZS30-NF, PZE50-NF, PZE60-NF | 7.5 | 2.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 |
| ELCB | PZS50-NF | 15 | 2.5 | 10 | 10 | 10 | 10 | 10 | 15 | 15 | 15 | 15 | 15 |
| ELCB | PZS60-NF, PZE125-NF | 30 | 2.5 | 10 | 10 | 10 | 10 | 10 | 30 | 30 | 30 | 30 | 30 |
| ELCB | ZS50-SF, ZS125-SF | 50 | — | 6 | 6 | 6 | 6 | 6 | 36 | 50 | 36 | 36 | 36 |
| ELCB | ZS100-GF, ZS125-GF | 85 | — | 6 | 6 | 6 | 6 | 6 | 36 | 65 | 36 | 36 | 36 |
| ELCB | ZE250-SF | 35 | — | 5 | 5 | 5 | 5 | 5 | 35 | 35 | 35 | 35 | 35 |
| ELCB | ZS250-SF | 85 | — | 5 | 5 | 5 | 5 | 5 | 36 | 65 | 36 | 36 | 36 |
| ELCB | ZS225-GF, ZS250-GF | 85 | — | 5 | 5 | 5 | 5 | 5 | 36 | 65 | 36 | 36 | 36 |
| ELCB | ZE400-NF | 35 | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | ZS400-NF | 85 | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | ZS400-GF | 100 | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | ZS630-CF | 50 | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | ZS630-NF | 85 | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | ZS800-CF | 50 | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | ZS800-NF | 85 | — | — | — | — | — | — | — | — | — | — | — |

| | Main circuit breaker | | S800-NE | S800-NEH | S1000-CE | S1250-NE | S1250-NEH | S1250-GE | S1600-NE | S1600-NEH | XS2000NE | XS2000NE HIGH INST | XS2500NE | XS2500NE HIGH INST | XS3200NE |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | Rated current $I_r$ | | 800A | 800A | 1000A | 1250A | 1250A | 1250A | 1600A | 1600A | 2000A | 2000A | 2500A | 2500A | 3200A |
| | Rated breaking capacity $I_{cu}$ sym.（kA） / Branch circuit breaker | | 85 | 85 | 100 | 100 | 100 | 125 | 125 | 125 | 125 | 125 | 125 | 125 | 125 |
| MCCB | PS30-NF, PE50-NF, PE60-NF | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 |
| MCCB | PS50-NF | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 |
| MCCB | PS60-NF, PE125-NF | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 |
| MCCB | S50-SF, S125-SF | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| MCCB | PS125-NF | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| MCCB | S100-GF, S125-GF | 85 | 65 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| MCCB | PS50-PF, PS125-PF | 85 | 50 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| MCCB | H100-NF, H125-NF | 150 | 85 | 85 | 85 | 100 | 100 | 125 | 125 | 125 | 125 | 125 | 125 | 125 | 125 |
| MCCB | E250-SF | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 |
| MCCB | PS250-NE | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| MCCB | S250-SF | 85 | 50 | 65 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| MCCB | PS250-PF, PS250-PE | 85 | 50 | 65 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| MCCB | H225-NF, H250-NF | 150 | 85 | 85 | 85 | 100 | 100 | 125 | 125 | 125 | 125 | 125 | 125 | 125 | 125 |
| MCCB | E400-NF | 35 | 30 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 |
| MCCB | PS400-CF | 50 | 30 | 36 | 36 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| MCCB | PS400-NF, PS400-NE | 85 | 30 | 36 | 36 | 50 | 65 | 50 | 65 | 85 | 85 | 85 | 85 | 85 | 85 |
| MCCB | PS400-GF, PS400-GE | 100 | 30 | 36 | 36 | 50 | 65 | 50 | 65 | 85 | 85 | 100 | 100 | 100 | 100 |
| MCCB | PH400-CF, PH400-CE | 125 | 30 | 36 | 36 | 50 | 65 | 50 | 65 | 85 | 85 | 125 | 125 | 125 | 125 |
| MCCB | H400-NE | 150 | 50 | 65 | 65 | 85 | 85 | 85 | 85 | 100 | 100 | 125 | 125 | 125 | 125 |
| MCCB | S630-CF | 50 | — | — | — | 36 | 36 | 36 | 36 | 36 | 36 | 50 | 36 | 50 | 50 |
| MCCB | PS630-CF | 50 | — | — | — | 36 | 36 | 36 | 36 | 36 | 36 | 50 | 36 | 50 | 50 |
| MCCB | S630-NF, S630-NE | 85 | — | — | — | 36 | 36 | 36 | 36 | 36 | 36 | 50 | 36 | 50 | 50 |
| MCCB | PS630-NF, PS630-NE | 85 | — | — | — | 36 | 36 | 36 | 36 | 36 | 36 | 50 | 36 | 50 | 50 |
| MCCB | PS630-GF, PS630-GE | 100 | — | — | — | 36 | 36 | 36 | 36 | 36 | 36 | 50 | 36 | 50 | 50 |
| MCCB | PH630-CF, PH630-CE | 125 | — | — | — | 36 | 36 | 36 | 36 | 36 | 36 | 50 | 36 | 50 | 50 |
| MCCB | S800-CF | 50 | — | — | — | — | — | — | 25 | 30 | 30 | 50 | 36 | 50 | 50 |
| MCCB | S800-NF, S800-NE | 85 | — | — | — | — | — | — | 25 | 30 | 30 | 50 | 36 | 50 | 50 |
| ELCB | PZS30-NF, PZE50-NF, PZE60-NF | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 |
| ELCB | PZS50-NF | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 |
| ELCB | PZS60-NF, PZE125-NF | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 |
| ELCB | ZS50-SF, ZS125-SF | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| ELCB | ZS100-GF, ZS125-GF | 85 | 65 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| ELCB | ZE250-SF | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 |
| ELCB | ZS250-SF | 85 | 50 | 65 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| ELCB | ZS225-GF, ZS250-GF | 85 | 50 | 65 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| ELCB | ZE400-NF | 35 | 30 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 | 35 |
| ELCB | ZS400-NF | 85 | 30 | 36 | 36 | 50 | 65 | 50 | 65 | 85 | 85 | 85 | 85 | 85 | 85 |
| ELCB | ZS400-GF | 100 | 30 | 36 | 36 | 50 | 65 | 50 | 65 | 85 | 85 | 100 | 100 | 100 | 100 |
| ELCB | ZS630-CF | 50 | — | — | — | 36 | 36 | 36 | 36 | 36 | 36 | 50 | 36 | 50 | 50 |
| ELCB | ZS630-NF | 85 | — | — | — | 36 | 36 | 36 | 36 | 36 | 36 | 50 | 36 | 50 | 50 |
| ELCB | ZS800-CF | 50 | — | — | — | — | — | — | 25 | 30 | 30 | 50 | 36 | 50 | 50 |
| ELCB | ZS800-NF | 85 | — | — | — | — | — | — | 25 | 30 | 30 | 50 | 36 | 50 | 50 |

Note) It is assumed that the set current and set time of the main circuit breaker for long time trip, short time trip, and instantaneous trip are all set to the maximum.

## Breaker combination table for selectivity coordination for 415V AC circuit


| Main circuit breaker | | | PS125-NE | PS250-NE | PS400-NE | PS400-GE | PH400-CE | H400-NE | L400-NE | S630-NE | S630-NEH | PS630-NE | PS630-GE | PH630-CE |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Rated current $I_r$ | | | 125A | 250A | 400A | 400A | 400A | 400A | 400A | 630A | 630A | 630A | 630A | 630A |
| Rated breaking capacity $I_{cu}$ sym. (kA) / Branch circuit breaker | | | 36 | 36 | 50 | 70 | 110 | 125 | 200 | 50 | 50 | 50 | 70 | 110 |
| MCCB | PS30-NF, PE50-NF, PE60-NF | 2.5 | 1.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 |
| | PS50-NF | 7.5 | 1.5 | 2.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 |
| | PS60-NF, PE125-NF | 10 | — | 2.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 10 | 10 | 10 | 10 | 10 |
| | S50-SF, S125-SF | 30 | — | 30 | 25 | 25 | 25 | 6 | 6 | 30 | 30 | 30 | 30 | 30 |
| | PS125-NF, PS125-NE | 36 | — | 30 | 36 | 36 | 36 | 6 | 6 | 30 | 36 | 36 | 36 | 36 |
| | S100-GF, S125-GF | 65 | — | — | 6 | 6 | 6 | 6 | 6 | 42 | 50 | 30 | 30 | 30 |
| | PS50-PF, PS125-PF, PS125-PE | 70 | — | 30 | 50 | 50 | 50 | 6 | 6 | 30 | 50 | 50 | 70 | 70 |
| | H100-NF, H125-NF | 125 | — | — | 25 | 25 | 25 | 6 | 6 | 50 | 50 | 25 | 25 | 25 |
| | E250-SF | 25 | — | — | 5 | 5 | 5 | 5 | 5 | 25 | 25 | 25 | 25 | 25 |
| | PS250-NE | 36 | — | — | 10 | 10 | 10 | 5 | 5 | 25 | 36 | 36 | 36 | 36 |
| | S250-SF | 40 | — | — | 5 | 5 | 5 | 5 | 5 | 25 | 40 | 25 | 25 | 25 |
| | PS250-PF, PS250-PE | 70 | — | — | 10 | 10 | 10 | 5 | 5 | 25 | 50 | 50 | 70 | 70 |
| | H225-NF, H250-NF | 125 | — | — | 5 | 5 | 5 | 5 | 5 | 50 | 50 | 25 | 25 | 25 |
| | E400-NF | 25 | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-CF | 36 | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-NF, PS400-NE | 50 | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-GF, PS400-GE | 70 | — | — | — | — | — | — | — | — | — | — | — | — |
| | PH400-CF, PH400-CE | 110 | — | — | — | — | — | — | — | — | — | — | — | — |
| | H400-NE | 125 | — | — | — | — | — | — | — | — | — | — | — | — |
| | S630-CF | 36 | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS630-CF | 36 | — | — | — | — | — | — | — | — | — | — | — | — |
| | S630-NF, S630-NE | 50 | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS630-NF, PS630-NE | 50 | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS630-GF, PS630-GE | 70 | — | — | — | — | — | — | — | — | — | — | — | — |
| | PH630-CF, PH630-CE | 110 | — | — | — | — | — | — | — | — | — | — | — | — |
| | S800-CF | 36 | — | — | — | — | — | — | — | — | — | — | — | — |
| | S800-NF, S800-NE | 50 | — | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | PZS30-NF, PZE50-NF, PZE60-NF | 2.5 | 1.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 |
| | PZS50-NF | 7.5 | 1.5 | 2.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 |
| | PZS60-NF, PZE125-NF | 10 | — | 2.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 10 | 10 | 10 | 10 | 10 |
| | ZS50-SF, ZS125-SF | 30 | — | — | 6 | 6 | 6 | 6 | 6 | 30 | 30 | 30 | 30 | 30 |
| | ZS100-GF, ZS125-GF | 65 | — | — | 6 | 6 | 6 | 6 | 6 | 30 | 50 | 30 | 30 | 30 |
| | ZE250-SF | 25 | — | — | 5 | 5 | 5 | 5 | 5 | 25 | 25 | 25 | 25 | 25 |
| | ZS250-SF | 40 | — | — | 5 | 5 | 5 | 5 | 5 | 25 | 40 | 25 | 25 | 25 |
| | ZS225-GF, ZS250-GF | 65 | — | — | 5 | 5 | 5 | 5 | 5 | 25 | 50 | 25 | 25 | 25 |
| | ZE400-NF | 25 | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS400-NF | 50 | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS400-GF | 70 | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS630-CF | 36 | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS630-NF | 50 | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS800-CF | 36 | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS800-NF | 50 | — | — | — | — | — | — | — | — | — | — | — | — |

| Main circuit breaker | | | S800-NE | S800-NEH | S1000-CE | S1250-NE | S1250-NEH | S1250-GE | S1600-NE | S1600-NEH | XS2000NE | XS2000NE HIGH INST | XS2500NE | XS2500NE HIGH INST | XS3200NE |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Rated current $I_r$ | | | 800A | 800A | 1000A | 1250A | 1250A | 1250A | 1600A | 1600A | 2000A | 2000A | 2500A | 2500A | 3200A |
| Rated breaking capacity $I_{cu}$ sym. (kA) / Branch circuit breaker | | | 50 | 50 | 65 | 70 | 70 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| MCCB | PS30-NF, PE50-NF, PE60-NF | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 |
| | PS50-NF | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 |
| | PS60-NF, PE125-NF | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| | S50-SF, S125-SF | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 |
| | PS125-NF, PS125-NE | 36 | 30 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 |
| | S100-GF, S125-GF | 65 | 50 | 50 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 |
| | PS50-PF, PS125-PF, PS125-PE | 70 | 36 | 50 | 65 | 70 | 70 | 70 | 70 | 70 | 70 | 70 | 70 | 70 | 70 |
| | H100-NF, H125-NF | 125 | 50 | 50 | 65 | 65 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| | E250-SF | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 |
| | PS250-NE | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 |
| | S250-SF | 40 | 36 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 |
| | PS250-PF, PS250-PE | 70 | 36 | 50 | 50 | 70 | 70 | 70 | 70 | 70 | 70 | 70 | 70 | 70 | 70 |
| | H225-NF, H250-NF | 125 | 50 | 50 | 65 | 65 | 65 | 85 | 85 | 85 | 85 | 85 | 85 | 85 | 85 |
| | E400-NF | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 |
| | PS400-CF | 36 | 25 | 30 | 30 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 | 36 |
| | PS400-NF, PS400-NE | 50 | 25 | 30 | 30 | 36 | 36 | 36 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| | PS400-GF, PS400-GE | 70 | 25 | 30 | 30 | 36 | 36 | 36 | 50 | 70 | 70 | 70 | 70 | 70 | 70 |
| | PH400-CF, PH400-CE | 110 | 25 | 30 | 30 | 36 | 36 | 36 | 50 | 85 | 85 | 85 | 85 | 85 | 85 |
| | H400-NE | 125 | 35 | 50 | 50 | 65 | 65 | 65 | 65 | 70 | 70 | 85 | 85 | 85 | 85 |
| | S630-CF | 36 | — | — | — | 30 | 30 | 30 | 30 | 30 | 30 | 36 | 30 | 36 | 36 |
| | PS630-CF | 36 | — | — | — | 30 | 30 | 30 | 30 | 30 | 30 | 36 | 30 | 36 | 36 |
| | S630-NF, S630-NE | 50 | — | — | — | 30 | 30 | 30 | 30 | 30 | 30 | 36 | 30 | 36 | 36 |
| | PS630-NF, PS630-NE | 50 | — | — | — | 30 | 30 | 30 | 30 | 30 | 30 | 36 | 30 | 36 | 36 |
| | PS630-GF, PS630-GE | 70 | — | — | — | 30 | 30 | 30 | 30 | 30 | 30 | 36 | 30 | 36 | 36 |
| | PH630-CF, PH630-CE | 110 | — | — | — | 30 | 30 | 30 | 30 | 30 | 30 | 36 | 30 | 36 | 36 |
| | S800-CF | 36 | — | — | — | — | — | — | 20 | 25 | 25 | 36 | 30 | 36 | 36 |
| | S800-NF, S800-NE | 50 | — | — | — | — | — | — | 20 | 25 | 25 | 36 | 30 | 36 | 36 |
| ELCB | PZS30-NF, PZE50-NF, PZE60-NF | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 | 2.5 |
| | PZS50-NF | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 | 7.5 |
| | PZS60-NF, PZE125-NF | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| | ZS50-SF, ZS125-SF | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 | 30 |
| | ZS100-GF, ZS125-GF | 65 | 50 | 50 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 |
| | ZE250-SF | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 |
| | ZS250-SF | 40 | 36 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 |
| | ZS225-GF, ZS250-GF | 65 | 36 | 50 | 50 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 | 65 |
| | ZE400-NF | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 | 25 |
| | ZS400-NF | 50 | 25 | 30 | 30 | 36 | 50 | 36 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| | ZS400-GF | 70 | 25 | 30 | 30 | 36 | 50 | 36 | 50 | 65 | 65 | 70 | 70 | 70 | 70 |
| | ZS630-CF | 36 | — | — | — | 30 | 30 | 30 | 30 | 30 | 30 | 36 | 30 | 36 | 36 |
| | ZS630-NF | 50 | — | — | — | 30 | 30 | 30 | 30 | 30 | 30 | 36 | 30 | 36 | 36 |
| | ZS800-CF | 36 | — | — | — | — | — | — | 20 | 25 | 25 | 36 | 30 | 36 | 36 |
| | ZS800-NF | 50 | — | — | — | — | — | — | 20 | 25 | 25 | 36 | 30 | 36 | 36 |

Note) It is assumed that the set current and set time of the main circuit breaker for long time trip, short time trip, and instantaneous trip are all set to the maximum.

# 19 Combination of breakers for cascade breaking

The following table shows possible combinations of backup and backed-up breakers (conforming to Appendix A, JIS C 8201-2-1 ) as well as the cascade breaking capacity $I_{cu}$ sym.(kA) of each combination.




## Breaker combination table for cascade breaking for 240V AC circuit

| Main circuit breaker | | | PE125-NF | S125-SF | PS125-NF | S100-GF S125-GF | PS125-PF | H100-NF H125-NF | L100-NF L125-NF | E250-SF | PS250-NE | S250-SF | PS250-PF PS250-PE | H225-NF H250-NF | L225-NF L250-NF |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Rated breaking capacity $I_{cu}$ sym. (kA) / Branch circuit breaker | | | 30 | 50 | 50 | 85 | 85 | 150 | 200 | 35 | 50 | 85 | 85 | 150 | 200 |
| MCCB | PS30-NF, PE50-NF, PE60-NF | 7.5 | 25 | 30 | 30 | 30 | 30 | 30 | 30 | 10 | 10 | 10 | 10 | 10 | 10 |
| | PS50-NF | 15 | 25 | 36 | 36 | 36 | 36 | 50 | 50 | 25 | 25 | 25 | 25 | 36 | 36 |
| | PS60-NF, PE125-NF | 30 | — | 50 | 50 | 50 | 50 | 70 | 70 | — | 50 | 50 | 50 | 50 | 50 |
| | S50-SF, S125-SF | 50 | — | — | — | 85 | 85 | 150 | 200 | — | — | 70 | 85 | 150 | 200 |
| | PS125-NF | 50 | — | — | — | 85 | 85 | 100 | — | — | — | 85 | 85 | 100 | 100 |
| | S100-GF, S125-GF | 85 | — | — | — | — | — | 150 | 200 | — | — | — | — | 150 | 200 |
| | PS50-PF, PS125-PF | 85 | — | — | — | — | — | 125 | — | — | — | — | — | 125 | 125 |
| | H100-NF, H125-NF | 150 | — | — | — | — | — | — | 200 | — | — | — | — | — | 200 |
| | E250-SF | 35 | — | — | — | — | — | — | — | — | 50 | 70 | 85 | 50 | 85 |
| | PS250-NE | 50 | — | — | — | — | — | — | — | — | — | 85 | 85 | 100 | 100 |
| | S250-SF | 85 | — | — | — | — | — | — | — | — | — | — | — | 100 | 150 |
| | PS250-PF, PS250-PE | 85 | — | — | — | — | — | — | — | — | — | — | — | 125 | 125 |
| | H225-NF, H250-NF | 150 | — | — | — | — | — | — | — | — | — | — | — | — | 200 |
| | E400-NF | 35 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-CF | 50 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-NF, PS400-NE | 85 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-GF, PS400-GE | 100 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PH400-CF, PH400-CE | 125 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | H400-NE | 150 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | PZS30-NF, PZE50-NF, PZE60-NF | 7.5 | 25 | 30 | 30 | 30 | 30 | 30 | 30 | 10 | 10 | 10 | 10 | 10 | 10 |
| | PZS50-NF | 15 | 25 | 36 | 36 | 36 | 36 | 50 | 50 | 25 | 25 | 25 | 25 | 36 | 36 |
| | PZS60-NF, PZE125-NF | 30 | — | 50 | 50 | 50 | 50 | 70 | 70 | 35 | 36 | 36 | 36 | 50 | 50 |
| | ZS50-SF, ZS125-SF | 50 | — | — | — | 85 | 85 | 150 | 200 | — | — | 70 | 85 | 150 | 200 |
| | ZS100-GF, ZS125-GF | 85 | — | — | — | — | — | 150 | 200 | — | — | — | — | 150 | 200 |
| | ZE250-SF | 35 | — | — | — | — | — | — | — | — | 50 | 70 | 85 | 50 | 85 |
| | ZS250-SF | 85 | — | — | — | — | — | — | — | — | — | — | — | 100 | 150 |
| | ZS225-GF, ZS250-GF | 85 | — | — | — | — | — | — | — | — | — | — | — | 150 | 200 |
| | ZE400-NF | 35 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS400-NF | 85 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS400-GF | 100 | — | — | — | — | — | — | — | — | — | — | — | — | — |

| Main circuit breaker | | | PS400-CF | PS400-NF PS400-NE | PS400-GF PS400-GE | PH400-CF PH400-CE | H400-NE | L400-NE | S630-CF | PS630-CF | S630-NF S630-NE | PS630-NF PS630-NE | PS630-GF PS630-GE | PH630-CF PH630-CE | S800-CF | S800-NF S800-NE | S1250-NE | S1250-GE |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Rated breaking capacity $I_{cu}$ sym. (kA) / Branch circuit breaker | | | 50 | 85 | 100 | 125 | 150 | 200 | 50 | 50 | 85 | 85 | 100 | 125 | 50 | 85 | 100 | 125 |
| MCCB | PS30-NF, PE50-NF, PE60-NF | 7.5 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS50-NF | 15 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS60-NF, PE125-NF | 30 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | S50-SF, S125-SF | 50 | — | 70 | 70 | 70 | 85 | 85 | — | — | — | — | — | — | — | — | — | — |
| | PS125-NF | 50 | — | 70 | 70 | 70 | 85 | 85 | — | — | — | — | — | — | — | — | — | — |
| | S100-GF, S125-GF | 85 | — | — | 100 | 125 | 150 | 200 | — | — | — | — | — | — | — | — | — | — |
| | PS50-PF, PS125-PF | 85 | — | — | 100 | 125 | 150 | 200 | — | — | — | — | 100 | 100 | — | — | — | — |
| | H100-NF, H125-NF | 150 | — | — | — | — | — | 200 | — | — | — | — | — | — | — | — | — | — |
| | E250-SF | 35 | 50 | 70 | 85 | 85 | 50 | 85 | 50 | 50 | 50 | 70 | 85 | 85 | 50 | 50 | — | — |
| | PS250-NE | 50 | — | 70 | 70 | 70 | 85 | 85 | — | — | 85 | 85 | 85 | 85 | — | 85 | — | — |
| | S250-SF | 85 | — | — | 100 | 100 | 100 | 150 | — | — | — | — | 100 | 100 | — | — | — | — |
| | PS250-PF, PS250-PE | 85 | — | — | 100 | 100 | 125 | 125 | — | — | — | — | 100 | 100 | — | — | — | — |
| | H225-NF, H250-NF | 150 | — | — | — | — | — | 200 | — | — | — | — | — | — | — | — | — | — |
| | E400-NF | 35 | 50 | 70 | 70 | 70 | 85 | 85 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| | PS400-CF | 50 | — | 85 | 100 | 100 | 100 | 100 | — | — | 70 | 70 | 85 | 85 | — | 70 | 70 | 70 |
| | PS400-NF, PS400-NE | 85 | — | — | 100 | 125 | 125 | 125 | — | — | — | — | 100 | 125 | — | — | 100 | 100 |
| | PS400-GF, PS400-GE | 100 | — | — | — | 125 | 150 | 150 | — | — | — | — | — | 125 | — | — | — | 125 |
| | PH400-CF, PH400-CE | 125 | — | — | — | — | 150 | 200 | — | — | — | — | — | — | — | — | — | — |
| | H400-NE | 150 | — | — | — | — | — | 200 | — | — | — | — | — | — | — | — | — | — |
| ELCB | PZS30-NF, PZE50-NF, PZE60-NF | 7.5 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PZS50-NF | 15 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PZS60-NF, PZE125-NF | 30 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS50-SF, ZS125-SF | 50 | — | 70 | 70 | 70 | 85 | 85 | — | — | — | — | — | — | — | — | — | — |
| | ZS100-GF, ZS125-GF | 85 | — | — | 100 | 125 | 150 | 200 | — | — | — | — | — | — | — | — | — | — |
| | ZE250-SF | 35 | 50 | 70 | 85 | 85 | 50 | 85 | 50 | 50 | 50 | 70 | 85 | 85 | 50 | 50 | — | — |
| | ZS250-SF | 85 | — | — | 100 | 100 | 100 | 150 | — | — | — | — | 100 | 100 | — | — | — | — |
| | ZS225-GF, ZS250-GF | 85 | — | — | 100 | 125 | 150 | 200 | — | — | — | — | — | — | — | — | — | — |
| | ZE400-NF | 35 | 50 | 70 | 70 | 70 | 85 | 85 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 50 |
| | ZS400-NF | 85 | — | — | 100 | 125 | 150 | 200 | — | — | — | — | 100 | 100 | — | — | 100 | 100 |
| | ZS400-GF | 100 | — | — | — | 125 | 150 | 200 | — | — | — | — | — | 125 | — | — | — | 125 |


## Breaker combination table for cascade breaking for 415V AC circuit

| Main circuit breaker | | | PE125-NF | S125-SF | PS125-NF PS125-NE | S100-GF S125-GF | PS125-PF PS125-PE | H100-NF H125-NF | L100-NF L125-NF | E250-SF | PS250-NE | S250-SF | PS250-PF PS250-PE | H225-NF H250-NF | L225-NF L250-NF |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Rated breaking capacity $I_{cu}$ sym. (kA) | | | 10 | 30 | 36 | 65 | 70 | 125 | 200 | 25 | 36 | 40 | 70 | 125 | 200 |
| Branch circuit breaker | | | | | | | | | | | | | | | |
| MCCB | PS30-NF, PE50-NF, PE60-NF | 2.5 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 5 | 5 | 5 | 5 | 10 | 10 |
| | PS50-NF | 7.5 | 10 | 15 | 15 | 25 | 25 | 36 | 36 | 15 | 15 | 10 | 15 | 36 | 36 |
| | PS60-NF, PE125-NF | 10 | — | 25 | 25 | 25 | 25 | 50 | 50 | 15 | 15 | 15 | 15 | 50 | 50 |
| | S50-SF, S125-SF | 30 | — | — | 36 | 65 | 70 | 80 | 180 | — | 36 | 35 | 70 | 80 | 180 |
| | PS125-NF, PS125-NE | 36 | — | — | — | 50 | 50 | 85 | — | — | — | 40 | 50 | 70 | 70 |
| | S100-GF, S125-GF | 65 | — | — | — | — | 70 | 80 | 180 | — | — | — | 70 | 80 | 180 |
| | PS50-PF, PS125-PF, PS125-PE | 70 | — | — | — | — | — | 110 | — | — | — | — | — | 110 | 110 |
| | H100-NF, H125-NF | 125 | — | — | — | — | — | — | 180 | — | — | — | — | — | 200 |
| | E250-SF | 25 | — | — | — | — | — | — | — | — | 36 | 40 | 70 | 50 | 85 |
| | PS250-NE | 36 | — | — | — | — | — | — | — | — | — | 40 | 50 | 70 | 130 |
| | S250-SF | 40 | — | — | — | — | — | — | — | — | — | — | 70 | 80 | 130 |
| | PS250-PF, PS250-PE | 70 | — | — | — | — | — | — | — | — | — | — | — | 110 | 130 |
| | H225-NF, H250-NF | 125 | — | — | — | — | — | — | — | — | — | — | — | — | 200 |
| | E400-NF | 25 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-CF | 36 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-NF, PS400-NE | 50 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS400-GF, PS400-GE | 70 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PH400-CF, PH400-CE | 110 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | H400-NE | 125 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| ELCB | PZS30-NF, PZE50-NF, PZE60-NF | 2.5 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 5 | 5 | 5 | 5 | 10 | 10 |
| | PZS50-NF | 7.5 | 10 | 15 | 15 | 25 | 25 | 36 | 36 | 10 | 15 | 10 | 15 | 36 | 36 |
| | PZS60-NF, PZE125-NF | 10 | — | 25 | 25 | 25 | 25 | 50 | 50 | 15 | 15 | 15 | 15 | 50 | 50 |
| | ZS50-SF, ZS125-SF | 30 | — | — | 36 | 65 | 70 | 80 | 180 | — | 36 | 35 | 70 | 80 | 180 |
| | ZS100-GF, ZS125-GF | 65 | — | — | — | — | 70 | 80 | 180 | — | — | — | 70 | 80 | 180 |
| | ZE250-SF | 25 | — | — | — | — | — | — | — | — | 36 | 40 | 70 | 50 | 85 |
| | ZS250-SF | 40 | — | — | — | — | — | — | — | — | — | — | 70 | 80 | 130 |
| | ZS225-GF, ZS250-GF | 65 | — | — | — | — | — | — | — | — | — | — | 70 | 80 | 200 |
| | ZE400-NF | 25 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS400-NF | 50 | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS400-GF | 70 | — | — | — | — | — | — | — | — | — | — | — | — | — |

| Main circuit breaker | | | PS400-CF | PS400-NF PS400-NE | PS400-GF PS400-GE | PH400-CF PH400-CE | H400-NE | L400-NE | S630-CF | PS630-CF | S630-NF S630-NE | PS630-NF PS630-NE | PS630-GF PS630-GE | PH630-CF PH630-CE | S800-CF | S800-NF S800-NE | S1250-NE | S1250-GE |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Rated breaking capacity $I_{cu}$ sym. (kA) | | | 36 | 50 | 70 | 110 | 125 | 200 | 36 | 36 | 50 | 50 | 70 | 110 | 36 | 50 | 70 | 85 |
| Branch circuit breaker | | | | | | | | | | | | | | | | | | |
| MCCB | PS30-NF, PE50-NF, PE60-NF | 2.5 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS50-NF | 7.5 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PS60-NF, PE125-NF | 10 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | S50-SF, S125-SF | 30 | 36 | 50 | 50 | 50 | 70 | 70 | — | — | — | — | — | — | — | — | — | — |
| | PS125-NF, PS125-NE | 36 | — | 50 | 50 | 50 | 70 | 70 | — | — | — | — | — | — | — | — | — | — |
| | S100-GF, S125-GF | 65 | — | — | 70 | 70 | 70 | 85 | — | — | — | — | — | — | — | — | — | — |
| | PS50-PF, PS125-PF, PS125-PE | 70 | — | — | — | 85 | 85 | 110 | — | — | — | — | — | 85 | — | — | — | — |
| | H100-NF, H125-NF | 125 | — | — | — | — | — | 200 | — | — | — | — | — | — | — | — | — | — |
| | E250-SF | 25 | 36 | 50 | 70 | 70 | 50 | 70 | 36 | 36 | 40 | 50 | 70 | 70 | 36 | 40 | — | — |
| | PS250-NE | 36 | — | 50 | 50 | 50 | 70 | 70 | — | — | 50 | 50 | 50 | 50 | — | 50 | — | — |
| | S250-SF | 40 | — | 50 | 70 | 70 | 70 | 130 | — | — | 50 | 50 | 70 | 70 | — | 50 | — | — |
| | PS250-PF, PS250-PE | 70 | — | — | — | 85 | 110 | 110 | — | — | — | — | — | 85 | — | — | — | — |
| | H225-NF, H250-NF | 125 | — | — | — | — | — | 200 | — | — | — | — | — | — | — | — | — | — |
| | E400-NF | 25 | 36 | 36 | 36 | 36 | 50 | 50 | 30 | 36 | 36 | 36 | 36 | 36 | 30 | 36 | 30 | 30 |
| | PS400-CF | 36 | — | 50 | 50 | 50 | 50 | 50 | — | — | 50 | 50 | 50 | 50 | — | 50 | 50 | 50 |
| | PS400-NF, PS400-NE | 50 | — | — | 70 | 70 | 70 | 70 | — | — | — | — | 70 | 70 | — | — | 70 | 70 |
| | PS400-GF, PS400-GE | 70 | — | — | — | 110 | 110 | 110 | — | — | — | — | — | 110 | — | — | — | 85 |
| | PH400-CF, PH400-CE | 110 | — | — | — | — | 125 | 150 | — | — | — | — | — | — | — | — | — | — |
| | H400-NE | 125 | — | — | — | — | — | 200 | — | — | — | — | — | — | — | — | — | — |
| ELCB | PZS30-NF, PZE50-NF, PZE60-NF | 2.5 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PZS50-NF | 7.5 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | PZS60-NF, PZE125-NF | 10 | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| | ZS50-SF, ZS125-SF | 30 | 36 | 50 | 50 | 50 | 70 | 70 | — | — | — | — | — | — | — | — | — | — |
| | ZS100-GF, ZS125-GF | 65 | — | — | 70 | 70 | 70 | 70 | — | — | — | — | — | — | — | — | — | — |
| | ZE250-SF | 25 | 36 | 50 | 70 | 70 | 50 | 70 | 36 | 36 | 40 | 50 | 70 | 70 | 36 | 40 | — | — |
| | ZS250-SF | 40 | — | 50 | 70 | 70 | 70 | 130 | — | — | 50 | 50 | 70 | 70 | — | 50 | — | — |
| | ZS225-GF, ZS250-GF | 65 | — | — | 70 | 85 | 85 | 130 | — | — | — | — | 70 | 70 | — | — | — | — |
| | ZE400-NF | 25 | 36 | 36 | 36 | 36 | 50 | 50 | 30 | 36 | 36 | 36 | 36 | 36 | 30 | 36 | 30 | 30 |
| | ZS400-NF | 50 | — | — | 70 | 70 | 120 | 130 | — | — | — | — | 70 | 70 | — | — | 65 | 65 |
| | ZS400-GF | 70 | — | — | — | 110 | 120 | 200 | — | — | — | — | — | 110 | — | — | — | 85 |

# 19 Combination of breakers for cascade breaking

The following table shows possible combinations of backup and backed-up breakers (conforming to Appendix A, IEC 60947-2) as well as the cascade breaking capacity (kA sym.) of each combination.




## Breaker combination table for cascade breaking for 450V AC circuit (approved by NK, LR, AB)

| Backup breaker / Rated breaking capacity sym.(kA) / Backed-up breaker | | PS50-NF | PS60-NF | PE125-NF | E250-SF | PS125-NF PS125-NFL PS125-NFH | PS125-NE | S125-SF | PS250-NE PS250-NEH | S250-SF | PS400-CF | PS630-CF | S630-CF | S800-CF | PS400-NF | PS400-NE PS400-NEH | PS630-NF | S100-GF S100-GFL S100-GFH S125-GF | PS50-PF PS50-PFL PS50-PFH PS125-PF PS125-PFL PS125-PFH |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 7.5 | 10 | 10 | 15 | 25 | 25 | 25 | 25 | 30 | 30 | 30 | 30 | 30 | 45 | 45 | 45 | 50 | 50 |
| PS30-NF | 2.5 | 7.5 [13.4] | 10 [21.3] | 10 [21.3] | 5 [7.74] | 10 [21.3] | 10 [21.3] | 10 [21.3] | 5 [7.74] | 5 [7.74] | | | | | | | | | |
| PE50-NF | 2.5 | 7.5 [13.4] | 10 [21.3] | 10 [21.3] | 5 [7.74] | 10 [21.3] | 10 [21.3] | 10 [21.3] | 5 [7.74] | 5 [7.74] | | | | | | | | | |
| PS50-NF | 7.5 | | 10 [21.3] | 10 [21.3] | 15 [32.6] | 15 [32.6] | 15 [32.6] | 15 [32.6] | | | | | | | | | | 15 [32.6] | 15 [32.6] |
| PS60-NF | 10 | | | | 15 [32.6] | 22 [50.7] | 22 [50.7] | 22 [50.7] | 15 [32.6] | 15 [32.6] | | | | | | | | 22 [50.7] | 22 [50.7] |
| PE125-NF | 10 | | | | 15 [32.6] | 22 [50.7] | 22 [50.7] | 22 [50.7] | 15 [32.6] | 15 [32.6] | | | | | | | | 22 [50.7] | 22 [50.7] |
| E250-SF | 15 | | | | | | | | 25 [56.2] | 25 [56.2] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | | |
| S50-SF S125-SF | 25 | | | | | | | | | | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 42 [96.7] | 42 [96.7] |
| PS125-NF PS125-NFL PS125-NFH | 25 | | | | | | | | | | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 42 [96.7] | 42 [96.7] |
| PS125-NE | 25 | | | | | | | | | | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 42 [96.7] | 42 [96.7] |
| PS250-NE PS250-NEH | 25 | | | | | | | | | | 30 [70.8] | 30 [70.8] | 30 [70.8] | 30 [70.8] | 42 [96.7] | 42 [96.7] | 42 [96.7] | | |
| S250-SF | 30 | | | | | | | | | | | | | | 42 [96.7] | 42 [96.7] | 42 [96.7] | | |
| PS400-CF | 30 | | | | | | | | | | | | | | 45 [109] | 45 [109] | 45 [109] | | |
| PS630-CF | 30 | | | | | | | | | | | | | | | | 45 [109] | | |
| S630-CF | 30 | | | | | | | | | | | | | | | | 45 [109] | | |
| S800-CF | 30 | | | | | | | | | | | | | | | | | | |
| S100-GF S100-GFL S100-GFH S125-GF | 50 | | | | | | | | | | | | | | | | | | |
| PS50-PF PS50-PFL PS50-PFH PS125-PF PS125-PFL PS125-PFH | 50 | | | | | | | | | | | | | | | | | | |
| PS125-PE | 50 | | | | | | | | | | | | | | | | | | |
| PS250-PF PS250-PFL PS250-PFH | 50 | | | | | | | | | | | | | | | | | | |
| PS250-PE PS250-PEH | 50 | | | | | | | | | | | | | | | | | | |
| S630-NF | 50 | | | | | | | | | | | | | | | | | | |
| S630-NE S630-NEH | 50 | | | | | | | | | | | | | | | | | | |
| S800-NF | 50 | | | | | | | | | | | | | | | | | | |
| S800-NE S800-NEH | 50 | | | | | | | | | | | | | | | | | | |
| H100-NF H125-NF | 120 | | | | | | | | | | | | | | | | | | |
| H225-NF | 120 | | | | | | | | | | | | | | | | | | |
| H400-NE | 120 | | | | | | | | | | | | | | | | | | |

**Notes:** ① Values enclosed in square brackets "[ ]" represent the making current.

| | PS125-PE | PS250-PF<br>PS250-PFL<br>PS250-PFH | PS250-PE<br>PS250-PEH | S630-NF | S630-NE<br>S630-NEH | S800-NF | S800-NE<br>S800-NEH | PS400-GF | PS400-GE<br>PS400-GEH | PH400-CF | PH400-CE | H100-NF<br>H125-NF | H225-NF | H400-NE | H630-NE | H800-NE | L100-NF<br>L125-NF | L225-NF | L400-NE | L630-NE | L800-NE |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | 50 | 50 | 50 | 50 | 50 | 50 | 50 | 65 | 65 | 100 | 100 | 120 | 120 | 120 | 125 | 125 | 180 | 180 | 180 | 180 | 180 |
| | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | |
| | 15<br>[32.6] | | | | | | | | | | | | | | | | | | | | |
| | 22<br>[50.7] | 15<br>[32.6] | 15<br>[32.6] | | | | | | | | | | | | | | | | | | |
| | 22<br>[50.7] | 15<br>[32.6] | 15<br>[32.6] | | | | | | | | | | | | | | | | | | |
| | | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | | 50<br>[121] | 50<br>[121] | 30<br>[65.2] | 30<br>[65.2] | | 70<br>[165] | 70<br>[165] | 30<br>[70.8] | 30<br>[70.8] |
| | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 50<br>[121] | 50<br>[121] | 50<br>[121] | 30<br>[70.8] | 30<br>[70.8] | 180<br>[430] | 70<br>[165] | 70<br>[165] | 30<br>[70.8] | 30<br>[70.8] |
| | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 50<br>[112] | | | | | 180<br>[430] | | | | |
| | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 30<br>[70.8] | 50<br>[112] | | | | | 180<br>[430] | | | | |
| | | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | | 70<br>[165] | | | | | 130<br>[311] | | | |
| | | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | 42<br>[96.7] | | 70<br>[165] | 70<br>[165] | 70<br>[165] | 70<br>[165] | | 130<br>[311] | 130<br>[311] | 85<br>[203] | 85<br>[203] |
| | | | | 50<br>[112] | 50<br>[112] | 50<br>[112] | 50<br>[112] | 50<br>[112] | 50<br>[112] | 50<br>[112] | 50<br>[112] | | | | | | | | | | |
| | | | | 50<br>[112] | 50<br>[112] | 50<br>[112] | 50<br>[112] | | | | | | | | | | | | | | |
| | | | | 50<br>[117] | 50<br>[117] | 50<br>[117] | 50<br>[117] | | | | | | | | 100<br>[230] | 100<br>[230] | | | | 130<br>[311] | 130<br>[311] |
| | | | | | | 50<br>[117] | 50<br>[117] | | | | | | | | | 100<br>[230] | | | | | 130<br>[311] |
| | | | | | | | | | | | | 70<br>[165] | 70<br>[165] | 70<br>[165] | | | 180<br>[430] | 85<br>[203] | 85<br>[203] | | |
| | | | | | | | | | | | | 70<br>[165] | | | | | 180<br>[430] | | | | |
| | | | | | | | | | | | | 70<br>[165] | | | | | 180<br>[430] | | | | |
| | | | | | | | | | | | | | 70<br>[165] | | | | | 130<br>[311] | | | |
| | | | | | | | | | | | | | 70<br>[165] | | | | | 130<br>[311] | | | |
| | | | | | | | | | | | | | | | 100<br>[230] | 100<br>[230] | | | | 130<br>[311] | 130<br>[311] |
| | | | | | | | | | | | | | | | 100<br>[230] | 100<br>[230] | | | | 130<br>[311] | 130<br>[311] |
| | | | | | | | | | | | | | | | | 100<br>[230] | | | | | 130<br>[311] |
| | | | | | | | | | | | | | | | | 100<br>[230] | | | | | 130<br>[311] |
| | | | | | | | | | | | | | | | | | 180<br>[430] | | | | |
| | | | | | | | | | | | | | | | | | | 130<br>[311] | | | |
| | | | | | | | | | | | | | | | | | | | 180<br>[396] | 180<br>[396] | 180<br>[396] |

# 19 Combination of breakers for cascade breaking

## Breaker combination table for cascade breaking for 240V AC circuit (approved by NK, LR, AB)

| Backup breaker / Rated breaking capacity / Backed-up breaker | sym.(kA) | PS50-NF | PS60-NF | PE125-NF | S125-SF | PS125-NF PS125-NFL PS125-NFH | PS125-NE | S250-SF | PS250-NE PS250-NEH | PS250-PF PS250-PFL PS250-PFH | PS250-PE PS250-PEH |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | 15 | 30 | 30 | 50 | 50 | 50 | 85 | 50 | 85 | 85 |
| **TB-5P** | 5② | 15 [33.7] | 25 [55.0] | 25 [55.0] | 25 [55.6] | 25 [55.0] | 25 [55.0] | | | | |
| **TB-5D** | 5② | 15 [33.7] | 25 [55.0] | 25 [55.0] | 25 [55.6] | 25 [55.0] | 25 [55.0] | | | | |
| **PS30-NF** | 7.5 | 15 [31.0] | 25 [56.9] | 25 [56.9] | | 30 [61.9] | 30 [61.9] | | | | |
| **PE50-NF** | 7.5 | 15 [31.0] | 25 [56.9] | 25 [56.9] | | 30 [61.9] | 30 [61.9] | | | | |
| **PS50-NF** | 15 | | 25 [56.9] | 25 [56.9] | | 30 [61.9] | 30 [61.9] | 25 [56.9] | 25 [56.9] | 25 [56.9] | 25 [56.9] |
| **PS60-NF** | 30 | | | | 50 [115] | 50 [115] | 50 [115] | 50 [115] | 50 [115] | 50 [115] | 50 [115] |
| **PE125-NF** | 30 | | | | 50 [115] | 50 [115] | 50 [115] | 50 [115] | 50 [115] | 50 [115] | 50 [115] |



**Notes:**
① Values enclosed in square brackets "[ ]" represent the making current.
② If the rated current is 10A, the rated breaking capacity is 2.5 kA.



# 20 Selection of rated operational voltage and number of poles


Select according to the circuit voltage and the distribution system. The circuit voltage in the table below shows the standard value, but even if it is a special voltage, if the voltage including the voltage fluctuation of the circuit is within the operable voltage fluctuation range shown on the right, earth leakage operation will occur.

Rated operational voltage and operable voltage fluctuation range

| Rated operational voltage (AC) | operable voltage fluctuation range |
|---|---|
| For 100V | 80 – 121V |
| 100 to 100 / 200V common | 80 – 242V |
| For 100 / 200V | 80 – 242V |
| 100 to 200V common | 80 – 242V |
| 100 to 240V common | 80 – 264V |
| 100 to 440V common | 80 – 484V |
| 200 to 440V common | 160 – 484V |

| Distribution system | 1ø2W・100V or 200V circuit | 1ø3W・100 200V circuit |
|---|---|---|
| Connection example |  |  |

| Distribution system | 3ø3W・200V circuit | 3ø3W・415V circuit |
|---|---|---|
| Connection example |  |  |

| Distribution system | 3ø4W・415V circuit |
|---|---|
| Connection example |  |

〈Notes on selection connection〉

(1) When using a 3-pole product as a 2-pole product, be sure to use the left and right poles. If you connect other than the left and right poles, earth leakage operation will not occur.

(2) For the main trunk of a 1ø3W 100/200V circuit, use a 3-pole product of a single phase 3-wire earth leakage circuit breakers with neutral phase open protection with a rated operational voltage of 100/200V, and connect the neutral pole to the central pole.


(3) For the main trunk of a 3ø4W 415V circuit, use a 4-pole product with a rated operational voltage of 440V, and connect the neutral pole to the N pole on the right side.

# 21 Selection of single phase 3-wire circuit breakers with neutral phase open protection

Single phase 3-wire circuit breakers with neutral phase open protection, single phase 3-wire earth leakage circuit breakers with neutral phase open protection, and single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm protect load devices from single phase 3-wire neutral wire open phase accidents.

When the neutral wire of a single phase 3-wire circuit is open phase, the voltage that is normally balanced between the load devices becomes unbalanced. For example, in the example on the right, a voltage of 167V is applied to a 40W device and a voltage of 33V is applied to a 200W device. This may shorten the service life of the load device or cause a malfunction.

In order to prevent this, single phase 3-wire circuit breakers with neutral phase open protection, single phase 3-wire earth leakage circuit breakers with neutral phase open protection, and single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm detect the abnormal voltage, securely break the electric circuit, and at the same time, protect against overload and short circuit.




## Precautions for selection connection


(1) : A circuit breaker dedicated to single-phase 3-wire 100/200V circuits.

(2) : Connect the neutral wire to the central pole and the voltage line (200V) to the left and right poles.

(3) : Be sure to connect the overvoltage detection lead wire to the load side (OFF side) of the circuit breaker. If it is connected to the line side (ON side), voltage will be applied to the OFF side even when the circuit breaker is turned off.

(4) : Connect the overvoltage detection lead wire to the end of the neutral wire on the load side (OFF side) of the circuit. It will not operate unless it is connected.


(5) : The overvoltage test button of single phase 3-wire circuit breakers with neutral phase open protection and single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm checks the overvoltage operation.




(6) : The test button of single phase 3-wire earth leakage circuit breakers with neutral phase open protection checks the overvoltage and earth leakage operation.

## 22 Application of single phase 3-wire circuit breakers/earth leakage circuit breakers with neutral phase open protection to parallel circuits

When installing multiple parallel circuits under the single phase 3-wire circuit breakers / earth leakage circuit breakers with neutral phase open protection, it is possible to increase the number of detection circuits by inserting a diode in parallel with the overvoltage detection lead wire as shown below.




■ Diode specifications

Choose a general silicon rectifying diode with a reverse voltage of 1000V or more and an average forward current of 1A or more.

■ Warning

The wire thickness of the extension lead wire should be the same as the overvoltage detection lead wire.

The total wiring distance (①+②+③+④) between the overvoltage detection lead wire and the extension lead wire should be 30m or less.

# 23 Selection of single phase 3-wire earth leakage circuit breakers with neutral phase open protection for photovoltaic power generation systems

## System configuration


Connecting the electricity of a photovoltaic power generation system to the electricity of an electric power company and using both sources of electricity is called grid interconnection. The power generated from the solar cells installed on the roof is converted from DC to AC by the power conditioner, connected to the load side of the photovoltaic power generation side circuit breaker in the distribution board, and supplied to the load from the distribution board together with the power from the electric power company.

## Selection of circuit breaker

The power from the power conditioner is reversely connected to the load side of the photovoltaic power generation side circuit breaker by a single-phase 2-wire system (in the case of a general single-phase 2-wire interconnection). If there is an imbalance in the load, an overcurrent will occur in the neutral line at the receiving point. Therefore, a 3P3E circuit breaker with overcurrent protection elements at all poles is used as the main circuit breaker. In addition, to prevent overvoltage failure, a single phase 3-wire earth leakage circuit breakers with neutral phase open protection is used as the main circuit breaker.
If the main circuit breaker trips, the voltage will continue to be applied to the load side by the power of the power conditioner. With Terasaki single phase 3-wire breaker with neutral phase open protection, since the overvoltage and earth leakage detection circuits have a continuous rating specification, there is no need to turn off the power of the detection circuits using a Megger test switch, etc.
In the case of a relatively large photovoltaic power generation system such as on a commercial building, it is connected to the load side of the photovoltaic power generation side circuit breaker 3P3E by single-phase 3-wire (single-phase 3-wire interconnection).


| Grid interconnection | Circuit breakers that can be used on the main trunk side | Circuit breakers that can be used on the photovoltaic |
|---|---|---|
| Single phase 2-wire interconnection | Single phase 3-wire earth leakage circuit breakers with neutral phase open protection 3P3E | Moulded case circuit breaker 3P2E Reverse connection performance |
| Single phase 3-wire interconnection | Single phase 3-wire earth leakage circuit breakers with neutral phase open protection 3P3E | Moulded case circuit breaker 3P3E Reverse connection performance |

[**Single phase 2-wire interconnection**] Electricity is supplied from the solar cell through the power conditioner to the two 200V wires.




O:Connect a signal line to the central phase so that the solar cell does not supply electricity in stand-alone mode when the circuit breaker on the main trunk side opens (power failure).

[**Single phase 3-wire interconnection**] Electricity is supplied from the solar cell through the power conditioner to the three 100/200V wires.



# 4 Special Breakers


1 Instantaneous trip only breakers ····· 4-2
2 Special instantaneous trip breakers ····· 4-4
3 Circuit Breaker For DC Special Voltage ····· 4-6
4 DC specification product instantaneous trip set current value ····· 4-7
5 Type 2 Heat Resistant Circuit Breaker for Emergency Power Supplies ····· 4-8
6 Thermal Adjustable Circuit Breaker for Overseas Plants ····· 4-9
7 690V AC Circuit Breaker ····· 4-10
8 Special Mounting Dimensions 400 A Frame Circuit Breaker ····· 4-12
9 High-Performance Electronic Smart Circuit Breaker (TPOU type OCR) ····· 4-14
10 High-Performance Electronic Circuit Breaker (XOW type OCR) ····· 4-23
11 Circuit Breaker for Special Environments ····· 4-29

# 4 Special Breakers


## Moulded Case Circuit Breakers

### 1 Instantaneous trip only breakers

The instantaneous trip only breaker is a short circuit current protection-dedicated breaker that has only the magnetic tripping device with a thermal overload trip device excluded from the standard breaker. Other ratings and specifications and outline dimensions of these breakers are the same as those of standard breakers of the same types.

| Category | New type | Rated current (A) | Code number | Instantaneous trip current (A) |
|---|---|---|---|---|
| Fixed instantaneous trip ①⑤ | **PS50-NF** ③ | 20I | I50 | 500±100 |
| | | 50I | I60 | 600±120 |
| | **PE125-NF** ③ | 60I | I75 | 750±150 |
| | | 75I | I100 | 1000±200 |
| | | 125I | I150 | 1500±300 |
| | **H100-NF** **L100-NF** **S100-GF** ④ | 15I | I18 | 180±36 |
| | | 20I | I24 | 240±48 |
| | | 30I | I36 | 360±72 |
| | | 40I | I48 | 480±96 |
| | | 50I | I60 | 600±120 |
| | | 100I | I72 | 720±144 |
| | | | I90 | 900±180 |
| | | | I120 | 1200±240 |
| | **S125-GF** ④ | 125I | I125 | 1250±250 |
| | **S125-SF** ③ | 125I | I60 | 600±120 |
| | | | I100 | 1000±200 |
| | | | I160 | 1600±320 |
| | **H125-NF, L125-NF** ④ | 125I | I150 | 1500±300 |
| | **H225-NF, L225-NF** ④ | 225I | I162 | 1625±325 |
| | | | I195 | 1950±390 |
| | | | I227 | 2275±455 |
| | | | I260 | 2600±520 |
| | | | I292 | 2925±585 |
| | **E250-SF, S250-SF** ④ | 250I | I162 | 1625±325 |
| | | | I195 | 1950±390 |
| | | | I227 | 2275±455 |
| | | | I260 | 2600±520 |
| | | | I292 | 2925±585 |
| | **E400-NF** ④ | 400I | I250 | 2500±500 |
| | | | I300 | 3000±600 |
| | | | I350 | 3500±700 |
| | | | I400 | 4000±800 |

| Category | New type | Rated current (A) | Code number \ Dial position | 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|---|---|---|
| Adjustable instantaneous trip ②⑤ | **S630-CF** **S630-NF** ④ | 630I | V500 | 5000 | 4500 | 4000 | 3500 | 3000 | 2500 |
| | | | V600 | 6000 | 5400 | 4800 | 4200 | 3600 | 3000 |
| | | | V630 | 6300 | 5670 | 5040 | 4410 | 3780 | 3150 |
| | **S800-CF** **S800-NF** **S800-RF** **S800-PF** ④ | 800I | Code number \ Dial position | 10 | 9 | 8 | 7 | 6 | 5 |
| | | | V700 | 7000 | 6300 | 5600 | 4900 | 4200 | 3500 |
| | | | V800 | 8000 | 7200 | 6400 | 5600 | 4800 | 4000 |



Selector dial

● The instantaneous trip current values shown in the table above are standard settings. Contact us if you require other settings.

**Note:**

① Setting tolerance: ± 20% (Please specify the code number.)

② For AC, the dial position is set to 10 before delivery. Setting tolerance: ± 20% (Please specify the code number.)
For DC, it is fixed at one point. The dial position is set to the instantaneous trip current value you request before delivery.
Setting tolerance: ± 20% (Specify that the circuit breaker is for DC, the code number, and the instantaneous trip current value.)

③ See page 4-7 for the instantaneous trip current value when using with DC. Setting tolerance: ± 20%

④ Please specify whether you require a circuit breaker for DC. Unless otherwise specified, circuit breakers are manufactured for AC.


⑤ The colour of the circuit breaker cover is Grey Blue.



Nameplate installed on the magnetic breakers only


| Category | New type | Rated current (A) | Code number | Instantaneous trip current (A) |
|---|---|---|---|---|
| Fixed instantaneous trip ①④ | **PS50-PF** | 20I | I30 | 300±60 |
| | | 30I | I45 | 450±90 |
| | | 40I | I60 | 600±120 |
| | | 50I | I75 | 750±150 |
| | **PS125-NF**<br>**PS125-PF** | 20I | I30 | 300±60 |
| | | 30I | I45 | 450±90 |
| | | 40I | I60 | 600±120 |
| | | 50I | I75 | 750±150 |
| | | 60I | I90 | 900±180 |
| | | 75I | I112 | 1125±225 |
| | | 100I | I150 | 1500±300 |
| | | 125I | I150 | 1500±300 |
| | **PS250-PF** | 250I | I162 | 1625±325 |
| | | | I195 | 1950±390 |
| | | | I227 | 2275±455 |
| | | | I240 | 2400±480 |
| | | | I247 | 2475±495 |
| | | | I250 | 2500±500 |

| Adjustable instantaneous trip ②④ | **PS400-CF**<br>**PS400-NF**<br>**PS400-GF**<br>**PH400-CF** | 400I | Code number \ Dial position | 12 | 11 | 10 | 9 | 8 | 7 | 6 |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | V225 | 2700 | 2475 | 2250 | 2025 | 1800 | 1575 | 1350 |
| | | | V250 | 3000 | 2750 | 2500 | 2250 | 2000 | 1750 | 1500 |
| | | | V300 | 3600 | 3300 | 3000 | 2700 | 2400 | 2100 | 1800 |
| | | | V350 | 4200 | 3850 | 3500 | 3150 | 2800 | 2450 | 2100 |
| | | | V400 | 4800 | 4400 | 4000 | 3600 | 3200 | 2800 | 2400 |



Selector dial

| Adjustable instantaneous trip ③④ | **PS630-CF**<br>**PS630-NF**<br>**PS630-GF**<br>**PH630-CF** | 500I(PM,DR,PG)<br>600I(FC,RC,FP)<br>⑤ | Code number \ Dial position | 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|---|---|---|
| | | | V500 | 5000 | 4500 | 4000 | 3500 | 3000 | 2500 |
| | | | V600 | 6000 | 5400 | 4800 | 4200 | 3600 | 3000 |



Selector dial

**Note:**


① Setting tolerance: ±20% (Please specify the code number.)
See page 4-7 for the instantaneous trip current value when using with DC.

② For AC, the dial position is set to 12 before delivery. Setting tolerance: ±20% (Please specify the code number.)
See page 4-7 for the instantaneous trip current value when using with DC. The dial position is set to 12 before delivery. Setting tolerance: ±20% (Specify that the circuit breaker is for DC and the code number.)

③ For AC, the dial position is set to 10 before delivery. Setting tolerance: ±20% (Please specify the code number.)
See page 4-7 for the instantaneous trip current value when using with DC. The dial position is set to 10 before delivery. Setting tolerance: ±20% (Specify that the circuit breaker is for DC and the code number.)

④ The colour of the circuit breaker cover is Grey Blue.

⑤ For FC (front-connected type), RC (rear-connected type), and FP (flush-mounted type), 600I is indicated and a rated current of up to 600 A can flow. For PM (plug-in type), DR (draw-out type), and PG (TemPlug70), 500I is indicated, and the rated current must be reduced to 500 A.



Nameplate installed on the magnetic breakers only

# 1. High Instantaneous Trip

High instantaneous trip breakers are the breakers having a high instantaneous trip pickup current.
Use these breakers in order to achieve selective coordination or to provide protection on the primary side of transformer.

| Category | Type (Reference type ②) | Rated current (A) | | Instantaneous trip current (A) |
|---|---|---|---|---|
| Thermal -Magnetic type | PS50-PFH(PS50-PF) | 15 | | 300 |
| | | 20 | | 400 |
| | | 30 | | 600 |
| | | 40 | | 800 |
| | | 50 | | 1000 |
| | S100-GFH(S100-GF)<br>PS125-NFH(PS125-NF)<br>PS125-PFH(PS125-PF) | 15 | | 300 |
| | | 20 | | 400 |
| | | 30 | | 600 |
| | | 40 | | 800 |
| | | 50 | | 1000 |
| | | 60 | | 1200 |
| | | 75 | | 1500 |
| | | 100 | | 1800 |
| | PS125-NFH(PS125-NF)<br>PS125-PFH(PS125-PF) | 125 | | 1800 |
| | E250-SFH(E250-SF)<br>S250-SFH(S250-SF) | 125 | | 2250 |
| | | 150 | | 2700 |
| | | 175 | | 3150 |
| | | 200 | | 3600 |
| | | 225 | | 4050 |
| | PS250-PFH(PS250-PF) | 125 | | 2250 |
| | | 150 | | ⑨⓪ |
| | | 175 | | ⑨⓪ |
| | | 200 | | ⑨⓪ |
| | | 225 | | ⑨⓪ |
| | | 250 | | ⑨⓪ |
| Electronic type | PS250-NEH(PS250-NE)<br>PS250-PEH(PS250-PE) | Sensor rated current (A) : ($I_n$) | Rated current (A) : ($I_r$) | 3000 |
| | | 250 | 125 | |
| | | | 150 | |
| | | | 175 | |
| | | | 200 | |
| | | | 225 | |
| | | | 250 | |
| | PS400-NEH(PS400-NE)<br>PS400-GEH(PS400-GE)<br>PH400-CEH(PH400-CE) | Sensor rated current (A) : ($I_n$) | Rated current (A) : ($I_r$) | 6300 |
| | | 400 | 175 | |
| | | | 200 | |
| | | | 225 | |
| | | | 250 | |
| | | | 300 | |
| | | | 350 | |
| | | | 400 | |
| | S630-NEH(S630-NE) | CT rated current (A) : ($I_{CT}$) | Rated current (A) : ($I_r$) | 10000 |
| | | 630 | 250 | |
| | | | 300 | |
| | | | 350 | |
| | | | 400 | |
| | | | 500 | |
| | | | 600 | |
| | | | 630 | |
| | S800-NEH(S800-NE)<br>S800-REH(S800-RE)<br>S800-PEH(S800-PE) | CT rated current (A) : ($I_{CT}$) | Rated current (A) : ($I_r$) | 10000 |
| | | 800 | 350 | |
| | | | 400 | |
| | | | 450 | |
| | | | 500 | |
| | | | 600 | |
| | | | 700 | |
| | | | 800 | |
| | S1250-NEH(S1250-NE) | CT rated current (A) : ($I_{CT}$) | Rated current (A) : ($I_r$) | 15000 |
| | | 1250 | 500 | |
| | | | 600 | |
| | | | 700 | |
| | | | 800 | |
| | | | 1000 | |
| | | | 1200 | |
| | | | 1250 | |
| | S1600-NEH(S1600-NE) | CT rated current (A) : ($I_{CT}$) | Rated current (A) : ($I_r$) | 19200 |
| | | 1600 | 700 | |
| | | | 800 | |
| | | | 900 | |
| | | | 1000 | |
| | | | 1200 | |
| | | | 1400 | |
| | | | 1500 | |
| | | | 1600 | |
| | XS2000NE④ | CT rated current (A) : ($I_{CT}$) | Rated current (A) : ($I_r$) | 35000 |
| | | 2000 | 1000 | |
| | | | 1200 | |
| | | | 1400 | |
| | | | 1600 | |
| | | | 1800 | |
| | | | 2000 | |
| | XS2500NE④ | CT rated current (A) : ($I_{CT}$) | Rated current (A) : ($I_r$) | 35000 |
| | | 2500 | 1200 | |
| | | | 1400 | |
| | | | 1600 | |
| | | | 2000 | |
| | | | 2500 | |

**Note:**
① Setting tolerance: ±20%
② The rating, specifications, and external dimensions are the same as the circuit breakers in this column. (The instantaneous trip pickup current value is different.)
③ A circuit breaker with an optional trip indicator are not available.
④ The colour of the circuit breaker cover is Grey Blue.
⑨⓪ Please contact us for details.



Nameplate of High-Inst breakers

# 2. Low Instantaneous Trip

Low instantaneous trip breakers are the breakers having a low instantaneous trip pickup current. Use these breakers in order to achieve selective coordination with a upstream high-voltage fuse.

| Category | Type (Reference type ②) | Rated current (A) | Instantaneous trip current (A) |
|---|---|---|---|
| Thermal -Magnetic type ①③ | **PS50-PFL(PS50-PF)** | 15 | 90 |
| | | 20 | 120 |
| | | 30 | 180 |
| | | 40 | 240 |
| | | 50 | 300 |
| | **S100-GFL(S100-GF)**<br>**PS125-NFL(PS125-NF)**<br>**PS125-PFL(PS125-PF)** | 15 | 90 |
| | | 20 | 120 |
| | | 30 | 180 |
| | | 40 | 240 |
| | | 50 | 300 |
| | | 60 | 360 |
| | | 75 | 450 |
| | | 100 | 600 |
| | **PS125-NFL(PS125-NF)**<br>**PS125-PFL(PS125-PF)** | 125 | 750 |
| | **E250-SFL(E250-SF)**<br>**S250-SFL(S250-SF)**<br>**PS250-PFL(PS250-PF)** | 125 | 750 |
| | | 150 | 900 |
| | | 175 | 1050 |
| | | 200 | 1200 |
| | | 225 | 1350 |
| | | 250 | 1500 |

**Note:**

① Setting tolerance: ±20%
② The rating, specifications, and external dimensions are the same as the circuit breakers in this column.
(The instantaneous trip pickup current value is different.)
③ The colour of the circuit breaker cover is Grey Blue.




Nameplate of Low-Inst breakers

# 3 Circuit Breaker For DC Special Voltage

Standard circuit breakers cannot be used in circuits above 250 V DC.
Please see Catalogue I73K for the specifications of the circuit breakers for 350 V DC to 1000 V DC.

| | Voltage (DC) \ Frame size (A) | 50 | 100 / 125 | | 225 / 250 | | 400 | 800 | 1000 | 1250 | 1600 | 2000 | 2500 | 3200 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Moulded Case Circuit Breakers | 1000V | | | PVS125-SDH 4P 5kA/5kA | | PVS250-SDH 4P 5kA/5kA | PVS400-NDH 4P 10kA/5kA | PVS800-NDH 4P 10kA/5kA | | | | | | |
| | | | | PVS125-GDH 4P 10kA/5kA | | PVS250-GDH 4P 10kA/5kA | | PVS800-GDH 4P 15kA/15kA | | | | | | |
| | 750V | | PVE125-SDL 3P 3kA/3kA | PVS125-SDL 3P 10kA/5kA | | PVS250-SDL 3P 10kA/5kA | PVS400-NDL 3P 10kA/5kA | PVS800-NDL 3P 10kA/10kA | | | | | | |
| | | | | | | | PVS400-NDL 4P 10kA/10kA | PVS800-NDL 4P 10kA/10kA | | | | | | |
| | 600V | S50-SD 3P 5kA/5kA | S125-SD 3P 5kA/5kA | S125-GD 3P 10kA/5kA | S250-SD 3P 5kA/5kA | S250-GD 3P 10kA/5kA | S400-ND 3P 15kA/15kA | S800-ND 3P 20kA/10kA | S1000-ND 3P 20kA/10kA | XS1250ND 3P 20kA/15kA | XS1600ND 3P 20kA/15kA | XS2000ND 3P 20kA/15kA | XS2500ND 3P 20kA/15kA | XS3200ND 3P 20kA/15kA |
| | 500V | S50-SD 3P 7.5kA/7.5kA | S125-SD 3P 7.5kA/7.5kA | S125-GD 3P 15kA/7.5kA | S250-SD 3P 7.5kA/7.5kA | S250-GD 3P 15kA/7.5kA | | | | XS1250ND 3P 50kA/25kA | XS1600ND 3P 50kA/25kA | XS2000ND 3P 50kA/25kA | XS2500ND 3P 50kA/25kA | XS3200ND 3P 50kA/25kA |
| | 350V | S50-SD 3P 10kA/10kA | S125-SD 3P 10kA/10kA | | S250-SD 3P 10kA/10kA | | S400-ND 3P 20kA/20kA | S800-ND 3P 30kA/15kA | S1000-ND 3P 30kA/15kA | | | | | |
| | 250V | | | | | | | | S1000-ND 2P 50kA/20kA | XS1250ND 2P 50kA/30kA | XS1600ND 2P 50kA/30kA | XS2000ND 2P 50kA/30kA | XS2500ND 2P 50kA/30kA | XS3200ND 2P 50kA/30kA |
| Switch-disconnectors | 1000V | | PVS125-SNH 4P | | | PVS250-SNH 4P | PVS400-NNH 4P | PVS800-NNH 4P | | | | | | |
| | 800V | | PVS125-SNL 4P | | | PVS250-SNL 4P | PVS400-NNL 4P | PVS800-NNL 4P | | | | | | |
| | 750V | | | | | PVS250-SNL 3P | PVS400-NNL 3P | PVS800-NNL 3P | | | | | | |
| | 600V | | S125-SDN 3P | | S250-SDN 3P | | | | | | | | | |




# 4 DC specification product instantaneous trip set current value

The table below shows the DC specification product instantaneous trip pickup current value. Note that the instantaneous trip pickup current value is different from the standard AC product. DC specification product is a special specification. When ordering, please specify DC. The DC specification product in the table below shows the instantaneous trip pickup current value for the products.

| Breaker | Rated current (A) | DC instantaneous trip pickup current (A) |
|---|---|---|
| **PS30-NF**<br>**PE50-NF**<br>**PS50-NF** | 15 | 450±90 |
| | 20 | 500±100 |
| | 30 | 600±120 |
| **PE50-NF**<br>**PS50-NF** | 40 | 780±156 |
| | 50 | 960±192 |
| **PE60-NF**<br>**PS60-NF**<br>**PE125-NF** | 60 | 1125±225 |
| **PE125-NF** | 75 | 1300±260 |
| | 100 | 1950±390 |
| | 125 | 1950±390 |
| **S50-SF**<br>**S125-SF** | 15 | 750±150 |
| | 20 | 750±150 |
| | 30 | 750±150 |
| | 40 | 750±150 |
| | 50 | 750±150 |
| **S125-SF** | 60 | 1220±244 |
| | 75 | 1220±244 |
| | 100 | 1940±388 |
| | 125 | 1940±388 |
| **PS50-PF**<br>**PS125-NF**<br>**PS125-PF** | 15 | 375±75 |
| | 20 | 375±75 |
| | 30 | 563±113 |
| | 40 | 750±150 |
| | 50 | 938±188 |
| **PS125-NF**<br>**PS125-PF** | 60 | 1125±225 |
| | 75 | 1406±281 |
| | 100 | 1875±375 |
| | 125 | 1875±375 |
| **PS250-PF** | 125 | 2031±406 |
| | 150 | 2438±488 |
| | 175 | 2844±569 |
| | 200 | 3000±600 |
| | 225 | 3094±619 |
| | 250 | 3125±625 |

**PS400-CF** ①
**PS400-NF**
**PS400-GF**
**PH400-CF**


| Rated current (A) \ Dial position | 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|
| 225 | 2470 | 2180 | 1960 | 1640 | 1380 | 1125 |
| 250 | 2760 | 2440 | 2130 | 1820 | 1530 | 1250 |
| 300 | 3340 | 2950 | 2560 | 2200 | 1840 | 1500 |
| 350 | 3930 | 3460 | 3010 | 2570 | 2150 | 1750 |
| 400 | 4530 | 3980 | 3460 | 2950 | 2470 | 2000 |



Selector dial

**PS630-CF** ②
**PS630-NF**
**PS630-GF**
**PH630-CF**

| Rated current (A) \ Dial position | 8 | 7 | 6 | 5 | 4 |
|---|---|---|---|---|---|
| 500 | 4790 | 4030 | 3320 | 2660 | 2040 |
| 600 | 6050 | 5050 | 4120 | 3260 | 2480 |



Selector dial

**Note:**

①: The dial position is set to 10 before delivery. The instantaneous trip pickup current value is indicated on the product within the range of MAX side (dial position 10) and MIN side (dial position 5). Setting tolerance: ±20%

②: The dial position is set to 8 before delivery. The instantaneous trip pickup current value is indicated on the product within the range of MAX side (dial position 8) and MIN side (dial position 4). Setting tolerance: ±20%



Nameplate example for S125-SF for 125A



Nameplate example for PS400-NF for 400A

# 5 Type 2 Heat Resistant Circuit Breaker for Emergency Power Supplies




Equipment used in emergency electric circuits is required to have heat resistance that can withstand the temperature of a fire and ensure the functions of conduction and insulation.
The Fire Defense Agency Notification No. 10 “Standard for Switchboards and Distribution Boards for Emergency Power Supply Dedicated Power Incoming Equipment that Receives Power at Low Voltage” stipulates the heat-resistant structure of boards and the heat-resistant performance of the equipment used, and sets the heat-resistant classifications Type 1 and Type 2.
Terasaki heat-resistant circuit breakers have been certified by the “Emergency Switchboard Certification Committee”.

## Heat-resistant conduction performance (type 2 heat-resistant circuit breaker)

### ● Heat resistance standard

Following overheating for 30 minutes according to the 1/7 fire temperature curve, the heat-resistant rated current can be applied without any problem.





Heat-resistant conduction performance

### ● Heat-resistant rated current

Use the load current to be connected at the heat-resistant rated current of the heat-resistant circuit breaker (70% of the ambient temperature rated current) or less.
Also, select the connecting conductor size based on the rated current at ambient temperature.

## Ratings and Specifications (type 2 heat-resistant circuit breaker)


| Frame size (A) | | | 50 | 50 | 50 | 100 | 225 | 400 |
|---|---|---|---|---|---|---|---|---|
| **Type** | | | **FC-52ET ③** | **FC-53ET ③** | **FC-50HET ④** | **FC-100ET ④** | **FC-225ET ⑤** | **FC-400ET ⑤** |
| Number of poles | | | 2 | 3 | 3 | 3 | 3 | 3 |
| **■ Ratings** | | | | | | | | |
| Rated current, (A) | | | 15(10.5) 20(14) | 15(10.5) 20(14) | 15(10.5) 20(14) | 75(52.5) | 150(105) | 300(210) |
| The figure in parentheses is the heat-resistant rated current, A | | | 30(21) 50(35) | 30(21) 50(35) | 30(21) 50(35) | 100(70) | 225(157.5) | 400(280) |
| Rated voltage, V | AC | | 200 | 200 | 415 | 415 | 415 | 415 |
| | DC | | 125① | 125① | 250① | 250① | 250 | 250 |
| **■ Rated breaking capacity, kA (sym)** | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 415 V | — | — | 5 | 5 | 15 | 30 |
| | | 200 V | 2.5 | 2.5 | 10 | 10 | 30 | 42 |
| | DC | 250 V | — | — | 5 | 5 | 10 | 20 |
| | | 125 V | 1.5 | 1.5 | 5 | 5 | 10 | 20 |
| **■ External dimensions, mm** | | | | | | | | |
|  | a | | 50 | 75 | 75 | 75 | 105 | 140 |
| | b | | 100 | 100 | 100 | 100 | 165 | 257 |
| | c | | 60 | 60 | 60 | 60 | 68 | 103 |
| | d | | 84 | 84 | 84 | 84 | 95 | 146 |
| Weight (◉ marked standard type) kg | | | 0.4 | 0.5 | 0.5 | 0.6 | 1.3 | 5.0 |
| **■ Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ② | ◉ ② | ◉ ② | ◉ | ◉ | ◉ (With extension bars) |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ | ○ | ○ |
| Flush-mounted (FP) | Flat bar studs | | ○ | ○ | ○ | ○ | ○ | ○ |
| **■ Accessories (optional)** | | Symbol | | | | | | |
| Internally mounted | Auxiliary switch | A X | ● 1C | ● 1C | ● 1C | ● 1C | ● 1C | ● 1C |
| | Alarm switch | A L | ● | ● | ● | ● | ● | ● |
| **■ Heat resistance certification number** | | | 2CB-14184 | 2CB-14186 | 2CB-14185 | 2CB-14187 | 2CB-13182 | 2CB-13183 |
| **■ Standard specifications** | | | | | | | | |
| Overcurrent trip mechanism | | | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Thermal-magnetic | Thermal-magnetic |
| Colour of cover | | | Light grey | Light grey | Light grey | Light grey | Light grey | Light grey |
| Trip button | | | Yes | Yes | Yes | Yes | Yes | Yes |
| **■ Page of outline dimensions** | | | 7-242 | 7-242 | 7-242 | 7-242 | 7-242 | 7-242 |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering. ● : “yes” or “available”.
— : “no” or “not available”. ① : DC requires special specifications. The standard product cannot be used for DC circuits, so be sure to specify DC when ordering. ② : With wire clamping screw. ③ : The terminal barrier is included only for DC specifications. (1×2P, 2×3P)
④ : Two terminal barriers are included. ⑤ : Four terminal barriers are included.


# 6 Thermal Adjustable Circuit Breaker for Overseas Plants




The thermal adjustable circuit breaker complies with European standards (EN standards).
The rated current is continuously adjustable from 63% to 100%.
The rated current is set to maximum $I_n$ (100%) before delivery.




## Ratings and Specifications

| Frame size (A) | | | 160 | | | 160 | | | 160 | | | 160 | | | 250 | | | 250 | | | 250 | | | 250 | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **Type** | | | **S160-SCJ** | | | **S160-SJ** | | | **P160F** | | | **P160N** | | | **E250-SJ** | | | **P250F** | | | **P250N** | | | **P250H** | | |
| Number of poles | | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | |
| **■ Ratings** | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Rated current, A<br>Calibrated at 50℃ | | | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max |
| | | | 25 | 16 | 25 | 25 | 16 | 25 | 20 | 12.5 | 20 | 20 | 12.5 | 20 | 100 | 63 | 100 | 50 | 32 | 50 | 50 | 32 | 50 | 50 | 32 | 50 |
| | | | 40 | 25 | 40 | 40 | 25 | 40 | 32 | 20 | 32 | 32 | 20 | 32 | 125 | 80 | 125 | 63 | 40 | 63 | 63 | 40 | 63 | 63 | 40 | 63 |
| | | | 63 | 40 | 63 | 63 | 40 | 63 | 50 | 32 | 50 | 50 | 32 | 50 | 160 | 100 | 160 | 80 | 50 | 80 | 80 | 50 | 80 | 80 | 50 | 80 |
| | | | 80 | 50 | 80 | 80 | 50 | 80 | 63 | 40 | 63 | 63 | 40 | 63 | 200 | 125 | 200 | 100 | 63 | 100 | 100 | 63 | 100 | 100 | 63 | 100 |
| | | | 100 | 63 | 100 | 100 | 63 | 100 | 100 | 63 | 100 | 100 | 63 | 100 | 250 | 160 | 250 | 125 | 80 | 125 | 125 | 80 | 125 | 125 | 80 | 125 |
| | | | 125 | 80 | 125 | 125 | 80 | 125 | 125 | 80 | 125 | 125 | 80 | 125 | | | | 160 | 100 | 160 | 160 | 100 | 160 | 160 | 100 | 160 |
| | | | 160 | 100 | 160 | 160 | 100 | 160 | 160 | 100 | 160 | 160 | 100 | 160 | | | | 200 | 125 | 200 | 200 | 125 | 200 | 200 | 125 | 200 |
| | | | | | | | | | | | | | | | | | | 250 | 160 | 250 | 250 | 160 | 250 | 250 | 160 | 250 |
| Category | | | A | | | A | | | A | | | A | | | A | | | A | | | A | | | A | | |
| Rated insulation voltage, V | | | 800 | | | 800 | | | 800 | | | 800 | | | 800 | | | 800 | | | 800 | | | 800 | | |
| **■ Rated breaking capacity, kA** | | | | | | | | | | | | | | | | | | | | | | | | | | |
| IEC 60947-2 $I_{cu}/I_{cs}$ | AC | 690 V ① | — | | | 6/3 | | | 6/6 | | | 6/6 | | | — | | | 6/6 | | | 6/6 | | | 6/6 | | |
| BS EN60947-2 | | 525 V ① | 7.5/4 | | | 10/7.5 | | | 18/18 | | | 22/18 | | | 7.5/6 | | | 22/22 | | | 25/25 | | | 30/25 | | |
| (sym) | | 480 V | 7.5/4 | | | 10/7.5 | | | 25/22 | | | 35/22 | | | 10/7.5 | | | 25/22 | | | 36/25 | | | 50/25 | | |
| | | 415 V | 25/13 | | | 40/20 | | | 36/36 | | | 50/50 | | | 25/19 | | | 36/36 | | | 50/50 | | | 70/50 | | |
| | | 220/240 V | 35/18 | | | 50/25 | | | 50/50 | | | 85/85 | | | 35/27 | | | 50/50 | | | 85/85 | | | 85/85 | | |
| DC rated breaking capacity, kA | DC | 250 V | 20/10 | | | 25/13 | | | 25/19 | | | 40/40 | | | 15/12 | | | 25/19 | | | 40/40 | | | 40/40 | | |
| Rated impulse withstand voltage, kV | | | 8 | | | 8 | | | 8 | | | 8 | | | 8 | | | 8 | | | 8 | | | 8 | | |
| **■ External dimensions, mm** | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  | | a | 75 | 100 | | 75 | 100 | | 90 | 120 | | 90 | 120 | | 105 | 140 | | 105 | 140 | | 105 | 140 | | 105 | 140 | |
| | | b | 130 | | | 130 | | | 130 | | | 130 | | | 165 | | | 165 | | | 165 | | | 165 | | |
| | | c | 68 | | | 68 | | | 68 | | | 68 | | | 68 | | | 68 | | | 68 | | | 68 | | |
| | | d | 95 | | | 95 | | | 95.5 | | | 95.5 | | | 95 | | | 95.5 | | | 95.5 | | | 95.5 | | |
| Weight (◉ marked standard type) kg | | | 0.8 | 1.0 | | 0.8 | 1.0 | | 1.0 | 1.3 | | 1.0 | 1.3 | | 1.5 | 1.9 | | 1.5 | 2.0 | | 1.5 | 2.0 | | 1.5 | 2.0 | |
| Colour of cover | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | |

| Frame size (A) | | | 400 | | | 630 | | | 400 | | | 630 | | | 400 | | | 630 | | | 630 | | | 800 | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| **Type** | | | **P400F** | | | **P630F** | | | **P400N** | | | **P630N** | | | **P400H** | | | **P630H** | | | **S800-NJ** | | | | | |
| Number of poles | | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | | 3 | 4 | |
| **■ Ratings** | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Rated current, A<br>Calibrated at 50℃ | | | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max | Rated current $I_n$ | Adjustable range min | max |
| | | | 250 | 160 | 250 | 630 | 400 | 630 | 250 | 160 | 250 | 630 | 400 | 630 | 250 | 160 | 250 | 630 | 400 | 630 | 630 | 400 | 630 | 800 | 500 | 800 |
| | | | 400 | 250 | 400 | ② | | | 400 | 250 | 400 | ② | | | 400 | 250 | 400 | ② | | | | | | | | |
| Category | | | A | | | A | | | A | | | A | | | A | | | A | | | A | | | A | | |
| Rated insulation voltage, V | | | 800 | | | 800 | | | 800 | | | 800 | | | 800 | | | 800 | | | 800 | | | 800 | | |
| **■ Rated breaking capacity, kA** | | | | | | | | | | | | | | | | | | | | | | | | | | |
| IEC 60947-2 $I_{cu}/I_{cs}$ | AC | 690 V ① | 7/7 | | | 7/7 | | | 12/12 | | | 12/12 | | | 12/12 | | | 12/12 | | | 20/20 | | | 20/20 | | |
| BS EN60947-2 | | 525 V ① | 20/20 | | | 20/20 | | | 22/22 | | | 22/22 | | | 35/35 | | | 35/35 | | | 30/30 | | | 30/30 | | |
| (sym) | | 480 V | 25/25 | | | 25/25 | | | 30/30 | | | 30/30 | | | 50/50 | | | 50/50 | | | 30/30 | | | 30/30 | | |
| | | 415 V | 36/36 | | | 36/36 | | | 50/50 | | | 50/50 | | | 70/70 | | | 70/70 | | | 50/50 | | | 50/50 | | |
| | | 220/240 V | 50/50 | | | 50/50 | | | 85/85 | | | 85/85 | | | 100/100 | | | 100/100 | | | 85/85 | | | 85/85 | | |
| DC rated breaking capacity, kA | DC | 250 V | 25/25 | | | 25/25 | | | 50/50 | | | 50/50 | | | 50/50 | | | 50/50 | | | 50/50 | | | 50/50 | | |
| Rated impulse withstand voltage, kV | | | 8 | | | 8 | | | 8 | | | 8 | | | 8 | | | 8 | | | 8 | | | 8 | | |
| **■ External dimensions, mm** | | | | | | | | | | | | | | | | | | | | | | | | | | |
|  | | a | 140 | 185 | | 140 | 185 | | 140 | 185 | | 140 | 185 | | 140 | 185 | | 140 | 185 | | 210 | 280 | | 210 | 280 | |
| | | b | 260 | | | 260 | | | 260 | | | 260 | | | 260 | | | 260 | | | 273 | | | 273 | | |
| | | c | 103 | | | 103 | | | 103 | | | 103 | | | 103 | | | 103 | | | 103 | | | 103 | | |
| | | d | 151 | | | 151 | | | 151 | | | 151 | | | 151 | | | 151 | | | 145 | | | 145 | | |
| Weight (◉ marked standard type) kg | | | 5.5 | 7.3 | | 5.9 | 7.8 | | 5.5 | 7.3 | | 5.9 | 7.8 | | 5.5 | 7.3 | | 5.9 | 7.8 | | 8.5 | 11.5 | | 8.5 | 11.5 | |
| Colour of cover | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | | Grey Blue | | |

Note ① : Cannot be used with IT earthing systems.
② : Calibrated at 30°C not 50°C.

# 7 690V AC Circuit Breaker



A dedicated 690V AC circuit breaker. For the accessories, refer to the reference models in the table below.

## Ratings and Specifications

| Type | | | | L125-PF | L400-PE | L800-PE |
|---|---|---|---|---|---|---|
| Number of poles | | | | 3 | 3 | 3 |
| ■Ratings | | | | | | |
| Rated current, A<br>Calibrated at 45° C | | | | 15 60<br>20 75<br>30 100<br>40 125<br>50 | (Adjustable) (Adjustable)<br>125 175<br>150 200<br>175 225<br>200 250<br>225 300<br>350<br>400 | (Adjustable)<br>350 600<br>400 700<br>450 800<br>500 |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | 690 | 690 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | 8 | 8 |
| ■Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 70/33 | 70/50 | 70/50 |
| IEC 60947-2 $I_{cu}/I_{cs}$(sym) | | | | | | |
| ■Rated short time withstand current〔$I_{cw}$〕 kA | | | | — | 5(0.3sec) | 10(0.3sec) |
| Weight (◉ marked standard type) kg | | | | 2.4 | 8.9 | 15.6 |
| ■Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | — | — |
| | With extension bars | | | ○ | — | — |
| Rear-connected (RC) | Flat bar studs | | | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊿ | ○ ㊿ | ○ ㊿ |
| | Standard (PMC) | | | — | ◉ | ◉ |
| For distribution boards (PMD) | | | | — | — | — |
| Flush-mounted (FP) With flat bar studs | | | | — | — | — |
| Draw-out type (DR) | | | | — | — | — |
| TemPlug70 (PG) | | | | — | — | — |
| DIN rail mount | | | | — | — | — |
| Clip-in chassis mount | | | | — | — | — |
| ■Accessories (optional) | | | Symbol | | | |
| Externally mounted: Motor operator | | | M C | ● | ● | ● |
| Externally mounted: External operating handle | Breaker-mounted | | H B | ● | ● | ● |
| | Door-mounted (variable depth) | | H P | ● | ● | ● |
| Externally mounted: Toggle extension | | | H A | — | — | ● |
| Externally mounted: Mechanical interlock | Slide type | | M S | ● | ● | ● |
| Externally mounted: Toggle holder | | | H H | ● | ● | ● |
| Externally mounted: Toggle lock | | | H L | ● | | |
| Externally mounted: Terminal cover | For front-connected | | C F | ● | — | — |
| | For rear-connected and plug-in | | C R | ● ㊻ | ● ㊻ | ● ㊻ |
| Externally mounted: Terminal block for lead | | | T F | ● | ● | ● |
| Externally mounted: Door flange | | | D F | ● | ● | ● |
| CE marking | | | | Yes | Yes | Yes |
| Overcurrent trip mechanism | | | | Thermal-magnetic | Electronic ⑯ | Electronic ⑯ |
| Colour of cover | | | | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | | Yes | Yes | Yes |
| Reverse connection | | | | Non | Non | Non |
| Page of characteristics and outline dimensions | | | | 7-224 | 7-226 | 7-228 |
| ■Reference model | | | | L125-NF | L400-NE | L800-NE |


**Notes:**
◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".
⑯ : Optional preferential trip alarm or ground fault trip function available on request.
㊿ : A safety lock function is provided.
㊻ : Terminal covers are provided as standard on the line side and load side.

**MEMO**


# 8 Special Mounting Dimensions 400 A Frame Circuit Breaker

A 400 A frame circuit breaker that supports special mounting dimensions. We offer a complete range of moulded case circuit breakers, circuit breakers with earth leakage alarm, single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm, single phase 3-wire circuit breakers with neutral phase open protection, earth leakage circuit breakers, and single phase 3-wire earth leakage circuit breakers with neutral phase open protection. Please see Catalogue I64K for detailed specifications.


## [Moulded Case Circuit Breakers]

| | | | |
|---|---|---|---|
| Frame size (A) | | | 400 |
| Type | | | **E400-SF** |
| Number of poles | | | 3 |
| **■ Ratings** | | | |
| Rated current, A | | | 250 |
| Calibrated at 40° C | | | 300 |
| | | | 350 |
| | | | 400 |
| Rated insulation voltage〔$U_i$〕 V | | | 690 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — |
| Utilization Category | | | A |
| **■ Rated breaking capacity, kA** | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | — |
| IEC 60947-2 | | 500V | 15/15 |
| $I_{cu}/I_{cs}$(sym) | | 440V | 25/22 |
| | | 415V | 36/25 |
| | | 380V | 36/25 |
| | | 240V | 50/35 |
| | DC | 250V | — |
| | | 125V | — |
| **■ External dimensions, mm** | | | |
|  | | a | 140 |
| | | b | 257 |
| | | c | 103 |
| | | d | 145 |
| Weight (◉ marked standard type) kg | | | 4.1 |
| Page of characteristics and outline dimensions | | | 7-230 |


## [Circuit breakers with earth leakage alarm (Harmonics/surge with countermeasure)]

| | | | |
|---|---|---|---|
| Frame size (A) | | | 400 |
| Type | | | **ZAE400-SF** |
| Number of poles | | | 3 |
| **■ Ratings** | | | |
| Rated current, A | | | 250 |
| Calibrated at 40° C | | | 300 |
| | | | 350 |
| | | | 400 |
| Rated insulation voltage AC V | | | 100-440 common |
| Operable voltage fluctuation range V | | | 80 – 484 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 |
| **■ Rated breaking capacity, kA** | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 25 |
| $I_{cu}$(sym) | | 415V | 36 |
| | | 240V | 50 |
| **■ Earth leakage alarm specifications** | | | |
| Earth leakage detection (Current operation type) | | | Electronic |
| Rated sensitivity current mA | | | 100/200/500 selectable |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable |
| Earth leakage alarm output contact configuration | | | 1c |
| Alarm reset function (manual reset) | | | Push button |
| **■ External dimensions, mm** | | | |
|  | | a | 140 |
| | | b | 257 |
| | | c | 103 |
| | | d | 145 |
| Weight (◉ marked standard type) kg | | | 4.7 |
| Page of characteristics and outline dimensions | | | 7-232 |


## [Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm (Harmonics/surge with countermeasure)]

| | | | |
|---|---|---|---|
| Frame size (A) | | | 400 |
| Type | | | **NAE400-SF** |
| Number of poles / Elements | | | 3P3E |
| Phase and wires | | | 1ø3W |
| **■ Ratings** | | | |
| Rated current, A | | | 250 |
| Calibrated at 40° C | | | 300 |
| | | | 350 |
| | | | 400 |
| Rated operational voltage AC V | | | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 |
| | Rated non-operating overvoltage AC V | | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less |
| **■ Rated breaking capacity, kA** | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | AC | 100/200V | 50 |
| **■ External dimensions, mm** | | | |
|  | | a | 165 |
| | | b | 257 |
| | | c | 103 |
| | | d | 145 |
| Weight (◉ marked standard type) kg | | | 4.9 |
| **■ Earth leakage alarm specifications** | | | |
| Earth leakage detection (Current operation type) | | | Electronic |
| Rated sensitivity current mA | | | 30/100/500 selectable |
| | | | 100/200/500 selectable |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable |
| Earth leakage alarm output contact configuration ㉚ | | | 1c |
| Alarm reset function (manual reset) ㉙ | | | Push button |
| Earth leakage indication | | | LED (Red) |
| Page of characteristics and outline dimensions | | | 7-234 |


## [Single phase 3-wire circuit breakers with neutral phase open protection]

| | | | |
|---|---|---|---|
| Frame size (A) | | | 400 |
| Type | | | **NE400-SF** |
| Number of poles / Elements | | | 3P3E |
| Phase and wires | | | 1ø3W |
| **■ Ratings** | | | |
| Rated current, A | | | 250 |
| Calibrated at 40° C | | | 300 |
| | | | 350 |
| | | | 400 |
| Rated operational voltage AC V | | | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 |
| | Rated non-operating overvoltage AC V | | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less |
| **■ Rated breaking capacity, kA** | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | AC | 100/200V | 50 |
| **■ External dimensions, mm** | | | |
|  | | a | 140 |
| | | b | 257 |
| | | c | 103 |
| | | d | 145 |
| Weight (◉ marked standard type) kg | | | 4.2 |
| Page of characteristics and outline dimensions | | | 7-236 |

## [Earth leakage circuit breakers (Harmonics/surge with countermeasure)]

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | | 400 | |
| Type | | | **ZE400-SF** | |
| Number of poles | | | 3 | |
| Phase and wires | 1ø2W | | ● | |
| | 3ø3W, 1ø3W | | ● | |
| | 3ø4W | | — | |
| **■ Ratings** | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | |
| Rated current, A | | | 250 | |
| Calibrated at 40° C | | | 300 | |
| | | | 350 | |
| | | | 400 | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80 – 484 | |
| | Time delay tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80 – 484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | |
| | | | 100/200/500 selectable | |
| | | | — | |
| | Max. operating time sec | | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | 0.1/0.5/1.2 or over | |
| **■ Rated breaking capacity, kA** | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | | AC 440V | 25 | |
| | | 415V | 36 | |
| | | 240V | 50 | |
| | | 100V | 50 | |
| **■ External dimensions, mm** | | | | |
|  | | a | 140 | |
| | | b | 257 | |
| | | c | 103 | |
| | | d | 145 | |
| Weight (◉ marked standard type) kg | | | 4.7 | |
| Page of characteristics and outline dimensions | | | 7-238 | |

## [Single phase 3-wire earth leakage circuit breakers with neutral phase open protection (Harmonics/surge with countermeasure)]

| | | | |
|---|---|---|---|
| Frame size (A) | | 400 | |
| Type | | **ZNE400-SF** | |
| Number of poles / Elements | | 3P3E | |
| Phase and wires | | 1ø3W | |
| **■ Ratings** | | | |
| Rated current, A | | 250 | |
| Calibrated at 40° C | | 300 | |
| | | 350 | |
| | | 400 | |
| Rated operational voltage AC V | | 100/200 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | 8 | |
| Rated sensitivity current mA | Instantaneous tripping type | 30 | |
| | | 100/200/500 selectable | |
| | Max. operating time sec | 0.1 | |
| | Time delay tripping type | 100/200/500 selectable | |
| | Max. operating time sec | 0.45 | |
| | Non-operating time sec | 0.1 | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | 135 | |
| | Rated non-operating overvoltage AC V | 120 | |
| | Rated overvoltage operating time (sec) | 1 or less | |
| **■ Rated breaking capacity, kA** | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$ (sym) | AC 100/200V | 50 | |
| **■ External dimensions, mm** | | | |
|  | a | 140 | |
| | b | 257 | |
| | c | 103 | |
| | d | 145 | |
| Weight (◉ marked standard type) kg | | 4.7 | |
| Page of characteristics and outline dimensions | | 7-240 | |

# 9 High-Performance Electronic Smart Circuit Breaker (TPOU type OCR)

The TPOU-type high-performance electronic OCR has the functions of long time-delay trip, short time-delay trip, instantaneous trip, preferential trip alarm, ground fault trip, zone interlock, and HOT characteristics/COLD characteristic selection. Additionally, the built-in VT and CT measure the current, voltage, instantaneous power, integrated electric energy, and power factor of the electric circuit, and display them on the OLED display mounted on the front of the circuit breaker. For the setting values of each function, set the values displayed on the OLED display with the joystick.

## ■ Outer view





## ■ TPOU type OCR applicable model

| Breaker type | Rated current ($I_n$) (A) |
|---|---|
| **PS125-NE, PS125-PE** | 100, 125 |
| **PS250-NE, PS250-PE** | 250 |
| **PS400-NE, PS400-GE, PH400-CE** | 250, 400 |
| **PS630-NE, PS630-GE, PH630-CE** | 630 |

- The display of the smart circuit breaker uses an OLED. As a result, the viewing angle is much wider than that of LCD, it is self-luminous and has excellent visibility. The display unit can be easily replaced by the customer.
- Since the OCR uses an r.m.s. value control method, the effects of harmonics do not cause any malfunction.
- Smart circuit breakers can be reversely connected.

## ■ Example of TPOU type OCR for PS630-NE




① A terminal for connecting the OCR checker.
② Joystick for OCR operation
Use the joystick to select and confirm the various setting values shown on the display.
③ OLED display
The OCR display uses an ultra-high definition built-in OLED display, so no backlight is required and the brightness can be adjusted. The display can be rotated by 90 degrees according to the installation position of the circuit breaker main unit.
Symbols are shown on the display to enable easy and clear operation.
④ Short time-delay trip set current dial
You can fine-tune between the selected magnification and magnification +0.5 one level below in additional 0.5× steps on the display.
⑤ Rated current setting dial
You can fine-tune between the selected current value and the current value one level below in additional 1A steps on the display.
⑥ Set value lock release button
You can unlock this button to change the setting on the display.
⑦ Alarm LED
Lights red during long time-delay pickup.
⑧ PTA LED
The preferential trip alarm flashes orange during pickup and lights when it is output.
⑨ Status LED
Lights green when the OCR is operating normally. Flashes orange if there is an error.

## ■ Measurement/monitoring of electric circuits and preventive maintenance with TPOU type OCR

The TPOU-type OCR human-machine interface flexibly responds to various user system requirements such as various measurement and status display, system and network protection, and alarm management.

### ・Data transmission of various types of information

Compatible with Modbus open network to connect the communication module, it transmits all kinds of data such as circuit status, circuit breaker settings, measurement data and event history information.

### ・Custom alarm

OCR can make a wide range of measurements such as voltage, current, power, electric energy, power factor, frequency, demand current, demand power, total harmonic distortion, trip history, and alarm history. The user can set an alarm for any 12 items among these measurements.

### ・Preventive maintenance with temperature monitoring

If the board temperature inside the circuit breaker exceeds 105°C, the “TEMP” symbol is shown on the display to indicate the abnormal. Please use this function for preventive maintenance to prevent problems caused by contact and terminal connections. Since the OCR requires high reliability, we use CPUs and ICs with an upper limit operating ambient temperature above +105°C.

### ・Zone interlock reduces damage to electric circuits

By setting a zone interlock between TemBreak PRO circuit breakers equipped with OCR, it is possible to trip the upstream circuit breaker closest to the accident location in the shortest time without waiting for the short time-delay setting time. This means that in the event of a short circuit accident, thermal and mechanical damage to the electric circuit can be reduced. Up to 7 circuit breakers can be linked between upstream and downstream breakers.
However, the number of upstream circuit breaker is multiple, control power supply is needed for all of them.
Zone-selective interlocks are possible not only between circuit breakers but also between TemPower2 air circuit breakers. Ground fault protection coordination is also possible with zone selective interlocks.

### ・Reliable maintenance work with built-in clock function

The OCR has two built-in clock functions: a user-set clock and a clock that measures the cumulative operating time of the OCR. The user-set clock allows the user to set the date and time as desired. The clock that measures the cumulative operating time of the OCR calculates the cumulative operating that the OCR has actually been energized.
In the event of power loss, the events prior to the power loss are stored in memory as a time-stamped event history, for both the user-set clock and the clock that measures the cumulative operating time of the OCR.
Using these clock functions, reliable maintenance work can be performed.

### ・Uses multi-feed control power supply

A multi-feed control power supply is adopted. In case Smart circuit breakers are connected with communication module and remote display, if the control power is supplied to the communication module, there is no need to additionally supply the control power to the OCR or the remort display.


### ・Supports hot start

For long time-delay trip, you can switch between cold start and hot start. Hot start can function even without a control power supply.

## ■ Types of TPOU type overcurrent trip device (OCR)

| Rated current $I_n$ (A) | Poles | Protection code | Protection function ② | | | | Alarm function ② | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | Long time-delay, Short time-delay, Instantaneous L, S, I ④ | Ground fault trip GF | Neutral protection NP | Zone interlock ZSI ⑤ | Preferential trip alarm PTA | Alarm contact output OAC ⑥ | |
| 100<br>125 | 3 | SMART ① | ● | ● | — | ● | ● | ● | |
| 250<br>400<br>630 | 3 | SMART ① | ● | ● | — | ● | ● | ● | |
| | 4 | SMART | ● | ● | ● | ● | ● | ● | |

● : Supplied as standard. ○ : Optional. — : "no" or "not available".



| | Display function ③ | Measurement/display function ③ | | | Optional | | |
|---|---|---|---|---|---|---|---|
| | OLED display (built into OCR) | Line voltage U, phase voltage V ⑦, current I, power P, electric energy E, Power factor PF, frequency F, demand D, total harmonic distortion THD | Trip history | Alarm history | Communication module TPCM ⑧ | Remote display TPED ⑨ | AX/AL switch TPSS ⑩ |
| | ● | ● | ● | ● | ○ | ○ | ○ |
| | ● | ● | ● | ● | ○ | ○ | ○ |
| | ● | ● | ● | ● | ○ | ○ | ○ |

| Accessory order type | Accessory |
|---|---|
| TPCM00D02N | TPCM communication module (without contact input/output terminals) |
| TPCM00D02W | TPCM communication module (with contact input/output terminals) |
| TVP00 | TVP remort display |
| TPPHQTT130H | PTA preferential trip alarm/OAC customized alarm contact output cable 1.2m |
| TPPHQTT140H (For PS125,250) | 24V DC power supply cable 1.2m |
| TPPHQTT160H (For PS/PH400,630) | |
| TPPHQTT150H | ZSI zone interlock cable 1.2m |
| TPPHQTT330H (For PS125,250) | CIP remort display/ communication module Connection cable 0.5m |
| TPPHQTT430H (For PS/PH400,630) | |
| TPPHQTT340H (For PS125,250) | CIP remort display/ communication module Connection cable 1.5m |
| TPPHQTT440H (For PS/PH400,630) | |
| TPPHQTT350H (For PS125,250) | CIP remort display/ communication module Connection cable 3m |
| TPPHQTT450H (For PS/PH400,630) | |
| TPPHQTT360H (For PS125,250) | CIP remort display/ communication module Connection cable 5m |
| TPPHQTT460H (For PS/PH400,630) | |
| TPPHQTT370H (For PS125,250) | CIP remort display/ communication module Connection cable 10m |
| TPPHQTT470H (For PS/PH400,630) | |
| TPPHQTT500H | NSP cable 1.2m ① |
| TPSS00N | AX/AL switch ＊ (ACP output only) |
| TPSS00MXLSW | AX/AL switch ＊ (ACP output + contact output) |
| TPSS00MXLRW | AX/AL switch ＊ (ACP output + microload contact output) |

＊: See page 4-18 for the specifications of the AX/AL switch.

Note ①: Not compatible with 3-phase 4-wire systems. Select the NSP cable (TPPHQTT500H) if using a 3 pole smart circuit breaker for 3-phease 4-wire power distribution.

Note ②: Control power supply is not required.

Note ③: By supplying the control power of 24 V DC to the OCR with the optional cable (order type TPPHQTT140H), the value is displayed even when the circuit breaker is OFF and when the internal power supply is not established due to the small main circuit current.
If a communication module supplied with control power is connected to the OCR, that control power is supplied to the OCR. This means that there is no need to supply additional control power to the OCR.

| OCR control power supply |
|---|
| Voltage：24V DC ± 30% |
| Consumption current：60mA |

Note ④: You can select not only general cold start characteristics, but also hot start characteristics that take into consideration the thermal characteristics of load equipment such as electric wires and electric motors.

Note ⑤: An optional cable (order type TPPHQTT150H) is required for the input/output of the zone interlock. For PS125-NE/PE circuit breakers, the zone interlock is output only.

Note ⑥: By connecting the optional cable (order type TPPHQTT130H), data can be contact output from only one of the following items.

- System (OCR operation) error alarm
- OCR abnormal temperature alarm
- Preferential trip alarm PTA
- 1 output of 12 custom alarms

| Contact rating |
|---|
| Non-contact output 1a |
| Contact capacity 24V AC/DC 100mA |

Note ⑦ : Phase voltage is displayed only for 4-pole circuit breakers.

Note ⑧ : Supply 24 V DC control power to the control power terminal of the communication module. The control power supplied to the communication module is also supplied to the OCR.

Note ⑨ : Supply the 24 V DC control power to the OCR with the optional cable (order type TPPHQTT140H). Then, connect the optional cable (order type TPPHQTT330H to 470H) between the OCR and the remort display. This allows the OCR to supply control power to the remort display. However, if a communication module supplied with control power is connected to the OCR, it is not necessary to supply control power to the OCR.

Note ⑩ : ON/OFF information for auxiliary switch 1c and alarm switch 1c is read by the OCR and output to the remort display and communication module.

## ■ TPOU type OCR measurement/display function specifications

| Measurement/display items | | IEC 61557-12 Prescribed Class | Display ○: With display ×: No display | Remote display ○: With display ×: No display | Modbus ○: With communication ×: No communication |
|---|---|---|---|---|---|
| Current | Phase current | 1 | ○ | ○ | ○ |
| | Ground fault current | 1 | ○ | ○ | ○ |
| Voltage | Line voltage | 0.5 | ○ | ○ | ○ |
| | Phase voltage | 0.5 | ○ | ○ | ○ |
| Frequency | | 0.2 | ○ | ○ | ○ |
| Electric power | Active power | 2 | ○ | ○ | ○ |
| | Reactive power | 2 | ○ | ○ | ○ |
| | Apparent power | 2 | ○ | ○ | ○ |
| Electric energy | Active electric energy | 2 | ○ | ○ | ○ |
| | Reactive electric energy | 2 | ○ | ○ | ○ |
| | Apparent electric energy | 2 | ○ | ○ | ○ |
| Demand | Electric power | 2 | × | ○ | ○ |
| | Current | 1 | × | ○ | ○ |
| Power factor | | 2 | ○ | ○ | ○ |
| Total harmonic distortion | Current | 2 | × | ○ | ○ |
| | Voltage | 2 | × | ○ | ○ |
| Trip history | Accident current | — | ○ | ○ | ○ |
| | Cause of accident | — | ○ | ○ | ○ |
| | Accident occurrence phase | — | ○ | ○ | ○ |
| Alarm history | Alarm cause | — | ○ | ○ | ○ |

Note: Electric energy, trip history, and alarm history are stored in the non-volatile memory when a trip occurs.

## ■ Specifications of communication module

The communication module TPCM can communicate all the data recorded by the OCR to the Modbus RTU monitoring system. Modbus parameters are adjusted with the dial on the whole surface of the communication module.
The communication module can be mounted on the side of the circuit breaker by using the included support.

| Item | Modbus specifications |
|---|---|
| Transmission signal | RS-485 |
| Communication method | 2-wire half duplex |
| Topology | Multi-drop bus connection |
| Transmission speed | Max. 38.4kbps |
| Transmission distance | Max. 1.2km (at 38.4kbps) |
| Data type | Modbus-RTU |
| Maximum number of nodes | 1～99 |

## ■ AX/AL switch specifications

The TPSS00N AX/AL switch is connected to the ACP (Auxiliary Connection Port) of the OCR and the OCR displays the ON/OFF status of the AX/AL switch. The OCR also displays the number of ON/OFF operations during OCR energization.

The TPSS00MXLSW standard AX/AL switch adds a standard contact output to the above TPSS00N AX/AL switch.

The TPSS00MXLRW microload AX/AL switch adds a contact output for microloads to the above TPSS00N AX/AL switch.

The table below shows the contact ratings of the TPSS00MXLSW standard switch and the TPSS00MXLRW microload switch.

**• TPSS00MXLSW standard switch contact output**

| AC | | | | DC | | | Minimum load |
|---|---|---|---|---|---|---|---|
| Voltage (V) | Current (A) | | | Voltage (V) | Current (A) | | |
| | Resistive load | Inductive load power factor 0.7 or more | Inductive load power factor 0.3 or more | | Resistive load | Inductive load time constant 15ms or less | |
| 250 | 3 | 3 | 1 | 125 | 0.4 | 0.02 | 30mA at 10V DC |
| 125 | 3 | 3 | 2 | 30 | 3 | 0.3 | |

**• TPSS00MXLRW microload switch contact output**

| DC | | Minimum load |
|---|---|---|
| Voltage (V) | Current (A) Resistive load | |
| 30 | 0.1 | 1mA at 5V DC |

## ■ Remote display

The remort display TVP00 can be easily mounted to a panel, etc. of a switchboard by connecting it from the OCR with a single cable. The backlit LCD display has good visibility even in dark places. Display is possible in 8 languages: Japanese, English, French, German, Italian, Spanish, Portuguese, and Chinese.

| Display items |
|---|
| Circuit breaker protection setting value |
| Measured value of electric circuit |
| Alarm information |
| Event history information |
| Breaker identification information |

| Settings/change items |
|---|
| Circuit breaker protection setting value |
| Measured value parameters |
| Output contact parameters |
| Alarm management setting values |




## ■ TTP00 type OCR checker

The OCR checker is to easily check the OCR's long time-delay, short time-delay, instantaneous trip, ground fault trip and preferential trip alarm functions in the field. See page 9-6 for details.

## ■ Overcurrent tripping characteristics

### Rated current ($I_n$) : 100A, 125A

| | | |
|---|---|---|
| Rated current settings (A) : ($I_r$) ① ② | | When ($I_n$) = 100 A<br>($I_r$1) (A) = 40, 50, 60, 63, 75, 100 adjustable<br>When ($I_n$) = 125 A<br>($I_r$1)(A)=125<br>Select ($I_r$1) with the dial.<br>Adjustable in 1 A steps between the selected ($I_r$1) and the level below ($I_r$1).<br>However, the minimum is 40 A when ($I_n$) = 100 A and 101 A when ($I_n$) = 125 A. ③ |
| Long time-delay time settings (s) : ($t_r$) | | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable at ($I_r$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | | ($I_r$)×1.5 to 10 (0.5 steps) or OFF<br>Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | | 50, 100, 200, 300, 400 adjustable<br>Ramp characteristics $I^2t$: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more<br>When ($t_{sd}$) = 50ms<br>Time-delay setting tolerance –30 ms or more +30 ms or less<br>When ($t_{sd}$) = 100ms to 400ms<br>Time-delay setting tolerance –20 ms or more +50 ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | | When ($I_n$) = 100 A ($I_n$) × 3 to 15 (0.5 step)<br>When ($I_n$) = 125 A ($I_n$) × 3 to 11 (0.5 step)<br>Current setting tolerance within ±15% |
| Ground fault trip pick-up current (A) : ($I_g$) | | 3P for 3ø3W (3P 3ø4W not supported ④)<br>($I_n$)×20% to 100% (5% steps) or OFF<br>Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | | 50, 100, 200, 300, 400, 500 adjustable<br>Ramp characteristics $I^2t$: ON or OFF ⑤<br>However, definite time-delay characteristics with ($I_n$)×1 or more<br>Time-delay setting tolerance –20 ms or more +50 ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | | ($I_r$)×60% to 80% to 95% (5% steps) or OFF<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | | ($t_r$)×5% to 50% to 80% (5% steps) at ($I_P$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| ZSI Zone interlock | STD Short time-delay | ON or OFF |
| | GF Ground fault trip | ON or OFF |
| Start operating characteristics | | Hot start/cold start (selectable) |

### Rated current ($I_n$) : 250A

| | | |
|---|---|---|
| Rated current settings (A) : ($I_r$) ① | | ($I_r$1) (A) = 125, 150, 175, 200, 225, 250 adjustable ⑥<br>Select ($I_r$1) with the setting dial.<br>Adjustable in 1A steps between the selected ($I_r$1) and the level below ($I_r$1).<br>However, the minimum is 125A. |
| Long time-delay time settings (s) : ($t_r$) | | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable at ($I_r$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | | ($I_r$)×1.5 to 10 (0.5 steps) or OFF ⑦<br>Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | | 50, 100, 200, 300, 400 adjustable<br>Ramp characteristics $I^2t$: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more<br>When ($t_{sd}$) = 50ms<br>Time-delay setting tolerance –30 ms or more +30 ms or less<br>When ($t_{sd}$) = 100ms to 400ms<br>Time-delay setting tolerance –20 ms or more +50 ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_n$)×3 to 11 (0.5 steps)<br>Current setting tolerance within ±15% |
| Neutral protection pick-up current ⑧ (A) : ($I_N$) | | For 4P ($I_r$)×50%, 100% or OFF ⑨ |
| Neutral protection time settings (s) : ($t_N$) | | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip ⑩ |
| Ground fault trip pick-up current (A) : ($I_g$) | | 3P for 3ø3W,<br>4P for 3ø4W (3P 3ø4W not supported ④)<br>($I_n$)×20% to 100% (5% steps) or OFF<br>Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | | 50, 100, 200, 300, 400, 500 adjustable<br>Ramp characteristics $I^2t$: ON or OFF ⑤<br>However, definite time-delay characteristics with ($I_n$)×1 or more<br>Time-delay setting tolerance –20 ms or more +50 ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | | ($I_r$)×60% to 80% to 95% (5% steps) or OFF<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | | ($t_r$)×5% to 50% to 80% (5% steps) at ($I_P$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| ZSI Zone interlock | STD Short time-delay | ON or OFF |
| | GF Ground fault trip | ON or OFF |
| Start operating characteristics | | Hot start/cold start (selectable) |

**Remarks:** If not otherwise specified, the product will be delivered with the underlined standard setting values.

**Notes:**

①: Trip with a pickup current value exceeding $I_r$ × 1.05 and 1.2 or less.

②: It is a rated current adjustable product. The rated operational voltage is AC380 to 690V, and it is not subject to the Act on Product Safety of Electrical Appliances and Materials. Please contact us for details.

③: In the case of $I_n$=100A, $I_r$ is adjustable in 1A steps between 40, 41 to 50, 51 to 60, 61 to 63, 64 to 75, 76 to 100.
In the case of $I_n$=125A, $I_r$ is adjustable in 1A steps between 101 and 125.

④: A 3-pole circuit breaker cannot be used with a 3-phase 4-wire system.

⑤: The ramp characteristics can be switched ON/OFF separately from the short time-delay trip.

⑥: $I_r$ is adjustable in 1A steps between 125, 126 to 150, 151 to 175, 176 to 200, 201 to 225, 226 to 250.

⑦: Adjustable to $I_{sd}$=$I_r$ × 10 –9.5 –9 –8.5 –8 –7.5 –7 –6.5 –6 –5.5 –5 –4.5 –4 –3.5 –3 –2.5 –2 –1.5.

⑧: Trip with a pickup current value exceeding $I_N$ × 1.05 and 1.2 or less.

⑨: There is no N-phase protection function for 3P. Always set it to OFF.

⑩: The ON/OFF of the ramp characteristics conform to the short time-delay trip settings.

## Rated current ($I_n$) : 250A, 400A

| | | |
|---|---|---|
| Rated current settings (A) : ($I_r$) ① | | In the case of ($I_n$)=250 A<br>Adjustable to ($I_r$1)(A)=125, 150, 175, 200, 225, 250<br>In the case of ($I_n$)=400 A<br>Adjustable to ($I_r$1)(A)=175, 200, 225, 250, 300, 350, 400<br>Select ($I_r$1) with the dial.<br>Adjustable in 1 A steps between the selected ($I_r$1) and the level below ($I_r$1).<br>However, the minimum is 125 A when ($I_n$)=250 A, and 175 A when ($I_n$)=400 A. ⑩ |
| Long time-delay time settings (s) : ($t_r$) | | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable at ($I_r$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF<br>Select the magnification with the setting dial.<br>You can adjust between the selected magnification and magnification +0.5 one level below in additional 0.5× steps on the display. ⑪<br>Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | | 50, 100, 200, 300, 400 adjustable<br>Ramp characteristics $I^2t$: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more<br>When ($t_{sd}$) = 50ms<br>Time-delay setting tolerance –30 ms or more +30 ms or less<br>When ($t_{sd}$) = 100ms to 400ms<br>Time-delay setting tolerance –20 ms or more +50 ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_n$)×3 to 12 (0.5 steps)<br>Current setting tolerance within ±15% |
| Neutral protection pick-up current ⑦ (A) : ($I_N$) | | For 4P ($I_r$)×50%, 100% or OFF ⑧ |
| Neutral protection time settings (s) : ($t_N$) | | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip ⑨ |
| Ground fault trip pick-up current (A) : ($I_g$) | | 3P for 3ø3W,<br>4P for 3ø4W (3P 3ø4W not supported ③)<br>($I_n$)×20% to 100% (5% steps) or OFF<br>Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | | 50, 100, 200, 300, 400, 500 adjustable<br>Ramp characteristics $I^2t$: ON or OFF ④<br>However, definite time-delay characteristics with ($I_n$)×1 or more<br>Time-delay setting tolerance –20 ms or more +50 ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | | ($I_r$)×60% to 80% to 95% (5% steps) or OFF<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | | ($t_r$)×5% to 50% to 80% (5% steps)<br>at ($I_P$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| ZSI Zone interlock | STD Short time-delay | ON or OFF |
| | GF Ground fault trip | ON or OFF |
| Start operating characteristics | | Hot start/cold start (selectable) |

## Rated current ($I_n$) : 630A

| | | |
|---|---|---|
| Rated current settings (A) : ($I_r$) ① | | Adjustable to ($I_r$1)(A)=250, 300, 350, 400, 500, 600, 630<br>Select ($I_r$1) with the dial.<br>Adjustable in 1A steps between the selected ($I_r$1) and the level below ($I_r$1).<br>However, the minimum is 250 A. ⑫ |
| Long time-delay time settings (s) : ($t_r$) | | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable at ($I_r$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF<br>Select the magnification with the setting dial.<br>You can adjust between the selected magnification and magnification +0.5 one level below in additional 0.5× steps on the display. ⑪<br>Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | | 50, 100, 200, 300, 400 adjustable<br>Ramp characteristics $I^2t$: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more<br>When ($t_{sd}$) = 50ms<br>Time-delay setting tolerance –30 ms or more +30 ms or less<br>When ($t_{sd}$) = 100ms to 400ms<br>Time-delay setting tolerance –20 ms or more +50 ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_n$)×3 to 11 (0.5 steps)<br>Current setting tolerance within ±15% |
| Neutral protection pick-up current ⑦ (A) : ($I_N$) | | For 4P ($I_r$)×50%, 100% or OFF ⑧ |
| Neutral protection time settings (s) : ($t_N$) | | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip ⑨ |
| Ground fault trip pick-up current (A) : ($I_g$) | | 3P for 3ø3W,<br>4P for 3ø4W (3P 3ø4W not supported ③)<br>($I_n$)×20% to 100% (5% steps) or OFF<br>Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | | 50, 100, 200, 300, 400, 500 adjustable<br>Ramp characteristics $I^2t$: ON or OFF ④<br>However, definite time-delay characteristics with ($I_n$)×1 or more<br>Time-delay setting tolerance –20 ms or more +50 ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | | ($I_r$)×60% to 80% to 95% (5% steps) or OFF<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | | ($t_r$)×5% to 50% to 80% (5% steps)<br>at ($I_P$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| ZSI Zone interlock | STD Short time-delay | ON or OFF |
| | GF Ground fault trip | ON or OFF |
| Start operating characteristics | | Hot start/cold start (selectable) |

**Remarks:** If not otherwise specified, the product will be delivered with the underlined standard setting values.

**Notes:**

①: Trip with a pickup current value exceeding $I_r \times 1.05$ and 1.2 or less.

③: A 3-pole circuit breaker cannot be used with a 3-phase 4-wire system.

④: The ramp characteristics can be switched ON/OFF separately from the short time-delay trip.

⑦: Trip with a pickup current value exceeding $I_N \times 1.05$ and 1.2 or less.

⑧: There is no N-phase protection function for 3P. Always set it to OFF.

⑨: The ON/OFF of the ramp characteristics conform to the short time-delay trip settings.


⑩: In the case of $I_n$=250A, $I_r$ is adjustable in 1A steps between 125, 126 to 150, 151 to 175, 176 to 200, 201 to 225, 226 to 250.
In the case of $I_n$=400A, $I_r$ is adjustable in 1A steps between 175, 176 to 200, 201 to 225, 226 to 250, 251 to 300, 301 to 350, 351 to 400.

⑪: As an example
When the setting dial is set to $I_r \times 10$, on the display, $I_{sd}=I_r \times 10$ –9.5 –9 –8.5 is adjustable.
When the setting dial is set to $I_r \times 8$, on the display, $I_{sd}=I_r \times 8$ –7.5 is adjustable.
When the setting dial is set to $I_r \times 2$, on the display, $I_{sd}=I_r \times 2$ is fixed.


⑫: $I_r$ is adjustable in 1A steps between 250, 251 to 300, 301 to 350, 351 to 400, 401 to 500, 501 to 600, 601 to 630.

## ■ Operating characteristic curve


### Long time-delay trip, short time-delay trip characteristics





### Instantaneous trip characteristics




### N-phase protection, preferential trip alarm characteristics




### Ground fault trip characteristics




# 10 High-Performance Electronic Circuit Breaker (XOW type OCR)

The XOW type high-performance electronic OCR measures the electric circuit current, voltage, instantaneous power, integrated electric energy, and power factor using the built-in VT and CT and displays them on the LCD mounted on the front of the circuit breaker. Also, it supports Modbus open network and transmits these measurement data and accident history information as data.

## ■ Outer view







- The LCD display window displays the phase current, line voltage and their maximum values, and the power factor, power, and electric energy. Also, it can display the 1st to 19th harmonic currents for each phase.
- In the event of an accident, it displays the cause of operation and the accident current, and even if power is lost, the data is stored so that you can check the accident history after the power is restored.




The width of the LCD display window is the same as the width of the toggle frame, so it is easy to perform panel cut.

- We offer 3 types of circuit breakers with the display rotated 90 degrees to the left or right so that the LCD display can be aligned with the circuit breaker mounting orientation.

| Vertical ON side up (general mounting) | Horizontal ON side right | Horizontal ON side left |
|---|---|---|
|  |  |  |

If you require horizontal mounting, please specify either “Horizontal ON side right” or “Horizontal ON side left” when ordering.
If not otherwise specified, we will deliver “Vertical ON side up”.

# 10 High-Performance Electronic Circuit Breaker (XOW type OCR)

## ■ Types of XOW type overcurrent trip device (OCR)

| OCR type | Protection function | | | | Alarm function | Display function | | |
|---|---|---|---|---|---|---|---|---|
| | Long time-delay Short time-delay Instantaneous | Ground fault trip ① | Neutral protection | Reverse phase protection | Preferential trip alarm | LCD screen display | LCD backlight | |
| | A | GF | NP | NS | PTA | | | |
| XOW-1L-A | ● | — | — | — | — | ● | — | |
| XOW-1L-AGN | ● | ● | ● | — | — | ● | — | |
| XOW-1L-AP | ● | — | — | — | ● | ● | — | |
| XOW-1L-APGNS | ● | ● | ● | ● | ● | ● | — | |
| XOW-1L-APC | ● | — | — | — | ● | ● | — | |
| XOW-1L-APGNSC | ● | ● | ● | ● | ● | ● | — | |
| XOW-1S-A | ● | — | — | — | — | ● | ● | |
| XOW-1S-AGN | ● | ● | ● | — | — | ● | ● | |
| XOW-1S-AP | ● | — | — | — | ● | ● | ● | |
| XOW-1S-APGNS | ● | ● | ● | ● | ● | ● | ● | |
| XOW-1S-APCWH | ● | — | — | — | ● | ● | ● | |
| XOW-1S-APGNSCWH | ● | ● | ● | ● | ● | ● | ● | |

● : Standard equipment.
○ : Optional.
— : "no" or "not available".
① : In the case of ($I_{CT}$)=250 A, ground fault trip is not available.

## ■ XOW type OCR measurement/display function specifications

| Measurement/display items (accuracy) | | Modbus communication function ○ : Yes — : No | Remarks |
|---|---|---|---|
| Load current (±1.5%) | Present value of each phase | ○ | It is also possible to display ground fault current and reverse phase current depending on the specifications. |
| | Present value of maximum phase | ○ | Measures and displays the value of the max. phase of the R, S, and T phases. |
| Line voltage (±1.0%) | Present value between each line | ○ | |
| | Present value of maximum line voltage | ○ | |
| | Present value of phase voltage of each phase | ○ | Only selectable for 4-pole products |
| Harmonic current (±2.5%) | Present values of the 3rd, 5th, 7th, ... 19th order of each phase | — | |
| Electric power (±2.5%) | Present value | ○ | |
| | Demand value | ○ | |
| | Max. demand value | ○ | |
| Electric energy (±2.5%) | Electric energy | ○ | |
| Power factor (±5%) | Present value | ○ | |
| Trip history | Accident current (±1.5%) | ○ | |
| | Accident cause display | ○ | |
| Alarm history | Display of alarm cause and alarm operation value | ○ | |

Note: Electric energy is stored in flash memory every 2 hours and accident current and accident cause display are stored in flash memory when a trip occurs.

| | Measurement/display function | | | | | | Communication function Modbus | Remote display | Test function | Operation display contact output | Control power supply |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | Current | Voltage, power, electric energy, power factor, demand power | Electric energy pulse output | Harmonic current | Trip history | Alarm history | | | | | |
| | | | W | H | | | C | I | | Y | |
| | ● | — | — | — | ● | ● | — | — | ● | — | Required |
| | ● | — | — | — | ● | ● | — | — | ● | — | Required |
| | ● | — | — | — | ● | ● | — | — | ● | ● | Required |
| | ● | — | — | — | ● | ● | — | — | ● | ● | Required |
| | ● | — | — | — | ● | ● | ● | — | ● | ● | Required |
| | ● | — | — | — | ● | ● | ● | — | ● | ● | Required |
| | ● | ● | — | — | ● | ● | — | — | ● | — | Required |
| | ● | ● | — | — | ● | ● | — | — | ● | — | Required |
| | ● | ● | — | — | ● | ● | — | — | ● | ● | Required |
| | ● | ● | — | — | ● | ● | — | — | ● | ● | Required |
| | ● | ● | ● | ● | ● | ● | ● | ○ | ● | ● | Required |
| | ● | ● | ● | ● | ● | ● | ● | ○ | ● | ● | Required |

## ■Transmission line interface input/output specifications

| Item | Modbus specifications |
|---|---|
| Transmission signal | RS-485 |
| Communication method | 2-wire half duplex |
| Topology | Multi-drop bus connection |
| Transmission speed | Max. 19.2 kbps |
| Transmission distance | Max. 1.2 km (for 19.2kbps) |
| Data type | Modbus-RTU |
| Maximum number of nodes | 1 – 31 |

## ■ Overcurrent tripping characteristics


| Frame size (A) | Applicable circuit breaker type | CT rated primary current $I_{CT}$ | Rated current $I_n$ |
|---|---|---|---|
| 400 | **H400-NE, L400-NE** | 250A | 125-150-175-200-225A |
| | | 400A | 175-200-225-250-300-350-400A |
| 630 | **S630-NE, H630-NE, L630-NE** | 630A | 250-300-350-400-500-600-630A |
| 800 | **S800-NE, H800-NE, L800-NE** | 800A | 350-400-450-500-600-700-800A |
| 1000 | **S1000-CE** | 1000A | 400-500-600-700-800-900-1000A |

| Protection function | | Symbol | Setting range |
|---|---|---|---|
| Long time-delay trip LT | Pick-up current (A) | $I_r$ | ($I_n$)×1<br>• Non-trip at ($I_r$)×1.05 or less<br>• Trip operation is performed with a pickup current value exceeding ($I_r$)×1.05 and 1.2 or less. |
| | Time setting (s) | $t_r$ | At ($I_r$) 600% current<br>0.5-1.25-2.5-5-10-15-<u>20</u>-25-30s ①<br>Time-delay setting tolerance ±20% +0.13s −0s |
| | COLD / HOT characteristic switching | — | <u>COLD</u> / HOT |
| Short time-delay trip ST | Pick-up current (A) | $I_{sd}$ | ($I_n$)×(1-1.5-2-2.5-3-4-6-8-<u>10</u>-NON) ②<br>Current setting tolerance ±15% |
| | Time setting (s) | $t_{sd}$ | Ramp characteristics $I^2t$ at OFF: 0.05-<u>0.1</u>-0.2-0.3 s Definite time-delay characteristics<br>Current setting tolerance +50ms −20ms<br>Ramp characteristics $I^2t$ at ON: 0.05-<u>0.1</u>-0.2-0.3s Definite time-delay characteristics with ($I_n$)×1000% or more ③ |
| | Ramp characteristic switching | — | <u>OFF</u> / ON |
| Magnetic trip current INST | Pick-up current (A) | $I_i$ | ($I_n$)×(2-3-4-6-8-10-12-13-<u>14</u>-NON) ④ ⑤<br>Current setting tolerance ±20% |
| Ground fault trip GF ⑦ | Pick-up current (A) | $I_g$ | ($I_{CT}$)×(<u>0.2</u>-0.3-0.4-NON)<br>Current setting tolerance ±20% |
| | Time setting (s) | $t_g$ | Ramp characteristics $I^2t$ at OFF: 0.1-0.2-<u>0.3</u>-0.4-0.8 s Definite time-delay characteristics<br>Time-delay setting tolerance +50ms −20ms<br>Ramp characteristics $I^2t$ at ON: ($I_{CT}$) 40% or more and 0.1-0.2-<u>0.3</u>-0.4-0.8 s |
| | Ramp characteristic switching | — | <u>OFF</u> / ON |
| | Operation mode switching | — | <u>TRIP</u> / OFF ⑥ |
| Neutral protection NP | Pick-up current (A) | $I_N$ | ($I_{CT}$)×(0.4-0.5-0.63-0.8-<u>1.0</u>-NON)<br>• Non-trip at ($I_N$) ×1.05 or less<br>• Trip operation is performed with a pickup current value exceeding ($I_N$)×1.05 and 1.2 or less. |
| | Time setting (s) | $t_N$ | Operates at LT time setting at ($I_N$) ×600% current. |
| | COLD / HOT characteristic switching | — | <u>COLD</u> / HOT |
| Reverse phase protection NS | Pick-up current (A) | $I_{NS}$ | ($I_n$)×(0.2-0.3-0.4-0.5-0.6-0.7-0.8-0.9-<u>1.0</u>)<br>Current setting tolerance ±10% |
| | Time setting (s) | $t_{NS}$ | At ($I_{NS}$) ×150% current<br>0.4-0.8-1.2-1.6-2.0-2.4-2.8-3.2-3.6-<u>4.0</u>s<br>Time-delay setting tolerance ±20% +0.13s −0s |
| | Operation mode switching | — | TRIP / <u>OFF</u> ⑥ |
| Preferential trip alarm PTA | Pick-up current (A) | $I_P$ | ($I_n$)×(0.7-0.8-<u>0.9</u>-1.0)<br>Current setting tolerance ±10% |
| | Time setting (s) | $t_P$ | $I_P$ or more and 5-10-15-20-<u>40</u>-60-80-120-160-200s<br>Time-delay setting tolerance ±10% +0.1s −0s |
| | Operation mode switching | — | <u>AL</u> / OFF ⑥ |


**Notes:**
①: In the case of S1000, it is 0.5-1.25-2.5-5-10-<u>15</u>-16 s.
②: In the case of S1000, it is 1-1.5-2-2.5-3-4-6-<u>8</u>-NON.
③: In the case of S1000, it is Definite time-delay characteristics with ($I_n$) × 800% or more.
④: In the case of H400, L400, it is set to Max. ($I_{CT}$) × 1300%. In the case of S630, S800, H630, H800, L630, L800, it is set to Max. ($I_{CT}$) × 1200%.
In the case of S1000, it is set to Max. ($I_{CT}$) × 1000%.
⑤: When short time-delay trip is set to NON, instantaneous trip cannot be set to NON. When instantaneous trip is set to NON, short time-delay trip cannot be set to NON.
⑥: When OFF is selected, the protection function does not operate.
⑦: In the case of ($I_{CT}$)=250 A, ground fault trip cannot be used.
Remarks: If not otherwise specified, the product will be delivered with the underlined standard setting values.

## ■ Operating characteristic curve


### Long time-delay trip, instantaneous trip characteristics





### Short time-delay trip characteristics




### N-phase protection, ground fault trip characteristics




### Reverse phase protection, preferential trip alarm characteristics



## ■ XOW type OCR controller

The XOW type electronic OCR requires a control power supply and an XOW type OCR controller (supplied by Terasaki). When ordering, please specify whether you would like the OCR controller to be mounted on the breaker or separate.

Note ① : When the OCR controller is mounted on the breaker, the shunt trip device/undervoltage trip device with lead wire terminal block cannot be used.


### ● OCR controller specifications

| | |
|---|---|
| Control power supply Note ② (rated voltage) | 100 to 120V AC or 200 to 240V AC |
| VA consumption | 2VA |

Note ② : The allowable voltage range of the control power supply is 85 to 110% of the rated voltage. When ordering, please specify the rated voltage.


### ● OCR controller breaker mounting position/terminal arrangement diagram

| Applicable circuit breaker | | A(mm) | B(mm) | C(mm) | D(mm) |
|---|---|---|---|---|---|
| S400 | 3P、4P | 80 | 74 | 25.2 | 16.2 |
| H400, L400 | 3P、4P | 80 | 111 | 25.2 | 16.2 |
| S630, S800, S1000 | 3P、4P | 71.5 | 74 | 25.2 | 16.2 |
| H630, L630 H800, L800 | 3P、4P | 71.5 | 111 | 25.2 | 16.2 |




Note 1): Terminal screw tightening torque M3.5 ··· 0.88 – 1.18N·m
2): Connectable wire ····· 2.0mm² (max.)

### ● OCR controller separate outline drawing




Connect the red and white leads connected to the circuit breaker to OS1 and OS2.
(Lead wire length approx. 600mm)

# 11 Circuit Breaker for Special Environments

Standard circuit breakers are manufactured based on the <standard usage conditions>.
If you intend to use a circuit breaker in an environment that differs from these conditions, we will manufacture a circuit breaker for the special environment upon request. Please specify this when ordering.

**<Standard usage conditions>**

- **Operating ambient temperature** ··· Within the range of –10°C to 40°C. When using in high temperature conditions exceeding 40°C, reduce the current used. However, the average value over 24 hours should not exceed 35°C.
  50°C ····· Approx. 90%
  60°C ····· Approx. 70%
- **Relative humidity** ····· 85% or less, no condensation.
- **Altitude** ····· 2000m or less
- **Atmosphere** ····· No excess water vapour, oil vapour, smoke, dust, salt, or corrosive substances, etc. Atmosphere without condensation or freezing due to sudden temperature changes.

| Circuit Breaker for Special Environments | Specification | Nameplate display ✻ |
|---|---|---|
| **Low temperature treatment Note ①** | A circuit breaker designed for use in cold areas. The usage conditions are −40°C for storage and −20°C for use. The operating characteristics of the low temperature circuit breaker are adjusted to 40°C (45°C) so the characteristics change at low temperatures. The usage environment must have no sudden temperature changes and no condensation or freezing. | **PROOFED FOR LOW TEMPERATURE**<br>STORAGE −40°C or higher<br>OPERATION −20°C or higher |
| **Fungus-moisture proofing [Tropical treatment product]** | In high temperature and high humidity conditions, the dielectric strength and other electrical performance may deteriorate. This is a circuit breaker with tropical treatment that uses a special surface treatment and special materials to allow use under these conditions. The usage conditions are temperature 60°C or less, humidity 95% or less. However, the product must be in a constant humidity environment with no condensation due to sudden temperature changes, etc. | **FUNGUS-MOISTURE PROOFING** |
| **Anti-corrosion treatment** | When using a circuit breaker in an atmosphere with a large amount of corrosive gas or salt, it should be placed inside an anti-corrosion structure box. However, in places where the effects of corrosive gas are relatively small, as a simple method, this increased corrosion-resistance circuit breaker with a special surface treatment that has high corrosion resistance may be used. | **CORROSION RESISTING** |

**Notes:**
① : Electric operation devices cannot be used.
② : Compatible circuit breakers are limited. Please ask whether the model is compatible before placing your order.

# 5 Mounting and Connection






1 Type of connections and mountings ····· 5-2
List of connecting type ····· 5-2
Connecting parts ····· 5-6
Plug-in for switchboards (Plug-in) (PM) ····· 5-10
2 Compression terminals ····· 5-12
3 Terminal screw sizes and standard torques ····· 5-14
4 Insulation distance from the line side ····· 5-18
5 Lists of breaker mounting screws ····· 5-20
6 Effect of mounting angle ····· 5-21
7 Close fitting mounting ····· 5-22
8 Reverse connection ····· 5-23

# 5 Mounting and Connection

## Moulded Case Circuit Breakers / Earth Leakage Circuit Breakers

### 1 Type of connections and mountings








## List of Connecting Types

| Connecting types (Abbreviation) | | Front-connected (FC) | | | Rear-connected (RC) | | |
|---|---|---|---|---|---|---|---|
| | | For compression terminals/flat bars | With extension bars | With cable clamps | Flat bar studs | | |
| | | | | | Stud can be turned 45° or 90° | Stud can be tured 90° | Fixed |
| Outer view / Breaker | |  |  |  |  | | |
| Moulded Case Circuit Breakers | PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN | ◉ | ○ ⑥ | — | — | — | ○ ⑨ |
| | S50-SF, S125-SF, S125-SN | ◉ | ○ ⑥ | — | — | — | ○ ⑨ |
| | PS50-PF, PS125-NF/PF/NM/NN, PS125-NE/PE | ◉ | ○ ⑥ | △ | ○ | — | — |
| | S100-GF, S125-GF | ◉ | ○ | △ | ○ | — | — |
| | H100-NF, H125-NF, H225-NF | ◉ | ○ ⑥ | △ | ○ | — | — |
| | H250-NF, L250-NF, H225-NE | ◉ | ○ ⑥ | △ | ○ | — | — |
| | L100-NF, L125-NF, L225-NF | ◉ | ○ ⑥ | △ | ○ | — | — |
| | E250-SF, S250-SF, S250-SN | ◉ | ○ ⑥ | △ | ○ | — | — |
| | PS250-PF/NN, PS250-NE/PE | ◉ | ○ ⑥ | △ | ○ | — | — |
| | S250-SM | ◉ | ○ ⑥ | — | ○ | — | — |
| | E400-NF | ◉ | ○ | △ | ○ | — | — |
| | PS400-CF/NF/GF/NN, PS400-NE/GE | ◉ | ○ | △ | ○ | — | — |
| | PH400-CF, PH400-CE | ◉ | ○ | △ | ○ | — | — |
| | H400-NE, L400-NE | ◉ | ○ | △ | ○ | — | — |
| | PS630-CF/NF/GF/NN, PS630-NE/GE | — | ◉ | △ | ○ | — | — |
| | S630-CF/NF/NE/GN | — | ◉ | △ | — | ○ | — |
| | PH630-CF, PH630-CE | — | ◉ | △ | ○ | — | — |
| | S800-CF/NF/RF/PF, S800-NE/RE/PE/NN | — | ◉ | — | — | ○ | — |
| | H630-NE, L630-NE, H800-NE, L800-NE | — | ◉ | — | — | ○ | — |
| | S1000-CE/NN | — | ◉ | — | — | — | ○ ⑦ |
| | PE50-NFZ, PS50-NFZ, PE125-NFZ | ◉ | ○ ⑥ | — | — | — | ○ ⑨ |
| | ZAS125-SF | ◉ | ○ ⑥ | — | — | — | ○ ⑨ |
| | ZAS50-GF, ZAS100-GF, ZAS125-GF | ◉ | ○ ⑥ | △ | ○ | — | — |
| | ZAE250-SF, ZAS250-SF | ◉ | ○ ⑥ | — | ○ | — | — |
| | ZAS225-GF, ZAS250-GF | ◉ | ○ ⑥ | △ | ○ | — | — |
| | ZAE400-NF, ZAS400-NF/GF | ◉ | ○ | △ | ○ | — | — |
| | ZAS630-CF/NF | — | ◉ | △ | — | ○ | — |
| | ZAS800-CF/NF | — | ◉ | — | — | ○ | — |
| | PE50-NFN, PE125-NFN | ◉ | ○ ⑥ | — | — | — | — |
| | NS125-SF | ◉ | ○ ⑥ | — | — | — | — |
| | NE250-SF, NS250-SF, NE400-NF, NS400-NF | ◉ | ○ ⑥ | — | — | — | — |
| | NS630-NF, NS800-NF | — | ◉ | — | — | — | — |
| Earth Leakage Circuit Breakers | PZE30-NF, PZS30-NF, PZE50-NF, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF | ◉ | ○ ⑥ | — | — | — | ○ ⑨ |
| | ZS50-SF, ZS100-SM, ZS125-SF | ◉ | ○ ⑥ | — | — | — | ○ ⑨ |
| | ZE250-SF, ZS250-SF/SM | ◉ | ○ ⑥ | — | ○ | — | — |
| | ZE400-NF | ◉ | ○ | △ | ○ | — | — |
| | ZS100-GF, ZS125-GF | ◉ | ○ ⑥ | △ | ○ | — | — |
| | ZS225-GF, ZS250-GF, ZS400-NF/GF | ◉ | ○ ⑥ | △ | ○ | — | — |
| | PZE50-NFN, PZE125-NFN | ◉ | ○ ⑥ | — | — | — | — |
| | ZNS125-SF | ◉ | ○ ⑥ | — | — | — | — |
| | ZNE250-SF, ZNS250-SF | ◉ | ○ ⑥ | — | — | — | — |
| | ZNE400-NF, ZNS400-NF | ◉ | ○ | — | — | — | — |
| | ZS630-CF/NF | — | ◉ | △ | — | ○ | — |
| | ZS800-CF/NF | — | ◉ | — | — | ○ | — |
| Remarks | | ・Connect compression terminals or flat bars directly to breaker terminals. | ・Extension bars are attached to breaker terminals. Connect compression terminals or flat bars to the extension bars. | ・Cable clamps are attached to breaker terminals. Connect wires directly to cable clamps. | ・Flat bar studs will be factory installed in the horizontal position unless otherwise specified.<br>・Flat bar studs in the vertical position are available on request. Please select a position code from those shown in the table below: | | |

| Position code | Position of flat bar studs | |
|---|---|---|
| | Line side | Load side |
| RC-A | Vertical | Horizontal |
| RC-B | Horizontal | Vertical |
| RC-C | Vertical | Vertical |
| RC-D | Horizontal | Horizontal |

∗ See pages 5-14 to 5-17 for dimensions and tightening torques of terminal screws.

**Notes:** ① Except 4-pole breakers.
② Please refer to Chapter 10 for details.
③ Please order the DIN rail adapter separately.
④ 2-pole products are not available.
⑤ 4-pole products are not available.
⑥ For the extension bars, please place the order separately in parts.
⑦ Only vertical position.
⑨ Horizontal position is standard. Vertical position is a special specification.
⑫ PH630-CE is not available.
PH630-CF is only available for 500A.

| | Plug-in (PM) | | | Flush-mounted (FP) | Draw-out type (DR) | *TemPlug* (PG) ② | DIN rail mount |
|---|---|---|---|---|---|---|---|
| | For switchboards | | For distribution boards ① | Flat bar studs | | | |
| | PMB (High-performance) | PMC (Standard) | PMD | | | | |
| |  |  |  |  |  |  |  |
| | — | ○ ④ | ○ | ○ ⑨ | — | — | ○ ③④ |
| | — | ○ ④⑤ | ○ ⑤ | ○ ⑨ | — | ○ ⑤ | ○ ③④ |
| | ○ ④⑩ | ○ ⑤ | ○ ④⑤ | ○ | — | ○ ⑤ | ○ ③④ |
| | ○ ⑪ | ○ ④⑤ | ○ ④⑤ | ○ | — | ○ ⑤ | ○ ③④ |
| | ○ ⑪ | ○ ⑤ | — | ○ | — | ▲ ⑤ | — |
| | — | — | — | ○ | — | — | — |
| | ○ ⑪ | ○ ⑤ | — | ○ | — | — | — |
| | — | ○ ⑤ | — | ○ | — | ○ ⑤ | — |
| | ○ ⑩ | ○ ⑤ | — | ○ | ▲ | ○ ⑤ | — |
| | — | — | — | ○ | — | ○ ⑤ | — |
| | — | — | — | ○ | — | ○ | — |
| | ○ ⑩ | ○ ⑤ | — | ○ | ▲ | ○ ⑤ | — |
| | ○ ⑩ | ○ ⑤ | — | ○ | ▲ | ▲ ⑤ | — |
| | ○ ⑪ | ○ ⑤ | — | ○ | — | — | — |
| | ○ ⑩ | ○ ⑤ | — | ○ | ▲ | ○ ⑤⑬ | — |
| | ○ ⑪ | ○ ⑤ | — | ○ | ▲ | ○ ⑤ | — |
| | ○ ⑩ | ○ ⑤ | — | ○ | ▲ | ▲ ⑤⑫ | — |
| | ○ ⑪ | ○ ⑤ | — | ○ | ▲ | — | — |
| | ○ ⑪ | ○ ⑤ | — | ○ | — | — | — |
| | — | — | — | ○ ⑦ | — | — | — |
| | — | — | — | ○ ⑨ | — | — | — |
| | — | — | — | ○ ⑨ | — | ○ | ○ ③ |
| | — | — | — | ○ | — | ○ ⑤ | ○ ③ |
| | — | — | — | ○ | — | ○ | — |
| | — | — | — | ○ | — | ○ ⑤ | — |
| | — | — | — | ○ | — | ○ ⑤ | — |
| | — | — | — | ○ | — | ○ | — |
| | — | — | — | ○ | — | — | — |
| | — | — | — | — | — | — | ○ ③ |
| | — | — | — | — | — | — | ○ ③ |
| | — | — | — | — | — | — | — |
| | — | — | — | — | — | — | — |
| | — | | — | ○ ⑨ | — | — | ○ ③ |
| | — | — | — | ○ ⑨ | — | ○ | ○ ③ |
| | — | — | — | ○ | — | ○ | — |
| | — | — | — | ○ | — | ○ | — |
| | — | — | — | ○ | — | ○ ⑤ | ○ ③ |
| | — | — | — | ○ | — | ○ ⑤ | — |
| | — | — | — | — | — | — | ○ ③ |
| | — | — | — | — | — | — | ○ ③ |
| | — | — | — | — | — | — | — |
| | — | — | — | — | — | — | — |
| | — | — | — | ○ | — | ○ | — |
| | ⑩If you try to remove the circuit breaker while it is ON, it will automatically TRIP.<br>⑪High-performance models have a safety mechanism that prevents them from being mounted or removed as long as they are in the ON state. | | • Plug-in type with front connection suitable for the small depth. | • Fix the circuit breaker to the panel using the attached mounting frame.<br>• Use the flat bar studs in the same manner as for rear-connected breakers.<br>• The plate is painted in Munsell 5Y 7/1. | • To make connection, push the breaker into the draw-out cradle already wired to the main and control circuits. The draw-out cradle has two positions "Connected" and "Isolated".<br>• The breakers have a safety mechanism that prevents them from being mounted or removed as long as they are in the ON state.<br>• Models meeting protection grade IP20 are available as options. IEC 60529 specifies that IP20-compliant devices be designed and constructed so that live parts of the devices cannot be touched by hand. When ordering the products, please specify as "IP20 applied products". | • Simply plugging *TemPlug* onto the main busbars in a switchboard completes the connection of the breaker to a power distribution line. Use plug-in base mounting screws to secure the breaker. Direct coupling of the plug-in base to the main busbars reduces the lead time involved in completing a power distribution system.<br>• If the frame size or rated current of the breakers is changed, all you have to do is to replace the *TemPlug*. | • Can be mounted on an IEC 35mm rail. |
| | • Models meeting protection grade IP20 are available as options. IEC 60529 specifies that IP20-compliant devices be designed and constructed so that live parts of the devices cannot be touched by hand. When ordering the products, please specify as "IP20 applied products". | | | | | | |

⑬ PS630-NE/GE are not available. PS630-CF/NF/GF/NN are only available for 500A.

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
▲ : Semi-standard.
△ : Custom-built product. Please contact us for details.
— : "no" or "not available".

# 1 Type of connections and mountings

## List of Connecting Types


| Connecting types (Abbreviation) | | Front-connected (FC) | | Rear-connected (RC) | | |
|---|---|---|---|---|---|---|
| | | | | Flat bar studs | Bolt studs | |
| | | For compression terminals/flat bars | With extension bars | Fixed ① | | |
| Outer view / Breaker | |  |  | |  | |
| MCCB | E30-NM, S30-NM, E50-NM, S50-NM, E100-NM | ◉ | ○ ⑦ | ○ ⑥ | — | |
| MCCB | TL-1000NE, TL-1200NE | — | ◉ | ○ ② | — | |
| MCCB | S1250-NE, S1250-GE, S1250-NN | — | ◉ | ○ ② | — | |
| MCCB | S1600-NE, S1600-NN | — | ○ | ◉ ③ | — | |
| MCCB | XS2000NE, XS2000NN | — | ○ | ◉ ③ | — | |
| MCCB | XS2500NE, XS2500NN, XS3200NE, XS3200NN | — | — | ◉ ③ | — | |
| ELCB | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM | ◉ | ○ ⑦ | ○ ⑥ | — | |
| Remarks | | ・Connect compression terminals directly to breaker terminals. | ・Extension bars are attached to breaker terminals. Connect compression terminals or flat bars to the extension bars. | | | |

∗ See pages 5-14 to 5-17 for dimensions and tightening torques of terminal screws.

**Notes:** ① Breakers are mounted on angles.
② Flat bar studs will be factory installed in the horizontal position unless otherwise specified. If vertical installation is required, please state when ordering.

| Position code | Position of flat bar studs | |
|---|---|---|
| | Line side | Load side |
| RC-A | Vertical | Horizontal |
| RC-B | Horizontal | Vertical |
| RC-C | Vertical | Vertical |
| RC-D | Horizontal | Horizontal |

③ Vertical installation only.
④ The breakers can be installed on the panel door using mounting frame supplied as standard.
⑤ The breakers can be installed on the mounting angle as well as Rear-connected breakers.
⑥ Flat bar studs will be factory installed in the horizontal position unless otherwise specified. Flat bar studs in the vertical position are available on request.
⑦ For the extension bars, please place the order separately in parts.

| | Plug-in (PM)<br>For switchboards | Draw-out type (DR) | | Flush-mounted (FP) | DIN rail mount |
|---|---|---|---|---|---|
| | PMC (Standard) | Two-position type | Three-position type | Flat bar studs | |
| |  | | |  | |
| | — | — | — | ○ ⑥ | ◉ |
| | ○ | ▲ | — | ○ ②④ | — |
| | ○ | ▲ | — | ○ ②④ | — |
| | — | — | ○ | ○ ③④ | — |
| | — | — | ○ | ○ ③⑤ | — |
| | — | — | — | ○ ③⑤ | — |
| | — | — | — | ○ ⑥ | ◉ |
| | ・To make connection, push the breaker into the plug-in base already wired to the main and control circuits. Use breaker mounting screws to secure the breaker.<br>・Models meeting protection grade IP20 are available as options. IP20 refers to the protection grade specified under IEC 60529 that states that IP20-compliant devices be designed and constructed so that live parts of the devices cannot be touched by hand. | ・To make connection, push the breaker into the draw-out cradle already wired to the main and control circuits. The draw-out cradle has two positions “Connected” and “Isolated”.<br>・The breakers are fitted with a safety trip. If an attempt is made to remove the breakers while ON position it will automatically trip.<br>・Models meeting protection grade IP20 are available as options. IP20 refers to the protection grade specified under IEC 60529 that states that IP20-compliant devices be designed and constructed so that live parts of the devices cannot be touched by hand.<br>・The auxiliary circuit is connected or isolated automatically through the auxiliary circuit terminals of a plug-in breaker. (When the motor operator is mounted, the auxilary circuit is connected or isolated manually.) | ・To make connection, push the breaker into the draw-out cradle already wired to the main and control circuits. The draw-out cradle has three positions “Connected”, “Test” and “Isolated”.<br>・The breakers are fitted with a safety trip. If an attempt is made to remove the breakers while ON position it will automatically trip.<br>・Safety shutters are available as option which automatically cover the live parts on the cradle side in the isolated position.<br>・The auxiliary circuit is connected or isolated automatically. Connected on “CONN” and “TEST” position. Isolated on “ISOLATED” position.<br>・We can also manufacture a design with a manual connector upon request. | ・The plate is painted in Munsell 5Y 7/1. | |

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
▲ : Semi-standard.
△ : Custom-built product. Please contact us for details.
— : “no” or “not available”.

## Connecting parts

There are the following connecting/mounting hardware available as options:

### 1. Extension bars for front conection

| Type | Number of poles | Shape | Applicable breakers | | Min order qty ① | Constituent parts | | |
|---|---|---|---|---|---|---|---|---|
| | | | Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | | Extension bar | Screw B | Screw C |
| T2FB053B | 3 | Straight extension bars | E30-NM, S30-NM, E50-NM, S50-NM, | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM | 1 | 6 | — | — |
| T2FB063B | 3 | Straight extension bars | E100-NM | ZE100-NM | 1 | 6 | — | — |
| T2FB12L2SB | 2 | Straight extension bars | PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN | ——— | 1 | 4 | 4 | 4 |
| T2FB12L3SB | 3 | | PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN | PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN | | 6 | 6 | 6 |
| T2FB12L2SB | 2 | Straight extension bars | S50-SF, S125-SF | ——— | 1 | 4 | 4 | 4 |
| T2FB12L3SB | 3 | | S50-SF, S125-SF, S125-SN, ZAS125-SF, NS125-SF | ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF | | 6 | 6 | 6 |
| T2FB12L4SB | 4 | | S50-SF, S125-SF, S125-SN | ——— | | 8 | 8 | 8 |
| TPFB162SB | 2 | Straight extension bars | PS50-PF, PS125-NF/PF | ——— | 1 | 4 | 4 | 4 |
| TPFB163SB | 3 | | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | ——— | | 6 | 6 | 6 |
| TPFB164SB | 4 | | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | ——— | | 8 | 8 | 8 |
| T2FB122B | 2 | Straight extension bars | S100-GF, S125-GF | ——— | 1 | 4 | 4 | 4 |
| T2FB123B | 3 | | S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF | ZS100-GF, ZS125-GF | | 6 | 6 | 6 |
| T2FB124B | 4 | | S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF | | | 8 | 8 | 8 |
| T2FB25L3WB | 3 | Spread extension bars | E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF, NE250-SF, NS250-SF | ZE250-SF, ZS250-SF, ZS250-SM, ZNE250-SF, ZNS250-SF | 1 | 6 | 6 | 6 |
| T2FB25L4WB | 4 | | S250-SF, S250-SN | ——— | | 8 | 8 | 8 |
| T2FB25L2SB | 2 | Straight extension bars | E250-SF, S250-SF | ——— | 1 | 4 | 4 | 4 |
| T2FB25L3SB | 3 | | E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF, NE250-SF, NS250-SF | ZE250-SF, ZS250-SF, ZS250-SM, ZNE250-SF, ZNS250-SF | | 6 | 6 | 6 |
| T2FB25L4SB | 4 | | S250-SF, S250-SN | ——— | | 8 | 8 | 8 |
| T2FB25L3WB | 3 | Spread extension bars | PS250-PF/NN, PS250-NE/PE | ——— | 1 | 6 | 6 | 6 |
| T2FB25L4WB | 4 | | PS250-PF/NN, PS250-NE/PE | ——— | | 8 | 8 | 8 |
| T2FB25L3SB | 3 | Straight extension bars | PS250-PF/NN, PS250-NE/PE | ——— | 1 | 6 | 6 | 6 |
| T2FB25L4SB | 4 | | PS250-PF/NN, PS250-NE/PE | ——— | | 8 | 8 | 8 |
| T2FB253B | 3 | Spread extension bars | H100-NF, H125-NF, H225-NF, H225-NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, ZAS225-GF, ZAS250-GF | ZS225-GF, ZS250-GF | 1 | 6 | 6 | 6 |
| T2FB254B | 4 | Straight extension bars | H100-NF, H125-NF, H225-NF, H225-NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, ZAS225-GF, ZAS250-GF | | | 8 | 8 | 8 |
| T2FB403B | 3 | Spread extension bars | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | ——— | 1 | 6 | 6 | 6 |
| T2FB404B | 4 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | ——— | | 8 | 8 | 8 |
| T2FB403B | 3 | Spread extension bars | H400-NE, L400-NE, ZAE400-NF, ZAS400-NF/GF, NE400-NF, NS400-NF, E400-NF | ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF | 1 | 6 | 6 | 6 |
| T2FB404B | 4 | | H400-NE, L400-NE, ZAS400-NF/GF | ZS400-NF/GF | | 8 | 8 | 8 |

●See page 5-16 for screws B and C.

**Note:** ① The min order qty is one unit on the line side and one on the load side. Please specify it separately if you need 1/2 of either the line side or the load side.

## 2. Flat bar stud for rear connection

| Type | Number of poles | Connection ① | Applicable breakers | | Min order qty | Constituent parts | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | | Stud unit | Unit mounting screw | Stud bar | Screw D | Screw E |
| T2RP053A | 3 | Vertical – Horizontal | E30-NM, S30-NM, E50-NM, S50-NM | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM | 1 | 2 | 4 | ② | 6 | 6 |
| T2RP053C | | Vertical – Vertical | | | | | | | | |
| T2RP053D | | Horizontal – Horizontal | | | | | | | | |
| T2RP063A | 3 | Vertical – Horizontal | E100-NM | ZE100-NM | 1 | 2 | 4 | ② | 6 | 6 |
| T2RP063C | | Vertical – Vertical | | | | | | | | |
| T2RP063D | | Horizontal – Horizontal | | | | | | | | |
| TPRP052KB | 2 | Horizontal – Horizontal | PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF | ——— | 1 | — | — | 4 | 4 | 4 |
| TPRP053KB | 3 | Horizontal – Horizontal | PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ, PS50-NF/NFZ | PZE30-NF, PZS30-NF, PZE50-NF, PZS50-NF | | | | 6 | 6 | 6 |
| TPRP122KB | 2 | Horizontal – Horizontal | PE60-NF, PS60-NF, PE125-NF/NN | ——— | 1 | — | — | 4 | 4 | 4 |
| TPRP123KB | 3 | Horizontal – Horizontal | PE60-NF, PS60-NF, PE125-NF/NN/NFZ | PZE60-NF, PZS60-NF, PZE125-NF | | | | 6 | 6 | 6 |
| T2RP05L2S | 2 | Horizontal – Horizontal | S50-SF, S125-SF (15-50A) | ——— | 1 | — | — | 4 | 4 | 4 |
| T2RP05L3S | 3 | Horizontal – Horizontal | | | | | | 6 | 6 | 6 |
| T2RP05L4S | 4 | Horizontal – Horizontal | | | | | | 8 | 8 | 8 |
| T2RP12L2S | 2 | Horizontal – Horizontal | S125-SF (60-125A) | ——— | 1 | — | — | 4 | 4 | 4 |
| T2RP12L3S | 3 | Horizontal – Horizontal | S125-SF (60-125A), S125-SN | | | | | 6 | 6 | 6 |
| T2RP12L4S | 4 | Horizontal – Horizontal | | | | | | 8 | 8 | 8 |
| T2RP05L3Z | 3 | Horizontal – Horizontal | ZAS125-SF (15-50A) | ZS50-SF, ZS125-SF (15-50A), ZS100-SM (16-45A) | 1 | — | — | 6 | 6 | 6 |
| T2RP12L3Z | 3 | Horizontal – Horizontal | ZAS125-SF (60-125A) | ZS125-SF (60-125A), ZS100-SM (60-100A) | 1 | — | — | 6 | 6 | 6 |
| TPRP162SB | 2 | * | PS50-PF, PS125-NF/PF | ——— | 1 | — | — | 4 | 4 | 4 |
| TPRP163SB | 3 | | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | | | | | 6 | 6 | 6 |
| TPRP164SB | 4 | | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | | | | | 8 | 8 | 8 |
| T2RP122S | 2 | * | S100-GF, S125-GF | ——— | 1 | — | — | 4 | 4 | 4 |
| T2RP123S | 3 | | S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF | ZS100-GF, ZS125-GF | | | | 6 | 6 | 6 |
| T2RP124S | 4 | | | | | | | 8 | 8 | 8 |
| T2RP253S | 3 | * | E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF | ZE250-SF, ZS250-SF, ZS250-SM | 1 | — | — | 6 | 6 | 6 |
| T2RP254S | 4 | | S250-SF, S250-SN | ——— | | | | 8 | 8 | 8 |
| T2RP253S | 3 | * | ZAS225-GF, ZAS250-GF | ZS225-GF, ZS250-GF | 1 | — | — | 6 | 6 | 6 |
| T2RP254S | 4 | | | | | | | 8 | 8 | 8 |
| T2RP253S | 3 | * | PS250-PF/NN, PS250-NE/PE | ——— | 1 | — | — | 6 | 6 | 6 |
| T2RP254S | 4 | | | | | | | 8 | 8 | 8 |
| T2RP253L | 3 | * | H100-NF, H125-NF, H225-NF, H225-NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF | ——— | 1 | — | — | 6 | 6 | 6 |
| T2RP254L | 4 | | | | | | | 8 | 8 | 8 |
| T2RP403S | 3 | * | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | ——— | 1 | — | — | 6 | 6 | 6 |
| T2RP404S | 4 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | | | | | 8 | 8 | 8 |
| T2RP403S | 3 | * | E400-NF, ZAE400-NF, ZAS400-NF/GF | ZE400-NF, ZS400-NF/GF | 1 | — | — | 6 | 6 | 6 |
| T2RP404S | 4 | | ZAS400-NF/GF | ZS400-NF/GF | | | | 8 | 8 | 8 |
| T2RP463S | 3 | * | PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE | ——— | 1 | — | — | 6 | 6 | 6 |
| T2RP464S | 4 | | PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE | | | | | 8 | 8 | 8 |
| T2RP403L | 3 | * | H400-NE, L400-NE | ——— | 1 | — | — | 6 | 6 | 6 |
| T2RP404L | 4 | | | | | | | 8 | 8 | 8 |

● See page 5-17 for screws D and E.

**Note:**

① In the case of "vertical-horizontal," "vertical-vertical," or "horizontal-horizontal," the orientation cannot be changed. In the case of "*", the studs can be rotated to four angular positions: 0 (horizontal), 45, 90 (vertical) and 135 degrees.

② The stud bar is integrated with the stud unit.

### 3. Plug-in base

#### PMB Plug-in base for switchboards (High-performance)

| Type | Number of poles | IP20 | Applicable breakers<br>Moulded Case Circuit Breakers | Min order qty | Constituent parts<br>Plug-in base | <br>Nut J |
|---|---|---|---|---|---|---|
| TPPM12B3 | 3 | Non | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | 1 | 1 | 6 |
| TPPM12B4 | 4 | | | | 1 | 8 |
| T2PM12B2 | 2 | | S100-GF, S125-GF | 1 | 1 | 4 |
| T2PM12B3 | 3 | | | | 1 | 6 |
| T2PM12B4 | 4 | | | | 1 | 8 |
| T2PM25B3 | 3 | | PS250-PF/NN, PS250-NE/PE | 1 | 1 | 6 |
| T2PM25B4 | 4 | | | | 1 | 8 |
| T2PM25B3 | 3 | | H100-NF, H125-NF, H225-NF,<br>L100-NF, L125-NF, L225-NF | 1 | 1 | 6 |
| T2PM25B4 | 4 | | | | 1 | 8 |
| TPPM63B3 | 3 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | 1 | 1 | 6 |
| TPPM63B4 | 4 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | | 1 | 8 |
| T2PM40B3 | 3 | | H400-NE, L400-NE | 1 | 1 | 6 |
| T2PM40B4 | 4 | | | | 1 | 8 |
| TPPM63B3 | 3 | | PS630-CF/NF/GF/NN, PH630-CF | 1 | 1 | 6 |
| TPPM63B4 | 4 | | PS630-CF/NF/GF/NN, PH630-CF | | 1 | 8 |
| T2PM80B3 | 3 | | S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NE/RE/PE/NN, H630-NE, L630-NE, H800-NE, L800-NE | 1 | 1 | 6 |
| T2PM80B4 | 4 | | | | 1 | 8 |
| TPPM12P3 | 3 | Compliant | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | 1 | 1 | 6 |
| TPPM12P4 | 4 | | | | 1 | 8 |
| T2PM12P2 | 2 | | S100-GF, S125-GF | 1 | 1 | 4 |
| T2PM12P3 | 3 | | | | 1 | 6 |
| T2PM12P4 | 4 | | | | 1 | 8 |
| T2PM25P3 | 3 | | PS250-PF/NN, PS250-NE/PE | 1 | 1 | 6 |
| T2PM25P4 | 4 | | | | 1 | 8 |
| T2PM25P3 | 3 | | H100-NF, H125-NF, H225-NF,<br>L100-NF, L125-NF, L225-NF | 1 | 1 | 6 |
| T2PM25P4 | 4 | | | | 1 | 8 |
| TPPM63P3 | 3 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | 1 | 1 | 6 |
| TPPM63P4 | 4 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | | 1 | 8 |
| T2PM40P3 | 3 | | H400-NE, L400-NE | 1 | 1 | 6 |
| T2PM40P4 | 4 | | | | 1 | 8 |
| TPPM63P3 | 3 | | PS630-CF/NF/GF/NN, PH630-CF | 1 | 1 | 6 |
| TPPM63P4 | 4 | | PS630-CF/NF/GF/NN, PH630-CF | | 1 | 8 |
| T2PM80P3 | 3 | | S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NE/RE/PE/NN, H630-NE, L630-NE, H800-NE, L800-NE | 1 | 1 | 6 |
| T2PM80P4 | 4 | | | | 1 | 8 |

#### PMC Plug-in base for switchboards (Standard)

| Type | Number of poles | IP20 | Applicable breakers<br>Moulded Case Circuit Breakers | Min order qty | Constituent parts<br>Plug-in base | <br>Nut J |
|---|---|---|---|---|---|---|
| T2PM12LT3 | 3 | Non | PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN | 1 | 1 | 6 |
| TPPM12E2 | 2 | | PS50-PF, PS125-NF/PF | 1 | 1 | 4 |
| TPPM12E3 | 3 | | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | 1 | 1 | 6 |
| T2PM12E3 | 3 | | S100-GF, S125-GF | 1 | 1 | 6 |
| T2PM12LT3 | 3 | | S50-SF, S125-SF/SN | 1 | 1 | 6 |
| T2PM25LE3 | 3 | | E250-SF, S250-SF, S250-SN | 1 | 1 | 6 |
| T2PM25LE4 | 4 | | S250-SF, S250-SN | 1 | 1 | 8 |
| T2PM25LE3 | 3 | | PS250-PF/NN, PS250-NE/PE | 1 | 1 | 6 |
| T2PM25E3 | 3 | | H100-NF, H125-NF, H225-NF, L100-NF, L125-NF, L225-NF | 1 | 1 | 6 |
| T2PM40E3 | 3 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | 1 | 1 | 6 |
| T2PM40E3 | 3 | | H400-NE, L400-NE | 1 | 1 | 6 |
| T2PM40E3 | 3 | | PS630-CF/NF/GF/NN, PH630-CF | 1 | 1 | 6 |
| T2PM80E3 | 3 | | S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NE/RE/PE/NN | 1 | 1 | 6 |
| T2PM80M3 | 3 | | H630-NE, L630-NE, H800-NE, L800-NE | 1 | 1 | 6 |
| T2PMX3E3 | 3 | | S1250-NE/GE/NN | 1 | 1 | 6 |
| XDM8 | 3 | | TL-1000NE, TL-1200NE | 1 | 1 | 6 |
| T2PM12LC3 | 3 | Compliant ② | PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN | 1 | 1 | 6 |
| TPPM12C2 | 2 | | PS50-PF, PS125-NF/PF | 1 | 1 | 4 |
| TPPM12C3 | 3 | | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | 1 | 1 | 6 |
| T2PM12C3 | 3 | | S100-GF, S125-GF | 1 | 1 | 6 |
| T2PM12LC3 | 3 | | S50-SF, S125-SF/SN | 1 | 1 | 6 |
| T2PM25LC3 | 3 | | E250-SF, S250-SF, S250-SN | 1 | 1 | 6 |
| T2PM25LC4 | 4 | | S250-SF, S250-SN | 1 | 1 | 8 |
| T2PM25LC3 | 3 | | PS250-PF/NN, PS250-NE/PE | 1 | 1 | 6 |
| T2PM25C3 | 3 | | H100-NF, H125-NF, H225-NF, L100-NF, L125-NF, L225-NF | 1 | 1 | 6 |
| T2PM40C3 | 3 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | 1 | 1 | 6 |
| T2PM40C3 | 3 | | H400-NE, L400-NE | 1 | 1 | 6 |
| T2PM40C3 | 3 | | PS630-CF/NF/GF/NN, PH630-CF | 1 | 1 | 6 |
| T2PM80C3 | 3 | | S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NE/RE/PE/NN ① | 1 | 1 | 6 |
| T2PM80N3 | 3 | | H630-NE, L630-NE, H800-NE, L800-NE ① | 1 | 1 | 6 |
| T2PMX3C3 | 3 | | S1250-NE/GE/NN | 1 | 1 | 6 |

● See page 5-17 for nut J. Nut J is common to PMB and PMC.

Remarks: Normally the plug-in base should be ordered at the same time as the breaker body. However, please order it if you will connect the plug-in base in advance.

**Note:** ① An IP20 applied plug-in base requires a dedicated IP20 circuit breaker body. When ordering the circuit breaker body, please specify "IP20 applied product".

② If internal accessories are fitted in the circuit breaker, auxiliary circuit terminals for IP20 are required. Please specify "IP20 applied product" when ordering the circuit breaker body.

## 4. Flush-mounted (with flat bar studs)

| Type | Number of poles | Connection ① | Applicable breakers | | Min order qty | Constituent parts | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | | Flush plate ② | Flush-mounting frame | Stud unit | Frame mounting screw | Panel mounting screw | Bush | Screw F | Screw G |
| T2FP05A3B | 3 | Vertical – Horizontal | E30-NM, S30-NM, E50-NM, S50-NM | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM | 1 | 1 | 1 | 2④ | 4 | — | 4 | 6 | 6 |
| T2FP05C3B | | Vertical – Vertical | | | | | | | | | | | |
| T2FP05D3B | | Horizontal – Horizontal | | | | | | | | | | | |
| T2FP06A3B | 3 | Vertical – Horizontal | E100-NM | ZE100-NM | 1 | 1 | 1 | 2④ | 4 | — | 4 | 6 | 6 |
| T2FP06C3B | | Vertical – Vertical | | | | | | | | | | | |
| T2FP06D3B | | Horizontal – Horizontal | | | | | | | | | | | |
| T2FP12LS2 | 2 | Horizontal – Horizontal | PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF | ——— | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| T2FP12LS3 | 3 | Horizontal – Horizontal | PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ, PS50-NF/NFZ | PZE30-NF, PZS30-NF, PZE50-NF, PZS50-NF | | | | | | | — | — | — |
| T2FP12LS2 | 2 | Horizontal – Horizontal | PE60-NF, PS60-NF, PE125-NF/NN | ——— | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| T2FP12LS3 | 3 | Horizontal – Horizontal | PE60-NF, PS60-NF, PE125-NF/NN/NFZ | PZE60-NF, PZS60-NF, PZE125-NF | | | | | | | — | — | — |
| T2FP12LS2 | 2 | Horizontal – Horizontal | S50-SF, S125-SF | ——— | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| T2FP12LS3 | 3 | Horizontal – Horizontal | S50-SF, S125-SF, ZAS125-SF, S125-SN | ZS50-SF, ZS125-SF, ZS100-SM | | | | | | | — | — | — |
| TPFP12S2 | 2 | * | PS50-PF, PS125-NF/PF | ——— | 1 | 1 | 1 | —⑤ | 2 | 4 | — | — | — |
| TPFP12S3 | 3 | | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | ——— | | | | | 4 | | — | — | — |
| TPFP12S4 | 4 | | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | | | | | | | | — | — | — |
| T2FP12S2 | 2 | * | S100-GF, S125-GF | ——— | 1 | 1 | 1 | —⑤ | 2 | 4 | — | — | — |
| T2FP12S3 | 3 | | S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF | ZS100-GF, ZS125-GF | | | | | 4 | | — | — | — |
| T2FP12S4 | 4 | | | | | | | | | | — | — | — |
| T2FP25S3 | 3 | * | E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF | ZE250-SF, ZS250-SF, ZS250-SM | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| T2FP25S4 | 4 | | S250-SF, S250-SN | ——— | | | | | | | — | — | — |
| T2FP25S3 | 3 | * | ZAS225-GF, ZAS250-GF | ZS225-GF, ZS250-GF | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| T2FP25S4 | 4 | | | | | | | | | | — | — | — |
| T2FP25S3 | 3 | * | PS250-PF/NN, PS250-NE/PE | ——— | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| T2FP25S4 | 4 | | | | | | | | | | — | — | — |
| T2FP25L3 | 3 | * | H100-NF, H125-NF, H225-NF, H225-NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF | ——— | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| T2FP25L4 | 4 | | | | | | | | | | — | — | — |
| TPFP40S3 | 3 | * | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | ——— | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| TPFP40S4 | 4 | | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE | | | | | | | | — | — | — |
| TPFP40S3 | 3 | * | E400-NF, ZAE400-NF, ZAS400-NF/GF | ZE400-NF, ZS400-NF/GF | 1 | 1 | 1 | —⑤ | —③ | 4 | — | — | — |
| TPFP40S4 | 4 | | ZAS400-NF/GF | ZS400-NF/GF | | | | | | | — | — | — |
| TPFP40S3 | 3 | * | PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE | ——— | 1 | 1 | 1 | —⑤ | 4 | 4 | — | — | — |
| TPFP40S4 | 4 | | PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE | | | | | | | | — | — | — |
| TPFP40L3 | 3 | * | H400-NE, L400-NE | ——— | 1 | 1 | 1 | —⑤ | —③ | 4 | — | — | — |
| TPFP40L4 | 4 | | | | | | | | | | — | — | — |

● See page 5-17 for screws F and G.

**Note:**

① In the case of "vertical-horizontal," "vertical-vertical," or "horizontal-horizontal," the orientation cannot be changed. In the case of "*", the studs can be rotated to four angular positions: 0 (horizontal), 45, 90 (vertical) and 135 degrees.

② The flash plate is painted in Munsell 5Y 7/1.

③ Use the breaker mounting screws (supplied with the breaker) to secure the breaker in the flush-mounting frame.


④ The stud bar is integrated with the stud unit.

⑤ The stud bar is not provided as standard. Please order the flat bar stud for rear connection in page 5-7 separately.


## Plug-in for switchboards (PM)

### 1. Plug-in base for switchboards

#### Standard (PMC)





Warnig





Secure the conductor with the correct nut and washer to ensure full contact of conductor with terminal on the plug-in base, so that the steel stud bolt is not used as the current path.
(See page 5-17)

#### High-performance (PMB)




Warnig





Secure the conductor with the correct nut and washer to ensure full contact of conductor with terminal on the plug-in base, so that the steel stud bolt is not used as the current path.
(See page 5-17)

## 2. High-performance plug-in base connection method


Three types of mounting method are possible with the high-performance plug-in base PMB type.

### Rear-connected

Mount to an angle or panel and connect with the main busbar at the rear.
The main busbar can be connected either externally or internally.





Angle mounting




Front panel mounting

### Front-connected

Attach to a panel and connect the main busbar to the extension bars from the front.
A plug-in base with extension bars is available as an option.




Rear panel mounting

## 3. High-performance plug-in base safety mechanism

The high-performance plug-in base PMB type is supplied with the following safety mechanism as standard.

### Safety trip

If you try to remove the circuit breaker while it is ON, it will automatically TRIP.
See Chapter 2 for applicable models.

### Safety lock

Since the breakers have a safety mechanism as standard that prevents them from being mounted or removed as long as they are in the ON state, they can be safely mounted or removed in non-energized state any time.
See Chapter 2 for applicable models.

## Front connected type (without extension bar)

| Frame size (A) | MCCB | ELCB | Rated current | Nominal wire size (mm²) | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | 2 | 5.5 | 8 | 14 | 22 | 38 | 60 | 80 | 100 | 150 |
| 30, 50 | **E30-NM, S30-NM, PE30-NF/NN, PS30-NF** | **ZE30-NM, ZS30-NM, PZE30-NF, PZS30-NF** | | R2-5 | R5.5-5 | R8-5 | R14-5 | NTM CB22-5S AMP 33114 | | | | | |
| | **TB-5S, TB-5P, TB-5D** (Load side) | | | R2-5 | R5.5-5 | R8-5 | R14-5 | NTM CB22-5S | | | | | |
| | **TB-51C, TB-52C** | **TZ-51C, TZ-52C** | | R2-5 | R5.5-5 | JST8-5SC-9 AMP8-5A NTM8-5S | | | | | | | |
| | | **TZ30EC** | | R2-5 | R5.5-5 | R8-5 | R14-5 | | | | | | |
| | **E50-NM, S50-NM, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ** | **ZE50-NM, ZS50-CM, PZE50-NF/NFN, PZS50-NF** | | R2-5 | R5.5-5 | R8-5 | R14-5 | NTM CB22-5S AMP 33114 | | | | | |
| | **S50-SF** | **ZS50-SF** | | R2-5 (R2-6) | R5.5-5 (R5.5-6) | R8-5 (R8-6) | R14-5 | NTM CB22-5S AMP 33114 | | | | | |
| | | **TZ50EE** | | R2-5 | R5.5-5 | R8-5 | R14-5 | | | | | | |
| | **ZAS50-GF** | | | R2-8 | R5.5-8 | R8-8 | R14-8 | R22-8 | AMP 322870 JST 38-S8 NTK R38-8S NTM R38-8S | 60-S8 Note ③<br>CB60-8 | | | |
| 60 | **PE60-NF, PS60-NF** | **PZE60-NF, PZS60-NF** | | R2-8 | R5.5-8 | R8-8 | R14-8 | R22-8 | | | | | |
| 100, 125 | | **TZ100EC** | | | | R8-8 | R14-8 | R22-8 | NTM R38-8S | NTM CB60-8 | | | |
| | **E100-NM** | **ZE100-NM** | (60-125A) | R2-8 | R5.5-8 | R8-8 | R14-8 | JST 22-S8 | JST 38-S8 NTM R38-8S | 60-S8 Note ③ | | | |
| | **S125-SF, ZAS125-SF, NS125-SF** | **ZS125-SF, ZS100-SM, ZNS125-SF** | (15-50A) | R2-5 (R2-6) | R5.5-5 (R5.5-6) | R8-5 (R8-6) | R14-5 | NTM CB22-5S AMP 33114 | | | | | |
| | **S125-SF, S125-SN, ZAS125-SF, NS125-SF, PE125-NF/NN/NFZ/NFN** | **PZE125-NF/NFN** | (60-125A) | | | R8-8 | R14-8 | R22-8 | AMP 322870 JST38-S8 NTM R38-8S | NTM CB60-8<br>60-S8 Note ③ | | | |
| | **H100-NF, H125-NF, L100-NF, L125-NF, PS125-NF/NE/PF/PE/NN, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | | R2-8 | R5.5-8 | R8-8 | R14-8 | R22-8 | AMP 322870 JST 38-S8 NTK R38-8S NTM R38-8S | 60-S8 Note ③<br>CB60-8 | | | |
| 225, 250 | **E250-SF, S250-SF, S250-SM/SN, H225-NF/NE, H250-NF, L225-NF, L250-NF, ZAE250-SF, ZAS225-GF, ZAS250-GF/SF, NE250-SF, NS250-SF, PS250-NE/PF/PE/NN** | **ZE250-SF, ZS225-GF, ZS250-GF/SF/SM, ZNE250-SF, ZNS250-SF** | | | | | | | R38-8 | R60-8 | 80-3BA Note ③<br>CB80-8 | 100-3BA Note ③<br>CB100-8 | CB150-8 |
| 400 | **H400-NE, L400-NE, ZAE400-NF, ZAS400-NF/GF, NE400-NF, NS400-NF, E400-NF, PS400-CF/NF/NE/GF/GE/NN, PH400-CF/CE** | **ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | | | | | | | R38-10 Note ② | R60-10 Note ② | 80-4B Note ②③<br>CB80-10 Note ② | 100-4B Note ②③<br>CB100-10 Note ② | 150-4B Note ②③<br>CB150-10 Note ② |

## Front connected type (with extension bar)

| Frame size (A) | MCCB | ELCB | Nominal wire size (mm²) | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| | | | 38 | 60 | 80 | 100 | 150 | 200 | 325 |
| 225, 250 | **E250-SF, S250-SF, S250-SM/SN, H225-NF/NE, H250-NF, L225-NF, L250-NF, ZAE250-SF, ZAS225-GF, ZAS250-GF/SF, NE250-SF, NS250-SF, PS250-NE/PF/PE/NN** | **ZE250-SF, ZS225-GF, ZS250-GF/SF/SM, ZNE250-SF, ZNS250-SF** | R38-10 | R60-10 | R80-10 | R100-10 | R150-10 Note ⑤<br>CB150-10 Note ⑥ | | |
| 400 | **H400-NE, L400-NE, ZAE400-NF, ZAS400-NF/GF, NE400-NF, NS400-NF, E400-NF, PS400-CF/NF/NE/GF/GE/NN, PH400-CF/CE** | **ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | R38-12 | R60-12 | R80-12 | R100-12 | R150-12 | R200-12 | JST325-12 |
| 630 | **S630-CF/NF/NE/GN, PS630-CF/NF/NE/GF/GE/NN, PH630-CF/CE, H630-NE, L630-NE, ZAS630-CF/NF, NS630-NF** | **ZS630-CF/NF** | | R60-12 RD60-12 | R80-12 RD80-12 | R100-12 RD100-12 | R150-12 RD150-12 | R200-12 RD200-12 | JST325-12 RD325-12 |
| 800 | **S800-CF/NF/NE/RF/RE/PF/PE/NN, H800-NE, L800-NE, ZAS800-CF/NF, NS800-NF** | **ZS800-CF/NF** | | R60-12 RD60-12 | R80-12 RD80-12 | R100-12 RD100-12 | R150-12 RD150-12 | R200-12 RD200-12 | JST325-12 RD325-12 |
| 1000 | **S1000-CE/NN, TL-1000NE** | | | | R80-12 RD80-12 | R100-12 RD100-12 | R150-12 RD150-12 | R200-12 RD200-12 | JST325-12 RD325-12 |
| 1200, 1250 | **S1250-NE/GE/NN, TL-1200NE** | | | | R80-12 RD80-12 | R100-12 RD100-12 | R150-12 RD150-12 | R200-12 RD200-12 | JST325-12 RD325-12 |

**Note:**

① : Commercially made compression terminals can be used (refer to ▭ boxes)
- R/RD ····· JIS-compliant
- CB ····· JEM 1399-compliant
- AMP ····· Made by Tyco Electronics Japan G.K.
- JST ····· Made by Japan Solderless Terminal Manufacturing Co., Ltd.
- NTK ····· Made by Nippon Tanshi Co., Ltd.
- NTM ····· Made by Nichifu Terminal Industries Co., Ltd.

② : Only a single terminal can be connected. If it is necessary to connect two terminals, use a circuit breaker with extension bars.

③ : Compression terminals in ▭ box cells are made by us at Terasaki. They are available from us or our authorized agents.


④ : Compression terminals enclosed in parentheses are to be used as the lower terminal when two terminals are connected.

⑤ : For spread extension bars.

⑥ : For straight extension bars.


## Connection (two terminals)

If a shortage of insulating occurs between the mounting plate and a terminal, use a recommended taping or insulator.





## Terasaki made compression terminals are used (refer to ☐ box)


80-3BA





80-4B





100-3BA




100-4B





150-4B




## Connection (one electric cable)


If a shortage of insulating occurs, use a recommended taping or insulator.



Make connection so that the screw heads face toward the mounting surface.




## Connection (two electric cables)

If a shortage of insulating occurs, use a recommended taping or insulator.





Make connection so that the screw heads face toward the mounting surface.

## 3 Terminal screw sizes and standard torques

| Connecting types / Type | Front connection (FC) | | | | Rear connection (RC) (Flat bar stud) | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| |  | | | |  | | | |  | |
| Frame size (A) | MCCB | ELCB | Compression terminal Screw size (A) | Compression terminal Torque (N·m) | Extension bar Screw size (B) | Extension bar Torque (N·m) | Screw size (C) | Torque (N·m) | Screw size (D) | Torque (N·m) | Screw size (E) | Torque (N·m) |
| 30 | | **TZ30EC** | Pan head M5×15 Wire clamping screw | 2.3 – 3.5 | — | — | — | — | — | — | — | — |
| 50 | | **TZ50EE** | Pan head M5×15 Wire clamping screw | 2.5 – 3.5 | — | — | — | — | — | — | — | — |
| 100 | | **TZ100EC** | Pan head M8×15 | 5.0 – 7.0 | — | — | — | — | — | — | — | — |
| 1000 | **TL-1000NE** | | — | — | Hex head M12×55 | 40.2 – 65.7 | — | — | — | — | Hex head M12×47 | 40.2 – 65.7 |
| 1200, 1250 | **S1250-NE**<br>**S1250-GE**<br>**S1250-NN**<br>**TL-1200NE** | | — | — | Hex head M12×55 | 40.2 – 65.7 | — | — | — | — | Hex head M12×47 | 40.2 – 65.7 |
| 1600 ② | **S1600-NE**<br>**S1600-NN** | | — | — | Hex head M12×60 | 40.2 – 65.7 | — | — | — | — | Hex head M10×45 | 22.5 – 37.2 |
| 2000 ② | **XS2000NE**<br>**XS2000NN** | | — | — | Hex head M10×60 | 22.5 – 37.2 | — | — | — | — | Hex head M10×60 | 22.5 – 37.2 |
| 2500 ② | **XS2500NE**<br>**XS2500NN** | | — | — | — | — | — | — | — | — | Hex head M10×60 | 22.5 – 37.2 |
| 3200 ② | **XS3200NE**<br>**XS3200NN** | | — | — | — | — | — | — | — | — | Hex head M10×70 | 22.5 – 37.2 |


Note ①: The connector appearance, screw dimensions, and tightening torque are the same as the plug-in (PM).
Note ②: Terminal screws for 1600AF and over are not provided as standard.

| | Rear connection (RC) (Bolt stud) | | | | Plug-in (PM) | | Draw-out (DR) | |
|---|---|---|---|---|---|---|---|---|
| |  | | | | | |  | |
| | Screw size (F) | Torque (N·m) | Nut size (G) | Torque (N·m) | Nut size (J) | Torque (N·m) | Screw size (I) | Torque (N·m) |
| | — | — | — | — | — | — | — | — |
| | — | — | — | — | — | — | — | — |
| | — | — | — | — | — | — | — | — |
| | — | — | — | — | Hex head M12×47 (screw) | 40.2 – 65.7 | ① | |
| | — | — | — | — | Hex head M12×47 (screw) | 40.2 – 65.7 | ① | |
| | — | — | — | — | — | — | Hex head M10×45 | 22.5 – 37.2 |
| | — | — | — | — | — | — | Hex head M10×60 | 22.5 – 37.2 |
| | — | — | — | — | — | — | — | — |
| | — | — | — | — | — | — | — | — |


## 3 Terminal screw sizes and standard torques





Type / Connecting types

Front connection (FC)





| Frame size (A) | MCCB | ELCB | Compression terminal | | Extension bar | | | |
|---|---|---|---|---|---|---|---|---|
| | | | Screw size (A) | Torque (N·m) | Screw size (B) | Torque (N·m) | Screw size (C) | Torque (N·m) |
| 30, 50 | E30-NM, S30-NM, E50-NM, S50-NM | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM | Wire clamping M5×14 | 2.3 – 2.8 | Wire clamping M5×14 | 2.5 – 3.5 | Hex head M5×16 | 3.5 – 4.5 |
| | PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF | | Wire clamping M5×14 | 2.3 – 3.4 | Wire clamping M5×14 | 2.3 – 3.4 | Hex head M8×30 | 11.8 – 18.6 |
| | PE50-NFZ, PS50-NFZ | PZE30-NF, PZS30-NF, PZE50-NF, PZS50-NF | Wire clamping M5×14 | 2.3 – 3.4 | Wire clamping M5×14 | 2.3 – 3.4 | Hex head M8×30 | 11.8 – 18.6 |
| | PE50-NFN | PZE50-NFN | Wire clamping M5×14 | 2.3 – 3.4 | Wire clamping M5×14 | 2.3 – 3.4 | Hex head M8×30 | 11.8 – 18.6 |
| | S50-SF | | Wire clamping M5×14 | 2.3 – 3.4 | Wire clamping M5×14 | 2.3 – 3.4 | Hex head M8×30 | 11.8 – 18.6 |
| | | ZS50-SF | Wire clamping M5×14 | 2.3 – 3.4 | Wire clamping M5×14 | 2.3 – 3.4 | Hex head M8×30 | 11.8 – 18.6 |
| | ZAS50-GF | | Pan head M8×16 | 4.9 – 6.9 | Pan head M8×16 | 4.9 – 6.9 | Hex head M8×25 | 11.8 – 18.6 |
| | PS50-PF | | Pan head M8×16 | 4.9 – 6.9 | Pan head M8×16 | 4.9 – 6.9 | Hex head M8×25 | 11.8 – 18.6 |
| 60 | PE60-NF, PS60-NF | | Pan head M8×14 | 4.9 – 6.9 | Pan head M8×14 | 4.9 – 6.9 | Hex head M8×30 | 11.8 – 18.6 |
| | | PZE60-NF, PZS60-NF | Pan head M8×14 | 4.9 – 6.9 | Pan head M8×14 | 4.9 – 6.9 | Hex head M8×30 | 11.8 – 18.6 |
| 100, 125 | E100-NM | ZE100-NM | Pan head M8×15 | 5.5 – 7.5 | Pan head M8×14 | 5.5 – 7.5 | Hex head M8×22 | 8 – 10 |
| | PE125-NF/NN | | Pan head M8×14 | 4.9 – 6.9 | Pan head M8×14 | 4.9 – 6.9 | Hex head M8×30 | 11.8 – 18.6 |
| | PE125-NFZ | PZE125-NF | Pan head M8×14 | 4.9 – 6.9 | Pan head M8×14 | 4.9 – 6.9 | Hex head M8×30 | 11.8 – 18.6 |
| | PE125-NFN | PZE125-NFN | Pan head M8×14 | 4.9 – 6.9 | Pan head M8×14 | 4.9 – 6.9 | Hex head M8×30 | 11.8 – 18.6 |
| | S125-SF(15 – 50A) | | Wire clamping M5×14 | 2.3 – 3.4 | Wire clamping M5×14 | 2.3 – 3.4 | Hex head M8×30 | 11.8 – 18.6 |
| | ZAS125-SF(15 – 50A) | ZS125-SF(15 – 50A), ZS100-SM(16 – 45A) | Wire clamping M5×14 | 2.3 – 3.4 | Wire clamping M5×14 | 2.3 – 3.4 | Hex head M8×30 | 11.8 – 18.6 |
| | S125-SF(60 – 125A), S125-SN | | Pan head M8×14 | 4.9 – 6.9 | Pan head M8×14 | 4.9 – 6.9 | Hex head M8×30 | 11.8 – 18.6 |
| | ZAS125-SF(60 – 125A) | ZS125-SF(60 – 125A), ZS100-SM(60 – 100A) | Pan head M8×14 | 4.9 – 6.9 | Pan head M8×14 | 4.9 – 6.9 | Hex head M8×30 | 11.8 – 18.6 |
| | NS125-SF, NAE125-SF, NAS125-SF(15 – 50A) | ZNS125-SF(15 – 50A) | Wire clamping M5×14 | 2.3 – 3.4 | Wire clamping M5×14 | 2.3 – 3.4 | Hex head M8×30 | 11.8 – 18.6 |
| | NS125-SF, NAE125-SF, NAS125-SF(60 – 125A) | ZNS125-SF(60 – 125A) | Pan head M8×14 | 4.9 – 6.9 | Pan head M8×14 | 4.9 – 6.9 | Hex head M8×30 | 11.8 – 18.6 |
| | PS125-NF/NE/PF/PE/NM/NN | | Pan head M8×16 | 4.9 – 6.9 | Pan head M8×16 | 4.9 – 6.9 | Hex head M8×25 | 11.8 – 18.6 |
| | S100-GF, S125-GF | | Pan head M8×16 | 4.9 – 6.9 | Pan head M8×16 | 4.9 – 6.9 | Hex head M8×25 | 11.8 – 18.6 |
| | ZAS100-GF, ZAS125-GF | ZS100-GF, ZS125-GF | Pan head M8×16 | 4.9 – 6.9 | Pan head M8×16 | 4.9 – 6.9 | Hex head M8×25 | 11.8 – 18.6 |
| | H100-NF, H125-NF, L100-NF, L125-NF | | Hex socket head M8×20 | 7.8 – 12.7 | Hex socket head M8×20 | 7.8 – 12.7 | Hex head M10×25 | 22.5 – 37.2 |
| 225, 250 | E250-SF, S250-SF, S250-SN | | Hex socket head M8×20 | 7.8 – 12.7 | Hex socket head M8×20 | 7.8 – 12.7 | Hex head M10×25 | 22.5 – 37.2 |
| | S250-SM, ZAE250-SF, ZAS250-SF | ZE250-SF, ZS250-SF/SM | Hex socket head M8×20 | 7.8 – 12.7 | Hex socket head M8×20 | 7.8 – 12.7 | Hex head M10×25 | 22.5 – 37.2 |
| | NE250-SF, NS250-SF | ZNE250-SF, ZNS250-SF | Hex socket head M8×20 | 7.8 – 12.7 | Hex socket head M8×20 | 7.8 – 12.7 | Hex head M10×25 | 22.5 – 37.2 |
| | PS250-NE/PF/PE/NN | | Hex socket head M8×20 | 7.8 – 12.7 | Hex socket head M8×20 | 7.8 – 12.7 | Hex head M10×25 | 22.5 – 37.2 |
| | H225-NF, L225-NF | | Hex socket head M8×20 | 7.8 – 12.7 | Hex socket head M8×20 | 7.8 – 12.7 | Hex head M10×25 | 22.5 – 37.2 |
| | H225-NE, H250-NF, L250-NF, ZAS225-GF, ZAS250-GF | ZS225-GF, ZS250-GF | Hex socket head M8×20 | 7.8 – 12.7 | Hex socket head M8×20 | 7.8 – 12.7 | Hex head M10×25 | 22.5 – 37.2 |
| 400 | E400-NF, ZAE400-NF, ZAS400-NF/GF | ZE400-NF, ZS400-NF/GF | Hex socket head M10×25 | 13.7 – 22.5 | Hex socket head M10×25 | 13.7 – 22.5 | Hex head M12×35 | 40.2 – 65.7 |
| | PS400-CF/NF/NE/GF/GE/NN, PH400-CF/CE | | Hex socket head M10×30 | 13.7 – 22.5 | Hex socket head M10×30 | 13.7 – 22.5 | Hex head M12×35 | 40.2 – 65.7 |
| | H400-NE, L400-NE | | Hex socket head M10×30 | 13.7 – 22.5 | Hex socket head M10×30 | 13.7 – 22.5 | Hex head M12×35 | 40.2 – 65.7 |
| | NE400-NF, NS400-NF | ZNE400-NF, ZNS400-NF | Hex socket head M10×25 | 13.7 – 22.5 | Hex socket head M10×25 | 13.7 – 22.5 | Hex head M12×35 | 40.2 – 65.7 |
| 600, 630, 800 | S630-CF/NF/NE/GN, S800-CF/NF/NE/RF/RE/PF/PE/NN, H630-NE, L630-NE, H800-NE, L800-NE | | — | — | Hex socket head M8×25×2 | Standard mounting | Hex head M12×40 | 40.2 – 65.7 |
| | PS630-CF/NF/NE/GF/GE/NN, PH630-CF/CE | | — | — | Hex socket head M10×30 | 13.7 – 22.5 | Hex head M12×40 | 40.2 – 65.7 |
| | ZAS630-CF/NF, ZAS800-CF/NF | ZS630-CF/NF, ZS800-CF/NF | — | — | Hex socket head M8×25×2 | Standard mounting | Hex head M12×40 | 40.2 – 65.7 |
| | NS630-NF, NS800-NF | | — | — | Hex socket head M8×25×2 | Standard mounting | Hex head M12×40 | 40.2 – 65.7 |
| 1000 | S1000-CE/NN | | — | — | Hex socket head M8×30×2 | Standard mounting | Hex head M12×55 | 40.2 – 65.7 |



| | Rear connection (RC) (Flat bar stud) | | | | Flush-mounted (FP) | | | | Plug-in (PM) | | Draw-out (DR) | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| |  | | | |  | | | |  | |  | |
| | | | | | With flat bar stud | | | | | | | |
| | Screw size (D) | Torque (N·m) | Screw size (E) | Torque (N·m) | Screw size (F) | Torque (N·m) | Screw size (G) | Torque (N·m) | Nut size (J) | Torque (N·m) | Nut size (K) | Torque (N·m) |
| | Wire clamping M5×14 | 2.3 – 2.8 | Hex head M6×18 | 4 – 5 | Wire clamping M5×14 | 2.3 – 2.8 | Hex head M6×18 | 4 – 5 | — | — | — | — |
| | Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | — | — | — | — |
| | — | — | — | — | — | — | — | — | — | — | — | — |
| | Special Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | Special Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | Special Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | Special Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | — | — | — | — |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | — | — | — | — |
| | Hex socket head M6×16 | 7.8 – 11.8 | Hex head M8×23 | 11.8 – 18.6 | Hex socket head M6×16 | 7.8 – 11.8 | Hex head M8×23 | 11.8 – 18.6 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | Pan head M6×16 | 3.2 – 4.8 | Hex head M8×23 | 11.8 – 18.6 | Pan head M6×16 | 3.2 – 4.8 | Hex head M8×23 | 11.8 – 18.6 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | Pan head M6×16 | 3.2 – 4.8 | Hex head M8×23 | 11.8 – 18.6 | Pan head M6×16 | 3.2 – 4.8 | Hex head M8×23 | 11.8 – 18.6 | — | — | — | — |
| | Pan head M8×15 | 5.5 – 7.5 | Hex head M6×18 | 4 – 5 | Pan head M8×15 | 5.5 – 7.5 | Hex head M6×18 | 4 – 5 | — | — | — | — |
| | Pan head M6×16 | 3.2 – 4.8 | Hex head M8×23 | 11.8 – 18.6 | Pan head M6×16 | 3.2 – 4.8 | Hex head M8×23 | 11.8 – 18.6 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | Pan head M6×16 | 3.2 – 4.8 | Hex head M8×23 | 11.8 – 18.6 | Pan head M6×16 | 3.2 – 4.8 | Hex head M8×23 | 11.8 – 18.6 | — | — | — | — |
| | — | — | — | — | — | — | — | — | — | — | — | — |
| | Special Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | Special Pan head M5×14 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | (ON) Special Pan head M5×14<br>(OFF) Special Pan head M5×24 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | (ON) Special Pan head M5×14<br>(OFF) Special Pan head M5×24 | 2.3 – 2.8 | Hex head M6×22 | 4.7 – 7.4 | — | — | — | — |
| | Hex socket head M6×16 | 7.8 – 11.8 | Hex head M8×23 | 11.8 – 18.6 | Hex socket head M6×16 | 7.8 – 11.8 | Hex head M8×23 | 11.8 – 18.6 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | Hex socket head M6×16 | 7.8 – 11.8 | Hex head M8×23 | 11.8 – 18.6 | Hex socket head M6×16 | 7.8 – 11.8 | Hex head M8×23 | 11.8 – 18.6 | — | — | — | — |
| | — | — | — | — | — | — | — | — | — | — | — | — |
| | — | — | — | — | — | — | — | — | — | — | — | — |
| | Hex socket head M6×16 | 7.8 – 11.8 | Hex head M8×23 | 11.8 – 18.6 | Hex socket head M6×16 | 7.8 – 11.8 | Hex head M8×23 | 11.8 – 18.6 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex. nut M6 | 3.6 – 6.0 | — | — |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | — | — | — | — |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex. nut M8 | 8.8 – 14.7 | — | — |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex. nut M8 | 8.8 – 14.7 | — | — |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | — | — | — | — |
| | — | — | — | — | — | — | — | — | — | — | — | — |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex. nut M8 | 8.8 – 14.7 | Hex. nut M8 | 8.8 – 14.7 |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex. nut M8 | 8.8 – 14.7 | — | — |
| | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | Hex socket head M6×20 | 7.8 – 11.8 | Hex head M8×25 | 11.8 – 18.6 | — | — | — | — |
| | Hex socket head M10×20 | 18.6 – 29.4 | Hex head M12×35 | 40.2 – 65.7 | Hex socket head M10×20 | 18.6 – 29.4 | Hex head M12×35 | 40.2 – 65.7 | — | — | — | — |
| | Hex socket head M10×20 | 18.6 – 29.4 | Hex head M12×35 | 40.2 – 65.7 | Hex socket head M10×20 | 18.6 – 29.4 | Hex head M12×35 | 40.2 – 65.7 | Hex. nut M10 | 18.6 – 29.4 | Hex. nut M10 | 18.6 – 29.4 |
| | Hex socket head M10×20 | 18.6 – 29.4 | Hex head M12×35 | 40.2 – 65.7 | Hex socket head M10×20 | 18.6 – 29.4 | Hex head M12×35 | 40.2 – 65.7 | Hex. nut M10 | 18.6 – 29.4 | Hex. nut M10 | 18.6 – 29.4 |
| | — | — | — | — | — | — | — | — | — | — | — | — |
| | Hex socket head M10×25 | 18.6 – 29.4 | Hex head M12×40 | 40.2 – 65.7 | Special hex socket head M10×27 | 18.6 – 29.4 | Hex head M12×40 | 40.2 – 65.7 | Standard (PMC):<br>Hex. nut M16<br>High-performance (PMB):<br>Hex. nut M12 | <br>51.5 – 84.3<br><br>32.3 – 51.9 | Hex. nut M12 ② | 32.3 – 51.9 |
| | Hex socket head M8×25 | 8.8 – 14.7 | Hex head M12×30 | 40.2 – 65.7 | Hex socket head M8×25 | 8.8 – 14.7 | Hex head M12×30 | 40.2 – 65.7 | Hex. nut M10 | 18.6 – 29.4 | Hex. nut M10 | 18.6 – 29.4 |
| | Hex socket head M10×25 | 18.6 – 29.4 | Hex head M12×40 | 40.2 – 65.7 | Special hex socket head M10×27 | 18.6 – 29.4 | Hex head M12×40 | 40.2 – 65.7 | — | — | — | — |
| | — | — | — | — | — | — | — | — | — | — | — | — |
| | Special hex socket head M10×30 | 18.6 – 29.4 | Hex head M12×47 | 40.2 – 65.7 | Special hex socket head M10×30 | 18.6 – 29.4 | Hex head M12×47 | 40.2 – 65.7 | — | — | — | — |

Note ①: Secure the conductor with the correct nut and washer to ensure full contact of conductor with terminal on the plug-in base, so that the steel terminal bolt is not used as the current path.





Note ②: Applies only to S630 and S800.


# 5 Mounting and Connection

## Moulded Case Circuit Breakers / Earth Leakage Circuit Breakers

### 4 Insulation distance from the line side

The insulation distance between the breaker and earthed metal parts and insulators shown in the table on the next page must be maintained to prevent arcing faults occurring due to conductive ionised gas. In addition, completely cover exposed conductors, to their roots at the breaker or to below the height protected by interpole barriers, on the line side of the breaker using insulation tube or tape, in order to provide positive protection against short circuit or ground fault due to metal chipping, surge voltage, dust particles or salt. Be sure to install the interpole barriers supplied with the breaker.




A : Distance from lower breaker to exposed live part of upper breaker terminal (front connection) or distance from lower breaker to end face of upper breaker (rear connection, plug-in).
$B_1$ : Distance from end face of breaker to top plate.
$B_2$ : Distance from end face of breaker to insulation plate.
C : Gap between breakers.
D : Distance from side of breaker to side plate (earthed metal).
E : Dimension of insulation over exposed conductors.

## Insulation distance, mm (415V AC or less) Note ①

| Series | Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | A Breaker upper and lower gap Note ② | B1 Bare grounded metal plate | B2 Insulating plate, coated plate | | C | D | E |
|---|---|---|---|---|---|---|---|---|---|
| E: Economical | **PE30-NF, PE50-NF, PE60-NF** | **PZE30-NF, PZE50-NF, PZE60-NF** | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **PE125-NF** | **PZE125-NF** | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **E250-SF** | **ZE250-SF** | 50 | 40 | 40 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **E400-NF** | **ZE400-NF** | 100 | 80 | 60 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| Standard N: Standard | **PS30-NF** | **PZS30-NF** | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **PS50-NF** | **PZS50-NF** | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **PS60-NF** | **PZS60-NF** | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **S50-SF, S125-SF** | **ZS50-SF, ZS125-SF** | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **PS125-NF, PS125-NE** | | 50 | 10 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **PS250-NE** | | 50 | 40 | 30 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **S250-SF** | **ZS250-SF** | 50 | 50 | 40 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **PS400-CF, PS400-NF, PS400-NE** | | 80 Note ⑤ | 80 | 60 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | | **ZS400-NF** | 100 | 80 | 60 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **PS630-CF, PS630-NF, PS630-NE** | | 80 Note ⑤ | 80 | 60 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **S630-CF, S630-NF, S630-NE, S800-CF, S800-NF, S800-NE** | **ZS630-CF, ZS630-NF, ZS800-CF, ZS800-NF** | 120 | 100 | 80 | | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **S1000-CE, S1250-NE** | | 150 | 120 | 80 | | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **S1600-NE, XS2000NE, XS2500NE, XS3200NE** | | 150 | 150 | 100 | | Possible to set close Note ③ | 100 | Not less than the length of the bare live part Note ④ |
| Standard G: High-fault Level | **S100-GF, S125-GF** | **ZS100-GF, ZS125-GF** | 75 | 60 | 25 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **PS50-PF, PS125-PF, PS125-PE** | | 75 | 45 | 25 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | | **ZS225-GF, ZS250-GF** | 100 | 80 | 60 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **PS250-PF, PS250-PE** | | 80 | 80 | 30 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **PS400-GF, PS400-GE** | | 80 Note ⑤ | 80 | 60 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | | **ZS400-GF** | 100 | 80 | 60 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **PS630-GF, PS630-GE** | | 80 Note ⑤ | 80 | 60 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **S800-RF, S800-PF, S800-RE, S800-PE** | | 150 | 120 | 80 | | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **S1250-GE** | | 150 | 150 | 100 | | Possible to set close Note ③ | 100 | Not less than the length of the bare live part Note ④ |
| Current-limiting H: Standard | **H100-NF, H125-NF, H225-NF, H225-NE, H250-NF** | | 100 | 80 | 60 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **PH400-CF, PH400-CE, PH630-CF, PH630-CE** | | 80 Note ⑤ | 120 | 80 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **H400-NE** | | 120 | 120 | 80 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **H630-NE, H800-NE** | | 120 Note ⑤ | 120 | 80 | | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **TL-1000NE, TL-1200NE** | | 150 | 150 | 100 | | Possible to set close Note ③ | 100 | Not less than the length of the bare live part Note ④ |
| Current-limiting L: High-fault Level | **L100-NF, L225-NF, L125-NF, L250-NF** | | 100 | 80 | 60 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **L400-NE** | | 120 | 120 | 80 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **L630-NE, L800-NE** | | 120 Note ⑤ | 120 | 80 | | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| Motor protection | **E30-NM, S30-NM, E50-NM** | **ZE30-NM, ZS30-NM, ZE50-NM** | 30 | 10 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | | **ZS50-CM** | 40 | 30 | 30 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **S50-NM, E100-NM** | **ZE100-NM** | 50 | 50 | 50 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | | **ZS100-SM** | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **S250-SM** | **ZS250-SM** | 50 | 50 | 40 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| Circuit Breaker with Earth Leakage Alarm | **PE50-NFZ** | | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **PE125-NFZ, PS50-NFZ** | | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **ZAS125-SF** | | 30 | 30 | 10 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **ZAS50-GF, ZAS100-GF, ZAS125-GF** | | 75 | 60 | 25 | ✻ | Possible to set close Note ③ | 25 | Not less than the length of the bare live part Note ④ |
| | **ZAS225-GF, ZAS250-GF** | | 100 | 80 | 60 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **ZAE250-SF** | | 50 | 40 | 40 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **ZAS250-SF** | | 50 | 50 | 40 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **ZAE400-NF, ZAS400-NF, ZAS400-GF** | | 100 | 80 | 60 | ✻ | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |
| | **ZAS630-CF, ZAS630-NF, ZAS800-CF, ZAS800-NF** | | 120 | 100 | 80 | | Possible to set close Note ③ | 80 | Not less than the length of the bare live part Note ④ |

## Insulation distance, mm (690V AC) Note ①

| Series | Moulded Case Circuit Breakers | A Breaker upper and lower gap Note ② | B1 Bare grounded metal plate | B2 Insulating plate, coated plate | | C | D | E |
|---|---|---|---|---|---|---|---|---|
| 690V AC Circuit Breaker | **L125-PF** | 120 | 120 | 80 | ✻ | Possible to set close Note ③ | 50 | Not less than the length of the bare live part Note ④ |
| | **L400-PE** | 120 | 120 | 80 | | Possible to set close Note ③ | 80 | — |
| | **L800-PE** | 200 | 200 | 160 | | Possible to set close Note ③ | 100 | — |

**Notes:**

①: Required to allow free and uninterrupted flow of arc gases. Ensure additional clearance or insulation distance if required to perform wiring, barrier installation or electrical work or to meet the need for more insulation distance between bare live parts and grounded metal members in a switchboard or the like.

②: The figures are for lower breakers.

③: It may not be possible to set close in case of breakers fitted with accessories. For details see page 5-22 "7 Close fitting mounting".

④: For front connection breakers, insulate all exposed conductors of the line side until the breaker end. If interpole barriers are packed, be sure to use the barriers; more over, insulate all exposed conductors by insulating tape or the like so that the tape overlaps with the barriers.

⑤: Arc gas is discharged to the line side and load side. Please be careful when arranging within the board.

✻. If using extension bars (optional), ensure the insulation distance specified for the application.

# 5 Lists of breaker mounting screws

| Series | Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | Number of poles | Front-connected (FC) | | Rear-connected (RC) | | Plug-in (PM) for switchboards | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | | | | PMB High-performance | | PMC Standard | |
| | | | | Screw size | Qty | Screw size | Qty | Screw size | Qty | Screw size | Qty |
| E, PE, ZAE, ZE, PZE | E30-NM, E50-NM, E100-NM | ZE30-NM, ZE50-NM, ZE100-NM | 3 | Pan head M4×55 | 2 | Pan head M4×65 | 2 | — | — | — | — |
| | E250-SF | | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | Pan head M4×65 | 2 |
| | | | 4 | Pan head M4×55 | 4 | Pan head M4×55 | 4 | | | Pan head M4×65 | 4 |
| | PE30-NF/NN, PE50-NF/NN, PE60-NF, PE125-NF/NN | PZE30-NF, PZE50-NF, PZE60-NF, PZE125-NF | 2 | Pan head M4×60 | 2 | Pan head M4×60 | 2 | — | — | — | — |
| | | | 3 | | | | | | | Pan head M4×75 | 2 |
| | PE50-NFZ, PE125-NFZ | | 3 | Pan head M4×60 | 2 | Pan head M4×60 | 2 | — | — | — | — |
| | PE50-NFN, PE125-NFN | PZE50-NFN, PZE125-NFN | 3 | Pan head M4×60 | 2 | — | — | — | — | — | — |
| | E400-NF | | 3 | Pan head M6×100 | 4 | Pan head M6×100 | 4 | — | — | — | — |
| | ZAE250-SF | ZE250-SF | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | — | — |
| | ZAE400-NF | ZE400-NF | 3 | Pan head M6×100 | 4 | Pan head M6×100 | 4 | — | — | — | — |
| S, PS, ZAS, ZS, PZS | S30-NM, S50-NM | ZS30-NM, ZS50-CM | 3 | Pan head M4×55 | 2 | Pan head M4×65 | 2 | — | — | — | — |
| | S50-SF, S125-SF | | 2 | Pan head M4×61 | 2 | Pan head M4×61 | 2 | — | — | — | — |
| | | | 3 | | | | | | | Pan head M4×75 | 2 |
| | | | 4 | | | | | | | — | — |
| | S125-SN | | 3 | Pan head M4×61 | 2 | Pan head M4×61 | 2 | — | — | Pan head M4×75 | 2 |
| | | | 4 | | | | | | | — | — |
| | S100-GF, S125-GF | | 2 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | Pan head M4×80 | 2 | — | — |
| | | | 3 | | | | | Pan head M4×80 | 2 | Pan head M4×58 | 2 |
| | | | 4 | Pan head M4×55 | 4 | Pan head M4×55 | 4 | Pan head M4×80 | 4 | — | — |
| | S250-SF | | 2 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | Pan head M4×65 | 2 |
| | | | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | Pan head M4×65 | 2 |
| | | | 4 | Pan head M4×55 | 4 | Pan head M4×55 | 4 | — | — | Pan head M4×65 | 4 |
| | S250-SM | ZS250-SM | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | — | — |
| | S250-SN | | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | Pan head M4×65 | 2 |
| | | | 4 | Pan head M4×55 | 4 | Pan head M4×55 | 4 | — | — | — | — |
| | S630-CF/NF/NE/GN, S800-CF/NF/NE/RF/RE/PF/PE/NN | | 3 | Pan head M8×45 | 4 | Pan head M8×45 | 4 | Pan head M8×45 | 4 | Cap nut ＊ | 4 |
| | | | 4 | | | | | | | — | — |
| | S1000-CE/NN | | 3,4 | Pan head M8×45 | 4 | Pan head M8×45 | 4 | — | — | — | — |
| | S1250-NE/GE/NN | | 3,4 | Pan head M8×50 | 4 | Pan head M8×50 | 4 | — | — | Cap nut ＊ | 4 |
| | S1600-NE/NN | | 3,4 | Pan head M8×50 | 4 | Pan head M8×50 | 4 | — | — | — | — |
| | PS30-NF, PS50-NF, PS60-NF | PZS30-NF, PZS50-NF, PZS60-NF | 2 | Pan head M4×60 | 2 | Pan head M4×60 | 2 | — | — | — | — |
| | | | 3 | | | | | | | Pan head M4×75 | 2 |
| | PS50-NFZ | | 3 | Pan head M4×60 | 2 | Pan head M4×60 | 2 | — | — | — | — |
| | PS50-PF, PS125-NF/NE/PF/PE | | 2 | Pan head M4×62 | 2 | Pan head M4×62 | 2 | — | — | Pan head M4×75 | 2 |
| | | | 3 | | | | | Pan head M4×90 | 2 | | |
| | | | 4 | | | | | Pan head M4×90 | 4 | — | — |
| | PS125-NM | | 3 | Pan head M4×62 | 2 | Pan head M4×62 | 2 | — | — | — | — |
| | PS125-NN | | 3 | Pan head M4×62 | 2 | Pan head M4×62 | 2 | Pan head M4×90 | 2 | Pan head M4×75 | 2 |
| | | | 4 | | | | | Pan head M4×90 | 4 | — | — |
| | PS250-NE/PF/PE/NN | | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | Pan head M4×80 | 2 | Pan head M4×65 | 2 |
| | | | 4 | Pan head M4×55 | 4 | Pan head M4×55 | 4 | Pan head M4×80 | 4 | — | — |
| | PS400-CF/NF/NE/GF/GE/NN | | 3 | Pan head M6×100 | 4 | Pan head M6×100 | 4 | Pan head M6×120 | 4 | Pan head M6×100 | 4 |
| | | | 4 | | | | | | | — | — |
| | PS630-CF/NF/NE/GF/GE/NN | | 3 | Pan head M6×100 | 4 | Pan head M6×100 | 4 | Pan head M6×120 | 4 | Pan head M6×100 | 4 |
| | | | 4 | | | | | | | — | — |
| | ZAS125-SF | ZS50-SF, ZS125-SF, ZS100-SM | 3 | Pan head M4×61 | 2 | Pan head M4×61 | 2 | — | — | — | — |
| | ZAS50-GF, ZAS100-GF, ZAS125-GF | ZS100-GF, ZS125-GF | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | — | — |
| | | | 4 | Pan head M4×55 | 4 | Pan head M4×55 | 4 | — | — | — | — |
| | ZAS250-SF | ZS250-SF | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | — | — |
| | ZAS225-GF, ZAS250-GF | ZS225-GF, ZS250-GF | 3 | Pan head M4×55 | 2 | Pan head M4×55 | 2 | — | — | — | — |
| | | | 4 | Pan head M4×55 | 4 | Pan head M4×55 | 4 | — | — | — | — |
| | ZAS400-NF/GF | ZS400-NF/GF | 3,4 | Pan head M6×100 | 4 | Pan head M6×100 | 4 | — | — | — | — |
| | ZAS630-CF/NF, ZAS800-CF/NF | ZS630-CF/NF, ZS800-CF/NF | 3,4 | Pan head M8×45 | 4 | Pan head M8×45 | 4 | — | — | — | — |
| PH, H, L | H225-NE, H250-NF, L250-NF | | 3 | Pan head M4×90 | 2 | Pan head M4×90 | 2 | — | — | — | — |
| | | | 4 | Pan head M4×90 | 4 | Pan head M4×90 | 4 | — | — | — | — |
| | H100-NF, H125-NF, H225-NF, L100-NF, L125-NF, L225-NF | | 3 | Pan head M4×90 | 2 | Pan head M4×90 | 2 | Pan head M4×115 | 4 | Pan head M4×100 | 4 |
| | | | 4 | Pan head M4×90 | 4 | Pan head M4×90 | 4 | Pan head M4×115 | 4 | Pan head M4×100 | 4 |
| | PH400-CF/CE | | 3 | Pan head M6×100 | 4 | Pan head M6×100 | 4 | Pan head M6×120 | 4 | Pan head M6×100 | 4 |
| | | | 4 | | | | | | | — | — |
| | H400-NE, L400-NE | | 3 | Pan head M6×140 | 4 | Pan head M6×140 | 4 | Pan head M6×160 | 4 | Pan head M6×140 | 4 |
| | | | 4 | | | | | | | — | — |
| | PH630-CF/CE | | 3 | Pan head M6×100 | 4 | Pan head M6×100 | 4 | Pan head M6×120 | 4 | Pan head M6×100 | 4 |
| | | | 4 | | | | | | | — | — |
| | H630-NE, L630-NE, H800-NE, L800-NE | | 3 | Pan head M8×85 | 4 | Pan head M8×85 | 4 | Pan head M8×85 | 4 | Cap nut ＊ | 4 |
| | | | 4 | | | | | | | — | — |
| NE, ZNE, NS, ZNS | NS125-SF | ZNS125-SF | 3 | Pan head M4×61 | 2 | — | — | — | — | — | — |
| | NE250-SF, NS250-SF | ZNE250-SF, ZNS250-SF | 3 | Pan head M4×55 | 2 | — | — | — | — | — | — |
| | NE400-NF, NS400-NF | ZNE400-NF, ZNS400-NF | 3 | Pan head M6×100 | 4 | — | — | — | — | — | — |
| | NS630-NF, NS800-NF | | 3 | Pan head M8×45 | 4 | — | — | — | — | — | — |
| XS | XS2000NE/NN | | 3,4 | Hex socket head M10×160 | 4 | Hex socket head M10×120 | 4 | — | — | — | — |
| | XS2500NE/NN, XS3200NE/NN | | 3,4 | — | — | Hex socket head M10×120 | 4 | — | — | — | — |
| TL | TL-1000NE, TL-1200NE | | 3,4 | Pan head M8×50 | 4 | Pan head M8×50 | 4 | — | — | Cap nut ＊ | 4 |
| TZ | | TZ30EC, TZ50EE | 2,3 | Pan head M4×35 | 2 | — | — | — | — | — | — |
| | | TZ100EC | 3 | Pan head M4×58 | 2 | — | — | — | — | — | — |

＊ Width across flats of hex socket: 8mm (M10), thread size: M8

## 6 Effect of mounting angle

The overcurrent tripping characteristics of electronic and thermal-magnetic moulded case circuit breakers are not affected by mounting angle. However, please note that the overcurrent tripping characteristics of hydraulic-magnetic type moulded case circuit breakers will change depending on the mounting angle due to the effect of gravity on the iron core inside the oil dashpot.
Generally, it is recommended to use hydraulic-magnetic type moulded case circuit breakers in a vertical orientation.





Fig. 1. Rate of change of rated current value depending on mounting angle (example)

● Hydraulic-magnetic type

| Frame size (A) | Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | Fig |
|---|---|---|---|
| 30 | **E30-NM, S30-NM** | **ZE30-NM, ZS30-NM** | 1 |
| | **PE30-NF (3 – 10A), PS30-NF (3 – 10A)** | **PZE30-NF (5 – 10A), PZS30-NF (5 – 10A)** | 3 |
| 50 | **E50-NM, S50-NM** | **ZE50-NM, ZS50-CM** | 1 |
| 100 | **E100-NM** | **ZE100-NM** | 1 |





Fig. 3. Rate of change of rated current value depending on mounting angle (example)

## 7 Close fitting mounting

1. The following models can be closely fitted even when internal accessories are mounted. (Except when auxiliary circuit terminals are used with the plug-in.)

| Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers |
|---|---|
| E30-NM, S30-NM, E50-NM,<br>PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF,<br>PE60-NF, PS60-NF, PE125-NF/NN,<br>S50-SF, S125-SF/SN, NS125-SF,<br>S100-GF, S125-GF,<br>PS50-PF, PS125-NF/NE/PF/PE/NN,<br>PS250-NE/PF/PE/NN,<br>H100-NF, H125-NF,<br>H225-NF, H225-NE, H250-NF,<br>L100-NF, L125-NF, L225-NF, L250-NF,<br>E250-SF, S250-SF, S250-SM/SN, NE250-SF, NS250-SF,<br>ZAE250-SF, ZAS250-SF,<br>E400-NF, PS400-CF/NF/NE/GF/GE/NN,<br>PH400-CF/CE,<br>H400-NE, L400-NE,<br>NE400-NF, NS400-NF,<br>ZAE400-NF, ZAS400-NF/GF,<br>TB-5S/5P/5D/51C/52C,<br>TB50KSL, TB50KSZ, TB100KSZ | ZE30-NM, ZS30-NM, ZE50-NM,<br>TZ30EC, TZ50EE, TZ100EC,<br>PZE30-NF, PZS30-NF, PZE50-NF, PZS50-NF,<br>PZE60-NF, PZS60-NF, PZE125-NF,<br>ZS50-SF, ZS100-SM, ZS125-SF, ZNS125-SF,<br>ZS100-GF, ZS125-GF,<br>ZS225-GF, ZS250-GF,<br>ZE250-SF, ZS250-SF/SM,<br>ZNE250-SF, ZNS250-SF,<br>ZE400-NF, ZS400-NF/GF,<br>ZNE400-NF, ZNS400-NF,<br>TZ-51C, TZ-52C |

2. When internal accessories are mounted to the following models, those cannot be closely fitted because the lead wires can not be pulled out to the load side.

| Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers |
|---|---|
| S50-NM, E100-NM,<br>PE50-NFZ, PS50-NFZ, PE125-NFZ,<br>PE50-NFN, PE125-NFN,<br>ZAS50-GF, ZAS100-GF, ZAS125-GF,<br>ZAS125-SF, ZAS225-GF, ZAS250-GF,<br>S630-CF/NF/NE/GN,<br>NS630-NF, NS800-NF,<br>ZAS630-CF/NF, ZAS800-CF/NF,<br>H630-NE, L630-NE, H800-NE, L800-NE,<br>S800-CF/NF/NE/RF/RE/PF/PE/NN,<br>S1000-CE/NN | ZS50-CM, ZE100-NM,<br>PZE50-NFN, PZE125-NFN,<br>ZS630-CF/NF,<br>ZS800-CF/NF |

3. When closely fitting the following models, please use them at 80% or less of the rated current capacity.


| Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers |
|---|---|
| E30-NM, S30-NM, E50-NM, S50-NM,<br>E100-NM | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM,<br>ZE100-NM |

Note ①: In the case of front-connected configuration, please also mount an interpole barrier between the breakers.
Note ②: In the case of rear-connected configuration, if the short studs are located next to each other, the insulation distance will be insufficient, so use taping or similar after connection.

# 8 Reverse connection

1. The breakers are available for normal connection by default. Reverse connection is optionally allowed. See the tables below.

| Series | Breaker | 240V AC | 415V AC | 440V AC | 500V AC | 690V AC |
|---|---|---|---|---|---|---|
| Motor protection series | **E30-NM** | ○ (2.5kA/2kA)① | × | × | × | × |
| | **S50-NM, E100-NM** | ○ (5kA/5kA)① | ○ (2.5kA/2.5kA) | ○ (2.5kA/2.5kA) | × | × |
| | **S30-NM, E50-NM, S250-SM** | ◎ | ◎ | ◎ | × | × |
| Moulded Case Circuit Breakers | **E250-SF** | ◎ | ◎ | ◎ | ◎ | × |
| | **H100-NF, H125-NF, H225-NF, H225-NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF** | ◎ | ◎ | ◎ | ◎ | × |
| | **PE30-NF** | ◎② | ◎② | ◎② | × | × |
| | **PS30-NF** | ◎② | ◎② | ◎② | ◎② | × |
| | **PE50-NF, PE60-NF, PE125-NF, PS50-NF, PS60-NF, E400-NF** | ◎ | ◎ | ◎ | ◎ | × |
| | **PS50-PF, PS125-NF/NE/PF/PE** | ◎ | ◎ | ◎ | ◎ | ◎ |
| | **PS250-NE/PF/PE** | ◎ | ◎ | ◎ | ◎ | ◎ |
| | **S50-SF, S125-SF, S100-GF, S125-GF, S250-SF, S630-CF/NF/NE, S800-CF/NF/NE/RF/RE/PF/PE, S1000-CE, S1250-NE/GE, S1600-NE, H400-NE, L400-NE, H630-NE, L630-NE, H800-NE, L800-NE, TL-1000NE, TL-1200NE, XS2000NE, XS2500NE, XS3200NE** | ◎ | ◎ | ◎ | ◎ | ◎ |
| | **PS400-CF/NF/NE/GF/GE, PS630-CF/NF/NE/GF/GE** ④ | ◎ | ◎ | ◎ | ◎ | ◎ |
| | **PH400-CF/CE, PH630-CF/CE** ④ | ◎ | ◎ | ◎ | ◎ | ◎ |
| | **L125-PF, L400-PE, L800-PE** | × | × | × | × | × |
| Switch-disconnectors / Non-automatic trip breakers | **PE30-NN** | ◎ | ◎ | × | × | × |
| | **PE50-NN, PE125-NN** | ◎ | ◎ | ◎ | ◎ | × |
| | **S125-SN, PS125-NN, S250-SN, PS250-NN, PS400-NN, PS630-NN, S630-GN, S800-NN, S1000-NN, S1250-NN, S1600-NN, XS2000NN, XS2500NN, XS3200NN** | ◎ | ◎ | ◎ | ◎ | ◎ |
| Circuit Breakers with Earth Leakage Alarm | **ZAS125-SF** | ◎ | × | × | × | × |
| | **PE50-NFZ, PS50-NFZ, PE125-NFZ** | × | × | × | × | × |
| | **ZAS50-GF, ZAS100-GF, ZAS125-GF, ZAE250-SF, ZAS250-SF, ZAS225-GF, ZAS250-GF, ZAE400-NF, ZAS400-NF/GF, ZAS630-CF/NF, ZAS800-CF/NF** | ◎ | ◎ | ◎ | × | × |
| Circuit Breakers with Earth Leakage Alarm for Distribution Boards and Control Boards | **TB50KSL, TB50KSZ, TB100KSZ** | × | × | × | × | × |
| Earth Leakage Circuit Breakers | **ZE250-SF, ZS250-SF** | ◎ | ◎ | ◎ | × | × |
| | **PZE30-NF, PZE50-NF, PZE60-NF, PZE125-NF, PZS30-NF, PZS50-NF, PZS60-NF** | × | × | × | × | × |
| | **ZS50-SF, ZS125-SF** | ◎ | ◎② | ◎② | × | × |
| | **ZS100-GF, ZS125-GF, ZS225-GF, ZS250-GF** | ◎ | × | × | × | × |
| | **ZE400-NF, ZS400-NF, ZS400-GF ZS630-CF/NF, ZS800-CF/NF** | ◎ | △ | △ | × | × |
| Earth Leakage Circuit Breakers for Motor Protection | **ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM** | × | × | × | × | × |
| | **ZS100-SM** | ◎ | ◎② | ◎② | × | × |
| | **ZS250-SM** | ◎ | ◎ | ◎ | × | × |
| Earth Leakage Circuit Breakers for Distribution Boards and Control Boards | **TZ30EC, TZ50EE, TZ100EC** | ◎ | × | × | × | × |
| TB for Distribution Boards and Control Boards | **TB-5S/5P/5D** | ◎ | ◎ | × | × | × |




Normal connection　　Reverse connection

Note ③ : Please mount an interpole barrier on the | (ON) side whether the connection is normal connection or reverse connection.
(Except the model with Note ④)

◎ : Standard.
○ : A standard product can be applied, but the breaking capacity will be lower ($I_{CU}$/$I_{CS}$)
△ : Custom-built product. The rated operational voltage is 415V AC to 440V AC common.
× : Not available.

Note ① : This is the value for 230V AC.
Note ② : The applicable specifications are as follows.
- **PE30-NF** 2P 3P 15A, 20A, 30A
- **PS30-NF** 2P 3P 15A, 20A, 30A
- **ZS50-SF** 3P 40A, 50A
- **ZS125-SF** 3P 40A, 50A, 60A, 75A, 100A, 125A
- **ZS100-SM** 3P 40A, 45A, 60A, 75A, 90A, 100A

Note ④ : In case of normal connection, please mount an interpole barrier on | (ON) side.
In case of reverse connection, please mount an interpole barrier on O (OFF) side.

## 8 Reverse connection

2. The table below shows the applicability of single phase 3-wire circuit breakers with neutral phase open protection to "system interconnection with reverse power flow".

| Series | Breaker | 100/200V AC |
|---|---|---|
| Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm | **NAE125-SF, NAS125-SF, NAE250-SF, NAS250-SF, NAE400-NF, NAS400-NF** | ◎ |
| Single phase 3-wire circuit breakers with neutral phase open protection | **PE50-NFN, PE125-NFN** | × |
| | **NS125-SF, NE250-SF, NS250-SF, NE400-NF, NS400-NF, NS630-NF, NS800-NF** | ◎ |
| Single phase 3-wire earth leakage circuit breakers with neutral phase open protection | **PZE50-NFN, PZE125-NFN** | × |
| | **ZNS125-SF, ZNE250-SF, ZNS250-SF** ③ | ◎ |
| | **ZNE400-NF, ZNS400-NF** | ◎ |

◎: Standard.
×: Not available.
Note ③: Can also be applied to circuits where overcurrent flows to the neutral wire. Can be used as a main circuit breaker for photovoltaic power generation systems.
For details see page 3-32.

# 6 Accessories


1 OCR for electronic breakers ····· 6-2
1 . TPOT type, TPOP type electronic OCR ····· 6-2
2 . XOU type electronic OCR ····· 6-6
3 . XOS type electronic OCR ····· 6-10
2 Internally mounted accessories ····· 6-14
1 . Overview ····· 6-14
2 . Connection diagrams and terminal numbers ····· 6-15
3 . Possible combinations ····· 6-16
4 . Ratings and operation data of auxiliary and alarm switches ··· 6-22
5 . Shunt trip device (SH) ····· 6-23
6 . Undervoltage trip device (UV) ····· 6-24
7 . Shunt Trip for Circuit Breaker with Earth Leakage Alarm (SH) ····· 6-27
8 . Circuit Breaker with Earth Leakage Alarm Option ····· 6-27
9 . Remote reset voltage at both ends and current at closed path ··· 6-28
10. Test lead voltage at both ends and current at closed path ··· 6-28
3 Externally mounted accessories ····· 6-29
1 . Overview ····· 6-29
2 . Toggle extension (HA) ····· 6-30
3 . Motor operators (MC) ····· 6-31
4 . External operating handles ····· 6-36
• Breaker-mounted (HB) ····· 6-36
• Door-mounted (HP) ····· 6-51
5 . Mechanical interlock ····· 6-63
• Slide interlock (MS) ····· 6-63
• Rear-connected interlock (MB) ····· 6-90
• Link interlock (ML) ····· 6-91
• Wire interlock (MW) ····· 6-102
6 . Toggle holder (HH) and toggle lock (HL) ····· 6-117
7 . Terminal covers CF/CR/CS ····· 6-119
8 . Interpole barriers (BA) ····· 6-124
9 . Terminal blocks (TF) ····· 6-125
10. Flush-mounted (flush plate) auxiliary circuit terminal block (TB) ··· 6-137
11. Plug-in auxiliary circuit terminal block ····· 6-147
12. DIN rail adapter ····· 6-152
13. Door Flange (DF) ····· 6-153

# 1. TPOT type, TPOP type electronic OCR

## (1) Overcurrent trip characteristics

### ■ TPOT type, TPOP type OCR applicable model


| Type of breaker | Rated Current ($I_n$) (A) |
|---|---|
| **PS125-NE, PS125-PE** | 100, 125 |
| **PS250-NE, PS250-PE** | 250 |
| **PS400-NE, PS400-GE, PH400-CE** | 250, 400 |
| **PS630-NE, PS630-GE, PH630-CE** | 630 |

The TPOT electronic OCR is an overcurrent trip device with three elements: long time-delay trip, short time-delay trip, and instantaneous trip. It also has a preferential trip alarm function.
There are six dials to set the long time-delay trip time, short time-delay current, short time-delay time and instantaneous trip current. Two dials are assigned to allow the long time-delay trip current to be finely tuned. (125 A has one dial.)

The TPOP electronic OCR is an OCR with long time-delay trip, short time-delay trip, instantaneous trip, ground fault trip, and a preferential trip alarm function. And in the case of 4-pole products, N-phase protection feature is also provided.
It is set with seven dials, with one additional dial for ground fault trip ON/OFF. (125 A has six dials.) In the case of 4-pole products, the same dial is used for neutral protection pick-up current selection and ground fault trip ON/OFF.

In addition, since TPOT type electronic OCRs and TPOP type electronic OCRs use an r.m.s. value control method, the effects of harmonics do not cause any malfunction.

### ■ TPOP type electronic OCR for PS400-NE 3P




① A terminal for connecting the OCR checker.
② The rated current settigs is set with two dials: current value and magnification.
③ This is the long time-delay time settings dial.
④ This is the short time-delay pickup current dial.
⑤ This is the short time-delay time settings dial.
⑥ This is the instantaneous trip pick-up current dial.
⑦ This is the ground fault trip function ON/OFF dial.
⑧ Temperature LED
Lights red when the OCR ambient temperature reaches a high temperature of 105°C or higher.
⑨ Alarm LED
Lights red during long time-delay pickup.
During energisation at 105% × $I_r$ to 112.5% × $I_r$: Flashing
During energisation at 112.5% × $I_r$ or more: Lights
⑩ PTA LED
The preferential trip alarm flashes orange during pickup and lights when it is output.
⑪ Status LED
Lights green when the OCR is operating normally. Flashes orange if there is an error.

## ■Types of TPOT and TPOP types overcurrent trip devices (OCR)

| Rated Current $I_n$ (A) | Number of poles | OCR type | Protection code | Setting method | Protective functions | | | Alarm function |
|---|---|---|---|---|---|---|---|---|
| | | | | | Long time, Short time, Instantaneous | Ground fault | Neutral protection | Preferential trip alarm |
| | | | | | L, S, I | GF | NP | PTA ② |
| 100<br>125 | 3 ① | TPOT | LSI | Six dial type ③ | ● | — | — | ● |
| | | TPOP | LSIG | Seven dial type ③ | ● | ● | — | ● |
| | 4 | TPOT | LSI | Six dial type ③ | ● | — | — | ● |
| 250<br>400<br>630 | 3 ① | TPOT | LSI | Six dial type | ● | — | — | ● |
| | | TPOP | LSIG | Seven dial type | ● | ● | — | ● |
| | 4 | TPOT | LSI | Six dial type | ● | — | — | ● |
| | | TPOP | LSIG | Seven dial type | ● | ● | ● | ● |

● : Supplied as standard — : "no" or "not available".

Note ①: 3-phase 4-wire systems cannot be used.

Note ②: Output contact is possible by connecting an optional cable (order type TPPHQTT130H).

Note ③: For 125A, there is no dial for $I_r1$, so the number of dials is reduced by one.

## ■OCR characteristics for PS400-NE

TPOP type OCR (LSIG) ($I_n$)=250A, 400A

| | |
|---|---|
| Rated current settings (A)<br>($I_r$) = ($I_r1$)×($I_r2$) ③ | When ($I_n$)=250 A<br>($I_r1$) (A)=125, 150, 175, 200, 225, <u>250</u> adjustable<br>When ($I_n$)=400A<br>($I_r1$) (A)=175, 200, 225, 250, 300, 350, <u>400</u> adjustable |
| | ($I_r2$)=0.91, 0.92, 0.93, 0.94, 0.95, 0.96, 0.97, 0.98, 0.99, <u>1.00</u> |
| Long time-delay time settings (s) : ($t_r$) | 0.5, 1.5, 2.5, <u>5</u>, 7.5, 9, 10, 12, 14, 16 adjustable at ($I_r$)×600% |
| | Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, <u>10</u> or OFF |
| | Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | 50, <u>100</u>, 200, 300, 400 adjustable |
| | Ramp characteristics $I^2t$: ON or <u>OFF</u><br>However, definite time-delay characteristics with ($I_r$)×10 or more |
| | When ($t_{sd}$) = 50ms<br>Time-delay setting tolerance –30 ms or more +30 ms or less<br>When ($t_{sd}$) = 100 ms to 400ms<br>Time-delay setting tolerance –20ms or more +50ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | ($I_n$)×3, 4, 5, 6, 7, 8, 10, 11, <u>12</u> adjustable |
| | Current setting tolerance within ±15% |
| Neutral protection pick-up current (A) : ($I_N$) | For 3P OFF fixed ④ |
| | For 4P ($I_r$)×50%, <u>100%</u> or OFF ⑤ |
| Neutral protection time settings (s) : ($t_N$) | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip ⑥ |
| Ground fault trip pick-up current (A) : ($I_g$) | Settings for 3P 3ø3W and 4P 3ø4W (3P 3ø4W not supported) or OFF ⑦<br>($I_n$)×20%<br>Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | 200<br>Time-delay setting tolerance –20ms or more +50ms or less ⑧ |
| Preferential trip alarm pick-up current (A) : ($I_p$) | ($I_r$)×80%<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | ($t_r$)×50%<br>at ($I_P$)×600%<br>Time-delay setting tolerance –20% –20ms or more +0% +30 ms or less |

**Notes:**

③: The rated current settings ($I_r$) can be set by two dials, the current value ($I_r1$) and the magnification ($I_r2$). Trip operation is performed with a pick-up current value exceeding ($I_r$) × 1.05 and 1.2 or less.

④: There is no N-phase protection function for 3P.

⑤: N-phase protection is adjustable to 50% or 100% of the rated current setting ($I_r$). It is also possible to turn off the protection function. The N-phase protection setting dial also serves as the ON/OFF switch for ground fault trip. Trip operation is performed with a pick-up current value exceeding ($I_N$) × 1.05 and 1.2 or less.

⑥: There is no N-phase time setting dial. The ON/OFF of the ramp characteristics conforms to the short time-delay trip settings.

⑦: In the case of 4P, the ON/OFF switch for ground fault trip is shared with the dial for N-phase protection pick-up current.


⑧: The ON/OFF of the ground fault trip ramp characteristics conforms to the short time-delay trip settings. However, ($I_n$) × 1 or more with definite time-delay characteristics.

Remarks 1:
If not otherwise specified, the product will be delivered with the underlined standard setting values.


Remarks 2:
The TPOT type OCR (LSI) only has long time-delay trip, short time-delay trip, instantaneous trip, and preferential trip alarm.

## ■ TPOT type, TPOP type OCR operation characteristic curves


### Long time-delay trip, short time-delay trip characteristics





### Instantaneous trip characteristics




### N-phase protection, preferential trip alarm characteristics




### Ground fault trip characteristics



## (2) Alarm function/protective function

### ■ Preferential trip alarm (PTA)


The load current is constantly monitored and if it exceeds the preferential trip alarm pick-up current $I_p$ (= rated current setting ($I_r$) × 80%), the LED flashes and then the LED lights up and the contacts close at the operating times shown in the table below. If the load current becomes equal to or less than $I_p$, the LED turns off and the contacts open. Control power supply to the PTA is not required.

| Long time-delay time setting $t_r$ (s) | | 0.5 | 1.5 | 2.5 | 5.0 | 7.5 | 9.0 | 10 | 12 | 14 | 16 |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Estimated PTA operating time $t_p$ (s) | For $I_p$ × 200% | 2.6 | 7.7 | 13 | 26 | 38 | 46 | 51 | 61 | 71 | 82 |
| | For $I_p$ × 600% | 0.3 | 0.8 | 1.3 | 2.5 | 3.8 | 4.5 | 5.0 | 6.0 | 7.0 | 8.0 |
| | For $I_p$ × 720% | 0.2 | 0.5 | 0.9 | 1.7 | 2.6 | 3.1 | 3.5 | 4.2 | 4.8 | 5.5 |

## Contact rating

| | |
|---|---|
| Output contact | Non-contact output 1a |
| | Contact capacity 24V AC/DC 100mA |

By connecting the optional cable (order type TPPHQTT130H) to the PTA port, an alarm can be output using contact output (1a).




### ■ Ground fault trip (GF)

Protects equipment against fires caused by arc-ground fault currents. The ground fault trip current is set to 20% for rated current ($I_n$) of 100, 125, 250, 400 and 630 A and 40% for rated current ($I_n$) of 40 A.
Note: A 3-pole circuit breaker cannot be used with a 3-phase 4-wire system.

### ■ N-phase protection (NP)

A 4-pole circuit breaker can be used. This function protects against neutral wire overcurrent in a 3-phase 4-wire circuit. The N-phase protection pick-up current ($I_N$) can be switched to 100% or 50% of the rated current setting ($I_r$). It is also possible to turn off the N-phase protection function.


### ■ TTP00 type OCR checker

You can use the OCR checker to easily check the long time-delay, short time-delay, instantaneous trip, ground fault trip, and preferential trip alarm functions in the field. For details, see page 9-6.

# 2. XOU type electronic OCR

## (1) Overcurrent trip characteristics

### ■ XOU type electronic OCR for H400-NE




### ■ XOU type OCR Specifications

| CT rated current ($I_{CT}$) | poles | Protection code | Long time-delay, Short time-delay, Instantaneous | Preferential trip alarm (PTA) | Ground fault trip (GF) | Neutral protection (NP) |
|---|---|---|---|---|---|---|
| | | | A | P | G | N |
| 250 | 3 | A | ● | — | — | — |
| | 3 | AP | ● | ● | — | — |
| | 4 | A | ● | — | — | — |
| | 4 | AP | ● | ● | — | — |
| | 4 | AN | ● | — | — | ● |
| | 4 | APN | ● | ● | — | ● |
| 400<br>630<br>800<br>1000<br>1250<br>1600 | 3 | A | ● | — | — | — |
| | 3 | AP | ● | ● | — | — |
| | 3 | AG | ● | — | ● | — |
| | 3 | APG | ● | ● | ● | — |
| | 4 | A | ● | — | — | — |
| | 4 | AP | ● | ● | — | — |
| | 4 | AN | ● | — | — | ● |
| | 4 | APN | ● | ● | — | ● |
| | 4 | AGN | ● | — | ● | ● |
| | 4 | APGN | ● | ● | ● | ● |

### ■ OCR characteristics for H400-NE

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 250A<br>125, 150, 175, 200, 225 | | | | | | |
| | | CT rated current : ($I_{CT}$) = 400A<br>175, 200, 225, 250, 300, 350, 400 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max. ($I_{CT}$) × 1300%<br>Setting tolerance ±20% | | | | | | |
| Option | Preferential trip alarm | | | | | | | |
| | Pick-up current (A) : ($I_p$) | ($I_r$)×80% Setting tolerance±10% | | | | | | |
| | Time-settings (s) : ($t_p$) | Definite time-delay characteristic, 40sec. Setting tolerance±10% | | | | | | |
| | Ground falut trip | | | | | | | |
| | Pick-up current (A) : ($I_g$) | ($I_{CT}$)×20% Setting tolerance±15% ① | | | | | | |
| | Time-settings (s) : ($t_g$) | Difinite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| | Neutral protection | | | | | | | |
| | Pick-up current (A) : ($I_N$) | ($I_r$)×100% or 50% selectable ② | | | | | | |
| | Time-settings (s) : ($t_N$) | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

**Notes:**
①: Ground fault trip is not available when ($I_{CT}$) is 250A.
②: In case of ($I_R$)<($I_{CT}$), the setting tolerance becomes big when ($I_N$) is set at ($I_R$)×50%.
Remarks: Characteristic No.4 will be applied as standard setting unless otherwise specified.

### ■ XOU type OCR Applicable breakers

| Frame size (A) | Type of breaker |
|---|---|
| 225 | **H225-NE** |
| 400 | **H400-NE, L400-NE** |
| 630 | **S630-NE, H630-NE, L630-NE** |
| 800 | **S800-NE, S800-RE, S800-PE, H800-NE, L800-NE** |
| 1000 | **S1000-CE** |
| 1250 | **S1250-NE, S1250-GE** |
| 1600 | **S1600-NE** |

XOU type electronic OCRs allow you to select a wide range of protection characteristics simply by setting two dials located on the front of the breakers; one for selecting the rated current and the other for selecting a protection characteristic. They are equipped with five to seven protection characteristics as standard, providing optimum protective coordination between upstream circuit breakers and downstream circuit breakers and/or loads.

Characteristic 1: For generator protection

Characteristics 2, 3 and 4: For general feeder protection.

The possibility of selecting one from three options makes it easy to achieve selective coordination with upstream or downstream breakers.


Characteristics 5, 6 and 7: For motor protection.

The selection of the option best suited to motor startup characteristics provides an optimum protection solution to motors.

If you require a characteristic which is not available as a preset on our standard electronic protection unit, send us the details and we will program a customized characteristic to your specification.

Note: Characteristic is programmable within certain limits. Contact us for details.

### ■ XOU type OCR Time/Current characteristic curves



## (2) Optional OCR functions

### ■Preferential trip alarm (PTA)

The preferential trip alarm function causes the alarm LED to flash when the load current exceeds 80% of the rated current (IR) and, after 40 seconds, provides a contact output (1a). The contact output can be used to provide an alarm. The PTA function uses RMS sensing and hence does not suffer a malfunction due to harmonics. Control power and the OCR controller (supplied by Terasaki) are required to use this function.

Note ① : When the OCR controller is installed on the breaker, the breaker cannot be equipped with a terminal block for connection to the shunt trip device and undervoltage trip device.

#### ● Specifications of OCR controller

| | |
|---|---|
| Control voltage ② (Rated voltage) | 100 – 120V AC or 200 – 240V AC |
| Power consumption, VA | 2VA |

Note ② : The control voltage must be 85 to 110% of the rated voltage. Please state the rated voltage when ordering.


#### Contact rating

| | | | |
|---|---|---|---|
| Operating time (s) ($t_p$) | 40 secs (fixed definite time-delay) setting tolerance is ±10%. | | |
| Output contact | Contact output, (1a) lead wire standard. length (450mm) | | |
| | | Resistive load | Inductive load |
| | Rating of contact 250V AC | 125VA (2A max) | 20VA (2A max) |
| | Rating of contact 220V DC | 60W (2A max) | 10W (2A max) |
| Tripped indication ① | Pick-up LED flickers | | |

Note ①: The pick-up LED flickers at a higher current than [$I_P$]. When higher current flows continuously for 40 secs, the contact (1a) is output. PTA is automatically reset at a lower current than [$I_P$].

#### ● OCR controller connection diagram


**Applicable breakers: H225**





Note ③ : Separate installation of the OCR controller is not available. Flush-mounted type (FP) cannot be used.

**Applicable breakers: H400, L400, S630, H630, L630, S800, H800, L800, S1000, S1250, S1600**

OCR controller installed on the breaker




OCR controller installed external to the breaker





Note 4 : Standard installation of the OCR controller is on the right side of the breaker. Separate installation is standard for the flush-mounted breakers.

## (2) Optional OCR functions


- Mounting dimensions and terminal arrangement of the OCR controller installed on the breaker

Applicable breakers: H225




**Notes:** 1. Tightening torque of terminal screws M3.5: 0.9 – 1.2 Nm
2. Applicable wire size: 2.0 mm² max


| Applicable breakers | | A(mm) | B(mm) | C(mm) | D(mm) |
|---|---|---|---|---|---|
| H400, L400 | 3P、4P | 71 | 111 | 25.2 | 16.2 |
| S630, S800, S1000 | 3P、4P | 62.5 | 74 | 25.2 | 16.2 |
| H630, L630, H800, L800 | 3P、4P | 62.5 | 111 | 25.2 | 16.2 |
| S1250 | 3P | 33 | 72 | 21 | 12 |
| | 4P | 43 | 72 | 21 | 12 |
| S1600 | 3P | 33 | 92 | 21 | 12 |
| | 4P | 43 | 92 | 21 | 12 |




**Notes:** 1. Tightening torque of terminal screws M3.5: 0.9 – 1.2 Nm
2. Applicable wire size: 2.0 mm² max

- Outline of the OCR controller installed external to the breaker

Applicable breakers: H400, L400, S630, H630, L630, S800, H800, L800, S1000, S1250, S1600




## ■ Ground fault trip (GF)

The ground fault trip pickup current is 20% of the CT rated current ($I_{CT}$). The GF function provides protection against fire that may be caused by arcing ground fault current. The GF function is not available when $I_{CT}$ is 250A.

Note: Separate type neutral CT is required when the GF function is added to a 3-pole breaker used in a 3-phase, 4-wire system. Contact us for details.

## ■ N-phase protection (NP)

The NP function is available on 4-pole breakers and provides protection to the neural conductor in a 3-phase, 4-wire system against overcurrent The NP pick-up current ($I_N$) can be switched to 100% or 50% of the rated current setting ($I_r$). The NP protection function can also be turned off. However, in the case of H225, NP protection becomes ($I_r$) × 100% interlocking, and the protection function cannnot be turned off.

When ($I_r$) < ($I_{CT}$) , ($I_N$) = ($I_r$) × 50% setting will result in a large setting current error.


## ■ TNS-3 type OCR checker


You can use the OCR checker to easily check the OCR's long time-delay, short time-delay, instantaneous trip, ground fault trip and preferential trip alarm functions in the field. For details, see page 9-6.

## (3) How to change the tripping characteristics

The electronic breakers are designed so that their protective functions, i.e., long time delay trip, short time delay trip, instantaneous trip, ground fault trip and preferential trip alarm functions, can be adjusted depending on a change in load or layout of power distribution lines.

**Outer view**





| Item | Rated current | Long time delay trip, short time delay trip, instantaneous trip, ground fault trip, preferential trip alarm |
|---|---|---|
| Adjusting procedure | ● Turn the breaker to OFF position before changing the settings<br><br>1. Peel the sealing sticker off and remove the cover.<br>2. Rotate the "$I_r$(A)" dial to the desired position using a flatblade screwdriver.<br><br>3. Take an appropriate rated current sticker and a sealing sticker from the replacement sticker storage.<br>4. Peel the existing rated current sticker off and affix the replacement rated current sticker.<br>5. Reinstall the cover and affix the replacement sealing sticker. | ● Turn the breaker to OFF position before changing the settings.<br><br>1. Peel the sealing sticker off and remove the cover.<br>2. Rotate the "Characteristics" dial to the desired position using a flatblade screwdriver.<br>3. Take a sealing sticker from the replacement sticker storage.<br>4. Reinstall the cover and affix the replacement sealing sticker. |

# 3. XOS type electronic OCR

## (1) Overcurrent trip characteristics

### ■ XOS type electronic OCR for XS2500NE




### ■ XOS type OCR Applicable breakers

| Frame size (A) | Type of breaker |
|---|---|
| 1000 | **TL-1000NE** |
| 1200 | **TL-1200NE** |
| 2000 | **XS2000NE** |
| 2500 | **XS2500NE** |
| 3200 | **XS3200NE** |


With XOS type electronic OCRs, the long time-delay trip, short time-delay trip, instantaneous trip, ground fault trip setting values can be independently changed.
You can set the ramp characteristics for short time-delay to facilitate selective coordination with downstream circuit breakers and fuses.
The ramp characteristics and the definite time-delay characteristics can be switched with the SHORT TIME $I^2t$ switch in the OCR unit.

### ■ OCR characteristics for XS2500NE

| | |
|---|---|
| CT rated current (A) : ($I_{CT}$) | 2500 |
| Rated current settings (A) : ($I_1$) | 1200, 1400, 1600, 2000, 2500 |
| Long time-delay time settings (S) : ($T_1$) | (5–10–15–20–30) at ($I_1$) × 600% current<br>Setting tolerance ±20% |
| Short time-delay pick-up current (A) : ($I_2$) | ($I_1$)×200、400、600、800、1000% adjustable<br>Setting tolerance ±15% |
| Short time-delay time settings (S) : ($T_2$) | Opening time (0.1, 0.15, 0.2, 0.25, 0.3) in the definite time-delay.<br>Total clearing time is +50ms and resettable time –20ms for the time-delay settings |
| Instantaneous trip pick-up current (A) : ($I_3$) | Continuously adjustable from ($I_{CT}$) × 300 to 1200%.<br>Setting tolerance ±20% |
| Pre-trip alarm pick-up current (A) : ($I_P$) (optional) | ($I_1$)×70、80、90、100% adjustable<br>Setting tolerance ±10% |
| Pre-trip alarm time setting (S) : ($T_P$) (optional) | 40 fixed definite time-delay.<br>Setting tolerance ±10% |
| Ground fault trip pick-up current (A) : ($I_G$) (optional) ㊸ | Continuously adjustable from ($I_{CT}$) ×10 to 40%<br>Setting tolerance ±15% |
| Ground fault trip-time setting (S) : ($T_G$) (optional) ㊸ | Opening time (0.1, 0.2, 0.3, 0.4, 0.8) in the definite time- delay.<br>Total clearing time is +50ms and resettable time –20ms for the time-delay settings |

**Remarks:** The underlined values will be applied as standard ratings unless otherwise specified when ordering.
**Note** ㊸: Cannot be used with the preferential trip alarm.

### ■ XOS type OCR Time/Current characteristic curves




## (2) Optional OCR functions

### ■Preferential trip alarm (PTA)

The preferential trip alarm function causes the alarm LED to flash when the load current exceeds the pre-set current value and, after 40 seconds, provides a contact output (1a). The contact output can be used to provide an alarm. The PTA function uses RMS sensing and hence does not suffer a malfunction due to harmonics. Control power and the OCR controller (supplied by Terasaki) are required to use this function.

#### ● PTA specifications

| | | | |
|---|---|---|---|
| PTA pick-up current ($I_P$)   | Adjustable steps of 70, 80, 90, 100% of the selected rated current [$I_1$]. Setting tolerance ±10% Note: The long time-delay trip does not operate 'first' when the pick-up current is adjusted to 100% of the rated current [$I_1$]. | | |
| Operating time (S)($T_P$) | 40 secs (fixed definite time-delay) setting tolerance is ±10%. | | |
| Output contact | Contact output, (1a) lead wire standard length (450mm) | | |
| | | Resistive load | Inductive load |
| | Rating of contact 250V AC | 125VA (2A max) | 20VA (2A max) |
| | Rating of contact 220V DC | 60W (2A max) | 10W (2A max) |
| Tripped indication ① | Pick-up LED flickers | | |

Note ①: The pick-up LED flickers at a higher current than [$I_P$]. When higher current flows continuously for 40 secs, the contact (1a) is output. PTA is automatically reset at a lower current than [$I_P$].

#### ● OCR controller (PTA and trip indication)


The OCR controller is installed in the left hand of the breaker (standard). This can also be installed externally to the breaker (please specify when ordering).

#### ● Specifications of OCR controller


| | |
|---|---|
| Power voltage ② (Rated voltage) | 100 – 120V AC or 200 – 240V AC |
| Power consumption, VA | 2VA |

Note ②: The control voltage must be 80 to 110% of the rated voltage. Please state the rated voltage when ordering.

#### ● OCR controller connection diagram




#### ● Mounting dimensions and terminal arrangement of the OCR controller installed on the breaker





Dimension table (mm)


| Type of MCCB | A | | B |
|---|---|---|---|
| | With UVT contoroller | Without UVT contoroller | |
| TL-1000NE TL-1200NE | 51 | 114 | 92 |
| XS2000NE XS2500NE XS3200NE | 54 | 180 | 115 |

Remarks 1): Standard torque for the terminal screws M3.5 ····· 0.9 – 1.2Nm
2): Applicable cable size ····· Max. 2.0mm²

#### ● PTA Characteristics




#### ● Outline of the OCR controller installed external to the breaker





## (2) Optional OCR functions

### ■ Ground fault trip (GF)


The ground fault trip pickup current is 10 to 40% of the CT rated current ($I_{CT}$).
The GF function provides protection against fire that may be caused by arcing ground fault current.
Note that a separate type neutral CT is required when the GF function is added to a 3-pole breaker used in a 3-phase, 4-wire system. Contact us for details.

● GF Specifications

| | |
|---|---|
| GF Pick-up current (A) ($I_G$)<br> | Continuously adjustable from 10 to 40% of the rated CT current [$I_{CT}$].<br>Setting tolerance ±15% |
| GF Time-delay (S) ($T_G$)<br> | The GFT has a definite time-delay characteristic and is adjustable in steps of 0.1, 0.2, 0.3, 0.4 and 0.8s.<br>Total clearing time is +50ms and resettable time is –20ms for the pre-set timedelay. |

Note: See Chapter 7, "Characteristics and Outline Dimensions" for CT rated currents ($I_{CT}$).


● GF characteristics




### ■ Trip indicators

The LEDS, when lit, indicate which trip function tripped the breaker; Long time-delay (LTD), short time-delay/instantaneous (ST/INST) or ground fault (GF). (control power required)
If a pre-trip alarm (PTA) is fitted, the LED control power can be used (common). See page 6-11 for PTA.
This is not applicable to high instantaneous trip breakers (See page 4-4).

Trip indicator display




Example XS2500NE


## ■ TNS-3 type OCR checker


You can use the OCR checker to easily check the OCR's long time-delay, short time-delay, instantaneous trip, ground fault trip, and preferential trip alarm functions in the field. For details, see page 9-6.

## (3) How to change the tripping characteristics

The electronic breakers are designed so that their protective functions, i.e., long time delay trip, short time delay trip, instantaneous trip, ground fault trip and preferential trip alarm functions, can be adjusted depending on a change in load or layout of power distribution lines.

**Outer view**




| Item | Rated current | Long time delay trip, short time delay trip, instantaneous trip, ground fault trip, preferential trip alarm |
|---|---|---|
| Adjusting procedure | ● Turn OFF the breaker before changing the settings.<br><br>1. Peel the sealing sticker off, loosen the cover mounting screws and remove the cover.<br>2. Rotate the "RATED CUR. (A)" dial using a flatblade screwdriver so that the black dots to be aligned to the desired position.<br><br><br>(Ex.: XS2500NE)<br>3. Take an appropriate rated current sticker and a sealing sticker from the replacement sticker storage.<br>4. Peel the existing rated current sticker off and affix the replacement rated current sticker.<br>5. Reinstall the cover and affix the replacement sealing sticker. | ● Turn OFF the breaker before changing the settings.<br><br>1. Peel the sealing sticker off, loosen the cover mounting screws and remove the cover.<br>2. Rotate the each dial using a flatblade screwdriver so that the black dots to be aligned to the desired position. The instantaneous trip and ground fault trip pickup current can be continuously adjusted.<br>3. Take a sealing sticker from the replacement sticker storage.<br>4. Reinstall the cover and affix the replacement sealing sticker. |

# 1. Overview

The following internally mounted accessories are available. See the tables of possible combinations of internally mounted accessories on pages 6-16 for the number of accessories that can be installed per breaker and their locations.

**AL — Alarm switch**

Provides an electrical indication that the breaker is in a tripped state.

**AX — Auxiliary switch**

Provides an electrical indication that the breaker is in a ON or OFF state.


**SH — Shunt trip device**


Electrically trips the breaker open from a remote location.

**UV — Undervoltage trip device**

Trips the breaker open when the circuit voltage lowers. This device can also be used to trip the breaker open from a remote location.

Caution: Combined use of SH and UV is not available.




## Termination or ending of lead wires from accessories

There are three manners in which lead wires from accessories are ended or terminated, as shown below:

### Lead wires are open

- Standard lead wire ending manner for front-connected, rear-connected and flush-mounted breakers. Lead wires from accessories are derived vertically, thereby enabling close fitting mounting. Excludes some models. For details, see 5-22.
- **Lead wire specifications**

**TemBreak PRO Series for 100A to 1600A frames**

| Accessory | Grade | Size | Finished OD | Length | Colour |
|---|---|---|---|---|---|
| SH | Heat resistant | 0.5 mm² | 3 mm ø | 500 mm | Black |
| UV | | | 3 mm ø | 500 mm | Black |
| AX | | | 1.8 mm ø | 700 mm | Grey |
| AL | | | 1.8 mm ø | 700 mm | Black |

**Motor breakers for 30 A to 100 A frames, earth leakage circuit breakers for motor protection**
(E30-NM, S30-NM, E50-NM, S50-NM, E100-NM, ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM)

| Accessory | Grade | Size | Finished OD | Length | Colour |
|---|---|---|---|---|---|
| SH | Heat resistant | 0.34 mm² | 1.58 mm ø | 500 mm | Black |
| AX | | | 1.58 mm ø | 500 mm | Grey |
| AL | | | 1.58 mm ø | 500 mm | Black |

Note: UV undervoltage trip is only for the terminal block.

**X, TL series**
(XS2000NE/NN, XS2500NE/NN, XS3200NE/NN, TL-1000NE, TL-1200NE)


| Accessory | Grade | Size | Finished OD | Length | Colour |
|---|---|---|---|---|---|
| SH | Heat resistant | 0.5 mm² | 3 mm ø | 450 mm | Black |
| UV | | | 3 mm ø | 450 mm | Black |
| AX | | | 1.8 mm ø | 450 mm | Grey |
| AL | | | 1.8 mm ø | 450 mm | Black |

### Lead wires are terminated in a terminal block (TF)

- Optional lead wire termination manner for front-connected and rear-connected breakers.
- See page 6-125 to 6-136 for details on the lead wire terminal block.


### With flush-mounted auxiliary circuit terminal block (TB)

- Optional lead wire termination manner for flush-mounted breakers.
- See page 6-137 to 6-146 for the standard.
























### Lead wires are ended at auxiliary circuit (self-engaging) terminals

- Standard lead wire ending manner for plug-in breakers.
- See page 6-147 to 6-151 for the standard arrangement of auxiliary circuit terminals.














# 2. Connection diagrams and terminal numbers

| Accessory | Combination symbol | Connection diagrams and terminal numbers | Remarks |
|---|---|---|---|
| Shunt trip device (SH) |  | • With anti-burn switch   | See page 6-23 for applicable models. |
| |  | • With anti-burn switch   | See page 6-23 for applicable models. |
| |  Mounted on the side of the circuit breaker | • Without anti-burn switch   | See page 6-23 for applicable models. Shunt trips are continuous rating without anti-burn switches. |
| Undervoltage trip devic (UV) |  Mounted on the side of the circuit breaker |   | Undervoltage trip for the model other than below. |
| |  | For AC With UVT controller   Without UVT controller   For DC   | For X, TL type undervoltage trip. For AC UVT, a separate UVT controller is required for some models. See page 6-25. |
| Auxiliary switch (AX) |  |   | 1pc Aux. SW installed. |
| |  |   | 2pcs Aux. SW installed. |
| |  |   | 2pcs Aux. SW installed. The auxiliary switches are mounted on the left and right sides, so the lead wires pulled out from the left and right-hand sides. |
| |  |   | 4pcs Aux. SW installed. |
| |  |   | 6pcs Aux. SW installed. For X, TL type auxiliary switches. |
| Alarm switch (AL) |  |   | 1pc Alarm. SW installed. |
| |  |   | 2pcs Alarm. SW installed. For motor circuit breakers except for S250-SM and earth leakage circuit breakers for motor protection except for ZS100-SM and ZS250-SM. |
| |  |   | 2pcs Alarm. SW installed. Compatible with the model other than the above. |
| |  |   | For X and TL series. Alarm SW for X and TL series. |
| Test lead (TL) |  |   | Remotely electrically trip an earth leakage circuit breaker or a circuit breaker with single 3-phase neutral wire open phase protection. Do not apply an external voltage to the test lead wires because voltage is applied to them. Connect a switch that can switch the voltage and current listed on page 6-28 without any difficulty. Also, do not share the switch with other earth leakage circuit breaker test lead wires. |
| Megger test switch (MG) |  |   | It is linked to the main contact of the earth leakage circuit breaker and when the handle is turned OFF or tripped, the control circuit is automatically de-energized to allow for load-side interphase Megger measurement. |

# 3. Possible combinations

## Moulded Case Circuit Breakers























Economical series
Standard series
Current limiting series
Motor protection series
Switch disconnectors

| | | TemBreak2 | TemBreak PRO | | | | |
|---|---|---|---|---|---|---|---|
| Type | E | E30-NM, E50-NM, E100-NM | PE30-NF/NN, PE50-NF/NN, PE60-NF, PE125-NF/NN | PE30-NF/NN, PE50-NF/NN, PE60-NF, PE125-NF/NN | | | |
| | S | S30-NM, S50-NM | PS30-NF, PS50-NF, PS60-NF, S50-SF, S125-SF | PS30-NF, PS50-NF, PS60-NF, S50-SF, S125-SF/SN | PS50-PF, PS125-NF/PF | PS50-PF, PS125-NF/PF, PS125-NE/PE, PS125-NN | S100-GF, S125-GF | S100-GF, S125-GF |
| | H | | | | | | | H100-NF, H125-NF, H225-NF/NE, H250-NF |
| | L | | | | | | | L100-NF, L125-NF, L225-NF, L250-NF |
| Number of poles ① | | 3 ②④ | 2 | 3 ② | 2 | 3 ② | 2 | 3 |
| Combinations of accessories | AX |  |  |  |  |  |  |  |
| | AL |  |  |  |  |  |  |  |
| | SH |  |  |  |  |  |  |  |
| | UV |  |  |  |  |  |  |  |
| | AX<br>AL |  |  |  |  |  |  |  |
| | AX<br>SH |  | |  | |  | |  |
| | AX<br>UV |  | |  | |  | |  |
| | AL<br>SH |  | |  | |  | |  |
| | AL<br>UV |  | |  | |  | |  |
| | AX<br>AL<br>SH |  | |  | |  | |  |
| | AX<br>AL<br>UV |  | |  | |  | |  |

**Notes:**
①: For the four-pole type, see the column for the three-pole type.
②: For auxiliary switches or alarm switches, left-hand mounting has priority.
④: Undervoltage trip UVTs are mounted on the side of the circuit breaker. See page 6-24 for the outline dimensions.

## Moulded Case Circuit Breakers

Economical series
Standard series
Current limiting series
Motor protection series
Switch disconnectors








| | | TemBreak PRO | | | | | |
|---|---|---|---|---|---|---|---|
| Type | E | | E250-SF | E400-NF | | | |
| | S | PS250-PF/NN, PS250-NE/PE | S250-SF, S250-SM, S250-SN | | PS400-CF/NF/NE, PS400-GF/GE, PS400-NN, PS630-CF/NF/NE, PS630-GF/GE, PS630-NN | S630-CF/NF/NE, S630-GN, S800-CF/NF/NE, S800-RF/RE/PF/PE, S800-NN, S1000-CE/NN | S1250-NE/GE/NN, S1600-NE/NN |
| | H | | | H400-NE | PH400-CF/CE PH630-CF/CE | H630-NE, H800-NE | |
| | L | | | L400-NE | | L630-NE, L800-NE | |
| Number of poles ① | | 3 ② | 3 ② | 3 | 3 ② | 3 ② | 3 |
| Combinations of accessories | AX |  |  |  |  |  |  |
| | AL |  |  |  |  |  |  |
| | SH |  |  |  |  |  |  |
| | UV |  |  |  |  |  |  |
| | AX<br>AL |  |  |  |  |  |  |
| | AX<br>SH |  |  |  |  |  |  |
| | AX<br>UV |  |  |  |  |  |  |
| | AL<br>SH |  |  |  |  |  |  |
| | AL<br>UV |  |  |  |  |  |  |
| | AX<br>AL<br>SH |  |  |  |  |  |  |
| | AX<br>AL<br>UV |  |  |  |  |  |  |

**Notes:**
①: For the four-pole type, see the column for the three-pole type.
②: For auxiliary switches or alarm switches, left-hand mounting has priority.

# 3. Possible combinations




## Moulded Case Circuit Breakers

Standard series
Current limiting series
Motor protection series

| | | X, TL series | |
|---|---|---|---|
| Type | XS | | XS2000NE/NN, XS2500NE/NN, XS3200NE/NN |
| | TL | TL-1000NE, TL-1200NE | |
| | XM | | |
| Number of poles ① | | 3 ③ | 3 ③ |
| Combinations of accessories | AX |  |  |
| | AL |  |  |
| | SH |  |  |
| | UV |  |  |
| | AX AL |  |  |
| | AX SH |  |  |
| | AX UV |  |  |
| | AL SH |  |  |
| | AL UV |  |  |
| | AX AL SH |  |  |
| | AX AL UV |  |  |

## Moulded Case Circuit Breakers

















Circuit Breaker with earth leakage alarm
for distribution boards and control boards

| | | TB series | |
|---|---|---|---|
| Type | | TB50KSL | TB50KSZ, TB100KSZ ⑥ |
| Number of poles ① | | 2 | 3 |
| Combinations of accessories | AX |  |  |
| | AL |  |  |
| | SH | |  |
| | MG |  |  |
| | AX AL |  |  |
| | MG AL |  |  |

**Notes:**
①: For the four-pole type, see the column for the three-pole type.
③: A breaker with AC UVT is provided with an external UVT controller. See page 6-25.
⑥: Simultaneous mounting of AL–SH is possible as an option.

## Moulded Case Circuit Breakers

Circuit Breaker with earth leakage alarm

| | | TemBreak PRO | | | | | |
|---|---|---|---|---|---|---|---|
| Type | E | PE50-NFZ, PE125-NFZ | | | ZAE250-SF | ZAE400-NF | |
| | S | PS50-NFZ | ZAS125-SF | ZAS50-GF, ZAS100-GF, ZAS125-GF, ZAS225-GF, ZAS250-GF | ZAS250-SF | ZAS400-NF/GF | ZAS630-CF/NF, ZAS800-CF/NF |
| Number of poles ④ | | 3 | 3 | 3 | 3 | 3 | 3 |
| Combinations of accessories | AX |  |  |  |  |  |  |
| | AL |  |  |  |  |  |  |
| | SH | | ⑤ | ⑤ | ⑤ |  |  |
| | AX<br>AL |  |  |  |  |  |  |
| | AX<br>SH | | ⑤ | ⑤ | ⑤ |  |  |
| | AL<br>SH | | ⑤ | ⑤ | ⑤ |  |  |
| | AX<br>AL<br>SH | | ⑤ | ⑤ | ⑤ |  |  |
| | MG | |  |  |  |  |  |
| | MG<br>AX | |  |  |  |  |  |
| | MG<br>AL | |  |  |  |  |  |
| | MG<br>AX<br>AL | | |  |  |  |  |
| | MG<br>AX<br>AL<br>SH | | | | |  |  |
| | TL | |  |  |  |  |  |

**Notes:**

②: For auxiliary switches or alarm switches, left-hand mounting has priority.

④: For the four-pole type, see the column for the three-pole type.

⑤: Custom-built product. See page 6-27 for details.

*: SHT for **ZAE400, ZAS400, ZAS630** and **ZAS800** are factory installed.












# 3. Possible combinations

## Moulded Case Circuit Breakers

Single phase 3-wire circuit breaker with neutral phase open protection

## Earth Leakage Circuit Breakers

Economical series
Standard series
Earth Leakage Circuit Breakers for motor protection
Single phase 3-wire earth leakage circuit breaker with neutral phase open protection
Earth Leakage Circuit Breakers for distribution boards and control boards

| | | TemBreak PRO | | TemBreak 2 | | |
|---|---|---|---|---|---|---|
| Type | MCCB E | PE50-NFN, PE125-NFN | | | | |
| | ELCB E | PZE50-NFN, PZE125-NFN | PZE30-NF, PZE50-NF, PZE60-NF, PZE125-NF | ZE30-NM, ZE50-NM, ZE100-NM | TZ30EC, TZ50EE | TZ30EC, TZ50EE, TZ100EC |
| | ELCB S | | PZS30-NF, PZS50-NF, PZS60-NF | ZS30-NM, ZS50-CM | | |
| Number of poles | | 3 | 3 | 3 ②③④ | 2 | 3 |
| Combinations of accessories | AX |  |  |  |  |  |
| | AL |  |  |  |  |  |
| | SH ③ | | |  | | |
| | UV | | |  | | |
| | AX AL |  |  |  |  |  |
| | AX SH | | |  | | |
| | AX UV | | |  | | |
| | AL SH | | |  | | |
| | AL UV | | |  | | |
| | AX AL SH | | |  | | |
| | AX AL UV | | |  | | |
| | MG | | |  |  |  |
| | MG AX | | |  | | |
| | MG AL | | |  |  |  |
| | MG AX AL | | |  | | |
| | TL | | |  |  |  |
| | TL AX | | |  |  |  |
| | TL AL | | |  |  |  |
| | TL AX AL | | |  | |  |
| | LAL | | | | | |











**Notes:**
②: For auxiliary switches or alarm switches, left-hand mounting has priority.
③: SHTs are mounted on the side of the circuit breaker. See page 6-23 for the outline dimensions. For DC, comes with an anti-burn switch.
④: Undervoltage trip UVTs are mounted on the side of the circuit breaker. See page 6-24 for the outline dimensions.

## Moulded Case Circuit Breakers

Single phase 3-wire circuit breaker with neutral phase open protection

## Earth Leakage Circuit Breakers

Economical series
Standard series
Earth Leakage Circuit Breakers for motor protection
Single phase 3-wire earth leakage circuit breaker with neutral phase open protection

| | | TemBreak PRO | | | | |
|---|---|---|---|---|---|---|
| Type | MCCB **E** | | | **NE250-SF** | **NE400-NF** | |
| | ELCB **E** | | | **ZE250-SF, ZNE250-SF** | **ZE400-NF, ZNE400-NF** | |
| | MCCB **S** | **NS125-SF, NAE125-SF＊, NAS125-SF＊** | | **NS250-SF, NAE250-SF＊, NAS250-SF＊** | **NS400-NF, NAE400-NF＊, NAS400-NF＊** | **NS630-NF, NS800-NF** |
| | ELCB **S** | **ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF** | **ZS100-GF, ZS125-GF, ZS225-GF, ZS250-GF** | **ZS250-SF, ZS250-SM, ZNS250-SF** | **ZS400-NF/GF, ZNS400-NF** | **ZS630-CF/NF, ZS800-CF/NF** |
| Number of poles | | 3 | 3 | 3 | 3 | 3 |
| Combinations of accessories | **AX** |  |  |  |  |  |
| | **AL** |  |  |  |  |  |
| | **AX** / **AL** |  |  |  |  |  |
| | **MG** |  |  |  |  |  |
| | **MG** / **AX** |  |  |  |  |  |
| | **MG** / **AL** |  |  |  |  |  |
| | **MG** / **AX** / **AL** | |  |  |  |  |
| | **MG** / **TL** | |  | |  |  |
| | **MG** / **TL** / **AX** | |  | |  |  |
| | **MG** / **TL** / **AL** | |  | |  |  |
| | **MG** / **TL** / **AX** / **AL** | |  | |  |  |
| | **TL** |  |  |  |  |  |
| | **TL** / **AX** |  |  |  |  |  |
| | **TL** / **AL** |  |  |  |  |  |
| | **TL** / **AX** / **AL** |  |  |  |  |  |

＊: Test Lead (TL) is not applicable

# 4. Ratings and operation data of auxiliary and alarm switches


## (1) Ratings of AX and AL

- The applicable load of the switch shall be no larger than the rating and no smaller than the minimum load.

| Type of breaker | | Standard | | | | | | | For microload ① | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | | AC(V) | | | DC(V) | | | Minimum load | DC(V) | | Minimum load |
| Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | Voltage (V) | Current (A) Resistive load | Current (A) Inductive load | Voltage (V) | Current (A) Resistive load | Current (A) Inductive load | | Voltage (V) | Current (A) Resistive load | |
| **E30-NM, S30-NM, E50-NM, S50-NM, E100-NM** | **ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM** | 480 | — | — | 250 | 0.3 | 0.3 | DC5V 160mA DC30V 30mA | 30 | 0.1 | DC5V 1mA DC30V 1mA |
| | | 250 | 5 | 5 | 125 | 0.6 | 0.6 | | | | |
| | | 125 | 5 | 5 | 30 | 3 | 3 | | | | |
| **PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN, S50-SF, S125-SF, S125-SN, ZAS125-SF, NS125-SF, PS50-PF, PS125-NF/PF/NN, PS125-NE/PE, ZAS50-GF, ZAS100-GF, ZAS125-GF, E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF, NE250-SF, NS250-SF, PS250-PF/NN, PS250-NE/PE, S100-GF, S125-GF, H100-NF, H125-NF, H225-NF, H225-NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, ZAS225-GF, ZAS250-GF, E400-NF, PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, H400-NE, L400-NE, ZAE400-NF, ZAS400-NF/GF, NAE125-SF, NAS125-SF, NAE250-SF, NAS250-SF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF, NS630-NF, NS800-NF, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE, S630-CF/NF/NE/GN, ZAS630-CF/NF, H630-NE, L630-NE, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, H800-NE, L800-NE, ZAS800-CF/NF, S1000-CE/NN, S1250-NE/GE/NN, S1600-NE/NN** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN, ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF, ZS100-GF, ZS125-GF, ZE250-SF, ZS250-SF, ZS250-SM, ZNE250-SF, ZNS250-SF, ZS225-GF, ZS250-GF, ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF, ZS630-CF, ZS630-NF, ZS800-CF, ZS800-NF** | 480 | — | — | 250 | — | — | DC15V 100mA | 30 | 0.1 | DC5V 1mA |
| | | 250 | 3 | 2 | 125 | 0.4 | 0.05 | | | | |
| | | 125 | 3 | 2 | 30 | 3 | 2 | | | | |
| — | **TZ30EC, TZ50EE, TZ100EC** | 250 | 2 | 0.6 | 125 | 0.3 | 0.03 | DC5V 100mA DC24V 60mA | — | — | — |
| | | 125 | 3 | 2 | 30 | 2 | 1.5 | | | | |
| **XS2000NE/NN, XS2500NE/NN, XS3200NE/NN, TL-1000NE, TL-1200NE** | — | 480 | 3 | 2 | 250 | 0.3 | 0.3 | DC5V 160mA DC30V 26.7mA | 30 | 0.1 | DC5V 1mA DC30V 1mA |
| | | 250 | 5 | 5 | 125 | 0.6 | 0.6 | | | | |
| | | 125 | 5 | 5 | 30 | 5 | 4 | | | | |

Note: ① This is a custom-built product. When ordering for this product, specify that it is intended for microlead use.
Remarks: The inductive load means power factor of no smaller than 0.4 for AC and time constant of no larger than 7 ms for DC.

## (2) Operation of AX and AL


| Switch | Breaker status | "ON" | "OFF" | "TRIP" |
|---|---|---|---|---|
| Auxiliary switch (AX) status |  | 11/AXc — 14/AXa "Closed"<br>11/AXc — 12/AXb "Open" | 11/AXc — 14/AXa "Open"<br>11/AXc — 12/AXb "Closed" | 11/AXc — 14/AXa "Open"<br>11/AXc — 12/AXb "Closed" |
| Alarm switch (AL) status |  | 91/ALc — 94/ALa "Open"<br>91/ALc — 92/ALb "Closed" | 91/ALc — 94/ALa "Open"<br>91/ALc — 92/ALb "Closed" | 91/ALc — 94/ALa "Closed"<br>91/ALc — 92/ALb "Open" |

## (3) Circuit breakers with earth leakage alarm Rating of earth leakage alarm output contact


| Circuit breaker with earth leakage alarm type | Voltage | cosø =1 | cosø =0.4 L/R =0.007 | Switch |
|---|---|---|---|---|
| **PE50-NFZ, PS50-NFZ, PE125-NFZ, ZAS50-GF, ZAS125-SF, ZAS100-GF, ZAS125-GF, ZAE250-SF, ZAS250-SF, ZAS225-GF, ZAS250-GF, ZAE400-NF, ZAS400-NF/GF, ZAS630-CF/NF, ZAS800-CF/NF, NAE125-SF, NAS125-SF, NAE250-SF, NAS250-SF, NAE400-NF, NAS400-NF** | 125V AC | 3A | 2A |  |
| | 250V AC | 3A | 2A | |
| | 30V DC | 2A | 2A | |
| | 100V DC | 0.4A | 0.3A | |
| **TB50KSZ, TB100KSZ** | 125V AC | 3A | 2A |  |
| | 250V AC | 3A | 2A | |
| | 30V DC | 2A | 2A | |

# 5. Shunt trip device (SH)

## (1) Ratings of SHT

| Type of breaker | Peak exciting current, (A) | | | | | | | Connection diagrams and terminal numbers |
|---|---|---|---|---|---|---|---|---|
| Moulded Case Circuit Breakers | Rated voltage | AC (V) | | | DC (V) | | | |
| | | 100-120 | 200-240 | 380-450 | 24 | 48 | 100-120 | 200-240 | |
| **E30-NM, S30-NM, E50-NM, S50-NM, E100-NM** | | 1.5 | 0.75 | 0.53 | — | — | 1.5 ① | — |  With anti-burn switch |
| **PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN, S50-SF, S125-SF, S125-SN, PS50-PF, PS125-NF/PF/NN, PS125-NE/PE, E250-SF, S250-SF, S250-SM/SN, PS250-PF/NN, PS250-NE/PE, PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE S630-CF/NF/NE/GN, H630-NE, L630-NE, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, H800-NE, L800-NE, S1000-CE/NN, S1250-NE/GE/NN, S1600-NE/NN ZAS630-CF/NF, ZAS800-CF/NF** | | 0.016 | 0.016 | 0.0062 | 0.124 | 0.032 | 0.014 | 0.012 |  Without anti-burn switch |
| **S100-GF, S125-GF, H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, E400-NF, H400-NE, L400-NE, ZAE400-NF, ZAS400-NF/GF** | | 0.018 | 0.017 | 0.0068 | 0.124 | 0.032 | 0.014 | 0.012 | |

Note ①: The rated voltage is 100 to 110V DC.


| Type of breaker | Peak exciting current, (A) | | | | | Connection diagrams and terminal numbers | |
|---|---|---|---|---|---|---|---|
| Earth Leakage Circuit Breakers | Rated voltage | AC (V) | | | DC (V) | | For AC | For DC |
| | | 100 (50Hz) 100-110 (60Hz) | 200 (50Hz) 200-220 (60Hz) | 400 (50Hz) 400-440 (60Hz) | 24 | 100-110 | | |
| **ZE30-NM, ZE50-NM, ZS30-NM, ZS50-CM, ZE100-NM** | | 0.16 | 0.08 | 0.055 | 1.5 | 0.23 |  Without anti-burn switch |  With anti-burn switch |

| Type of breaker | Peak exciting current, (A) (60Hz AC) | | | | | | Connection diagrams and terminal numbers |
|---|---|---|---|---|---|---|---|
| Moulded Case Circuit Breakers | Rated voltage | AC(V) | | DC(V) | | | | |
| | | 100-115 | 200-480 | 24 | 48 | 100-115 | 200-230 | |
| **XS2000NE, XS2000NN, XS2500NE, XS2500NN, XS3200NE, XS3200NN** | | 1.1 | 0.4(200-240V AC) 0.93(380-480V AC) ③ | 2.52 | 1.55 | 0.67 | 0.35 |  With anti-burn switch |
| **TL-1000NE, TL-1200NE** | | 1.1 | 0.93 | 2.52 | 1.55 | 0.67 | 0.35 | |

Notes: ③: Exclusive use for 200V class and 400V class.
Remarks:
(1) The permissible voltage range is from 70% to 110% of the rated voltage.
Ensure that the voltage does not drop exceeding the permissible voltage range when SHT is actuated.
(2) Breaker contacts usually start opening within 30 ms after the rated voltage is applied.

## (2) Circuit breaker side mounting SHT outline dimensions

| Type of breaker |
|---|
| **ZE30-NM, ZE50-NM, ZE100-NM, ZS30-NM, ZS50-CM** |




# 6. Undervoltage trip device (UV)

## (1) Instantaneous UVT (circuit breaker side mounting)

| Type of breaker | | Power supply capacity, (VA) ① | | | Exciting current, (mA) ① | | |
|---|---|---|---|---|---|---|---|
| Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | Voltage (V) | AC (V) | | | DC (V) | |
| | | | 100(50Hz) 100-110(60Hz) | 200(50Hz) 200-220(60Hz) | 400(50Hz) 400-440(60Hz) | 24 | 100-110 | 200-240 |
| **E30-NM, S30-NM, E50-NM, S50-NM, E100-NM** | **ZE30-NM, ZE50-NM, ZS30-NM, ZS50-CM, ZE100-NM** | | 2.8 | 3.4 | 4.4 | — | 28.6 | — |

Remarks:
(1) Tripping voltage is 70 to 35% of the rated voltage. Resettable voltage is 85% or less of the rated voltage.
(2) Operating time is below 50ms. (The time between no voltage and the main contact opening.)

Outline dimensions




## (2) Ratings of UVT with Inst

| Type of breaker | | Power supply capacity, (VA) | | | | Exciting current, (mA) | | |
|---|---|---|---|---|---|---|---|---|
| Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | Voltage (V) | AC(V) | | | DC(V) | | |
| | | | 100-120 | 200-240 | 380-450 | 24 | 100-120 | 200-240 |
| **PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN, S50-SF, S125-SF, S125-SN, PS50-PF, PS125-NF/PF/NN, PS125-NE/PE, E250-SF, S250-SF, S250-SM/SN, PS250-PF/NN, PS250-NE/PE, PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | — | | 1.3 | 1.1 | 2.0 | 22 | 9 | 3.7 |
| **S100-GF, S125-GF, H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, E400-NF, H400-NE, L400-NE,** | — | | 1.5 | 1.3 | 2.6 | 29 | 9.6 | 10 |

Remarks
(1) Tripping voltage is 70 to 35% of the rated voltage. Resettable voltage is 85% or less of the rated voltage.
(2) Operating time is below 50ms. (The time between no voltage and the main contact opening.)

| Type of breaker | | Power supply capacity, (VA) | | | | | | Exciting current, (mA) | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | Voltage (V) | AC(V) | | | | | DC(V) | | |
| | | | 100-110 | 115-120 | 200-220 | 230-240 | 380-415 | 440-450 | 24 | 100-120 | 200-240 |
| **S630-CF/NF/NE/GN, H630-NE, L630-NE, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, H800-NE, L800-NE, S1000-CE/NN, S1250-NE/GE/NN, S1600-NE/NN** | — | | 1.3 | 1.5 | 1.1 | 1.3 | 2.2 | 2.6 | 29 | 9.6 | 10 |

Remarks
(1) Tripping voltage is 70 to 35% of the rated voltage. Resettable voltage is 85% or less of the rated voltage.
(2) Operating time is below 50ms. (The time between no voltage and the main contact opening.)

## (3) Instantaneous UVT (with UVT controller)


| Type of breaker | | Voltage (V) | Power supply capacity, (VA) ⑥ | | | Exciting current, (mA) ① | | |
|---|---|---|---|---|---|---|---|---|
| Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | | AC(V) | | | DC(V) | | |
| | | | 100-120 | 200-240 | 380-450 | 24 | 100-115 | 200-240 |
| **XS2000NE, XS2500NE, XS3200NE<br>TL-1000NE, TL1200NE<br>XS2000NN, XS2500NN, XS3200NN** | — | | 5 or more | 5 or more | 5 or more | 22.7 | 6.0 | — |

Note: ①: No UVT controller is required. Note: ⑥: Equipped with the UVT controller.
Remarks:
(1) Tripping voltage is 70 to 35% of the rated voltage. Resettable voltage is 85% or less of the rated voltage.
(2) When the breaker is in OFF position and becomes no control voltage, the UVT may trip or maintain OFF position the breakers.
Please reset the breaker before turning the handle to ON position in either case.

A breaker equipped with the AC UVT needs a UVT controller (type XCU1S). The UVT controller is installed on the breaker by default. Separate installation of the controller is also available on request. If the breaker is of flush-mounted (FP) type, the UVT controller is separately installed by default. Also, a UVT controller (XCU1D type) in the same shape with a time delay of less than 500 ms is available on request.


● UVT controller connection diagram

UVT controller installed on the breaker





Note:
If the UVT controller is installed on the breaker, terminals UC1 and UC2 are factory wired.

UVT controller installed external to the breaker




● Mounting dimensios and terminal arrangement of the UVT controller installed on the breaker






Mounting dimensions

| Type of breaker | A | B |
|---|---|---|
| **TL-1000NE, TL-1200NE** | 114(138) | 92 |
| **XS2000NE, XS2000NN<br>XS2500NE, XS2500NN<br>XS3200NE, XS3200NN** | 180 | 115 |

**Notes:**
Dimension A shown in parentheses "( )" are the case fitted with OCR controller.
Remarks:
(1)Tightening torque of terminal screws M3.5: 0.88 – 1.18 Nm
(2)Applicable wire size: 2.0 mm² max

● Outline of the UVT controller installed external to the breaker (mm)




*1: This is the mounting configuration when the OCR controller is mounted separately at the same time.
See page 6-11 for details of the OCR controller.

# 6. Undervoltage trip device (UV)

## (4) Time delay type UVT (with UVT controller)

For the time-delay type UVT, the UVT controller is mounted on the circuit breaker body.
UVT controllers are available with 500 ± 300 ms operating times.


| Applicable breakers | Power supply capacity, (VA) ⑥ | | | | | | Exciting current, (mA) ① | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | Rated voltage | AC (V) | | | | | | DC (V) | | | |
| | | 100-110 | 115-120 | 200-220 | 230-240 | 380-415 | 440-450 | 24 | 100-110 | 115-120 | 200-220 | 230-240 |
| **PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN, S50-SF, S125-SF, S125-SN, PS50-PF, PS125-NF/PF/NN, PS125-NE/PE, E250-SF, S250-SF, S250-SM/SN, PS250-PF/NN, PS250-NE/PE, PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | | 1.1 | 1.3 | 0.9 | 1.1 | 1.7 | 2.0 | 22 | 8.1 | 8.9 | 3.4 | 3.7 |
| **S100-GF, S125-GF, H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, E400-NF, H400-NE, L400-NE S630-CF/NF/NE/GN, H630-NE, L630-NE, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, H800-NE, L800-NE, S1000-CE/NN, S1250-NE/GE/NN, S1600-NE/NN** | | 1.3 | 1.5 | 1.1 | 1.3 | 2.2 | 2.6 | 29 | 8.8 | 9.6 | 9.2 | 10 |

Note: ①: In case the UV for DC voltege, no UVT controller is required. Note: ⑥: Equipped with the UVT controller.

● Mounting dimensios and terminal arrangement of the UVT controller installed on the breaker

| Applicable breakers | A(mm) | B(mm) | C(mm) | D(mm) |
|---|---|---|---|---|
| **PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN, S50-SF, S125-SF, S125-SN** | 34 | 55 | 24 | 15 |
| **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | 33 | 55 | 24 | 15 |
| **E250-SF, S250-SF, S250-SN, S250-SM** | 49.5 | 55 | 24 | 15 |
| **PS250-PF/NN, PS250-NE/PE** | 50.5 | 55 | 24 | 15 |
| **S100-GF, S125-GF** | 28.5 | 44 | 25.2 | 16.2 |
| **H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF** | 33.5 | 79 | 25.2 | 16.2 |
| **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | 102 | 85 | 24 | 15 |
| **E400-NF** | 71 | 74 | 25.2 | 16.2 |
| **H400-NE, L400-NE** | 71 | 111 | 25.2 | 16.2 |
| **S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, S1000-CE/NN** | 62.5 | 74 | 25.2 | 16.2 |
| **H630-NE, L630-NE, H800-NE, L800-NE** | 62.5 | 111 | 25.2 | 16.2 |


・The UVT controller is installed in the right hand side of the breaker




**Notes:** 1) Tightening torque of terminal screws M3.5: 0.9 – 1.2 Nm
2) Applicable lead wire size: 2.0 mm² max

| Applicable breakers | A(mm) | B(mm) | C(mm) | D(mm) |
|---|---|---|---|---|
| **S1250-NE/GE/NN** | 114 | 72 | 21 | 12 |
| **S1600-NE/NN** | 114 | 92 | 21 | 12 |

・The UVT controller is installed in the left hand side of the breaker




**Notes:** 1) Tightening torque of terminal screws M3.5: 0.9 – 1.2 Nm
2) Applicable lead wire size: 2.0 mm² max

# 7. Shunt Trip for Circuit Breaker with Earth Leakage Alarm (SH)

## ■ Outer view



## ■ SHT rating

| Applicable circuit breaker with earth leakage alarm type | Peak exciting current, (A) | | | | | | |
|---|---|---|---|---|---|---|---|
| | Rated voltage | AC (V) | | | DC (V) | | |
| | | 100-120 | 200-240 | 380-450 | 24 | 48 | 100-120 | 200-240 |
| **ZAS50-GF, ZAS100-GF, ZAS125-GF, ZAS125-SF, ZAE250-SF, ZAS225-GF, ZAS250-SF, ZAS250-GF** | | 0.016 | 0.016 | 0.0062 | 0.124 | 0.032 | 0.014 | 0.012 |


**Remarks:**

(1) The allowable voltage range is 70 to 110% of the rated voltage. Make sure that the voltage drop due to SHT operation does not fall below the allowable voltage range.

(2) The circuit breaker contacts usually begin to open within 30 ms after the rated voltage is applied.


(3) No anti-burn switch required.

## ■ Outline dimensions




**Notes:** 1) Tightening torque of terminal screws M3.5: 0.9 – 1.2 Nm
2) Applicable lead wire size: 2.0 mm² max


| Applicable circuit breaker with earth leakage alarm type | W(mm) | |
|---|---|---|
| | 3P | 4P |
| **ZAS50-GF, ZAS100-GF, ZAS125-GF** | 90 | 120 |
| **ZAS225-GF, ZAS250-GF** | 105 | 140 |




**Notes:** 1) Tightening torque of terminal screws M3.5: 0.9 – 1.2 Nm
2) Applicable lead wire size: 2.0 mm² max

| Applicable circuit breaker with earth leakage alarm type | W(mm) | A (mm) | B (mm) | C (mm) |
|---|---|---|---|---|
| | 3P | | | |
| **ZAS125-SF** | 75 | 18 | 49 | 31 |
| **ZAE250-SF, ZAS250-SF** | 105 | 16 | 47 | 33 |

## ■ Terminal code




Shunt trip devices are provided with control power and earth leakage alarm output contact terminals.

*1: b contact can also be manufactured as a special product.

## ■ Other Specifications

The controller for voltage trip devices is mounted on the right-hand side of the circuit breaker with earth leakage alarm together with the terminal block. When equipped with a shunt trip device, the control power supply and earth leakage alarm output contact of the shunt trip device are equipped with a terminal block. Auxiliary switches (AX) and alarm switches (AL) can be specified with lead wire draw-in or lead wire terminal blocks (TF) as in the past.
Flush-mounted type cannot be applied when a shunt trip device is mounted.

# 8. Circuit Breaker with Earth Leakage Alarm Option

(1) Earth leakage alarm automatic reset

The standard earth leakage alarm has a self-maintaining output, but is available with automatic reset as an option. It resets 0.15 seconds after the leakage is gone.

(2) Earth leakage alarm remote reset

The earth leakage alarm output can be reset remotely. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. Do not apply an external voltage to the remote reset lead wires because the voltage shown in the table on the next page is applied to them.

(3) Test lead for circuit breaker with earth leakage alarm

If an earth leakage alarm remote reset is attached, a test lead can be applied as an option. Please apply this when the test button cannot be pressed due to the installation of external accessories, etc. Do not apply an external voltage to the test lead wires because the voltage shown in the table on the next page is applied to them.

Earth leakage alarm remote reset, test lead application table ○ : Applicable × : Not applicable

| Applicable circuit breaker types | Shunt trip device (SH) | Remote reset | Remote reset + test lead |
|---|---|---|---|
| **ZAS50-GF, ZAS100-GF, ZAS125-GF** | Yes | × | × |
| | Non | ○ | ○ |
| **ZAS125-SF** | Yes | × | × |
| | Non | ○ | × |
| **ZAE250-SF, ZAS250-SF, ZAS225-GF, ZAS250-GF** | Yes | × | × |
| | Non | ○ | ○ |
| **ZAE400-NF, ZAS400-NF, ZAS400-GF** | Yes | ○ | × |
| | Non | ○ | ○ |
| **ZAS630-CF, ZAS630-NF, ZAS800-CF, ZAS800-NF** | Yes | ○ | × |
| | Non | ○ | ○ |
| **NAE125-SF, NAS125-SF** | Non | ○ | × |
| **NAE250-SF, NAS250-SF** | Non | ○ | × |
| **NAE400-NF, NAS400-NF** | Non | ○ | × |

Lead wire draw-in is standard for remote reset and test lead.

| Lead wire | Type | Size | Finished OD | Length | Colour |
|---|---|---|---|---|---|
| Remote reset | Heat resistant | 0.5㎟ | 1.8mmø | 450mm ① | Black |
| Test lead | | | 1.8mmø | 450mm ① | Grey |

Lead wire terminal blocks are also applicable. See pages 6-128 to 6-130, 6-132, 6-134 for details.

Note ①: When extending lead wires, they should be 10m or less.

# 9. Remote reset voltage at both ends and current at closed path

Do not apply an external voltage to the remote reset lead wires because voltage is applied to them. Use a switch that can switch the voltages and currents shown in the table below without any difficulty.


| Series | Type of breaker | Remote reset lead voltage at both ends | Current at closed path |
|---|---|---|---|
| Circuit Breaker with earth leakage alarm | **ZAS50-GF, ZAS100-GF, ZAS125-GF, ZAS125-SF, ZAE250-SF, ZAS250-SF, ZAS225-GF, ZAS250-GF, ZAE400-NF, ZAS400-NF, ZAS400-GF, ZAS630-CF, ZAS630-NF, ZAS800-CF, ZAS800-NF, NAE125-SF, NAS125-SF, NAE250-SF, NAS250-SF, NAE400-NF, NAS400-NF** | DC60V | 5mA |

# 10. Test lead voltage at both ends and current at closed path

Do not apply an external voltage to the test lead wires because voltage is applied to them. Use a switch that can switch the voltages and currents shown in the table below without any difficulty.

<table>
<tr><th>Series</th><th>Type of breaker</th><th>Test lead voltage at both ends</th><th>Current at closed path</th></tr>
<tr><td>Circuit Breaker with earth leakage alarm</td><td>ZAS50-GF, ZAS100-GF, ZAS125-SF, ZAS125-GF, ZAE250-SF, ZAS250-SF, ZAS225-GF, ZAS250-GF, ZAE400-NF, ZAS400-NF, ZAS400-GF, ZAS630-CF, ZAS630-NF, ZAS800-CF, ZAS800-NF</td><td>DC60V</td><td>5mA</td></tr>
<tr><td rowspan="2">Single phase 3-wire circuit breaker with neutral phase open protection</td><td>NS125-SF</td><td>120 V (half-wave rectification)</td><td>12mA</td></tr>
<tr><td>NE250-SF, NS250-SF, NE400-NF, NS400-NF NS630-NF, NS800-NF</td><td>120V (half-wave rectification)</td><td>8mA</td></tr>
<tr><td rowspan="2">Earth Leakage Circuit Breakers</td><td>ZS50-SF, ZS125-SF, ZS250-SF, ZE250-SF</td><td>DC60V</td><td>2mA</td></tr>
<tr><td>ZS100-GF, ZS125-GF, ZS225-GF, ZS250-GF, ZS400-GF, ZE400-NF, ZS400-NF, ZS630-CF, ZS800-CF, ZS630-NF, ZS800-NF</td><td colspan="2"><table>
<tr><th>Sensitivity current</th><th>Test lead voltage at both ends (main circuit voltage)</th><th>Current at closed path</th></tr>
<tr><td rowspan="3">30mA</td><td>AC 100V</td><td>1mA</td></tr>
<tr><td>AC 220V</td><td>2mA</td></tr>
<tr><td>AC 440V</td><td>4mA</td></tr>
<tr><td rowspan="3">100/200/500mA</td><td>AC 100V</td><td>11mA</td></tr>
<tr><td>AC 220V</td><td>25mA</td></tr>
<tr><td>AC 440V</td><td>50mA</td></tr>
</table></td></tr>
<tr><td rowspan="2">Earth Leakage Circuit Breakers for motor protection</td><td>ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM</td><td colspan="2">The main circuit voltage is applied</td><td>1A</td></tr>
<tr><td>ZS100-SM, ZS250-SM</td><td>DC60V</td><td>2mA</td></tr>
<tr><td rowspan="2">Single phase 3-wire earth leakage circuit breaker with neutral phase open protection</td><td>ZNS125-SF, ZNE250-SF, ZNS250-SF</td><td>DC60V</td><td>2mA</td></tr>
<tr><td>ZNE400-NF, ZNS400-NF</td><td colspan="2"><table>
<tr><th>Sensitivity current</th><th>Test lead voltage at both ends</th><th>Current at closed path</th></tr>
<tr><td>30mA</td><td rowspan="2">The main circuit voltage is applied</td><td>1mA</td></tr>
<tr><td>100/200/500mA</td><td>14mA</td></tr>
</table></td></tr>
<tr><td>Earth Leakage Circuit Breaker for distribution boards and control boards</td><td>TZ30EC, TZ50EE, TZ100EC</td><td colspan="2"><table>
<tr><th>Sensitivity current</th><th>Test lead voltage at both ends (main circuit voltage)</th><th>Current at closed path</th></tr>
<tr><td rowspan="2">15mA</td><td>AC 100V</td><td>33mA</td></tr>
<tr><td>AC 200V</td><td>67mA</td></tr>
<tr><td rowspan="2">30mA</td><td>AC 100V</td><td>67mA</td></tr>
<tr><td>AC 200V</td><td>133mA</td></tr>
<tr><td rowspan="2">100mA</td><td>AC 100V</td><td>83mA</td></tr>
<tr><td>AC 200V</td><td>167mA</td></tr>
</table></td></tr>
</table>

# 1. Overview




**①Toggle extension** ——— HA
Lessens the force require to close, open or reset the breaker.

**②Motor operator** ——— MC
Allows electrical operation (closing, opening and resetting) of the breaker.

**③External operating handle**
Allows the breaker installed in a switchboard or box to be operated from outside.

Breaker-mounted ——— HB
The handle is mounted directly on the breaker.

Door-mounted (depth adjustable) ——— HP
The handle is coupled to the breaker through a shaft.

Door-mounted (depth fixed) ——— HE

**④Mechanical interlock**
Provides an interlock that allows one of two breakers to be closed.
Slide type ——— MS
Rear-connected type ——— MB
Link type ——— ML
Wire type ——— MW

**⑤Toggle holder** ——— HH
Holds the breaker ON or OFF when simply fitted onto the breaker toggle.

**⑥Toggle lock** ——— HL
Allows the breaker to be locked ON or OFF with commercially available padlocks.

**⑦Terminal cover**
Prevents live parts of the breaker from being exposed.
For front-connected breakers ——— CF
For rear-connected and plug-in breakers ——— CR
For front-connected breakers with cable clamps — CS

**⑧Interpole barrier** ——— BA
Enhances electrical insulation between poles and prevents shortcircuit due to electrically conductive foreign matter.

**⑨Terminal block** ——— TF
Terminates lead wires from internally mounted accessories.

**⑩Door flange** ——— DF
Is intended to cover the cutout of a switchboard panel from the front.

**⑪DIN rail adaptor**
Allows the breaker to be mounted on DIN rails.

# 2. Toggle extension (HA)


## Reduces the force of ON, OFF, and RESET operations.

### Outline dimensions


| Frame size (A) | Type of breaker | Toggle extension Order code |
|---|---|---|
| 400 | **E400-NF, PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, H400-NE, L400-NE, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF, ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | T2HA40L |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | |

**Note:** Optional. Specify when ordering.
When used in conjunction with mechanical interlocks, care must be taken in the mounting direction.
For more details please refer to the instruction manual.


T2HA40L




### Outline dimensions XHA9B, T2HA80





XHA10




| Frame size (A) | Type of breaker | | Toggle extension Order code |
|---|---|---|---|
| 600, 630 | **S630-CF/NF/NE/GN, H630-NE, L630-NE, ZAS630-CF/NF, NS630-NF, ZS630-CF/NF** | ① | T2HA80 |
| 800 | **S800-CF/NF/NE/RF/RE/PF/PE/NN, H800-NE, L800-NE, ZAS800-CF, ZAS800-NF, NS800-NF, ZS800-CF/NF** | | |
| 1000 | **S1000-CE/NN** | | |
| | **TL-1000NE** | ② | XHA9B |
| 1200 | **TL-1200NE** | | |
| 1250 | **S1250-NE/GE/NN** | | T2HA80 |
| 1600 | **S1600-NE/NN** | | |
| 2000 | **XS2000NE/NN** | ③ | XHA10 |
| 2500 | **XS2500NE/NN** | | |
| 3200 | **XS3200NE/NN** | | |

**Note:** ① Optional. Specify when ordering.
② One is supplied with every five breakers. Please specify if more are required.
③ Supplied as standard.




- **Mounting and Removal**
  Pull lock pins out left and right in direction of the arrows, and slot the toggle extension in place. The lock pins are spring loaded. Removal-Pull out left and right hand lock pins and hold while removing.

# 3. Motor operators (MC)

## (1) T2MC/TPMC motor operators

### Features

**★Installation and removal ease**

Motor driven type: Simply rotate the two fixing levers to allow the motor operator to be installed on or removed from the circuit breaker. Spring charged type: The compact and lightweight design enables easy installation and removal.

**★High-speed, stable actuation**

The operating time as short as up to 0.1 second makes it possible to use the motor operators for synchronized closing of breakers.

**★Silent operation**

The motor driven type uses a direct drive system, so it operates quietly.

**★"Lock-in off" capability**

This capability allows the breaker to be padlocked in the OFF state. Up to thee padlocks with a 5 to 8 mm hasp diameter can be used.Padlocks are not supplied.


**★Compact and lightweight**

The spring charged type is small and the OCR part of the circuit breaker is not hidden. This means that it is not necessary to be removed when changing the circuit breaker settings.




(T2MC12, T2MC25/25L, TPMC16S, TPMC25S)

Motor driven type




(T2MC40, TPMC63S, T2MC80)

Spring charged type

### Ratings and Specifications

Motor driven type

| | | T2MC12 | T2MC25 | T2MC25L | TPMC16S | TPMC25S |
|---|---|---|---|---|---|---|
| Type of breaker | E | | | **E250-SF, ZAE250-SF, NAE250-SF, NE250-SF, ZE250-SF, ZNE250-SF** | | |
| | S | **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF, ZS100-GF, ZS125-GF** | **ZAS225-GF, ZAS250-GF, ZS225-GF, ZS250-GF** | **S250-SF, S250-SM/SN, ZAS250-SF, NAS250-SF, NS250-SF, ZS250-SF, ZS250-SM, ZNS250-SF** | **PS50-PF, PS125-NF/PF, PS125-NN, PS125-NE/PE** | **PS250-PF, PS250-NN, PS250-NE/PE** |
| | H | | **H100-NF, H125-NF, H225-NF/NE, H250-NF,** | | | |
| | L | | **L100-NF, L125-NF, L225-NF, L250-NF** | | | |
| Rated operational voltage ① | | ●100-110V AC<br>●200-220V AC<br>●230-240V AC<br>●24V DC<br>●48V DC<br>●100-110V DC<br>●200-220V DC | | | ●AC100-110V<br>●AC200-220V<br>●AC230-240V<br>●DC24V<br>●DC48V<br>●DC100-110V<br>●DC200-220V | |
| Steady-state current / Starting current (Peak value) (A) ② | 100-110V AC | 4.5/8 | | | 3.6/8.7 | |
| | 200-220V AC | 4/8 | | | 3.6/6.6 | |
| | 230-240V AC | 3.5/7 | | | 3.4/6 | |
| | 24V DC | 18/26 | | | 14/27 | |
| | 48V DC | 12/18 | | | 12/17 | |
| | 100-110V DC | 2.2/6 | | | 3.4/7.6 | |
| | 200-220V DC | 2.2/5.5 | | | 4.2/5.9 | |
| Operation method | | Motor driven (direct drive system) | | | | |
| Operating time, (s) | ON | 0.1 ③ | | | | |
| | OFF/RESET | 0.1 ③④ | | | | |
| Operating switch ratings | | 100V 0.1A (Open voltage/current: 44V/4mA) ⑤ | | | | |
| Power supply required | | 300VA or higher | | | | |
| Dielectric withstand voltage (for one minute) | | 1500V AC (1000V AC for 24/48V DC) | | | | |
| Weight | | 1.4kg | | | | |
| Colour of cover | | Grey Blue | | | | |
| Page of outline dimensions | | 7-244 — 7-249 | | | | |

# 3. Motor operators (MC)

## Ratings and Specifications Spring charged type

| | | T2MC40 | TPMC63S | T2MC80 |
|---|---|---|---|---|
| Type of breaker | E | **E400-NF, ZAE400-NF, NAE400-NF, NE400-NF, ZE400-NF, ZNE400-NF** | | |
| | S | **ZAS400-NF/GF, NAS400-NF, NS400-NF, ZS400-NF/GF, ZNS400-NF** | **PS400-CF/NF/GF, PS400-NE/GE/NN, PS630-CF/NF/GF, PS630-NE/GE/NN** | **S630-CF/NF/NE/GN, ZAS630-CF/NF, NS630-NF, ZS630-CF/NF, S800-CF/NF/RF/PF, S800-NE/RE/PE/NN, ZAS800-CF/NF, NS800-NF, ZS800-CF/NF, S1000-CE/NN** |
| | H | **H400-NE** | **PH400-CF/CE, PH630-CF/CE** | **H630-NE, H800-NE** |
| | L | **L400-NE** | | **L630-NE, L800-NE** |
| Rated operational voltage ① | | ●100-240V AC ●24-48V DC ●100-120V DC | ●100-240V AC ●24-48V DC ●100-120V DC | ●100-240V AC ●24-48V DC ●100-120V DC |
| Steady-state current / Starting current (Peak value) (A) ② | 100-110V AC | —/4.1 (ON) 1.3/3.8 (OFF,RESET) | —/4.1 (ON) 1.7/4.2 (OFF,RESET) | —/4.1 (ON) 1.7/3.5 (OFF,RESET) |
| | 200-220V AC | —/4.0 (ON) 0.9/3.8 (OFF,RESET) | —/4.0 (ON) 1.4/3.9 (OFF,RESET) | —/4.0 (ON) 1.3/3.5 (OFF,RESET) |
| | 230-240V AC | —/4.0 (ON) 0.9/3.8 (OFF,RESET) | —/4.0 (ON) 1.4/3.9 (OFF,RESET) | —/4.0 (ON) 1.3/3.5 (OFF,RESET) |
| | 24V DC | —/12 (ON) 4.3/9.8 (OFF,RESET) | —/12 (ON) 6.7/15.3 (OFF,RESET) | —/12 (ON) 6.0/11.5 (OFF,RESET) |
| | 48V DC | —/12 (ON) 4.3/9.8 (OFF,RESET) | —/12 (ON) 3.5/7.4 (OFF,RESET) | —/12 (ON) 3.2/6.5 (OFF,RESET) |
| | 100-110V DC | —/4.1 (ON) 2.0/5.2 (OFF,RESET) | —/4.1 (ON) 1.4/4.4 (OFF,RESET) | —/4.1 (ON) 1.3/3.5 (OFF,RESET) |
| | 200-220V DC | — | — | — |
| Operation method | | Spring charged | | |
| Operating time, (s) | ON | 0.1 ③ | | |
| | OFF/RESET | 1.5 ③④ | | |
| Operating switch ratings | | 100V 0.1A (Open voltage/current: 48V/1mA) | | |
| Power supply required | | 300VA or higher | | |
| Dielectric withstand voltage (for one minute) | | 1500V AC (1000V AC for 24/48V DC) | | |
| Weight | | 3.5kg | | |
| Colour of cover | | Grey Blue | | |
| Page of outline dimensions | | 7-250 — 7-257 | | |

**Notes:**
① : Permissible operating range is 85 to 110%. A power transformer is available as option for 380V AC or 400-460V AC.
② : The currents shown are the maximum values at the maximum rated operational voltage.
③ : The operating time is the value when the rated operational voltage is supplied. Loss of the control power in this operating time may cause the motor operator to fail to work.
④ : The motor operator is of a short time duty. Do not subject it to more than 10 continuous ON-OFF operations. If this occurs, allow the motor operator to cool for at least 15 minutes.
⑤ : When the rated operational voltage is 24V DC the open voltage will be 22V DC.

## Motorized operation

The motor operator has an input-signal self-hold circuit. To reset the tripped breaker to the OFF position, close the OFF (RESET) switch.
The voltage presence LED indication is on when the power is supplied to the motor operator.

### ■ Auto reset feature (optional)

The auto reset feature allows the breaker to be automatically reset approx. 1.5 seconds after the breaker trips open. This option contains auto-reset switches and does not require to use auxiliary or alarm switches installed in the breaker.
**Note 1:** that after the thermal OCR trips a thermal-magnetic breaker, the breaker cannot be immediately closed though it can be auto-reset. Wait for a few minutes after the tripping and provide a close signal to the breaker.
**Note 2:** Do not use an alarm switch to reset breakers.
This option resets the tripped breaker automatically, regardless of the cause of the tripping.

## Manual operation

Motor driven type: Pull the manual operating handle out to turn it ON and OFF. Rotating the handle anticlockwise turns ON the breaker and clockwise turns OFF or resets the breaker.
Spring charged type: Switch to manual operation from motorized operation using the select lever. Use the manual spring charging handle to charge the spring and press the ON or TRIP button to perform manual operation.
Spring charged type: When the TRIP button is pressed while the control power is supplied, the circuit breaker turns OFF automatically, and if equipped with an alarm switch, it provides an output signal because the MCCB trips once. Press the TRIP button all the way in. Pressing the TRIP button halfway causes the breaker to go off without tripping, resulting in no alarm signal delivered even if the breaker is equipped with an alarm switch.

## Breakers position in tripped state

Breakers position when the breaker has tripped differs depending on the motor operator being of standard type or being equipped with the auto reset feature (optional), as shown in the table below:

Motor driven type

| Cause of trip | Breakers position in tripped state | |
|---|---|---|
| | Standard type | With auto reset feature |
| Manually tripped | TRIP | ○ (OFF)＊ |
| SHT/UVT | | |
| Overcurrent | | |

＊: The motor operator automatically provides OFF (reset) operation to the breaker.

Spring charged type

| Cause of trip | Breakers position in tripped state | |
|---|---|---|
| | Standard type | With auto reset feature |
| Manually tripped | ○ (OFF)＊ | ○ (OFF)＊ |
| SHT/UVT | TRIP | |
| Overcurrent | | |

＊: The motor operator automatically provides OFF (reset) operation to the breaker.

### Table 1 Electrical interlock cables


| Interlock cables Order codes | Length | Remarks |
|---|---|---|
| **T2MM25L05** | 500mm | An electrical interlock is adopted between T2MC12, T2MC25/25L, TPMC16S, and TPMC25S types. |
| **T2MM25L15** | 1500mm | |
| **T2MM40L06** | 600mm | An electrical interlock is adopted between T2MC40, T2MC80, and TPMC63S types. |
| **T2MM40L21** | 2100mm | |
| **T2MM40S06** | 600mm | An electrical interlock is adopted between T2MC40 (or TPMC63S, T2MC80) and T2MC12 types (or T2MC25, TPMC16S, TPMC25S types). |
| **T2MM40S21** | 2100mm | |

### Operation precautions


1. Ensure that the actual operation voltage ranges from 85% to 110% of the rated one.
2. Use operation switches whose ratings and power capacity is as specified in the “Ratings and Specifications” table on the previous page.
3. Ensure an operating time of 50 msec or more when operating switches to turn on/off the breaker. A shorter operating time may result in failure in operating the breaker. In such a case, repeat the operation.
4. Do not continuously apply ON/OFF operating signals. ON/OFF signals must be separated by 0.3 sec or more. With spring charged type, OFF and RESET operations must be 1.5 sec or more apart.
5. With motor driven type, do not connect alarm switches (AL) to the control circuit (OFF, ON or COM terminals). Doing so may cause the motor operator to fail to work.
6. If the motor operator is used in conjunction with a shunt trip device (SH), ensure that voltage supply to the SHT is shut off after the reset operation ends.
7. To operate multiple motor operators in batch, do not directly connect their control terminals in series, but through a separate relay for each. Otherwise, sneak circuits may form and cause the motor operators to fail to work.
8. Use noise filters if the control power supply of the motor operator is shared by peripheral devices. Otherwise, power supply noise may cause malfunction of the peripheral devices.
9. When the motors are used in conjunction with the mechanical interlock the electrical interlock should be provided between the motors in order to avoid the simultaneous closing. The followings are the available electrical interlock cables.

## Control circuit diagrams of motor operators

Motor driven type





Spring charged type



# 3. Motor operators (MC)

## (3) T2MC/XMD motor operators




(T2MCX6)
Spring charged type

### Ratings and Specifications

| | | | T2MCX6 | XMD9 |
|---|---|---|---|---|
| Applicable breakers | | | **S1250-NE/GE/NN, S1600-NE/NN** | **TL-1000NE, TL-1200NE** |
| Rated operational voltage ① | | | ● AC100-115V<br>● AC200-230V<br>● DC100-110V<br>● DC24V | |
| Steady-state current / Starting current (Peak value) (A) ② | 100-115V AC | ON | —/3.1 | |
| | | OFF, RESET | 1.8/6.0 | |
| | 200-230V AC | ON | —/1.2 | |
| | | OFF, RESET | 1.0/3.2 | |
| | 100-110V DC | ON | —/0.8 | |
| | | OFF, RESET | 1.1/4.2 | |
| | 24V DC | ON | —/4.5 | |
| | | OFF, RESET | 4.0/12.0 | |
| Operation method | | | Spring charged | |
| Operating time, (s) | ON (Max) | | 0.06 ③ | |
| | OFF/RESET | | 3 ③ | |
| Power supply required | | | 300VA | |
| Dielectric withstand voltage (for one minute) | | | AC1500V ④ | |
| Weight | | | 6.4kg | |
| Colour of cover | | | Grey Blue | Black |
| Page of outline dimensions | | | 7-258 – 7-260 | |

**Notes:**
① : Permissible operating range is 85 to 110%. A power transformer is available as option for 380V AC or 400-460V AC.
② : The currents shown are the maximum values at the maximum rated operational voltage.
③ : The operating time is the value when the rated operational voltage is supplied. Loss of the control power in this operating time may cause the motor operator to fail to work.
④ : Dielectric withstand voltage for 24V DC motor is 500V AC .

### Features

**★Clear status indication**
Colour indication: Red means ON, green OFF and white TRIPPED.

**★Quick closing**
Energy in a charged spring closes the breaker 60 msec or less.
High-speed, time-stable operation is ensured after multiple times of closing cycles.

**★Equipped with anti-pumping circuit**
When the closing signal is applied, TRIP–RESET–ON cycles are not repeated even though the cause of tripping is in the breaker.

**★Ease of manual ON-OFF operation**
It turns ON and OFF with one stroke using manual operating handle.

**★"Lock-in off" capability**
This capability allows the breaker to be padlocked in the OFF state.
Padlocks are not supplied.



# Operation mechanism

## Motorized operation

### ■ Breaker ON

Closing the ON switch activates the latch release coil (LRC), thereby releasing the closing spring to turn the breaker ON.

### ■ Breaker OFF (RESET)

Closing the OFF/RESET switch activates the (Y) control relay, thereby starting the motor to turn the breaker OFF. At the same time, the closing spring is charged. The motor is deenergized when the breaker turns OFF (RESET).

### ■ Breaker auto-reset (optional)

The auto-reset option uses an auto-reset switch (alarm switch) through which the closing spring is charged and the breaker is reset automatically after the breaker trips open. This option both for XMD and T2MC will be factory wired.


**Notes:** 1. For S1250 and S1600, installable alarm switch will be only 1 piece.
2. When the breaker is equipped with the auto-reset option, a signal self-hold circuit is required because the signal provided by the alarm switch is a pulse.
3. Not applicable to thermal-magnetic breakers

## Manual operation ✻

### ■ Breaker ON . OFF (RESET)

Pulling down the manual operating handle turns the breaker ON and OFF/REST alternately.
The handle returns to the original position when released.
✻ With auto-charge/discharge feature:
When manual ON operation is performed while the control power is applied, the handle switch (HS) operates to discharge the closing spring.
OFF operation causes the closing spring to be charged.
When manual ON or OFF operation is performed while the control power is lost, and afterwards the control power is recovered, the closing spring is discharged or charged in the same manner as described above.
When the auto-charge/discharge action is in progress, mechanical noises will be heard. The noises however do not mean a failure.

## Control circuit diagram




### Operation Precautions

- Ensure that the actual operation voltage ranges from 85% to 110% of the rated one.
- The motor operator is short-time rated. The number of continuous switching (ON-OFF) cycles must not exceed 10. After any 10 continuous switching cycles, provide a pause of at least 15 minutes to the motor operator for cooling.
- When conducting the dielectric withstand voltage test, apply voltage between the control terminal group and ground. Ensure that the test voltage does not exceed 1500V AC (500V AC if the rated operation voltage is 24V DC).
- f the breaker is equipped with the UVT device, ensure that the UVT device is reset before providing a closing signal to the breaker.
- It takes up to three seconds to complete motorized OFF operation. If the breaker requires to be immediately opened from a remote location in an emergency, add the SHT or UVT device to the breaker for remote electrical tripping.
- Make sure that the current and switching capacities of the operation switch are appropriate for the application.
- Avoid repeated and continuous applications of the operation power supply to the motor operator.
- Use noise filters if the control power supply of the motor operator is shared by peripheral devices. Otherwise, power supply noise may cause malfunction of the peripheral devices.
- Be sure to apply power to control power terminal MP1. If the breaker is turned ON or OFF manually without power applied to MP1, the auto charge/discharge feature is disabled, and thus the motor operator will not be activated next time. In such a case, applying the rated operation voltage between control power terminals MP1 and MP2 will enable the auto charge/discharge feature.
- The control power lost at the breaker charge process, and afterwards the control power is recovered, the closing spring is no more charged. Unusually the breaker reopen a charge depending on the handle position of the breaker.


# 4. External operating handles

## (1) Breaker-mounted (field installable small type) (HB)

The external operating handle is a tool that allows the breaker installed in a switchboard to be operated from outside and complies with IEC 60204-1. The breaker-mounted type external operating handle is designed to be mounted directly to the breaker body.

### ■ Outer view

Types
T2HB16L
TPHB16S
T2HB25L
TPHB25S




### ■ Mounting instructions


The external operating handle has not been mounted on the breakers.
For details on how to mount the handle, see the Operating Instructions packaged with the product.

**[1] Mounting of external operating handle assembly**

Install the circuit breakers and handles as follows.


- Make sure that the breaker is in the OFF position.
- Put the external operating handle assembly onto the breaker in place so that the breaker toggle is engaged with the slide lever of the assembly. Rotate two knobs to secure the handle assembly.





**[2] Installation of handle escutcheon and latch plate**




- Drill holes in the panel according to the panel cutout dimensions. Sandwich the panel between the handle escutcheon and latch plate and temporarily tighten using the supplied screws.
- Close the panel. Make adjustment so that the gap between the handle assembly and handle escutcheon is even and the assembly is not inclined against the breaker.




### ■ Breaker mounting direction

The ON (**I**) and OFF (O) indication of the external operating handle can be re-oriented in steps of 90 degrees with respect to the operating mechanism.
This allows the indication position to remain the same whether the breaker is mounted vertically (right side up or upside down) or horizontally (on its left side or on its right side).
The upper power supply type is standard. If a non-standard type is required, state the type when ordering.

| R: Right power supply type | U: Upper power supply type (standard) | L: Left power supply type |
|---|---|---|
|  |  |  |





- For a change in mounting direction, see the Operating Instructions packaged with the product.


## ■Panel lock mechanism

The external operating handle keeps the panel door locked when in the 'ON' position. There are two types, RESET Open and OFF Open.

(1) **RESET Open (Standard type)**
The handle is turned to the RESET OPEN position to open the panel door.

(2) **OFF Open**
The handle is turned to the OFF position to open the panel door.

- **Panel lock release knob (Standard)**
  The release knob enables the panel door to be opened with the handle in the 'ON' position. To release: turn the release knob in the direction of anti-clockwise with a flat-bladed screwdriver.
- **Safety interlock (Standard)**
  The safety interlock prevents the breaker from turning ON as long as the panel is open. This interlock can be released using the hook lever.




## ■Toggle lock mechanism


- **Padlock (Standard)**
  This mechanism allows the breaker to be padlocked in the ON or OFF position.
  Padlocks are not supplied.
  Up to three padlocks can be installed.




Padlock dimensions (mm)

| Type of handle | A | Dia. |
|---|---|---|
| T2HB | 13 min | ø5.5-8 |

✻ : Padlocking in OFF position only required by IEC 60204-1 is also available.
Please specify when ordering.




## ■Protection degree (IEC 60529)

Optional dust-proof gaskets may be used to protect against dust.

| | |
|---|---|
| IP30 | Standard specification |
| IP50 | Optional, with a dust proof packing |
| IP55 | Special specification ① |

Notes ① : For the depth of switchboard, take account of thickness of the packing. See the Operating Instructions packaged with the product.

## ■To be stated when ordering

Order code T2HB16L U R 3 B T P

| Type of external operating handle | Breaker mounting direction | Panel lock | Protection degree | Colour | Padlock | Series |
|---|---|---|---|---|---|---|
| T2HB16L<br>T2HB25L | U : Upper power supply type ✻<br>R : Right power supply type<br>L : Left power supply type | R : RESET open ✻<br>F : OFF open | 3 : IP30 ✻<br>5 : IP50<br>S : IP55 (special spec.) | B : Black handle (Grey Blue base) ✻<br>R : Red handle (Yellow base) | T : Lock in ON or OFF ✻<br>N : Lock in OFF | P : PRO Series ① |
| TPHB16S<br>TPHB25S | | | | | | — |

✻ : Standard specification
Note ① : For T2HB, specify "P". Do not specify anything in the case of TPHB (blank).


# 4. External operating handles

T2HB16L


| Applicable breaker types | Number of poles |
|---|---|
| S50-SF, S125-SF, S125-SN, ZAS125-SF, NAE125-SF, NAS125-SF, NS125-SF, ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF, | 3 |
| | 4 |
| PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN, PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN | 3 |

: Handle Frame Centre Line
: Handle Centre Line


• Outline dimensions




• Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the area.




## TPHB16S


| Applicable breaker types |
|---|
| **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** |

HL : Handle Frame Centre Line
℄ : Handle Centre Line


• Outline dimensions




• Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the ▨ area.




# 4. External operating handles

**T2HB25L**


| Applicable breaker types |
|---|
| E250-SF, S250-SF, S250-SM, S250-SN<br>ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF,<br>NE250-SF, NS250-SF<br>ZE250-SF, ZS250-SF, ZS250-SM, ZNE250-SF, ZNS250-SF |

H : Handle Frame Centre Line
℄ : Handle Centre Line


• Outline dimensions




• Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the ▨ area.




## TPHB25S


| Applicable breaker types |
|---|
| **PS250-PF/NN,** |
| **PS250-NE/PE** |

: Handle Frame Centre Line
: Handle Centre Line


• Outline dimensions




• Panel cutout dimensions




• Positions of the hinge and handle as see
from the load side of the breaker.
Ensure that the hinge is positioned
in the area.



# 4. External operating handles

## (2) Breaker-mounted (field installable standard type) (HB)

The external operating handle is a tool that allows the breaker installed in a switchboard to be operated from outside and complies with IEC 60204-1. The breaker-mounted type external operating handle is designed to be mounted directly to the breaker body.

### ■ Outer view

Types
T2HB12
T2HB25
T2HB40
TPHB63S
T2HB80




### ■ Mounting instructions

The external operating handle has not been mounted on the breakers.
For details on how to mount the handle, see the Operating Instructions packaged with the product.

**[1] Mounting of external operating handle assembly**


Install the circuit breakers and handles as follows.

- Make sure that the breaker is in the OFF position.
- Put the external operating handle assembly onto the breaker in place so that the breaker toggle is engaged with the slide lever of the assembly. Rotate two knobs to secure the handle assembly.
- For T2HB40, T2HB63S and T2HB80, tighten the bolts to secure the handle assembly.







**[2] Installation of handle escutcheon and latch plate**

- Drill holes in the panel according to the panel cutout dimensions. Sandwich the panel between the handle escutcheon and latch plate and temporarily tighten using the supplied screws.
- Close the panel. Make adjustment so that the gap between the handle assembly and handle escutcheon is even and the assembly is not inclined against the breaker.




### ■ Breaker mounting direction

The ON (**I**) and OFF (○) indication of the external operating handle can be re-oriented in steps of 90 degrees with respect to the operating mechanism.
This allows the indication position to remain the same whether the breaker is mounted vertically (right side up or upside down) or horizontally (on its left side or on its right side).
The upper power supply type is standard. If a non-standard type is required, state the type when ordering.

| R: Right power supply type | U: Upper power supply type (standard) | L: Left power supply type |
|---|---|---|
|  |  |  |



- For a change in mounting direction, see the Operating Instructions packaged with the product.

## ■Panel lock mechanism

The external operating handle keeps the panel door locked when in the 'ON' position. There are two types, RESET Open and OFF Open.

(1) **RESET Open (Standard type)**
The handle is turned to the RESET OPEN position to open the panel door.

(2) **OFF Open**
The handle is turned to the OFF position to open the panel door.

- **Panel lock release knob (Standard)**
  The release knob enables the panel door to be opened with the handle in the 'ON' position. To release: turn the release knob in the direction of anti-clockwise with a flat-bladed screwdriver.
- **Safety interlock (Standard)**
  The safety interlock prevents the breaker from turning ON as long as the panel is open. This interlock can be released using the hook lever.

## ■Toggle lock mechanism


- **Padlock (Standard)**
  This mechanism allows the breaker to be padlocked in the ON or OFF position. ∗
  Padlocks are not supplied.
  Up to three padlocks can be installed.




Padlock dimensions (mm)

| Type of handle | A | Dia. |
|---|---|---|
| T2HB, TPHB | 13 min | ø5.5-8 |

- **Key lock (Optional)**
  Key locking is possible in the ON or OFF position.




∗ : Padlocking in OFF position only required by IEC 60204-1 is also available.
Please specify when ordering.

## ■Protection degree (IEC 60529)

Optional dust-proof gaskets may be used to protect against dust.

| | |
|---|---|
| IP30 | Standard specification |
| IP50 | Optional, with a dust proof packing |
| IP55 | Special specification ① |

Notes ① : For the depth of switchboard, take account of thickness of the packing.
See the Operating Instructions packaged with the product.

## ■To be stated when ordering

Order code T2HB12 U R 3 B T P

| Type of external operating handle | Breaker mounting direction | Panel lock | Protection degree | Colour | Key lock / Padlock | Series |
|---|---|---|---|---|---|---|
| T2HB12<br>T2HB25<br>T2HB40<br>T2HB80 | U : Upper power supply type (standard) ∗<br>R : Right power supply type<br>L : Left power supply type | R : RESET open ∗<br>F : OFF open | 3 : IP30 ∗<br>5 : IP50<br>S : IP55 (special spec.) | B : Black handle (Grey Blue base) ∗<br>R : Red handle (Yellow base) | T : with padlock (Lock in ON or OFF) ∗<br>W : with key lock and padlock (Lock in ON or OFF)<br>N : with padlock (lock in OFF)<br>K : with key lock and padlock (lock in OFF) | P : PRO Series ① |
| TPHB63S | | | | | | — |

∗ : Standard specification
Note ① : For T2HB, specify "P". Do not specify anything in the case of TPHB (blank).


## ■ Outline dimensions


H : Handle Frame Centre Line
℄ : Handle Centre Line


### T2HB12

| Applicable breaker types |
|---|
| S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF, ZS100-GF, ZS125-GF |

● Panel cutout dimensions









• Positions of the hinge and handle as seen from the load side of the breaker.
Ensure that the hinge is positioned in the ▨ area.


### T2HB25

| Applicable breaker types | A (mm) |
|---|---|
| ZAS225-GF, ZAS250-GF, ZS225-GF, ZS250-GF | 106±2 |
| H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF | 141±2 |

● Panel cutout dimensions





• Positions of the hinge and handle as seen from the load side of the breaker.
Ensure that the hinge is positioned in the ▨ area.

## ■ Outline dimensions


℄ : Handle Frame Centre Line
℄ : Handle Centre Line

### T2HB40


| Applicable breaker types | A (mm) | B (mm) |
|---|---|---|
| **E400-NF, ZAE400-NF, ZAS400-NF/GF, NE400-NF, NS400-NF, NAE400-NF, NAS400-NF, ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | 150±2 | 97 |
| **H400-NE, L400-NE** | 187±2 | 134 |




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker.
Ensure that the hinge is positioned in the ▨ area.





## ■ Outline dimensions

TPHB63S

| Applicable breaker types |
|---|
| PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE |

⊬ : Handle Frame Centre Line
℄ : Handle Centre Line








## ■ Outline dimensions

T2HB80

| Applicable breaker types | A (mm) |
|---|---|
| **S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NN, ZAS630-CF/NF, ZAS800-CF/NF, NS630-NF, NS800-NF, S800-NE/RE/PE, S1000-CE/NN, ZS630-CF, ZS630-NF, ZS800-CF, ZS800-NF** | 150±2 |
| **H630-NE, L630-NE, H800-NE, L800-NE** | 187±2 |

HL : Handle Frame Centre Line
℄ : Handle Centre Line







# 4. External operating handles

## (3) Breaker-mounted (HB)

The external operating handle is a tool that allows the breaker installed in a switchboard to be operated from outside.
The breaker-mounted type external operating handle is designed to be mounted directly to the breaker body.

### ■ Outer view [Colour: Black (Munsell N1.5)]




- **Double-insulated structure**
  All actuators are double insulated and employ an insulator to further enhance safety.

### ■ Mounting instructions


The external operating handle has not been mounted on the breakers.
For details on how to mount the handle, see the Operating Instructions packaged with the product.

#### [1] Mounting of external operating handle assembly

Install the circuit breakers and handles as follows.

1.1 Secured to backing plate (TFJ21BP)

- Make sure that the breaker is in the OFF position.
- Put the external operating handle assembly onto the breaker in place so that the breaker toggle is engaged with the slide lever of the assembly. Secure the assembly together with the breaker to the backing plate.






1.2 Secured to breaker cover (TFJ38X / T2HBX6)

- Make sure that the breaker is in the OFF position.
- Remove the four breaker cover mounting screws at the positions where the external operating handle assembly is secured.
- Put the handle assembly onto the breaker in place so that the breaker toggle is engaged with the slide lever of the assembly. Use the supplied mounting screws to secure the assembly to the breaker.

#### [2] Installation of handle escutcheon and latch plate




- Drill holes in the panel according to the panel cutout dimensions. Sandwich the panel between the handle escutcheon and latch plate and temporarily tighten using the supplied screws.
- Close the panel.
  Make adjustment so that the gap between the handle assembly and handle escutcheon is even and the assembly is not inclined against the breaker.




### ■ Breaker mounting direction

The ON (**I**) and OFF (O) indication of the external operating handle can be re-oriented in steps of 90 degrees with respect to the operating mechanism. This allows the indication position to remain the same whether the breaker is mounted vertically (right side up or upside down) or horizontally (on its left side or on its right side).
The upper power supply type is standard. If a non-standard type is required, state the type when ordering.

| R: Right power supply type | U: Upper power supply type (standard) | L: Left power supply type |
|---|---|---|
|  |  |  |





- For a change in mounting direction, see the Operating Instructions packaged with the product.


## ■Panel lock mechanism

The external operating handle keeps the panel door locked when in the 'ON' position. There are two types, RESET Open and OFF Open.

(1) **RESET Open (Standard type)**
The handle is turned to the RESET OPEN position to open the panel door.

(2) **OFF Open**
The handle is turned to the OFF position to open the panel door.

- **Panel lock release knob (Standard)**
  The release knob enables the panel door to be opened with the handle in the 'ON' position. To release: turn the release knob in the direction of anti-clockwise with a flat-bladed screwdriver.
- **Safety interlock (Standard)**
  The safety interlock prevents the breaker from turning ON as long as the panel is open. This interlock can be released using the hook lever.





## ■Toggle lock mechanism

- **Padlock (Standard)**
  This mechanism allows the breaker to be padlocked in the ON or OFF position.
  Padlocks are not supplied.
  Up to three padlocks can be installed.




Padlock dimensions (mm)

| Type of handle | A | Dia. |
|---|---|---|
| TFJ21BP | 13 min | ø3.5-6 |
| TFJ38X<br>T2HBX6 | 19 min | |





## ■Protection degree (IEC 60529)


Optional dust-proof gaskets may be used to protect against dust.

| | |
|---|---|
| IP30 | Standard specification |
| IP50 | Optional, with a dust proof packing |
| IP55 | Special specification |

Dustproof packing for IP50 (oprional) mm

| Type of handle | Type of dustproof packing | A | B | C |
|---|---|---|---|---|
| TFJ21BP | Dustproof packing/2 | 93 | 73 | 7 |
| TFJ38X | Dustproof packing/3 | 145 | 117 | 7 |
| T2HBX6 | | | | |




## ■ To be stated when ordering

Order code TFJ21BP U R 3 B

| Type of external operating handle | Breaker mounting direction | Panel lock | Protection degree | Colour |
|---|---|---|---|---|
| TFJ21BP<br>TFJ38X<br>T2HBX6 | U : Upper power supply type (standard) ∗<br>R : Right power supply type<br>L : Left power supply type | R : RESET open ∗<br>F : OFF open | 3 : IP30 ∗<br>5 : IP50<br>S : IP55 (special spec.) | B : Black handle (Black base) ∗<br>R : Red handle (Yellow base) |

∗ : Standard specification


## ■ Outline dimensions


ASL : Arrangement Standard Line
⋕ : Handle Frame Centre Line
℄ : Handle Centre Line

### TFJ38X


| Applicable breaker types | Mounting screw ∗ |
|---|---|
| TL-1000NE, TL-1200NE | M6 × 110 4 pcs |

∗ Secure the breaker to the switchboard before secure the operating handle to the breaker.






● Panel cutout dimensions




● Panel cutout dimensions Relative positions of the hinge and handle as seen from the load side of the breaker




Toggle extension for TFJ38X (optional)






| Order code |
|---|
| THC5 |

### T2HBX6


| Applicable breaker types | A (mm) | Mounting screw ∗ |
|---|---|---|
| S1250-NE/GE/NN | 197±2 | M6 × 110 4 pcs |
| S1600-NE/NN | 217±2 | |


∗ Secure the breaker to the switchboard before secure the operating handle to the breaker.








● Panel cutout dimensions




Toggle extension for T2HBX6 (optional)





| Order code |
|---|
| T2HAX6 |

# 4. External operating handles

## (4) Door-mounted (depth adjustable) (HP)


Door-mounted type external operating handles allow breakers installed in control centers or switchboards to be manually operated from outside and complies with IEC 60204-1.
This handle assembly consists of an operation mechanism section which is to be installed in the breaker body, a handle section which is to be installed in a panel and a square shaft which couples both the sections.

### ■ Outer view



### ■ Operation direction of handles


Rotate the operating handle
clockwise to turn the breaker ON.



Rotate clockwise
to turn the breaker ON

### ■ Breaker mounting direction

The ON (**I**) and OFF (○) indication of the external operating handle can be re-oriented in steps of 90 degrees with respect to the operating mechanism.
This allows the indication position to remain the same whether the breaker is mounted vertically (right side up or upside down) or horizontally (on its left side or on its right side).



# 4. External operating handles


## ■ Panel lock mechanism

The external operating handle keeps the panel door locked when in the 'ON' position. There are two types, RESET Open and OFF Open.

**(1) RESET Open (Standard type)**
The handle is turned to the RESET OPEN position to open the panel door.

**(2) OFF Open**
The handle is turned to the OFF position to open the panel door.

- Panel lock release knob (Standard)
  The release knob enables the panel door to be opened with the handle in the 'ON' position. To release: turn the release knob in the direction of anti-clockwise with a flat-bladed screwdriver.



## ■ Toggle lock mechanism

- **Padlock (Standard)**
  This mechanism allows the breaker to be padlocked in the ON or OFF position. ∗
  Padlocks are not supplied.
  Up to three padlocks can be installed.




Padlock dimensions (mm)

| Type of handle | A | Dia. |
|---|---|---|
| T1HP, T2HP, TPHP | 13 min | ø5.5-8 |

- **Key lock (Optional)**
  Key locking is possible in the ON or OFF position.


∗ : Padlocking in OFF position only required by IEC 60204-1 is also available.
Please specify when ordering.

## ■ Protection degree (IEC 60529)

| | |
|---|---|
| IP54 | Standard specification |
| IP65 | Special specification |

## ■ Dimensions of square shafts available

There are the following shaft dimensions available. Select an appropriate shaft depending on the mounting position of the breaker. Cut the shaft to an appropriate length if required. Coat the cut end faces of the shaft with an anti-corrosion paint.




| Shafts order codes | LA(mm) | LB(mm) |
|---|---|---|
| T2PS251 | 121 | 8 |
| T2PS252 | 221 | |
| T2PS253 | 321 | |
| T2PS254 | 421 | |
| T2PS401 | 147.5 | 14 |
| T2PS402 | 247.5 | |
| T2PS403 | 347.5 | |
| T2PS404 | 447.5 | |

## ■ To be stated when ordering

Order code T2HP25 R 5 B T P


| Type of external operating handle | Panel lock | Protection degree | Colour | Key lock / Padlock | Series |
|---|---|---|---|---|---|
| T2HP16L T2HP40<br>T2HP25L T2HP80<br>T2HP12 T2HPX6<br>T2HP25 | R : RESET open ∗<br>F : OFF open | 5 : IP54 ∗<br>6 : IP65 | B : Black handle (Grey Blue base) ∗<br>R : Red handle (Yellow base) | T : with padlock (Lock in ON or OFF) ∗<br>W : with key lock and padlock (Lock in ON or OFF)<br>N : with padlock (lock in OFF)<br>K : with key lock and padlock (lock in OFF) | P : PRO Series ① |
| TPHP16S TPHP63S<br>TPHP25S T1HPX6 ② | | | | | — |

∗ : standard specification
Note ① : For T2HP, specify "P". Do not specify anything in the case of T1HP or TPHP (blank).
Note ② : "Panel lock" is applied "RESET open" only.


HL : Handle Frame Centre Line
℄ : Handle Centre Line

## ■Outline dimensions


### TPHP16S




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the ▨ area.




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | 229 min. | 56 | 107 | 186 | T2PS251 | Yes |
| | 243 max. | 70 | 121 | 186 | | |
| | 343 max. | 170 | 221 | 186 | T2PS252 | |
| | 443 max. | 270 | 321 | 186 | T2PS253 | |
| | 543 max. | 370 | 421 | 186 | T2PS254 | |

**Notes:**

①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.


A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface

# 4. External operating handles


: Handle Frame Centre Line
: Handle Centre Line

## ■ Outline dimensions


TPHP25S




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the ▨ area.




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **PS250-PF/NN, PS250-NE/PE** | 229 min. | 56 | 107 | 186 | T2PS251 | Yes |
| | 243 max. | 70 | 121 | 186 | | |
| | 343 max. | 170 | 221 | 186 | T2PS252 | |
| | 443 max. | 270 | 321 | 186 | T2PS253 | |
| | 543 max. | 370 | 421 | 186 | T2PS254 | |

**Notes:**


①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.

A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface


℄ : Handle Frame Centre Line
℄ : Handle Centre Line

## ■Outline dimensions


### T2HP16L




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the ▨ area.




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **S50-SF, S125-SF, S125-SN, ZAS125-SF, NAE125-SF, NAS125-SF, NS125-SF, ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF, PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN, PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN** | 229 min. | 56 | 107 | 186 | T2PS251 | Yes |
| | 243 max. | 70 | 121 | 186 | | |
| | 343 max. | 170 | 221 | 186 | T2PS252 | |
| | 443 max. | 270 | 321 | 186 | T2PS253 | |
| | 543 max. | 370 | 421 | 186 | T2PS254 | |

**Notes:**

①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.


A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface

# 4. External operating handles


: Handle Frame Centre Line
: Handle Centre Line

## ■ Outline dimensions


T2HP25L




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the area.




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, NE250-SF, NS250-SF, ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF, NAE250-SF, NAS250-SF** | 229 min. | 56 | 107 | 186 | T2PS251 | Yes |
| | 243 max. | 70 | 121 | 186 | | |
| | 343 max. | 170 | 221 | 186 | T2PS252 | |
| | 443 max. | 270 | 321 | 186 | T2PS253 | |
| | 543 max. | 370 | 421 | 186 | T2PS254 | |


**Notes:**
①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.

A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface


: Handle Frame Centre Line
: Handle Centre Line


## ■Outline dimensions

### T2HP12




● Panel cutout dimensions




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF, ZS100-GF, ZS125-GF** | 229 min. | 56 | 107 | 186 | T2PS251 | Yes |
| | 243 max. | 70 | 121 | 186 | | |
| | 343 max. | 170 | 221 | 186 | T2PS252 | |
| | 443 max. | 270 | 321 | 186 | T2PS253 | |
| | 543 max. | 370 | 421 | 186 | T2PS254 | |

**Notes:**

①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.


A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface


# 4. External operating handles

: Handle Frame Centre Line
: Handle Centre Line


## ■ Outline dimensions

T2HP25





● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the area.




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **ZAS225-GF, ZAS250-GF, ZS225-GF, ZS250-GF** | 229 min. | 56 | 107 | 186 | T2PS251 | Yes |
| | 243 max. | 70 | 121 | 186 | | |
| | 343 max. | 170 | 221 | 186 | T2PS252 | |
| | 443 max. | 270 | 321 | 186 | T2PS253 | |
| | 543 max. | 370 | 421 | 186 | T2PS254 | |
| **H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF** | 264 min. | 56 | 107 | 221 | T2PS251 | |
| | 278 max. | 70 | 121 | 221 | | |
| | 378 max. | 170 | 221 | 221 | T2PS252 | |
| | 478 max. | 270 | 321 | 221 | T2PS253 | |
| | 578 max. | 370 | 421 | 221 | T2PS254 | |

**Notes:**


①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.

A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface


HL : Handle Frame Centre Line
℄ : Handle Centre Line

## ■Outline dimensions


### T2HP40




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the ▨ area.




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **E400-NF, ZAE400-NF, ZAS400-NF, ZAS400-GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF, ZE400-NF, ZS400-NF, ZS400-GF, ZNE400-NF, ZNS400-NF** | 270 min. | 12 | 107.5 | —— | T2PS401 | Non |
| | 310 max. ② | 52 | 147.5 | —— | | |
| | 340 min. ② | 10 | 177.5 | 261 | T2PS402 | Yes |
| | 410 max. | 80 | 247.5 | 261 | | |
| | 510 max. | 180 | 347.5 | 261 | T2PS403 | |
| | 610 max. | 280 | 447.5 | 261 | T2PS404 | |
| **H400-NE, L400-NE** | 307 min. | 12 | 107.5 | —— | T2PS401 | Non |
| | 347 max.③ | 52 | 147.5 | —— | | |
| | 377 min.③ | 10 | 177.5 | 298 | T2PS402 | Yes |
| | 447 max. | 80 | 247.5 | 298 | | |
| | 547 max. | 180 | 347.5 | 298 | T2PS403 | |
| | 647 max. | 280 | 447.5 | 298 | T2PS404 | |

**Notes:**

①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.

②: When dimension A is in a range of 310 mm to 340 mm, cut square shaft T2PS402 to an appropriate length and use the shaft without shaft support.

③: When dimension A is in a range of 347mm to 377mm, cut square shaft T2PS402 to an appropriate length and use the shaft without shaft support.


A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface

# 4. External operating handles


: Handle Frame Centre Line
: Handle Centre Line

## ■ Outline dimensions


TPHP63S




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the area.




| Applicable breaker types | A ① | B | C | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|
| **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | 270 min. | 12 | 107.5 | T2PS401 | Non |
| | 310 max. ② | 52 | 147.5 | | |
| | 340 min. ② | 10 | 177.5 | T2PS402 | Yes |
| | 410 max. | 80 | 247.5 | | |
| | 510 max. | 180 | 347.5 | T2PS403 | |
| | 610 max. | 280 | 447.5 | T2PS404 | |

**Notes:**

①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.


②: When dimension A is in a range of 310 mm to 340 mm, cut square shaft T2PS402 to an appropriate length and use the shaft without shaft support.

A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft


HL : Handle Frame Centre Line
℄ : Handle Centre Line

## ■Outline dimensions


### T2HP80




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the ▨ area.




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **S630-CF/NF/NE/GN,** | 270 min. | 12 | 107.5 | —— | T2PS401 | Non |
| **S800-CF/NF/RF/PF/NN,** | 310 max. ② | 52 | 147.5 | —— | | |
| **ZAS630-CF/NF, ZAS800-CF/NF,** | 340 min. ② | 10 | 177.5 | 261 | T2PS402 | Yes |
| **NS630-NF, NS800-NF,** | 410 max. | 80 | 247.5 | 261 | | |
| **S800-NE/RE/PE, S1000-CE/NN,** | 510 max. | 180 | 347.5 | 261 | T2PS403 | |
| **ZS630-CF, ZS630-NF,** | 610 max. | 280 | 447.5 | 261 | T2PS404 | |
| **ZS800-CF, ZS800-NF** | | | | | | |
| **H630-NE, L630-NE,** | 307 min. | 12 | 107.5 | —— | T2PS401 | Non |
| **H800-NE, L800-NE** | 347 max.③ | 52 | 147.5 | —— | | |
| | 377 min.③ | 10 | 177.5 | 298 | T2PS402 | Yes |
| | 447 max. | 80 | 247.5 | 298 | | |
| | 547 max. | 180 | 347.5 | 298 | T2PS403 | |
| | 647 max. | 280 | 447.5 | 298 | T2PS404 | |

**Notes:**

①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.

②: When dimension A is in a range of 310 mm to 340 mm, cut square shaft T2PS402 to an appropriate length and use the shaft without shaft support.

③: When dimension A is in a range of 347mm to 377mm, cut square shaft T2PS402 to an appropriate length and use the shaft without shaft support.

A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface

# 4. External operating handles


ASL : Arrangement Standard Line
⊢⊣ : Handle Frame Centre Line
℄ : Handle Centre Line

## ■ Outline dimensions


### T1HPX6, T2HPX6

| Type of external operating handle | Applicable breaker types |
|---|---|
| T2HPX6 | **S1250-NE/GE/NN, S1600-NE/NN** |
| T1HPX6 ② | **TL-1000NE, TL-1200NE** |


Note ②: "Panel lock" is apply "RESET open" only.




● Panel cutout dimensions




• Positions of the hinge and handle as seen from the load side of the breaker. Ensure that the hinge is positioned in the ▨ area.




| Applicable breaker types | A ① | B | C | D | Square shaft applicable | Shaft support |
|---|---|---|---|---|---|---|
| **S1250-NE/GE/NN** | 367 min. | 52 | 147.5 | — | T2PS401 | Non |
| | 467 max. | 80 | 247.5 | 317 | T2PS402 | Yes |
| | 567 max. | 180 | 347.5 | 317 | T2PS403 | |
| | 667 max. | 280 | 447.5 | 317 | T2PS404 | |
| **S1600-NE/NN, TL-1000NE, TL-1200NE** | 387 min. | 52 | 147.5 | — | T2PS401 | Non |
| | 487 max. | 80 | 247.5 | 337 | T2PS402 | Yes |
| | 587 max. | 180 | 347.5 | 337 | T2PS403 | |
| | 687 max. | 280 | 447.5 | 337 | T2PS404 | |

**Notes:**

①: "Min (minimum)" means the minimum possible distance from the panel surface to the breaker mounting surface, which can be formed by cutting the square shaft.
"Max (maximum)" means the maximum distance of the same section, which is formed with no cutting of the square shaft.

A: Distance from the panel surface to the breaker mounting surface
B: Length of the tube to cover the square shaft
C: Length of the square shaft
D: Distance from the tip of the shaft support to the breaker mounting surface

# 5. Mechanical interlock

The slide interlock provides a mechanical interlock between two breakers so that only one of the two can be closed. There are four types: slide type, rear-connected type, link type, and wire type.

## (1) Slide interlock (MS)

Moving the slide on the front of the breaker left and right allows activation or deactivation of the interlock.

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Breaker connection method ① | Interlock Order codes | A | B | C |
|---|---|---|---|---|---|---|---|---|
| 30 | **E30-NM, S30-NM** | **ZE30-NM, ZS30-NM** | 2 | FC | T2MS052NF | 85 | 42.5 | 83 |
| | | | 3 | FC | T2MS053NF | 110 | 55 | 108 |
| 50 | **E50-NM, S50-NM** | **ZE50-NM, ZS50-CM** | 2 | FC | T2MS052NF | 85 | 42.5 | 83 |
| | | | 3 | FC | T2MS053NF | 110 | 55 | 108 |
| 100 | **E100-NM** | **ZE100-NM** | 2 | FC | T2MS052NF | 85 | 42.5 | 83 |
| | | | 3 | FC | T2MS053NF | 110 | 55 | 108 |

**Notes:**


①: In the case of RC, the interlock device is mounted on the surface of the breaker cover and the parts are different. Please contact us for details.

(1): The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.


(2): UVT cannot be fitted to the left circuit breaker.

H : Handle Frame Centre Line

℄ : Handle Centre Line




### Drilling plan (front view)



## (1) Slide interlock (MS)


H : Handle Frame Centre Line
℄ : Handle Centre Line

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|---|
| 50, 60, 100, 125 | **S50-SF, S125-SF, S125-SN, ZAS125-SF, NS125-SF** | **ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF** | 3 | FC, RC | T2MS16L3SF |
| | | | 4 | FC, RC | T2MS16L4SF |
| | **PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN** | 3 | FC, RC | T2MS16L3SF |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.


### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)





### Drilling plan (front view)



| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 30, 50, 60, 100, 125 | **S50-SF** | 3 | PMC | T2MS16L3SC |
| | **S125-SF, S125-SN** | | | |
| | **PE30-NF/NN, PS30-NF** | | | |
| | **PE50-NF/NN** | | | |
| | **PS50-NF, PE60-NF, PS60-NF** | | | |
| | **PE125-NF/NN** | | | |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.


### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.


### Panel cutout, B (front view)




### Drilling plan (front view)



## (1) Slide interlock (MS)

⊬ : Handle Frame Centre Line
℄ : Handle Centre Line


### Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 50, 100, 125 | **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | 3 | FC、RC | TPMS163SF |
| | | 4 | FC、RC | TPMS164SF |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.


### Panel cutout, A (front view)






### Drilling plan (front view)






### Panel cutout, B (front view)



HL : Handle Frame Centre Line
℄ : Handle Centre Line

## Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 50, 100, 125 | **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | 3 | PMB | TPMS163SP |
| | | 4 | PMB | TPMS164SP |

**Notes:**


1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.

2: UVT with time-delay cannot be fitted to the left circuit breaker.


3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

### Panel cutout, A (front view)


The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.






### Drilling plan (front view)






### Panel cutout, B (front view)



## (1) Slide interlock (MS)


Handle Frame Centre Line
Handle Centre Line

### Dimensions, mm


| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 50, 100, 125 | **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | 3 | PMC | TPMS163SC |

**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

Panel cutout, A (front view)






Panel cutout, B (front view)




The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

Drilling plan (front view)




HL : Handle Frame Centre Line
℄ : Handle Centre Line


## Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|---|
| 100, 125 | **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | 3 | FC, RC | T2MS123SF |
| | | | 4 | FC, RC | T2MS124SF |

**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.


## Panel cutout, A (front view)










The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.


## Panel cutout, B (front view)

















## Drilling plan (front view)



## (1) Slide interlock (MS)


⊬ : Handle Frame Centre Line
℄ : Handle Centre Line

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 100, 125 | **S100-GF, S125-GF** | 3 | PMB | T2MS123SP |
| | | 4 | PMB | T2MS124SP |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.


### Panel cutout, A (front view)






The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)




℄ : Handle Frame Centre Line
℄ : Handle Centre Line

## Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 100, 125 | **S100-GF, S125-GF** | 3 | PMC | T2MS123SC |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.


### Panel cutout, A (front view)






The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)



## (1) Slide interlock (MS)


: Handle Frame Centre Line
: Handle Centre Line

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|---|
| 225, 250 | **E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF, NE250-SF, NS250-SF** | **ZE250-SF, ZS250-SF, ZS250-SM, ZNE250-SF, ZNS250-SF** | 3 | FC, RC | T2MS25L3SF |
| | | | 4 | FC, RC | T2MS25L4SF |


**Notes:**
1: If the insulation distance is insufficient due to the front-connected extension bars, be sure to insulate with insulating tape or the like.
2: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
3: UVT with time-delay cannot be fitted to the left circuit breaker.

### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)




℄ : Handle Frame Centre Line
℄ : Handle Centre Line

## Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 225, 250 | **E250-SF, S250-SF, S250-SN** | 3 | PMC | T2MS25L3SC |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.

### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)



## (1) Slide interlock (MS)

H : Handle Frame Centre Line
℄ : Handle Centre Line


### Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 225, 250 | **PS250-PF/NN, PS250-NE/PE** | 3 | FC、RC | TPMS253SF |
| | | 4 | FC、RC | TPMS254SF |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.


### Panel cutout, A (front view)






### Drilling plan (front view)






### Panel cutout, B (front view)



: Handle Frame Centre Line
: Handle Centre Line

## Dimensions, mm


| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 225, 250 | **PS250-PF/NN, PS250-NE/PE** | 3 | PMB | TPMS253SP |
| | | 4 | PMB | TPMS254SP |

**Notes:**


1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

### Panel cutout, A (front view)


The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.






### Drilling plan (front view)






### Panel cutout, B (front view)



## (1) Slide interlock (MS)


Handle Frame Centre Line
Handle Centre Line

### Dimensions, mm


| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 225, 250 | **PS250-PF/NN, PS250-NE/PE** | 3 | PMC | TPMS253SC |

**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

### Panel cutout, A (front view)






### Panel cutout, B (front view)




The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Drilling plan (front view)



H : Handle Frame Centre Line
℄ : Handle Centre Line

## Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Breaker connection method | Interlock Order codes | Panel cutout, A (mm) | Panel cutout, B (mm) | C (mm) |
|---|---|---|---|---|---|---|---|---|
| 100<br>125 | **H100-NF, H125-NF,<br>L100-NF, L125-NF** | | 3 | FC, RC | T2MS253LF | 103 | 107 | 126.7 |
| | | | 4 | FC, RC | T2MS254LF | | | |
| 225<br>250 | **ZAS225-GF, ZAS250-GF** | **ZS225-GF, ZS250-GF** | 3 | FC, RC | T2MS253SF | 68 | 72 | 91.7 |
| | | | 4 | FC, RC | T2MS254SF | | | |
| | **H225-NF/NE, H250-NF,<br>L225-NF, L250-NF** | | 3 | FC, RC | T2MS253LF | 103 | 107 | 126.7 |
| | | | 4 | FC, RC | T2MS254LF | | | |


**Notes:**

1: If the insulation distance is insufficient due to the front-connected extension bars, be sure to insulate with insulating tape or the like.

2: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.


3: UVT with time-delay cannot be fitted to the left circuit breaker.

### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)



## (1) Slide interlock (MS)


: Handle Frame Centre Line
: Handle Centre Line

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 100, 125 | **H100-NF, L100-NF H125-NF, L125-NF** | 3 | PMB | T2MS253LP |
| | | 4 | PMB | T2MS254LP |
| 225 | **H225-NF, L225-NF** | 3 | PMB | T2MS253LP |
| | | 4 | PMB | T2MS254LP |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.


### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.


### Panel cutout, B (front view)



### Drilling plan (front view)



℄ : Handle Frame Centre Line
℄ : Handle Centre Line

## Dimensions, mm


| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 100, 125 | **H100-NF, L100-NF**<br>**H125-NF, L125-NF** | 3 | PMC | T2MS253LC |
| 225 | **H225-NF, L225-NF** | 3 | PMC | T2MS253LC |

**Notes:**

1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.


2: UVT with time-delay cannot be fitted to the left circuit breaker.


### Panel cutout, A (front view)






The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)





### Drilling plan (front view)



## (1) Slide interlock (MS)

Handle Frame Centre Line
Handle Centre Line


Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 400 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE** | 3 | FC、RC | TPMS633SF |
| | | 4 | FC、RC | TPMS634SF |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | 3 | FC、RC | TPMS633SF |
| | | 4 | FC、RC | TPMS634SF |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

### Panel cutout, A (front view)


The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.






### Drilling plan (front view)






### Panel cutout, B (front view)



: Handle Frame Centre Line
: Handle Centre Line

## Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 400 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE** | 3 | PMB | TPMS633SP |
| | | 4 | PMB | TPMS634SP |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | 3 | PMB | TPMS633SP |
| | | 4 | PMB | TPMS634SP |

**Notes:**


1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.

2: UVT with time-delay cannot be fitted to the left circuit breaker.


3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.


## Panel cutout, A (front view)


The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.





## Panel cutout, B (front view)



## (1) Slide interlock (MS)

HL : Handle Frame Centre Line
℄ : Handle Centre Line


Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 400 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE** | 3 | PMC | TPMS633SC |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | 3 | PMC | TPMS633SC |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

### Panel cutout, A (front view)


The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.






### Drilling plan (front view)




### Panel cutout, B (front view)



: Handle Frame Centre Line
: Handle Centre Line


## Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Breaker connection method | Interlock Order codes | Panel cutout, A (mm) | Panel cutout, B (mm) | C (mm) |
|---|---|---|---|---|---|---|---|---|
| 400 | **E400-NF, ZAE400-NF, ZAS400-NF/GF, NE400-NF, NS400-NF** | **ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | 3 | FC, RC | T2MS403SF | 103 | 107 | 135.5 |
| | | | 4 | FC, RC | T2MS404SF | | | |
| | **H400-NE, L400-NE** | | 3 | FC, RC | T2MS403LF | 140 | 144 | 172.5 |
| | | | 4 | FC, RC | T2MS404LF | | | |

**Notes:**


1: If the insulation distance is insufficient due to the front-connected extension bars, be sure to insulate with insulating tape or the like.
2: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
3: UVT with time-delay cannot be fitted to the left circuit breaker.
4: Wide terminal covers can not be fitted to interfere with each other. Straight terminal covers can be fitted.
5: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.


### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)



## (1) Slide interlock (MS)


H : Handle Frame Centre Line
℄ : Handle Centre Line

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 400 | **H400-NE, L400-NE** | 3 | PMB | T2MS403LP |
| | | 4 | PMB | T2MS404LP |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: Wide terminal covers can not be fitted to interfere with each other. Straight terminal covers can be fitted.
4: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.


### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)



℄ : Handle Frame Centre Line
℄ : Handle Centre Line


## Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes |
|---|---|---|---|---|
| 400 | **H400-NE, L400-NE** | 3 | PMC | T2MS403LC |

**Notes:**


1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: Wide terminal covers can not be fitted to interfere with each other. Straight terminal covers can be fitted.
4: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.


### Panel cutout, A (front view)






The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)





### Drilling plan (front view)



## (1) Slide interlock (MS)


### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Breaker connection method | Interlock Order codes | Panel cutout, A (mm) | Panel cutout, B (mm) | C (mm) |
|---|---|---|---|---|---|---|---|---|
| 600, 630, 800, 1000 | **S630-CF/NF/NE/GN, S800-CF/NF/NE/RF/RE/PF/PE/NN, ZAS630-CF/NF, ZAS800-CF/NF, NS630-NF, NS800-NF, S1000-CE/NN** | **ZS630-CF/NF, ZS800-CF/NF** | 3 | FC, RC | T2MS803SF | 103 | 107 | 135.5 |
| | | | 4 | FC, RC | T2MS804SF | | | |
| | **H630-NE, H800-NE, L630-NE, L800-NE** | — | 3 | FC, RC | T2MS803LF | 140 | 144 | 172.5 |
| | | | 4 | FC, RC | T2MS804LF | | | |


**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.


ASL : Arrangement Standard Line
H : Handle Frame Centre Line

### Panel cutout, A (front view)





### Panel cutout, B (front view)




### Drilling plan (front view)



## Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes | Panel cutout, A (mm) | Panel cutout, B (mm) | C (mm) |
|---|---|---|---|---|---|---|---|
| 600, 630, 800 | **S630-CF/NF/NE/GN S800-CF/NF/NE/RF/RE/PF/PE/NN** | 3 | PMB | T2MS803SP | 154.6 | 158.6 | 187 |
| | | 4 | PMB | T2MS804SP | | | |
| | **H630-NE, H800-NE, L630-NE, L800-NE** | 3 | PMB | T2MS803LP | 191.6 | 195.6 | 224 |
| | | 4 | PMB | T2MS804LP | | | |

**Notes:**

1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.


2: UVT with time-delay cannot be fitted to the left circuit breaker.

3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.

ASL : Arrangement Standard Line


H : Handle Frame Centre Line

### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)



## (1) Slide interlock (MS)


### Dimensions, mm

| Frame size (A) | Types of MCCBs | Number of poles | Breaker connection method | Interlock Order codes | Panel cutout, A (mm) | Panel cutout, B (mm) | C (mm) |
|---|---|---|---|---|---|---|---|
| 600, 630, 800 | **S630-CF/NF/NE/GN S800-CF/NF/NE/RF/RE/PF/PE/NN** | 3 | PMC | T2MS803SC | 121 | 125 | 153.5 |
| | **H630-NE, H800-NE, L630-NE, L800-NE** | 3 | PMC | T2MS803LC | 158 | 162 | 190.5 |

**Notes:**
1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.
3: For high-performance electronic smart circuit breakers, the panel cutout dimensions will vary. Please contact us for details.


ASL : Arrangement Standard Line
H : Handle Frame Centre Line


### Panel cutout, A (front view)





The cutout dimensions allow for a side clearance of 1.0mm from the bank of the breaker.

### Panel cutout, B (front view)




### Drilling plan (front view)



## Dimensions, mm

| Frame size (A) | Types of MCCBs | Interlock Order codes | Number of poles | a | b | c | d | e | f | g | h | k | m | ℓ | R |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 1000, 1200, 1250 | **S1250-NE/GE/NN** | **T2MSX63SF** | 3 | 220 | 340 | 124.5 | 61.5 | 343 | 53.5 | 74 | 127.5 | 430 | 159.2 | 30 | 8.5 |
| | | **T2MSX64SF** | 4 | 290 | 410 | 124.5 | 61.5 | 413 | 53.5 | 74 | 127.5 | 570 | 159.2 | 30 | 8.5 |
| | **TL-1000NE, TL-1200NE** | **XLF9** ① | 3 | 220 | 340 | 129 | 61.5 | 343 | 58 | 74 | 132 | 430 | 179.6 | 30 | 8.5 |
| | | | 4 | 290 | 410 | 129 | 61.5 | 413 | 58 | 74 | 132 | 570 | 179.6 | 30 | 8.5 |
| 1600 | **S1600-NE/NN** | **T2MSX63SF** | 3 | 220 | 340 | 124.5 | 61.5 | 343 | 53.5 | 74 | 127.5 | 430 | 179.2 | 30 | 8.5 |
| | | **T2MSX64SF** | 4 | 290 | 410 | 124.5 | 61.5 | 413 | 53.5 | 74 | 127.5 | 570 | 179.2 | 30 | 8.5 |

**Notes:**

①: Please order with the breakers.

1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.


2: The UVT controller or the OCR controller may be required to be installed external to the breaker.

3: See the outline dimensions of the breaker of chapter 7 for the drilling plan.

ASL : Arrangement Standard Line

⊬⊢ : Handle Frame Centre Line

## Panel cutout (front view)



# 5. Mechanical interlock


ASL : Arrangement Standard Line
H : Handle Frame Centre Line

## (2) Rear-connected interlock (MB)


### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes | A (mm) |
|---|---|---|---|---|
| 1000, 1200 | **TL-1000NE, TL-1200NE** | — | Factory-installed | ① |
| 1250 | **S1250-NE/GE/NN** | — | Factory-installed | 120 |
| 1600 | **S1600-NE/NN** | — | Factory-installed | 140 |
| 2000 | **XS2000NE, XS2000NN** | — | Factory-installed | ① |
| 2500, 3200 | **XS2500NE, XS2500NN, XS3200NE (3P only), XS3200NN (3P only)** | — | Factory-installed | ① |

**Notes:**
①: Contact us for the detailed dimensions.
1: Not applicable for plug-in.
2: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
3: The UVT controller or the OCR controller may be required to be installed external to the breaker.




### Drilling plan




## (3) Link Interlock (ML)


A type that interlocks the left and right circuit breakers with a link bar. It requires little space and is very easy to install.


### Dimensions, mm


| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes |
|---|---|---|---|---|---|
| 50, 100, 125 | **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | — | 3 | Right | Factory-installed |
| | | | 4 | | |
| | | | 3 | Left | Factory-installed |
| | | | 4 | | Factory-installed |


**Notes:**
1: The lead wire terminal block cannot be fitted to either side of the left circuit breaker or to the left-hand side of the right circuit breaker.
2: UVT with time-delay cannot be fitted to the left circuit breaker.









: Handle Frame Centre Line
: Handle Centre Line


## (3) Link Interlock (ML)


### Dimensions, mm


| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes |
|---|---|---|---|---|---|
| 225, 250 | **PS250-PF/NN, PS250-NE/PE** | — | 3 | Right | Factory-installed |
| | | | 4 | | |
| | | | 3 | Left | Factory-installed |
| | | | 4 | | Factory-installed |


**Notes:**
1: The extention bars for front connection cannot be applied due to insufficient insulation distance.
2: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
3: UVT with time-delay cannot be fitted to the left circuit breaker.









## Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes |
|---|---|---|---|---|---|
| 100, 125 | **S100-GF, S125-GF** | — | 3 | Right | Factory-installed |
| | | | 4 | | |
| | | | 3 | Left | Factory-installed |
| | | | 4 | | Factory-installed |

**Notes:**

1: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.

2: UVT with time-delay cannot be fitted to the left circuit breaker.




⊬ : Handle Frame Centre Line
℄ : Handle Centre Line


## (3) Link Interlock (ML)


### Dimensions, mm


| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes |
|---|---|---|---|---|---|
| 225, 250 | **E250-SF, S250-SF, S250-SM, S250-SN** | — | 3 | Right | Factory-installed |
| | | | 4 | | |
| | | | 3 | Left | Factory-installed |
| | | | 4 | | Factory-installed |


**Notes:**
1: The extention bars for front connection cannot be applied due to insufficient insulation distance.
2: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
3: UVT with time-delay cannot be fitted to the left circuit breaker.












## Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes |
|---|---|---|---|---|---|
| 100, 125, 225, 250 | **H100-NF, L100-NF, H125-NF, L125-NF, H225-NF/NE, L225-NF, H250-NF, L250-NF** | — | 3 | Right | Factory-installed |
| | | | 4 | | |
| | | | 3 | Left | Factory-installed |
| | | | 4 | | Factory-installed |

**Notes:**

1: The extention bars for front connection cannot be applied due to insufficient insulation distance.
2: The terminal block can not be fitted to the right-hand side of the left breaker and to the left-hand side of the right breaker.
3: UVT with time-delay cannot be fitted to the left circuit breaker.



⊬ : Handle Frame Centre Line
℄ : Handle Centre Line


## (3) Link Interlock (ML)

### With motor operators

**Dimensions, mm**

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes |
|---|---|---|---|---|---|
| 400 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF,PH400-CE** | — | 3 | Right | Factory-installed |
| | | | 4 | | |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF,PH630-CE** | | 3 | Left | Factory-installed |
| | | | 4 | | Factory-installed |

**Notes:**
1: The extention bars for front connection cannot be applied due to insufficient insulation distance.
2: Due to space limitations between the circuit breakers, the lead wire terminal block can only be fitted to either the right-hand side of the left breaker or the left-hand side of the right breaker.
3: Terminal covers cannot be fitted because they would interfere with each other.
4: The 400AF to 630AF link type interlock are only available with either the motor operator or external operating handle.
5: The interlock device is shipped installed to the breaker.




## With external operating handle

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes |
|---|---|---|---|---|---|
| 400 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF,PH400-CE** | — | 3 | Right | Factory-installed |
| | | | 4 | | |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF,PH630-CE** | | 3 | Left | Factory-installed |
| | | | 4 | | Factory-installed |

**Notes:**

1: The extention bars for front connection cannot be applied due to insufficient insulation distance.
2: Due to space limitations between the circuit breakers, the lead wire terminal block can only be fitted to either the right-hand side of the left breaker or the left-hand side of the right breaker.
3: Terminal covers cannot be fitted because they would interfere with each other.
4: The 400AF to 630AF link type interlock are only available with either the motor operator or external operating handle.
5: The interlock device is shipped installed to the breaker. The external operating handle is supplied separately.



: Handle Frame Centre Line
℄ : Handle Centre Line


## (3) Link Interlock (ML)


### With motor operators


#### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes | A (mm) |
|---|---|---|---|---|---|---|
| 400 | **E400-NF** | — | 3 | Right | Factory-installed | 213 |
| | | | 3 | Left | Factory-installed | |
| | **H400-NE, L400-NE** | — | 3 | Right | Factory-installed | 250 |
| | | | 4 | | | |
| | | | 3 | Left | Factory-installed | |
| | | | 4 | | Factory-installed | |

**Notes:**
1: The extention bars for front connection cannot be applied due to insufficient insulation distance.
2: Due to space limitations between the circuit breakers, the lead wire terminal block can only be fitted to either the right-hand side of the left breaker or the left-hand side of the right breaker.
3: Terminal covers cannot be fitted because they would interfere with each other.
4: The 400AF link type interlock is only available with either the motor operator or external operating handle.
5: The interlock device is shipped installed to the breaker.



℄ : Handle Frame Centre Line
℄ : Handle Centre Line


## With external operating handle


### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes | A (mm) | B (mm) |
|---|---|---|---|---|---|---|---|
| 400 | **E400-NF** | — | 3 | Right | Factory-installed | 200 | 150±2 |
| | | | 3 | Left | Factory-installed | | |
| | **H400-NE, L400-NE** | — | 3 | Right | Factory-installed | 237 | 187±2 |
| | | | 4 | | | | |
| | | | 3 | Left | Factory-installed | | |
| | | | 4 | | Factory-installed | | |

**Notes:**

1: The extention bars for front connection cannot be applied due to insufficient insulation distance.
2: Due to space limitations between the circuit breakers, the lead wire terminal block can only be fitted to either the right-hand side of the left breaker or the left-hand side of the right breaker.
3: Terminal covers cannot be fitted because they would interfere with each other.
4: The 400AF link type interlock is only available with either the motor operator or external operating handle.
5: The interlock device is shipped installed to the breaker. The external operating handle is supplied separately.



⊬ : Handle Frame Centre Line
℄ : Handle Centre Line


## (3) Link Interlock (ML)


### With motor operators


**Dimensions, mm**

| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes | A (mm) | B (mm) |
|---|---|---|---|---|---|---|---|
| 600<br>630,<br>800,<br>1000 | **S630-CF/NF/NE/GN,<br>S800-CF/NF/NE/RF/RE/PF/PE/NN,<br>S1000-CE/NN** | — | 3 | Right | Factory-installed | 213 | 156.5 |
| | | | 4 | | | | |
| | | | 3 | Left | Factory-installed | | |
| | | | 4 | | Factory-installed | | |
| | **H630-NE, H800-NE,<br>L630-NE, L800-NE** | — | 3 | Right | Factory-installed | 250 | 193.5 |
| | | | 4 | | | | |
| | | | 3 | Left | Factory-installed | | |
| | | | 4 | | Factory-installed | | |

**Notes:**
1: Due to space limitations between the circuit breakers, the lead wire terminal block can only be fitted to either the right-hand side of the left breaker or the left-hand side of the right breaker.
2: The 630AF to 1000AF link type interlock are only available with the motor operator or external operating handle.
3: The interlock device is shipped installed to the breaker.



## With external operating handle

### Dimensions, mm


| Frame size (A) | Types of MCCBs | Types of ELCBs | Number of poles | Position | Interlock Order codes | A (mm) | B (mm) |
|---|---|---|---|---|---|---|---|
| 600<br>630,<br>800,<br>1000 | **S630-CF/NF/NE/GN,**<br>**S800-CF/NF/NE/RF/RE/PF/PE/NN,**<br>**S1000-CE/NN** | — | 3 | Right | Factory-installed | 200 | 150 |
| | | | 4 | | | | |
| | | | 3 | Left | Factory-installed | | |
| | | | 4 | | Factory-installed | | |
| | **H630-NE, H800-NE,**<br>**L630-NE, L800-NE** | — | 3 | Right | Factory-installed | 237 | 187 |
| | | | 4 | | | | |
| | | | 3 | Left | Factory-installed | | |
| | | | 4 | | Factory-installed | | |


**Notes:**


1: Due to space limitations between the circuit breakers, the lead wire terminal block can only be fitted to either the right-hand side of the left breaker or the left-hand side of the right breaker.

2: The 630AF to 1000AF link type interlock are only available with either the motor operator or external operating handle.

3: The interlock device is shipped installed to the breaker. The external operating handle is supplied separately.



# 5. Mechanical interlock

: Handle Frame Centre Line
: Handle Centre Line

## (4) Wire interlock (MW)

A type that interlocks the left and right circuit breakers with a wire. It is possible to interlock between circuit breakers of different sizes.


**Dimensions, mm**


| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 50, 100, 125 | **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | — | Factory-installed |


| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| TPMW00S(1m) | 140min.-480max. | 170min.-480max. |
| TPMW00L(1.5m) | 140min.-980max. | 170min.-980max. |

**Note:**

1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.



: Handle Frame Centre Line
: Handle Centre Line


## Dimensions, mm


| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 225, 250 | **PS250-PF/NN, PS250-NE/PE** | — | Factory-installed |


| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| TPMW00S(1m) | 155min.-480max. | 180min.-480max. |
| TPMW00L(1.5m) | 155min.-980max. | 180min.-980max. |


**Note:**


1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.









6 Accessories

: Handle Frame Centre Line
: Handle Centre Line


## (4) Wire interlock (MW)


### Dimensions, mm


| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 100, 125 | **S100-GF, S125-GF** | — | Factory-installed |

| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| T2MW00S(1m) | 130min.-480max. | 160min.-480max. |
| T2MW00L(1.5m) | 130min.-980max. | 160min.-980max. |

**Note:**
1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.




## Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 225, 250 | **E250-SF, S250-SF, S250-SM, S250-SN** | — | Factory-installed |

| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| T2MW00S(1m) | 155min.-480max. | 180min.-480max. |
| T2MW00L(1.5m) | 155min.-980max. | 180min.-980max. |

**Note:**

1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.



⊬ : Handle Frame Centre Line
℄ : Handle Centre Line


## (4) Wire interlock (MW)


### Dimensions, mm


| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 100, 125, 225, 250 | **H100-NF, L100-NF, H125-NF, L125-NF, H225-NF/NE, L225-NF, H250-NF, L250-NF** | — | Factory-installed |

| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| T2MW00S(1m) | 155min.-480max. | 180min.-480max. |
| T2MW00L(1.5m) | 155min.-980max. | 180min.-980max. |

**Note:**
1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.



: Handle Frame Centre Line
: Handle Centre Line

## With motor operators

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 400 | **E400-NF** | — | Factory-installed |


| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| T2MW00S(1m) | 180min.-430max. | 225min.-430max. |
| T2MW00L(1.5m) | 180min.-930max. | 225min.-930max. |

**Notes:**

1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.

2: The 400AF Wire interlock is only available with either the motor operator or external operating handle.

3: The interlock device is shipped installed to the breaker.



: Handle Frame Centre Line
: Handle Centre Line

## (4) Wire interlock (MW)


### With external operating handle

**Dimensions, mm**

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 400 | **E400-NF** | — | Factory-installed |

| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| T2MW00S(1m) | 180min.-430max. | 225min.-430max. |
| T2MW00L(1.5m) | 180min.-930max. | 225min.-930max. |

**Notes:**
1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.
2: The 400AF Wire interlock is only available with either the motor operator or external operating handle.
3: The interlock device is shipped installed to the breaker. The external operating handle is supplied separately.



: Handle Frame Centre Line
: Handle Centre Line

## With motor operators

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 400 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE** | — | Factory-installed |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | | |


| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| TPMW00S(1m) | 180min.-430max. | 225min.-430max. |
| TPMW00L(1.5m) | 180min.-930max. | 225min.-930max. |

**Notes:**

1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.

2: The 400AF to 630AF Wire interlock are only available with either the motor operator or external operating handle.

3: The interlock device is shipped installed to the breaker.



⊬ : Handle Frame Centre Line
℄ : Handle Centre Line

## (4) Wire interlock (MW)

### With external operating handle


**Dimensions, mm**

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 400 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF,PH400-CE** | — | Factory-installed |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF,PH630-CE** | | |

| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| TPMW00S(1m) | 180min.-430max. | 225min.-430max. |
| TPMW00L(1.5m) | 180min.-930max. | 225min.-930max. |

**Notes:**

1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.
2: The 400AF to 630AF Wire interlock are only available with either the motor operator or external operating handle.
3: The interlock device is shipped installed to the breaker. The external operating handle is supplied separately.



: Handle Frame Centre Line
: Handle Centre Line

## With motor operators

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 400 | **H400-NE, L400-NE** | — | Factory-installed |


| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| T2MW00S(1m) | 180min.-430max. | 225min.-430max. |
| T2MW00L(1.5m) | 180min.-930max. | 225min.-930max. |

**Notes:**

1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.

2: The 400AF Wire interlock is only available with either the motor operator or external operating handle.

3: The interlock device is shipped installed to the breaker.



⊬ : Handle Frame Centre Line
℄ : Handle Centre Line

## (4) Wire interlock (MW)


### With external operating handle

**Dimensions, mm**

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 400 | **H400-NE**, **L400-NE** | — | Factory-installed |

| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| T2MW00S(1m) | 180min.-430max. | 225min.-430max. |
| T2MW00L(1.5m) | 180min.-930max. | 225min.-930max. |

**Notes:**
1: The lead wire terminal block cannot be fitted to the left-hand side of the circuit breaker because it would interfere with the interlock device.
2: The 400AF Wire interlock is only available with either the motor operator or external operating handle.
3: The interlock device is shipped installed to the breaker. The external operating handle is supplied separately.



: Handle Frame Centre Line
: Handle Centre Line

## With motor operators

### Dimensions, mm


| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes | A (mm) | B (mm) | C (mm) |
|---|---|---|---|---|---|---|
| 600, 630, 800, 1000 | **S630-CF/NF/NE/GN, S800-CF/NF/NE/RF/RE/PF/PE/NN, S1000-CE/NN** | — | Factory-installed | 213 | 124.5 | 156.5 |
| | **H630-NE, H800-NE, L630-NE, L800-NE** | — | Factory-installed | 250 | 161.5 | 193.5 |

| Interlock wire order codes (length) | D (mm) | E (mm) |
|---|---|---|
| T2MW00S(1m) | 250min.-430max. | 320min.-430max. |
| T2MW00L(1.5m) | 250min.-930max. | 320min.-930max. |


**Notes:**


1: The 630AF to 1000AF Wire interlock are only available with either the motor operator or external operating handle.

2: The interlock device is shipped installed to the breaker.




Wire:Outside dia. ø5
Length 1m or 1.5m



⊬ : Handle Frame Centre Line
℄ : Handle Centre Line

## (4) Wire interlock (MW)


### With external operating handle

**Dimensions, mm**

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes | A (mm) | B (mm) |
|---|---|---|---|---|---|
| 600, 630, 800, 1000 | **S630-CF/NF/NE/GN, S800-CF/NF/NE/RF/RE/PF/PE/NN, S1000-CE/NN** | — | Factory-installed | 200 | 150±2 |
| | **H630-NE, H800-NE, L630-NE, L800-NE** | — | Factory-installed | 237 | 187±2 |

| Interlock wire order codes (length) | C (mm) | D (mm) |
|---|---|---|
| T2MW00S(1m) | 250min.-430max. | 320min.-430max. |
| T2MW00L(1.5m) | 250min.-930max. | 320min.-930max. |

**Notes:**
1: The 630AF to 1000AF Wire interlock are only available with either the motor operator or external operating handle.
2: The interlock device is shipped installed to the breaker. The external operating handle is supplied separately.




ASL : Arrangement Standard Line


⊬ : Handle Frame Centre Line


### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 1250 | **S1250-NE/GE/NN** | — | Factory-installed |


| Interlock wire order codes (length) | P (mm) | L (mm) |
|---|---|---|
| 1m | 650-500-350 | 450-500-530 ±30 |
| 1.5m | 1000-900-750 | 550-600-700 ±30 |









### Vertical installation




### Drilling plan




### Horizontal installation




ASL : Arrangement Standard Line
⊬ : Handle Frame Centre Line


## (4) Wire interlock (MW)


**Dimensions, mm**


| Frame size (A) | Types of MCCBs | Types of ELCBs | Interlock Order codes |
|---|---|---|---|
| 1600 | **S1600-NE/NN** | — | Factory-installed |


| Interlock wire order codes (length) | P (mm) | L (mm) |
|---|---|---|
| 1m | 650-500-350 | 450-500-530 ±30 |
| 1.5m | 1000-900-750 | 550-600-700 ±30 |
















**Vertical installation**





**Drilling plan**




**Horizontal installation**



# 6. Toggle holder (HH) and toggle lock (HL)

## Toggle holder (HH)

Simply fitting the toggle holder onto the breaker toggle disables breaker operation without using padlocks.

## Toggle lock (HL)

The toggle lock is a tool that locks the breaker ON or OFF. When an overcurrent occurs, the breaker will trip even if the breaker toggle is locked in the ON position. (Use commercially available padlocks).

### Toggle holders/toggle locks

| Frame size (A) | Type of breaker | | Toggle holder | | Figure | Toggle lock | | Figure |
|---|---|---|---|---|---|---|---|---|
| | MCCB | ELCB | Order codes | Marking codes | | Order codes | Marking codes | |
| 30, 50, 60, 100 | **E30-NM, S30-NM, E50-NM, S50-NM, E100-NM** | **ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM** | T2HL05 ① | BZ6L10C | — | T2HL05 | BZ6L10C | 3 |
| | **PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN** | TPHH12K | — | 10 | TPHL12K | — | 11 |
| 50, 100, 125, 225, 250 | **S50-SF, S125-SF, S125-SN, ZAS125-SF, NS125-SF, E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, NE250-SF, NS250-SF NAE125-SF, NAS125-SF, NAE250-SF, NAS250-SF** | **ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF, ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF** | T2HH25L | T2HH25L | 1A | T2HL25L | T2HL25L | 2 |
| | **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | — | | | | | | |
| | **PS250-PF/NN, PS250-NE/PE** | — | | | | | | |
| | **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF, H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, ZAS225-GF, ZAS250-GF** | **ZS100-GF, ZS125-GF, ZS225-GF, ZS250-GF** | T2HH25 | T2HH25 | 1B | T2HL25 | T2HL25 | 2 |
| 400, 600, 630, 800, 1000 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | — | TPHL63S ① | TPHL63S | 12 | TPHL63S | TPHL63S | 12 |
| | **E400-NF, H400-NE, L400-NE, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF, NS630-NF, NS800-NF, S630-CF/NF/NE/GN, ZAS630-CF/NF, H630-NE, L630-NE, S800-CF/NF/RF/PF/NN, ZAS800-CF/NF, S800-NE/RE/PE, H800-NE, L800-NE, S1000-CE/NN** | **ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF, ZS630-CF, ZS630-NF, ZS800-CF, ZS800-NF** | T2HL40 ① | T2HL40 | 4 | T2HL40 | T2HL40 | 4 |
| 1000, 1200 | **TL-1000NE, TL-1200NE** | — | XKC9 ① | XKC9 | 7 ($\ell$=86) | XKC9 | XKC9 | 7 ($\ell$=86) |
| 1250, 1600 | **S1250-NE/GE/NN, S1600-NE/NN** | — | T2HLX 6 ① | XKC9 | 7 ($\ell$=86) | T2HLX6 | XKC9 | 7 ($\ell$=86) |
| For distribution boards | **TB-5S, TB-10S, TB-5P, TB-5D** | — | 1P···TKB-50SGH (TAA-5CR) ③ | 1P···TKB-50SGH (TAA-5CR) ③ | 9(a) | TKB-50SG | TKB-50SG | 13 |
| | | | 2P···TAA-52SH 3P···TAA-53SH | 2P···TAA-52SH 3P···TAA-53SH | 9(b) | — | — | — |
| | **TB-51C, TB-52C** | **TZ-51C, TZ52C** | LCBH1R (HC1R) ③ | LCBH1R (HC1R) ③ | 9(c) | — | — | — |
| | **TB50KSL, TB50KSZ, TB100KSZ** | **TZ30EC, TZ50EE, TZ100EC** | BC30308041 | BC30308041 | 8 | — | — | — |

**Notes:**

①: Same as toggle lock.

②: A hole must be drilled in the breaker toggle. Please state “with toggle lock (HL)” when ordering the breaker.

③: Order codes shown in parentheses “( )” are toggle caps. The colour is Red.

Fig. 1A

Red




Fig. 1B

Red




Fig. 2

Red





Fig. 3

Red





Fig. 4

Red






Fig. 7

Black




**Toggle holder (HH)**:
Make sure the lock lever of the toggle holder is in the UNLOCK position, fit the toggle holder onto the toggle and swing the lock lever to the LOCK position. The toggle is now locked ON or OFF.

**Toggle lock (HL)**:
Padlock the toggle in the ON or OFF position.

Fig. 8

Red




Fig. 9

Red





Fig. 10

Red




Fig. 11

Red





Fig. 12

Red






Fig. 13


Red



# 7. Terminal covers


Terminal covers prevent live parts of the circuit breaker from being exposed to the external environment. There are three types of terminal covers: front-connected type, rear-connected and plug-in type, and cable clamps type. Select appropriate terminal covers depending on the type and application of the breaker.

## (1) CF for front-connected breakers





### Plug-in mounted version

This version can be mounted simply by being plugged in the breaker body.




### Screw-mounted version

The terminal covers for 630 to 1000AF (except PS630 and PH630) are mounted to the breaker covers using tapping screws.
The terminal cover for 1250AF is mounted to insert nuts of the circuit breaker cover using screws. The insert nuts do not come standard with the circuit breaker. Please be sure to state “with terminal cover (CF)” when ordering the circuit breaker.




■ To be stated when ordering
- Please state the order codes on the next page if ordering separately from the breaker.
- For the terminal cover for 1250AF, please order with the breakers.

# 7. Terminal covers

## (1) CF for front-connected breakers

Dimensions, mm

| Frame size (A) | Types of MCCBs ① | Types of ELCBs ① | Terminal cover | | | | A | | | B | | C ⑦ | | D ⑦ | | Colour of cover P: Grey Blue G: Light grey G': Grey C': Transparent | Mounting version | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | Size | Note: | Order codes ② | Marking codes | 2 poles | 3 poles | 4 poles | 2, 3 poles | 4 poles | 2, 3 poles | 4 poles | 2,3 poles | 4 poles | | Plug-in mounted | Screw-mounted |
| 30, 50, 60, 100, 125 | E30-NM, S30-NM, E50-NM, S50-NM, E100-NM | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM | Large | ⑧ | T2CF05＊NLNG | — | — | 75 | — | 40 | — | 53 | — | 53 | — | G | ○ | — |
| | | | | | T2CF05＊NLNC | | | | | | | | | | | C' | | |
| | | | Small | ⑧ | T2CF05＊NSNG | — | — | 75 | — | 10 | — | 53 | — | 53 | — | G | | |
| | | | | | T2CF05＊NSNC | | | | | | | | | | | C' | | |
| | PS50-PF, PS125-NF/NE, PS125-PF/PE, PS125-NN | — | Large | | TPCF16＊SLNPB | TPCF16＊SL | 60 | 90 | 120 | 40 | 40 | 60.5 | 60.5 | 58.5 | 58.5 | P | ○ | — |
| | | | | | TPCF16＊SLNCB | | | | | | | | | | | C' | | |
| | | | Small | | TPCF16＊SSNPB | TPCF16＊SS | 60 | 90 | 120 | 20 | 20 | 60.5 | 60.5 | 58.5 | 58.5 | P | | |
| | | | | | TPCF16＊SSNCB | | | | | | | | | | | C' | | |
| | PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN | PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN | Large | | TPCF12＊KLNPB | TPCF12＊KL | 50 | 75 | — | 50 | — | 60.7 | — | 60 | — | P | ○ | — |
| | | | | | TPCF12＊KLNCB | | | | | | | | | | | C' | | |
| | | | Small | | TPCF12＊KSNPB | TPCF12＊KS | 50 | 75 | — | 25 | — | 60.7 | — | 60 | — | P | | |
| | | | | | TPCF12＊KSNCB | | | | | | | | | | | C' | | |
| | S50-SF, S125-SF/SN, ZAS125-SF, NAE125-SF, NAS125-SF, NS125-SF | ZS50-SF, ZS100-SM, ZS125-SF, ZNS125-SF | Large | | TPCF12＊KLNPB | TPCF12＊KL | 50 | 75 | 100 | 50 | 50 | 60.7 | 60.7 | 60 | 60 | P | ○ | — |
| | | | | | TPCF12＊KLNCB | | | | | | | | | | | C' | | |
| | | | Small | | TPCF12＊KSNPB | TPCF12＊KS | 50 | 75 | 100 | 25 | 25 | 60.7 | 60.7 | 60 | 60 | P | | |
| | | | | | TPCF12＊KSNCB | | | | | | | | | | | C' | | |
| | S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF | ZS100-GF, ZS125-GF | Large | | T2CF12＊SLNP | T2CF12＊SL | 60 | 90 | 120 | 40 | 40 | 48 | 48 | 46 | 46 | P | ○ | — |
| | | | | | T2CF12＊SLNC | | | | | | | | | | | C' | | |
| | | | Small | | T2CF12＊SSNP | T2CF12＊SS | 60 | 90 | 120 | 22 | 22 | 48 | 48 | 47 | 47 | P | | |
| | | | | | T2CF12＊SSNC | | | | | | | | | | | C' | | |
| | H100-NF, H125-NF, L100-NF, L125-NF | — | Large | ③ | T2CF25＊LLNP | T2CF25＊LL | — | 105 | 140 | 55 | 55 | 89 | 89 | 87 | 87 | P | ○ | — |
| | | | | | T2CF25＊LLNC | | | | | | | | | | | C' | | |
| 100, 125, 225, 250 | E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF, PS250-NE/PF/PE/NN | ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF | Small | ⑩ | T2CF25L＊SSNP | T2CF25L＊SS | 105 | 105 | 140 | 29 | 29 | 59 | 59 | 57.5 | 57.5 | P | ○ | — |
| | | | | | T2CF25L＊SSNC | | | | | | | | | | | C' | | |
| | | | Large | ④, ⑩ | T2CF25L＊SWNP | T2CF25L＊SW | 147.5 | 147.5 | 196 | 55 | 55 | 59 | 59 | 57.5 | 57.5 | P | ○ | — |
| | | | | | T2CF25L＊SWNC | | | | | | | | | | | C' | | |
| | | | Large | ⑩ | T2CF25L＊SLNP | T2CF25L＊SL | 105 | 105 | 140 | 55 | 55 | 59 | 59 | 57.5 | 57.5 | P | ○ | — |
| | | | | | T2CF25L＊SLNC | | | | | | | | | | | C' | | |
| | ZAS225-GF, ZAS250-GF | ZS225-GF, ZS250-GF | Large | ③, ⑩ | T2CF25＊SLNP | T2CF25＊SL | — | 105 | 140 | 55 | 55 | 54 | 54 | 52 | 52 | P | ○ | — |
| | | | | | T2CF25＊SLNC | | | | | | | | | | | C' | | |
| | | | Small | ③, ⑩ | T2CF25＊SSNP | T2CF25＊SS | — | 105 | 140 | 29 | 29 | 54 | 54 | 53.5 | 53.5 | P | ○ | — |
| | | | | | T2CF25＊SSNC | | | | | | | | | | | C' | | |
| | H225-NF/NE, H250-NF, L225-NF, L250-NF | — | Large | ③, ⑩ | T2CF25＊LLNP | T2CF25＊LL | — | 105 | 140 | 55 | 55 | 89 | 89 | 87 | 87 | P | ○ | — |
| | | | | | T2CF25＊LLNC | | | | | | | | | | | C' | | |
| 400, 600, 630 | E400-NF, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF | ZNE400-NF, ZNS400-NF, ZE400-NF, ZS400-NF/GF | Large | ④ | T2CF40＊SWNP | T2CF40＊SW | — | 180 | 240 | 110 | 114 | 97 | 98 | 94.5 | 98 | P | ○ | — |
| | | | | | T2CF40＊SWNC | | | | | | | | | | | C' | | |
| | | | Large | ⑤ | T2CF40＊SLNP | T2CF40＊SL | — | 140 | 185 | 85 | 85 | 97 | 97 | 94.5 | 94.5 | P | ○ | — |
| | | | | | T2CF40＊SLNC | | | | | | | | | | | C' | | |
| | PS400-CF/NF/NE/GF/GE/NN, PH400-CF/CE, PS630-CF/NF/NE/GF/GE/NN, PH630-CF/CE | — | Large | ④, ⑫ | TPCF63＊SWNPB | TPCF63＊SW | — | 180 | 240 | 110 | 110 | 97 | 97 | 95.5 | 95.5 | P | ○ | — |
| | | | | | TPCF63＊SWNCB | | | | | | | | | | | C' | | |
| | | | Large | ⑤ | TPCF63＊SLNPB | TPCF63＊SL | — | 140 | 185 | 85 | 85 | 97 | 97 | 95.5 | 95.5 | P | ○ | — |
| | | | | | TPCF63＊SLNCB | | | | | | | | | | | C' | | |
| | S630-CF/NF/NE/GN, ZAS630-CF/NF, NS630-NF | ZS630-CF/NF | Large | | T2CF80＊SLNP | TPR-5BA | — | 215 | 285 | 130 | 130 | 99.5 (102) | 99.5 (102) | 99 (101.5) | 99 (101.5) | P | — | ○ |
| | | | | | T2CF80＊SLNC | | | | | | | | | | | C' | | |
| | H400-NE, L400-NE | — | Large | ④, ⑥ | T2CF40＊SWNP | T2CF40＊SW | — | 180 | 240 | 110 | 114 | 134 | 135 | 94.5 | 98 | P | ○ | — |
| | | | | | T2CF40＊SWNC | | | | | | | | | | | C' | | |
| | | | Large | ⑤, ⑥ | T2CF40＊SLNP | T2CF40＊SL | — | 140 | 185 | 85 | 85 | 134 | 134 | 94.5 | 94.5 | P | ○ | — |
| | | | | | T2CF40＊SLNC | | | | | | | | | | | C' | | |
| | H630-NE, L630-NE | — | Large | ⑥ | T2CF80＊SLNP | TPR-5BA | — | 215 | 285 | 130 | 130 | 136.5 (139) | 136.5 (139) | 99 (101.5) | 99 (101.5) | P | — | ○ |
| | | | | | T2CF80＊SLNC | | | | | | | | | | | C' | | |
| 800 | S800-CF/NF/NE/RF/RE/PF/PE/NN, NS800-NF, ZAS800-CF/NF | ZS800-CF/NF | Large | | T2CF80＊SLNP | TPR-5BA | — | 215 | 285 | 130 | 130 | 99.5 (102) | 99.5 (102) | 99 (101.5) | 99 (101.5) | P | — | ○ |
| | | | | | T2CF80＊SLNC | | | | | | | | | | | C' | | |
| | H800-NE, L800-NE | — | Large | ⑥ | T2CF80＊SLNP | TPR-5BA | — | 215 | 285 | 130 | 130 | 136.5 (139) | 136.5 (139) | 99 (101.5) | 99 (101.5) | P | — | ○ |
| | | | | | T2CF80＊SLNC | | | | | | | | | | | C' | | |
| 1000 | S1000-CE/NN | — | Large | | T2CF80＊SLNP | TPR-5BA | — | 215 | 285 | 130 | 130 | 99.5 (102) | 99.5 (102) | 99 (101.5) | 99 (101.5) | P | — | ○ |
| | | | | | T2CF80＊SLNC | | | | | | | | | | | C' | | |
| 1250 | S1250-NE/GE/NN | — | Large | ⑨ | — | TPR-5BA | — | 215 | 285 | 130 | 130 | 115 | 115 | 99 (102.5) | 99 (102.5) | P | — | ○ |
| | | | | | | | | | | | | | | | | C' | | |
| For distribution boards and control boards | TB50KSL ⑪ | TZ30EC, TZ50EE | Large | | BCW20508033 | — | 50 | — | — | 23.5 | — | 52 | — | — | — | G' | ○ | — |
| | | | | | BCW30508033 | — | — | 75 | — | 23.5 | — | 52 | — | — | — | G' | | |
| | | | Small | | BCW20508125 | — | 50 | — | — | 5 | — | 52 | — | — | — | C' | ○ | — |
| | | | | | BCW30508125 | — | — | 75 | — | 5 | — | 52 | — | — | — | C' | | |
| | TB50KSZ, TB100KSZ | TZ100EC | Large | | BCW30508033 | — | — | 75 | — | 23.5 | — | 52 | — | — | — | G' | ○ | — |
| | | | Small | | BCW30508125 | — | — | 75 | — | 5 | — | 52 | — | — | — | C' | | |

**Notes:**

①: Some models are not available for 2-pole or 4-pole products. See the circuit breaker outline drawing in Chapter 7 for details.

②: The asterisk indicates the number of poles. Please state the number of poles at the asterisk position when ordering. One set includes 2 pcs for T2CF/TPCF, 1 pc for BCW.

③: Not applicable to 3-pole breakers with extension bars.

④: Applicable to 3-pole breakers with spread extension bars.

⑤: When used without the extension bars.

⑥: There will be an approx. 40 mm gap between the bottom of the terminal cover and the breaker mounting surface.

⑦: Values in parentheses indicate the distance to the head of terminal cover mounting screws.

⑧: There is no hole for Megger measurement.

⑨: Not sold as a single unit. When ordering the circuit breaker, please specify whether you require a grey-blue terminal cover or a transparent terminal cover.

⑩: Please use with a connection wire of 100mm² or less. If you use 150mm², the insulating sleeve will touch the terminal cover and cannot be attached.

⑪: Only for 2-pole products.

⑫: Please use with a connection wire of 200mm² or less. If you use 325mm², the insulating sleeve will touch the terminal cover and cannot be attached.

## (2) CR for rear-connected and plug-in breakers





Fig. 1

### Plug-in mounted version

This version can be mounted simply by being plugged in the breaker body.






Fig. 2




### Screw-mounted version

The terminal covers are mounted to the breakers using tapping screws.

■ To be stated when ordering

- Please state “with CR” if ordering along with the breaker.
- Please state the order codes on the next page if ordering separately from the breaker. One set includes one terminal cover for the ON side and one for the OFF side.

# 7. Terminal covers

## (2) CR for rear-connected and plug-in breakers

Dimensions, mm

| Frame size (A) | Types of MCCBs ① | Types of ELCBs ① | Order codes ② | Marking codes | A | | | B | | B' | C ④ | | D ④ | | Colour of cover B: Black P: Grey Blue | Mounting version | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | 2 poles | 3 poles | 4 poles | 2, 3 poles | 4 poles | | 2, 3 poles | 4 poles | 2,3 poles | 4 poles | | Plug-in mounted | Screw-mounted | Fig. |
| 30, 50, 60, 100, 125 | **E30-NM, S30-NM, E50-NM, S50-NM, E100-NM** | **ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM** | ③ | — | — | 75 | — | 10 (3P) | — | — | 53 (3P) | — | 53 (3P) | — | B | ○ | — | ⑤ |
| | **PS50-PF, PS125-NF/NE, PS125-PF/PE, PS125-NN** | — | TPCR16＊SPB | TPCR16＊S | 60 | 90 | 120 | 2 | 2 | 4.5 | 61 | 61 | 60 | 60 | P | ○ | — | 1 |
| | **PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN** | T2CR12L＊SP | — | 50 | 75 | 100 | 5.3 | 5.3 | — | 61 | 61 | 60.3 | 60.3 | P | ○ | — | 1 |
| | **S50-SF, S125-SF/SN, ZAS125-SF, NAE125-SF, NAS125-SF, NS125-SF** | **ZS50-SF, ZS100-SM, ZS125-SF, ZNS125-SF** | T2CR12L＊SP | — | 50 | 75 | 100 | 5.3 | 5.3 | — | 61 | 61 | 60.3 | 60.3 | P | ○ | — | 1 |
| | **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | T2CR12＊SP | T2CR12＊S | — | 90 | 120 | 2 | 2 | 6 | 41.5 | — | 40.5 | — | P | ○ | — | 1 |
| | **H100-NF, H125-NF, L100-NF, L125-NF** | — | T2CR25＊SP | T2CR25＊S | — | 105 | 140 | 2 | 2 | 6 | 77.5 | 77.5 | 39.5 | 39.5 | P | ○ | — | 1 |
| 100, 125, 225, 250 | **E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, PS250-NE/PF/PE/NN, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF** | **ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF** | T2CR25L＊SP | — | 105 | 105 | 140 | 2.3 | 2.3 | 5.3 | 58.6 | 58.6 | 57.1 | 57.1 | P | ○ | — | 1 |
| | **ZAS225-GF, ZAS250-GF** | **ZS225-GF, ZS250-GF** | T2CR25＊SP | T2CR25＊S | — | 105 | 140 | 2 | 2 | 6 | 42.5 | 42.5 | 39.5 | 39.5 | P | ○ | — | 1 |
| | **H225-NF/NE, H250-NF, L225-NF, L250-NF** | — | T2CR25＊SP | T2CR25＊S | — | 105 | 140 | 2 | 2 | 6 | 77.5 | 77.5 | 39.5 | 39.5 | P | ○ | — | 1 |
| 400, 600, 630 | **E400-NF, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF** | **ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | T2CR40＊SP | T2CR40＊S | — | 140 | 185 | 3 | 3 | 5 | 97 | 97 | 93 | 93 | P | ○ | — | 1 |
| | **PS400-CF/NF/NE/GF/GE/NN, PH400-CF/CE, PS630-CF/NF/NE/GF/GE/NN, PH630-CF/CE** | — | TPCR63＊SPB | TPCR63＊S | — | 140 | 185 | 3.5 | 3.5 | 5 | 97 | 97 | 96 | 96 | P | ○ | — | 1 |
| | **H400-NE, L400-NE** | — | T2CR40＊SP | T2CR40＊S | — | 140 | 185 | 3 | 3 | 5 | 134 | 134 | 93 | 93 | P | ○ | — | 1 |
| | **S630-CF/NF/NE/GN, ZAS630-CF/NF, NS630-NF** | **ZS630-CF/NF** | T2CR803SP | XPS6 | — | 206 | 280 | 15 | 18 | — | 101 (103.5) | 99 (101.5) | 100.5 (103) | 98 (100.5) | P (3 poles) | — | ○ | 2 |
| | | | T2CR804SB | | | | | | | | | | | | B (4 poles) | | | |
| | **H630-NE, L630-NE** | — | T2CR80＊LB | — | — | 210 | 280 | 15 | 15 | — | 136 (138.5) | 136 (138.5) | 135 (137.5) | 135 (137.5) | B | — | ○ | 2 |
| 800 | **S800-CF/NF/NE/RF/RE/PF/PE/NN, ZAS800-CF/NF, NS800-NF** | **ZS800-CF/NF** | T2CR803SP | XPS6 | — | 206 | 280 | 15 | 18 | — | 101 (103.5) | 99 (101.5) | 100.5 (103) | 98 (100.5) | P (3 poles) | — | ○ | 2 |
| | | | T2CR804SB | | | | | | | | | | | | B (4 poles) | | | |
| | **H800-NE, L800-NE** | — | T2CR80＊LB | — | — | 210 | 280 | 15 | 15 | — | 136 (138.5) | 136 (138.5) | 135 (137.5) | 135 (137.5) | B | — | ○ | 2 |
| 1000 | **S1000-CE/NN** | — | T2CR803SP | XPS6 | — | 206 | 280 | 15 | 18 | — | 101 (103.5) | 99 (101.5) | 100.5 (103) | 98 (100.5) | P (3 poles) | — | ○ | 2 |
| | | | T2CR804SB | | | | | | | | | | | | B (4 poles) | | | |

**Notes:**

①: Some models are not available for 2-pole or 4-pole products. See the circuit breaker outline drawing in Chapter 7 for details.


②: The asterisk indicates the number of poles. Please state the number of poles at the asterisk position when ordering. One set includes 2 pcs terminal covers.

③: Supplied as standard with the circuit breaker body.

④: Values in parentheses indicate the distance to the head of terminal cover mounting screws.

⑤: See the circuit breaker outline dimensions drawing in Chapter 7 for details.

## (3) CS for breakers with cable clamps




The holes for Megger measurement are ribbed to meet IP3X.
When performing Megger measurement, cut out this ribbing.

### Plug-in mounted version

This version can be mounted simply by being plugged in the breaker body.

■ To be stated when ordering

- Please state "with CS" if ordering along with the breaker.
- Please state the order codes on the next page if ordering separately from the breaker.
  One set includes one terminal cover for the ON side and one for the OFF side.

### Dimensions, mm

| Frame size (A) | Types of MCCBs | Types of ELCBs | Order codes ① | Marking codes | A | | B | B' | C | D | Colour of cover P: Grey Blue | Mounting version | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | | | | 3 poles | 4 poles | | | | | | Plug-in mounted | Screw-mounted |
| 50, 100, 125 | **PS50-PF, PS125-NF/PF/NM/NN, PS125-NE/PE** | — | TPCS16＊SPB | TPCS16＊S | 90 | 120 | 2 | 4.5 | 61 | 60 | P | ○ | — |
| 50, 100, 125, 225, 250 | **S50-SF, S125-SF/SN, ZAS125-SF** | **ZS50-SF, ZS100-SM, ZS125-SF** | T2CS12L＊SP | — | 75 | 100 | 25 | — | 61 | 60.3 | P | ○ | — |
| | **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | T2CS12＊SP | T2CS12＊S | 90 | 120 | 2.5 | 6 | 61 | 59.5 | P | ○ | — |
| | **H100-NF, H125-NF, L100-NF, L125-NF** | — | T2CS25＊SP | T2CS25＊S | 105 | 140 | 2.5 | 4.5 | 96 | 59.5 | P | ○ | — |
| | **E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, PS250-NE/PF/PE/NN** | **ZE250-SF, ZS250-SF/SM** | T2CS25L＊SP | T2CS25L＊S | 105 | 140 | 2.3 | 5.3 | 58.6 | 57.1 | P | ○ | — |
| | **ZAS225-GF, ZAS250-GF** | **ZS225-GF, ZS250-GF** | T2CS25＊SP | T2CS25＊S | 105 | 140 | 2.5 | 6 | 61 | 59.5 | P | ○ | — |
| | **H225-NF/NE, H250-NF, L225-NF, L250-NF** | — | T2CS25＊SP | T2CS25＊S | 105 | 140 | 2.5 | 4.5 | 96 | 59.5 | P | ○ | — |
| 400, 600, 630 | **E400-NF, ZAE400-NF, ZAS400-NF/GF** | **ZE400-NF, ZS400-NF/GF** | T2CS40＊SP | T2CS40＊S | 140 | 185 | 3 | 5 | 97 | 93 | P | ○ | — |
| | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | — | TPCS63＊SPB | TPCS63＊S | 140 | 185 | 3.5 | 4.6 | 97 | 96 | P | ○ | — |
| | **H400-NE, L400-NE** | — | T2CS40＊SP | T2CS40＊S | 140 | 185 | 3 | 5 | 134 | 93 | P | ○ | — |


**Notes:**

①: The asterisk indicates the number of poles. Please state the number of poles at the asterisk position when ordering.
One set includes one terminal cover for the ON side and one for the OFF side.


Remark 1: Terminal covers for motor protection breakers are 3-pole type only.

# 8. Interpole barriers (BA)

Interpole barriers serve to enhance electrical insulation between poles and prevent short-circuit due to electrically conductive foreign matter. Combined use of interpole barriers and terminal covers (standard type) is not possible.




● Slide interpole barriers into the grooves located on the breaker.



■ To be stated when ordering
Please specify the type when ordering. Supplied as a set of 2 pcs. (＊: Supplied as a set of 1 pc.)
Caution: Be sure to use the interpole barriers supplied with the breaker in order to prevent accidents.

Dimensions, mm

| Types of MCCBs | Types of ELCBs | Order codes | Marking codes | A | B | Front-connected |
|---|---|---|---|---|---|---|
| **TB-5S, TB-5P, TB-5D** | — | ＊ TQQ-2CC | — | 36 | 50 | ● |
| **E30-NM, S30-NM** | **ZE30-NM, ZS30-NM** | T2BA053NH | BZ6B10C | 50 | 45 | ● |
| **E50-NM, S50-NM, E100-NM** | **ZE50-NM, ZS50-CM, ZE100-NM** | T2BA053NH | BZ6B10C | 50 | 45 | ◎ |
| **PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN** | TPBA123KH | — | 50 | 55 | ◎ |
| **S50-SF, S125-SF, S125-SN, ZAS125-SF, NAE125-SF, NAS125-SF, NS125-SF** | **ZS50-SF, ZS100-SM,ZS125-SF, ZNS125-SF** | T2BA16L3SH | — | 50 | 55 | ◎ |
| **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | — | T2BA16L3SH | — | 50 | 55 | ◎ |
| **S100-GF, S125-GF, ZAS-50GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | T2BA123SH | T2BA12S | 47 | 53 | ◎ |
| **H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, L125-PF** | — | T2BA253LH | T2BA25L | 100 | 88 | ◎ |
| **E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF** | **ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF** | T2BA25L3SH | T2BA25LS | 101 | 53 | ◎ |
| **PS250-PF/NN, PS250-NE/PE** | — | T2BA25L3SH | T2BA25LS | 101 | 53 | ◎ |
| **ZAS225-GF, ZAS250-GF** | **ZS225-GF, ZS250-GF** | T2BA25L3SH | T2BA25LS | 100 | 53 | ◎ |
| **PS400-CF/NF/GF/NN, PS400-NE/GE** | — | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **PH400-CF, PH400-CE** | — | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **E400-NF, H400-NE, L400-NE, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF** | **ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **PS630-CF/NF/GF/NN, PS630-NE/GE** | — | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **S630-CF/NF/NE/GN, ZAS630-CF/NF, NS630-NF, H630-NE, L630-NE** | **ZS630-CF/NF** | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **PH630-CF, PH630-CE** | — | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **S800-CF/NF/RF/PF, S800-NE/RE/PE/NN, NS800-NF, ZAS800-CF/NF, H800-NE, L800-NE, S1000-CE/NN** | **ZS800-CF/NF** | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **S1250-NE/GE/NN** | — | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **S1600-NE/NN** | — | T2BA403SH | TQQ-5BA | 110 | 95 | ◎ |
| **TL-1000NE, TL-1200NE** | — | ＊ TQQ-5BA | TQQ-5BA | 110 | 95 | ◎ |
| **XS2000NE/NN, XS2500NE/NN, XS3200NE/NN** | — | — | — | — | — | — |
| **TB-51C, TB-52C, TB50KSL, TB50KSZ, TB100KSZ** | **TZ30EC, TZ50EE, TZ100EC, TZ-51C, TZ-52C** | — | — | — | — | — |

◎: 2P: 1 pc, 3P: 2 pcs, 4P: 3 pcs of interpole barriers are supplied as standard. (Front-connected only)
●: Optional One set include 2 pcs for a 3P single-sided pole. (One set include 1 pc for TQQ) — : "no" or "not available".


# 9. Terminal blocks (TF)

Applies to front-connected type and rear-connected type circuit breakers with internally mounted accessories.
The lead wires from internally mounted accessories are connected to this terminal block.

## 6 terminals

### Vertical leading type with 30/50/100A frame MCCB/ELCB

**Mounting position/typical terminal arrangement**




**Dimensions, mm**

| Frame size (A) | Types of breakers | | A | B | C | D | E |
|---|---|---|---|---|---|---|---|
| | MCCB | ELCB | | | | | |
| 30 | **E30-NM, S30-NM** | **ZE30-NM, ZS30-NM** | 0 | 9 | 23.5 | 36 | 48.5 |
| 50 | **E50-NM, S50-NM** | **ZE50-NM, ZS50-CM** | | | | | |
| 100 | **E100-NM** | **ZE100-NM** | | | | | |


**Notes:**

1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm$^2$ max
3) The undervoltage trip device (with terminal block) must be mounted on the right-hand side of the circuit breaker and the terminal blocks of the auxiliary switch and alarm switch cannot be mounted on the right-hand side.
4) The shunt trip device (with terminal block) of the earth leakage breaker is mounted on the right side of the breaker and the terminal blocks of the auxiliary switch and alarm switch cannot be mounted on the right-hand side.
5) Contact to TERASAKI for the combination other than the above.

## 6 terminals

### Vertical leading type 30/50/100 A frame Circuit breaker with earth leakage alarm/earth leakage circuit breaker for distribution boards and control boards

**Mounting position/typical terminal arrangement**




**Dimensions, mm**

| Frame size (A) | Types of breakers | | A | B | C | D |
|---|---|---|---|---|---|---|
| | Circuit Breaker with earth leakage alarm | ELCB | | | | |
| 30 | | **TZ30EC** | 0 | 31 | 40 | 49 |
| 50 | **TB50KSL, TB50KSZ** | **TZ50EE** | | | | |
| 100 | **TB100KSZ** | **TZ100EC** | | | | |

**Notes:**


1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm$^2$ max
3) TBL is a test lead terminal.
4) RST is a remote reset terminal.
5) ECAc, b, a are the terminals for the earth leakage alarm output contacts.
6) Contact to TERASAKI for the combination other than the above.

# 9. Terminal blocks (TF)

## 18mm width 6 terminals

### Vertical leading type (T2TF00L) with 50/100/125A frame MCCB

**Mounting position/typical terminal arrangement**




**Dimensions, mm**

| Frame size (A) | Types of breakers MCCB | Number of poles | A |
|---|---|---|---|
| 30, 50, 60 | **PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF** | 2/3 poles | 9 |
| | **S50-SF** | 2/3/4 poles | 9 |
| 100, 125 | **PE125-NF/NN** | 2/3 poles | 9 |
| | **S125-SF** | 2/3/4 poles | 9 |
| | **S125-SN** | 3/4 poles | 9 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max

Combination of terminal arrangement (for 3 poles/4 poles)


| AX | AL | SH | UV | Left terminal | Right terminal |
|---|---|---|---|---|---|
| 1C | 1C | 1 | — | Ex.2 | Ex.4 |
| 1C | 1C | — | 1 | Ex.2 | Ex.5 |
| 1C | 2C | — | — | Ex.2 | Ex.3 |
| 2C | — | 1 | — | Ex.1 | Ex.4 |
| 2C | — | — | 1 | Ex.1 | Ex.5 |
| 2C | 2C | — | — | Ex.2 | Ex.3 |
| 3C | 1C | — | — | Ex.2 | Ex.1 |
| 4C | — | — | — | Ex.1 | Ex.2 |

AX, AL takes precedence left terminal connection.
AL is connected to the left terminal in preference to the AX.
Contact TERASAKI for the combination other than the above.

## 18mm width 6 terminals

### Vertical leading type (T2TF00L) with 50/100/125A frame MCCB/ELCB

**Mounting position/typical terminal arrangement**




**Dimensions, mm**


| Frame size (A) | Types of breakers MCCB | Types of breakers ELCB | A |
|---|---|---|---|
| 30, 50, 60 | **PE50-NFZ *3) PE50-NFN PS50-NFZ *3)** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF ZS50-SF *5)** | 9 |
| 100, 125 | **PE125-NFZ *3) PE125-NFN ZAS125-SF *3) *4) *5) NS125-SF *5) NAE125-SF *6) NAS125-SF *6)** | **PZE125-NF PZE125-NFN ZS125-SF *5) ZS100-SM *5) ZNS125-SF *5)** | 9 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0 mm² (max)
3) If the terminal blocks are applied for internal accessories as standard, ELa, ELb, ELc (earth leakage alarm output terminal) is also applied the terminal block.
4) Ra1, Ra2 (remote reset terminal) can be used.
5) TL (test lead terminal) can be used.
6) Can only be used with the left terminal block.
7) Contact to TERASAKI for the combination other than the left.

## 18mm width 6 terminals

### Vertical leading type (T2TF00L) with 50/100/125A frame MCCB

**Mounting position/typical terminal arrangement**




**Dimensions, mm**

| Frame size (A) | Types of breakers MCCB | Poles | A |
|---|---|---|---|
| 50 | **PS50-PF** | 2/3/4 poles | 8 |
| 100, 125 | **PS125-NF/PF** | 2/3/4 poles | 8 |
| | **PS125-NN** | 3/4 poles | 8 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max

Combination of terminal arrangement (for 3 poles/4 poles)

| AX | AL | SH | UV | Left terminal | Right terminal |
|---|---|---|---|---|---|
| 1C | 1C | 1 | — | Ex.2 | Ex.4 |
| 1C | 1C | — | 1 | Ex.2 | Ex.5 |
| 1C | 2C | — | — | Ex.2 | Ex.3 |
| 2C | — | 1 | — | Ex.1 | Ex.4 |
| 2C | — | — | 1 | Ex.1 | Ex.5 |
| 2C | 2C | — | — | Ex.2 | Ex.3 |
| 3C | 1C | — | — | Ex.2 | Ex.1 |
| 4C | — | — | — | Ex.1 | Ex.2 |

AX, AL takes precedence left terminal connection.
AL is connected to the left terminal in preference to the AX.
Contact TERASAKI for the combination other than the above.

## 18mm width 6 terminals


### Vertical leading type (T2TF00L) with 100/125A frame Electronic MCCB

**Mounting position/ typical terminal arrangement**

Combination of terminal arrangement

| AX | AL | SH | UV | PTA | Left terminal | Right terminal |
|---|---|---|---|---|---|---|
| 1C | 1C | 1 | — | 1 | Ex.6 | Ex.4 |
| 1C | 1C | — | 1 | 1 | Ex.6 | Ex.5 |
| 2C | — | 1 | — | 1 | Ex.5 | Ex.4 |
| 2C | — | — | 1 | 1 | Ex.5 | Ex.5 |
| 1C | 2C | — | — | 1 | Ex.6 | Ex.3 |
| 2C | 2C | — | — | 1 | Ex.6 | Ex.3 |
| 3C | 1C | — | — | 1 | Ex.6 | Ex.1 |
| 4C | — | — | — | 1 | Ex.5 | Ex.2 |
| 1C | — | — | — | 1 | Ex.3 | |
| — | 1C | — | — | 1 | Ex.4 | |
| — | — | — | — | 1 | Ex.3 | |

AX, AL takes precedence left terminal connection.
AL is connected to the left terminal in preference to the AX.
Contact TERASAKI for the combination other than the above.




**Dimensions, mm**

| Frame size (A) | Types of breakers Electronic MCCB | A |
|---|---|---|
| 100, 125 | **PS125-NE/PE** | 8 |


**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) The following SMART MCCB cables cannot be connected to the terminal blocks.
   Zone selective interlocking
   Optional alarm output contact
   Control power supply
   Communication module

# 9. Terminal blocks (TF)

## 18mm width 6 terminals

### Vertical leading type (T2TFX0) with 100/125A frame MCCB

**Mounting position/typical terminal arrangement**




**Dimensions, mm**


| Frame size (A) | Types of breakers MCCB | B | C | D |
|---|---|---|---|---|
| 100, 125 | **S100-GF, S125-GF** | 22 | 34 | 46 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) Contact to TERASAKI for the combination other than the left.

## 18mm width 6 terminals

### Vertical leading type (T2TFX0) with 50/100/125A frame MCCB/ELCB

**Mounting position/typical terminal arrangement**





**Dimensions, mm**


| Frame size (A) | Types of breakers MCCB | Types of breakers ELCB | B | C | D |
|---|---|---|---|---|---|
| 50, 100, 125 | **ZAS50-GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | 22 | 34 | 46 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) Ra1, Ra2 are remote reset terminals.
4) If the terminal blocks are applied for internal accessories as standard, ELa, ELb, ELc (earth leakage alarm output terminal) is also applied the terminal block.
5) For earth leakage circuit breakers.
6) Contact to TERASAKI for the combination other than the left.

## 18mm width 6 terminals
### Vertical leading type (T2TFX0) with 100/125/225/250A frame MCCB

**Mounting position/typical terminal arrangement**





**Dimensions, mm**


| Frame size (A) | Types of breakers | | B | C | D | E |
|---|---|---|---|---|---|---|
| | MCCB | ELCB | | | | |
| 100, 125, 225, 250 | **H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF** | | 57 | 69 | 81 | 39 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) Contact to TERASAKI for the combination other than the below.

## 18mm width 6 terminals
### Vertical leading type (T2TFX0) with 225/250A frame MCCB/ELCB

**Mounting position/typical terminal arrangement**




**Dimensions, mm**


| Frame size (A) | Types of breakers | | B | C | D |
|---|---|---|---|---|---|
| | MCCB | ELCB | | | |
| 225, 250 | **ZAS225-GF, ZAS250-GF** | **ZS225-GF, ZS250-GF** | 22 | 34 | 46 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) Ra1, Ra2 are remote reset terminals.
4) If the terminal blocks are applied for internal accessories as standard, ELa, ELb, ELc (earth leakage alarm output terminal) is also applied the terminal block.
5) For earth leakage circuit breakers.
6) Contact to TERASAKI for the combination other than the below.

# 9. Terminal blocks (TF)

## 18mm width 6 terminals
### Vertical leading type (T2TF00L) with 225/250A frame MCCB

**Mounting position/typical terminal arrangement**




**Dimensions, mm**

| Frame size (A) | Types of breakers | Number of poles | A |
|---|---|---|---|
| | MCCB | | |
| 225, 250 | **E250-SF, S250-SM** | 3 poles | 7 |
| | **S250-SF, S250-SN** | 3/4 poles | 7 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max


Combination of terminal arrangement

| AX | AL | SH | UV | Left terminal | Right terminal |
|---|---|---|---|---|---|
| 1C | 1C | 1 | — | Ex.2 | Ex.6 |
| 1C | 1C | — | 1 | Ex.2 | Ex.7 |
| 2C | — | 1 | — | Ex.1 | Ex.6 |
| 2C | — | — | 1 | Ex.1 | Ex.7 |
| 2C | 2C | — | — | Ex.2 | Ex.3 |
| 2C | 1C | 1 | — | Ex.2 | Ex.8 |
| 2C | 1C | — | 1 | Ex.2 | Ex.9 |
| 3C | 1C | — | — | Ex.2 | Ex.1 |
| 3C | 2C | — | — | Ex.3 | Ex.4 |
| 4C | — | — | — | Ex.1 | Ex.2 |
| 4C | 2C | — | — | Ex.3 | Ex.5 |

AX, AL takes precedence left terminal connection.
AL is connected to the left terminal in preference to the AX.
1 row terminal block is used in preference to 2 rows the terminal blocks.
Contact TERASAKI for the combination other than the above.

## 18mm width 6 terminals
### Vertical leading type (T2TF00L) with 225/250A frame MCCB/ELCB

**Mounting position/typical terminal arrangement**





**Dimensions, mm**

| Frame size (A) | Types of breakers | | A |
|---|---|---|---|
| | MCCB | ELCB | |
| 225, 250 | **ZAE250-SF *3) *4) *5), ZAS250-SF *3) *4) *5), NE250-SF *5), NS250-SF *5), NAE250-SF *3) *4) *6), NAS250-SF *3) *4) *6)** | **ZE250-SF *5), ZS250-SF *5), ZNE250-SF *5), ZNS250-SF *5), ZS250-SM *5)** | 7 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) If the terminal blocks are applied for internal accessories as standard, ELa, ELb, ELc (earth leakage alarm output terminal) is also applied the terminal block.
4) Ra1, Ra2 (remote reset terminal) can be used.
5) TL (test lead terminal) can be used.
6) Can only be used with the left terminal block.
7) Contact to TERASAKI for the combination other than the left.

## 18mm width 6 terminals
### Vertical leading type (T2TF00L) with 225/250A frame MCCB

**Mounting position/typical terminal arrangement**




**Dimensions, mm**

| Frame size (A) | Types of breakers MCCB | A |
|---|---|---|
| 225, 250 | **PS250-PF/NN** | 8 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max

Combination of terminal arrangement

| AX | AL | SH | UV | Left terminal | Right terminal |
|---|---|---|---|---|---|
| 1C | 1C | 1 | — | Ex.2 | Ex.5 |
| 1C | 1C | — | 1 | Ex.2 | Ex.6 |
| 2C | 1C | 1 | — | Ex.3 | Ex.5 |
| 2C | 1C | — | 1 | Ex.3 | Ex.6 |
| 2C | 2C | — | — | Ex.2 | Ex.3 |
| 3C | 1C | — | — | Ex.2 | Ex.1 |
| 3C | 2C | — | — | Ex.3 | Ex.4 |
| 4C | — | — | — | Ex.1 | Ex.2 |

AX, AL takes precedence left terminal connection.
AL is connected to the left terminal in preference to the AX.
1 row terminal block is used in preference to 2 rows the terminal blocks.
Contact TERASAKI for the combination other than the above.


## 18mm width 6 terminals
### Vertical leading type (T2TF00L) with 225/250A frame Electronic MCCB

**Mounting position/typical terminal arrangement**

Combination of terminal arrangement

| AX | AL | SH | UV | PTA | Left terminal | Right terminal |
|---|---|---|---|---|---|---|
| 1C | 1C | 1 | — | 1 | Ex. 6 | Ex. 5 |
| 1C | 1C | — | 1 | 1 | Ex. 6 | Ex. 6 |
| 2C | 1C | 1 | — | 1 | Ex. 6 | Ex. 5 |
| 2C | 1C | — | 1 | 1 | Ex. 6 | Ex. 6 |
| 2C | 2C | — | — | 1 | Ex. 6 | Ex. 3 |
| 3C | 1C | — | — | 1 | Ex. 6 | Ex. 1 |
| 3C | 2C | — | — | 1 | Ex. 6 | Ex. 4 |
| 4C | — | — | — | 1 | Ex. 7 | Ex. 2 |
| 1C | — | — | — | 1 | Ex. 4 | |
| — | 1C | — | — | 1 | Ex. 5 | |
| — | — | — | — | 1 | Ex. 4 | |

AX, AL takes precedence left terminal connection.
AL is connected to the left terminal in preference to the AX.
1 row terminal block is used in preference to 2 rows the terminal blocks.
Contact TERASAKI for the combination other than the above.




**Dimensions, mm**

| Frame size (A) | Types of breakers Electronic MCCB | A |
|---|---|---|
| 225, 250 | **PS250-NE/PE** | 8 |


**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) The following SMART MCCB cables cannot be connected to the terminal blocks.
Zone selective interlocking
Optional alarm output contact
Control power supply
Communication module


# 9. Terminal blocks (TF)

## 18mm width 6 terminals

### Vertical leading type (T2TFX0) with 400A frame MCCB

**Mounting position/ typical terminal arrangement**




**Dimensions, mm**

| Frame size (A) | Types of breakers | A | B | C | D |
|---|---|---|---|---|---|
| | MCCB | | | | |
| 400 | **E400-NF** | 33.5 | 51.5 | 63.5 | 75.5 |
| | **H400-NE, L400-NE** | 70.5 | 88.5 | 100.5 | 112.5 |


**Notes:**


1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm$^2$ max
3) $k$, $\ell$ are the terminals to connect to the CT for a separate neutral wire. Separate neutral wire CTs are required for 3-phase 4-wire system, when a 3-pole circuit breaker with ground fault trip function is used.
4) In the case of providing pre-trip alarm terminals (PALa, PALc) to the terminal block,OCR controller will be installed external to the breaker.
5) Contact to TERASAKI for the combination other than the left.

## 18mm width 6 terminals

### Vertical leading type (T2TFX0) with 400A frame MCCB/ELCB

**Mounting position/ typical terminal arrangement**




**Dimensions, mm**

| Frame size (A) | Types of breakers | | A | B | C | D |
|---|---|---|---|---|---|---|
| | MCCB | ELCB | | | | |
| 400 | **ZAE400-NF *3) *4) *5)** | **ZE400-NF *5)** | 33.5 | 51.5 | 63.5 | 75.5 |
| | **ZAS400-NF *3) *4) *5)** | **ZS400-NF *5)** | | | | |
| | **ZAS400-GF *3) *4) *5)** | **ZS400-GF *5)** | | | | |
| | **NE400-NF *5), NS400-NF *5)** | **ZNE400-NF *5)** | | | | |
| | **NAE400-NF *6), NAS400-NF *6)** | **ZNS400-NF *5)** | | | | |

**Notes:**

1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm$^2$ max
3) If the terminal blocks are applied for internal accessories as standard, ELa, ELb, ELc (earth leakage alarm output terminal) is also applied the terminal block.
4) Ra1, Ra2 (remote reset terminal) can be used.
5) TL (test lead terminal) can be used.
6) Can only be used with the left terminal block.
7) Contact to TERASAKI for the combination other than the left.

## 18mm width 6 terminals
### Vertical leading type (T2TF00L) with 400/600A frame MCCB

#### Mounting position/typical terminal arrangement

Combination of terminal arrangement

| AX | AL | SH | UV | Left terminal | Right terminal |
|---|---|---|---|---|---|
| 1C | 1C | 1 | — | Ex. 2 | Ex. 3 |
| 1C | 1C | — | 1 | Ex. 2 | Ex. 4 |
| 2C | — | 1 | — | Ex. 1 | Ex. 3 |
| 2C | — | — | 1 | Ex. 1 | Ex. 4 |
| 2C | 2C | — | — | Ex. 2 | Ex. 1 |
| 2C | 1C | 1 | — | Ex. 2 | Ex. 5 |
| 2C | 1C | — | 1 | Ex. 2 | Ex. 6 |
| 3C | 1C | — | — | Ex. 3 | Ex. 3 |
| 3C | 2C | — | — | Ex. 3 | Ex. 2 |

AX, AL takes precedence left terminal connection.

AL is connected to the left terminal in preference to the AX.

1 row terminal block is used in preference to 2 rows the terminal blocks.


Contact TERASAKI for the combination other than the above.


Left terminal arrangement

| Ex.1 | Ex.2 | Ex.3 | |
|---|---|---|---|
| AXa2 | ALa1 | | ALa1 |
| AXb2 | ALb1 | | ALb1 |
| AXc2 | ALc1 | | ALc1 |
| AXc1 | AXc1 | AXc2 | AXc1 |
| AXb1 | AXb1 | AXb2 | AXb1 |
| AXa1 | AXa1 | AXa2 | AXa1 |

Right terminal arrangement

| Ex.1 | Ex.2 | Ex.3 | Ex.4 | Ex.5 | Ex.6 |
|---|---|---|---|---|---|
| ALa2 | ALa2 | AXa3 | AXa3 | AXa2 | AXa2 |
| ALb2 | ALb2 | AXb3 | AXb3 | AXb2 | AXb2 |
| ALc2 | ALc2 | AXc3 | AXc3 | AXc2 | AXc2 |
| AXc2 | AXc3 | C2 | D2 | C2 | D2 |
| AXb2 | AXb3 | | | | |
| AXa2 | AXa3 | C1 | D1 | C1 | D1 |




#### Dimensions, mm

| Frame size (A) | Types of breakers MCCB | A |
|---|---|---|
| 400 | **PS400-CF/NF/GF/NN** | 36 |
| 600 | **PS630-CF/NF/GF/NN** | 36 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max

## 18mm width 6 terminals
### Vertical leading type (T2TF00L) with 400/630A frame Electronic MCCB

#### Mounting position/typical terminal arrangement

Combination of terminal arrangement

| AX | AL | SH | UV | PTA | Left terminal | Right terminal |
|---|---|---|---|---|---|---|
| 1C | 1C | 1 | — | 1 | Ex. 6 | Ex. 3 |
| 1C | 1C | — | 1 | 1 | Ex. 6 | Ex. 4 |
| 2C | — | 1 | — | 1 | Ex. 7 | Ex. 3 |
| 2C | — | — | 1 | 1 | Ex. 7 | Ex. 4 |
| 2C | 2C | — | — | 1 | Ex. 6 | Ex. 1 |
| 2C | 1C | 1 | — | 1 | Ex. 8 | Ex. 5 |
| 2C | 1C | — | 1 | 1 | Ex. 8 | Ex. 6 |
| 3C | 1C | — | — | 1 | Ex. 6 | Ex. 3 |
| 3C | 2C | — | — | 1 | Ex. 6 | Ex. 2 |
| 1C | — | — | — | 1 | Ex. 4 | |
| — | 1C | — | — | 1 | Ex. 5 | |
| — | — | — | — | 1 | Ex. 4 | |

AX, AL takes precedence left terminal connection.

AL is connected to the left terminal in preference to the AX.

1 row terminal block is used in preference to 2 rows the terminal blocks.


Contact TERASAKI for the combination other than the left.


Left terminal arrangement

| Ex.1 | Ex.2 | Ex.3 | | Ex.4 | Ex.5 | Ex.6 | | Ex.7 | | Ex.8 | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| AXa2 | ALa1 | | ALa1 | PALa | ALa1 | PALa | ALa1 | PALa | AXa2 | PALa | ALa1 |
| AXb2 | ALb1 | | ALb1 | | ALb1 | | ALb1 | | AXb2 | | ALb1 |
| AXc2 | ALc1 | | ALc1 | PALc | ALc1 | PALc | ALc1 | PALc | AXc2 | PALc | ALc1 |
| AXc1 | AXc1 | AXc2 | AXc1 | AXc1 | PALc | AXc2 | AXc1 | | AXc1 | | AXc1 |
| AXb1 | AXb1 | AXb2 | AXb1 | AXb1 | | AXb2 | AXb1 | | AXb1 | | AXb1 |
| AXa1 | AXa1 | AXa2 | AXa1 | AXa1 | PALa | AXa2 | AXa1 | | AXa1 | | AXa1 |

Right terminal arrangement

| Ex.1 | Ex.2 | Ex.3 | Ex.4 | Ex.5 | Ex.6 |
|---|---|---|---|---|---|
| ALa2 | ALa2 | AXa3 | AXa3 | AXa2 | AXa2 |
| ALb2 | ALb2 | AXb3 | AXb3 | AXb2 | AXb2 |
| ALc2 | ALc2 | AXc3 | AXc3 | AXc2 | AXc2 |
| AXc2 | AXc3 | C2 | D2 | C2 | D2 |
| AXb2 | AXb3 | | | | |
| AXa2 | AXa3 | C1 | D1 | C1 | D1 |




#### Dimensions, mm

| Frame size (A) | Types of breakers Electronic MCCB | A |
|---|---|---|
| 400 | **PS400-NE/GE, PH400-CF, PH400-CE** | 36 |
| 600, 630 | **PS630-NE/GE, PH630-CF, PH630-CE** | 36 |

**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) The following SMART MCCB cables cannot be connected to the terminal blocks.
   Zone selective interlocking
   Optional alarm output contact
   Control power supply
   Communication module

# 9. Terminal blocks (TF)


## 18mm width 6 terminals
### Vertical leading type (T2TFX0) with 630/800/1000A frame MCCB

**Mounting position/ typical terminal arrangement**

**Dimensions, mm**

| Frame size (A) | Types of breakers | A | B | C | D |
|---|---|---|---|---|---|
| | MCCB | | | | |
| 600, 630, 800, 1000 | **S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, S1000-CE/NN** | 33.5 | 51.5 | 63.5 | 75.5 |
| | **H630-NE, L630-NE, H800-NE, L800-NE,** | 70.5 | 88.5 | 100.5 | 112.5 |


**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) *k*, *ℓ* are the terminals to connect to the CT for a separate neutral wire. Separate neutral wire CTs are required for 3-phase 4-wire system, when a 3-pole circuit breaker with ground fault trip function is used.








Note 4)




4) In the case of providing pre-trip alarm terminals (PALa, PALc) to the terminal block,OCR controller will be installed external to the breaker.
5) Contact to TERASAKI for the combination other than the above.


## 18mm width 6 terminals
### Vertical leading type (T2TFX0) with 630/800A frame MCCB/ELCB

**Mounting position/ typical terminal arrangement**

**Dimensions, mm**


| Frame size (A) | Types of breakers | | A | B | C | D |
|---|---|---|---|---|---|---|
| | MCCB | ELCB | | | | |
| 600, 630, 800 | **ZAS630-CF *3) *4) *5)** | **ZS630-CF *5)** | 33.5 | 51.5 | 63.5 | 75.5 |
| | **ZAS630-NF *3) *4) *5)** | **ZS630-NF *5)** | | | | |
| | **ZAS800-CF *3) *4) *5)** | **ZS800-CF *5)** | | | | |
| | **ZAS800-NF *3) *4) *5)** | **ZS800-NF *5)** | | | | |
| | **NS630-NF *5)** | | | | | |
| | **NS800-NF *5)** | | | | | |


**Notes:**
1) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
2) Applicable wire size: 2.0mm² max
3) If the terminal blocks are applied for internal accessories as standard, ELa, ELb, ELc (earth leakage alarm output terminal) is also applied the terminal block.
4) Ra1, Ra2 (remote reset terminal) can be used.
5) TL (test lead terminal) can be used.











6) Contact to TERASAKI for the combination other than the above.

## Horizontal leading type (LTF) with 1250/1600A frame MCCB

### Mounting position/typical terminal arrangement




### Dimensions, mm

| Frame size (A) | Types of breakers | A | B | C | D |
|---|---|---|---|---|---|
| 1250 | **S1250-NE/GE/NN** | 51 | 114 (124) | 57 | 72 |
| 1600 | **S1600-NE/NN** | 51 | 114 (124) | 77 | 92 |


**Notes:**

1) Values in parentheses applies to 4-pole breakers.
2) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
3) Applicable wire size: 2.0mm$^2$ max × 2
4) Contact to TERASAKI for the combination other than the left.

# 9. Terminal blocks (TF)

## Horizontal leading type (LTF) with 1000 to 3200A frame MCCB

### Mounting position/typical terminal arrangement




### Dimensions, mm

| Frame size (A) | Types of breakers | A | B | C | D |
|---|---|---|---|---|---|
| 1000, 1200 | **TL-1000NE, TL-1200NE** | 51 | 194 (184) | 77 | 92 |
| 2000 | **XS2000NE, XS2000NN** | 54 | 208 | 100 | 115 |
| 2500 | **XS2500NE, XS2500NN** | 54 | 208 | 100 | 115 |
| 3200 | **XS3200NE, XS3200NN** | 54 | 208 | 100 | 115 |

**Notes:**

1) Values in parentheses applies to 4-pole breakers.
2) Tightening torque of M3.5 terminal screws: 0.9 – 1.2 Nm
3) Applicable wire size: 2.0mm$^2$ max × 2
4) The example terminal arrangement applies only to types XS2000NE, XS2500NE and XS3200NE.
5) Contact to TERASAKI for the combination other than the left.


# 10. Flush-mounted (flush plate) auxiliary circuit terminal block (TB)

### Applicable breakers

| Frame size (A) | Types of breakers | |
|---|---|---|
| | MCCB | ELCB |
| 30 | **E30-NM, S30-NM** | **ZE30-NM, ZS30-NM** |
| 50 | **E50-NM, S50-NM** | **ZE50-NM, ZS50-CM** |
| 100 | **E100-NM** | **ZE100-NM** |

The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㉔ in the table are connected to the terminals numbered ① to ㉔ on the rear of the circuit breaker.

℄ : Handle Frame Centre Line
℄ : Handle Centre Line




2 poles breaker

| Terminal block | Combinations of accessories | Terminal code | | | | | |
|---|---|---|---|---|---|---|---|
| | | ⑦ | ⑧ | ⑨ | ⑩ | ⑪ | ⑫ |
| 3 terminals | AX1C (R) | AXaR | AXbR | AXcR | | | |
| | AL1C (R) | ALaR | ALbR | ALcR | | | |
| | SH | C1 | C2 | | | | |
| | TL | TL1 | TL2 | | | | |
| 6 terminals | AX1C+AL1C (R) | AXaR | AXbR | AXcR | ALaR | ALbR | ALcR |
| | AX1C+TL | AXaR | AXbR | AXcR | | TL1 | TL2 |
| | AL1C+TL | ALaR | ALbR | ALcR | | TL1 | TL2 |

3 poles breaker

| Terminal block | Combinations of accessories | Terminal code | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | ① | ② | ③ | ④ | ⑤ | ⑥ | ⑦ | ⑧ | ⑨ | ⑩ | ⑪ | ⑫ | ⑲ | ⑳ | ㉑ | ㉒ | ㉓ | ㉔ |
| 3 terminals | AX1C (L) | AXaL | AXbL | AXcL | | | | | | | | | | | | | | | |
| | AL1C (L) | ALaL | ALbL | ALcL | | | | | | | | | | | | | | | |
| | AX1C (R) | | | | | | | AXaR | AXbR | AXcR | | | | | | | | | |
| | AL1C (R) | | | | | | | ALaR | ALbR | ALcR | | | | | | | | | |
| | SH | | | | | | | C1 | C2 | | | | | | | | | | |
| | TL | | | | | | | TL1 | TL2 | | | | | | | | | | |
| 6 terminals | AX1C+AL1C (L) | AXaL | AXbL | AXcL | ALaL | ALbL | ALcL | | | | | | | | | | | | |
| | AX1C+AL1C (R) | | | | | | | AXaR | AXbR | AXcR | ALaR | ALbR | ALcR | | | | | | |
| | AX2C | AXaL | AXbL | AXcL | AXaR | AXbR | AXcR | | | | | | | | | | | | |
| | AL2C | ALaL | ALbL | ALcL | ALaR | ALbR | ALcR | | | | | | | | | | | | |
| | AX1C+SH | AXaL | AXbL | AXcL | | C1 | C2 | | | | | | | | | | | | |
| | AL1C+SH | ALaL | ALbL | ALcL | | C1 | C2 | | | | | | | | | | | | |
| | AX1C+TL | AXaL | AXbL | AXcL | | TL1 | TL2 | | | | | | | | | | | | |
| | AL1C+TL | ALaL | ALbL | ALcL | | TL1 | TL2 | | | | | | | | | | | | |
| 9 terminals | AX2C+AL1C | AXaL | AXbL | AXcL | ALaL | ALbL | ALcL | | | | | | | | | | AXaR | AXbR | AXcR |
| | AX1C+AL2C | AXaL | AXbL | AXcL | ALaL | ALbL | ALcL | | | | | | | | | | ALaR | ALbR | ALcR |
| | AX1C+AL1C+SH | AXaL | AXbL | AXcL | ALaL | ALbL | ALcL | | | | | | | | | | C1 | C2 | |
| | AX1C+AL1C+TL | AXaL | AXbL | AXcL | ALaL | ALbL | ALcL | | | | | | | | | | TL1 | TL2 | |
| 12 terminals | AX2C+AL2C | AXaL | AXbL | AXcL | ALaL | ALbL | ALcL | | | | | | | AXaR | AXbR | AXcR | ALaR | ALbR | ALcR |


# 10. Flush-mounted (flush plate) auxiliary circuit terminal block (TB)

### Applicable breakers

| Frame size (A) | Types of breakers MCCB |
|---|---|
| 30, 50 | **S50-SF, PE30-NF/NN, PE50-NF/NN, PS30-NF, PS50-NF** |
| 60, 100, 125 | **S125-SF/SN, PE60-NF, PE125-NF/NN, PS60-NF** |

The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㉔ in the table are connected to the terminals numbered ① to ㉔ on the rear of the circuit breaker.

⊬ : Handle Frame Centre Line
℄ : Handle Centre Line




2 poles breaker

| Terminal block | Combinations of accessories | Terminal code ① | ② | ③ | ④ | ⑤ | ⑥ | ⑲ | ⑳ | ㉑ | ㉒ | ㉓ | ㉔ |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 3 terminals | AX1C | | | | | | | | | | AXb1 | AXa1 | AXc1 |
| | AL1C | | | | | | | | | | ALb1 | ALa1 | ALc1 |
| | SH | | | | | | | | | | C1 | | C2 |
| | UV | | | | | | | | | | D1 | | D2 |
| 6 terminals | AX2C | | | | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX1C+AL1C | | | | | | | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 |

3 poles breaker


| Terminal block | Combinations of accessories | Terminal code ① | ② | ③ | ④ | ⑤ | ⑥ | ⑲ | ⑳ | ㉑ | ㉒ | ㉓ | ㉔ |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 3 terminals | AX1C | | | | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL1C | | | | ALb1 | ALa1 | ALc1 | | | | | | |
| | SH | | | | | | | | | | C1 | | C2 |
| | UV | | | | | | | | | | D1 | | D2 |
| 6 terminals | AX2C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL2C | | | | ALb1 | ALa1 | ALc1 | | | | ALb2 | ALa2 | ALc2 |
| | AX1C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| | AX1C+SH | | | | AXb1 | AXa1 | AXc1 | | | | C1 | | C2 |
| | AL1C+SH | | | | ALb1 | ALa1 | ALc1 | | | | C1 | | C2 |
| | AX1C+UV | | | | AXb1 | AXa1 | AXc1 | | | | D1 | | D2 |
| | AL1C+UV | | | | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| 9 terminals | AX3C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | AXb3 | AXa3 | AXc3 |
| | AX1C+AL2C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | ALb2 | ALa2 | ALc2 |
| | AX2C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | AXb2 | AXa2 | AXc2 |
| | AX2C+SH | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | C1 | | C2 |
| | AX1C+AL1C+SH | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | C1 | | C2 |
| | AX2C+UV | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | D1 | | D2 |
| | AX1C+AL1C+UV | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| 12 terminals | AX4C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | AXb4 | AXa4 | AXc4 | AXb3 | AXa3 | AXc3 |
| | AX2C+AL2C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | AXb2 | AXa2 | AXc2 | ALb2 | ALa2 | ALc2 |
| | AX3C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 |


### Applicable breakers


| Frame size (A) | Types of breakers | | A (mm) |
|---|---|---|---|
| | MCCB | ELCB | |
| 50 | **ZAS50-GF** | | 60.8 |
| 100, 125 | **S100-GF, S125-GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | 60.8 |
| | **H100-NF, H125-NF, L100-NF, L125-NF** | | 95.8 |
| 225, 250 | **ZAS225-GF, ZAS250-GF** | **ZS225-GF, ZS250-GF** | 60.8 |
| | **H225-NF/NE, H250-NF, L225-NF, L250-NF** | | 95.8 |


The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㉔ in the table are connected to the terminals numbered ① to ㉔ on the rear of the circuit breaker.


: Handle Frame Centre Line
: Handle Centre Line





2 poles breaker

| Terminal block | Combinations of accessories | Terminal code | | | | | |
|---|---|---|---|---|---|---|---|
| | | ⑦ | ⑧ | ⑨ | ⑩ | ⑪ | ⑫ |
| 3 terminals | AX1C | | | | AXb1 | AXa1 | AXc1 |
| | AL1C | | | | ALb1 | ALa1 | ALc1 |
| | SH | | | | C1 | | C2 |
| | UV | | | | D1 | | D2 |
| 6 terminals | AX2C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX1C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 |

3/4 poles breaker

| Terminal block | Combinations of accessories | Terminal code | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | ① | ② | ③ | ④ | ⑤ | ⑥ | ㉒ | ㉓ | ㉔ |
| 3 terminals | AX1C | | | | AXb1 | AXa1 | AXc1 | | | |
| | AL1C | | | | ALb1 | ALa1 | ALc1 | | | |
| | SH | | | | C1 | | C2 | | | |
| | UV | | | | D1 | | D2 | | | |
| | EL1C | | | | ELb1 | ELa1 | ELc1 | | | |
| | TL | | | | TL | | TL | | | |
| 6 terminals | AX2C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | |
| | AX1C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | |
| 9 terminals | AX2C+SH | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | C1 | | C2 |
| | AX1C+AL1C+SH | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | C1 | | C2 |
| | AX2C+UV | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | D1 | | D2 |
| | AX1C+AL1C+UV | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | D1 | | D2 |
| | AX1C+AL1C+EL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | ELb1 | ELa1 | ELc1 |
| | AX1C+AL1C+TL | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | TL | | TL |


# 10. Flush-mounted (flush plate) auxiliary circuit terminal block (TB)


### Applicable breakers


| Frame size (A) | Types of breakers | | A (mm) |
|---|---|---|---|
| | MCCB | ELCB | |
| 30, 50 | **PE50-NFZ, PS50-NFZ** | **ZS50-SF, PZE30-NF, PZE50-NF, PZS30-NF, PZS50-NF** | 30 |
| 60, 100, 125 | **ZAS125-SF, PE125-NFZ** | **ZS100-SM, ZS125-SF, PZE60-NF, PZE125-NF, PZS60-NF** | 30 |
| 225, 250 | **ZAE250-SF, ZAS250-SF** | **ZE250-SF, ZS250-SF, ZS250-SM** | 32 |


The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㉔ in the table are connected to the terminals numbered ① to ㉔ on the rear of the circuit breaker.


⊬ : Handle Frame Centre Line
℄ : Handle Centre Line





3 poles breaker


| Terminal block | Combinations of accessories | Terminal code | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| | | ① | ② | ③ | ④ | ⑤ | ⑥ | ㉒ | ㉓ | ㉔ |
| 3 terminals | AX1C | | | | AXb1 | AXa1 | AXc1 | | | |
| | AL1C | | | | ALb1 | ALa1 | ALc1 | | | |
| | EL1C | | | | | | | ELb1 | ELa1 | ELc1 |
| | TL | | | | | | | TL | | TL |
| 6 terminals | AX2C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | |
| | AX1C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | |
| | AX1C+EL1C | | | | AXb1 | AXa1 | AXc1 | ELb1 | ELa1 | ELc1 |
| | AL1C+EL1C | | | | ALb1 | ALa1 | ALc1 | ELb1 | ELa1 | ELc1 |
| | AX1C+TL | | | | AXb1 | AXa1 | AXc1 | TL | | TL |
| | AL1C+TL | | | | ALb1 | ALa1 | ALc1 | TL | | TL |
| 9 terminals | AX2C+EL1C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ELb1 | ELa1 | ELc1 |
| | AX1C+AL1C+EL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | ELb1 | ELa1 | ELc1 |
| | AX2C+TL | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | TL | | TL |
| | AX1C+AL1C+TL | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | TL | | TL |

### Applicable breakers

| Frame size (A) | Types of breakers |
|---|---|
| | MCCB |
| 50 | **PS50-PF** |
| 100, 125 | **PS125-NF/PF/NM/NN, PS125-NE/PE** |

The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㉔ in the table are connected to the terminals numbered ① to ㉔ on the rear of the circuit breaker.

: Handle Frame Centre Line
: Handle Centre Line




2 poles breaker

| Terminal block | Combinations of accessories | Terminal code | | | | | |
|---|---|---|---|---|---|---|---|
| | | ⑲ | ⑳ | ㉑ | ㉒ | ㉓ | ㉔ |
| 3 terminals | AX1C | | | | AXb1 | AXa1 | AXc1 |
| | AL1C | | | | ALb1 | ALa1 | ALc1 |
| | SH | | | | C1 | | C2 |
| | UV | | | | D1 | | D2 |
| 6 terminals | AX2C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX1C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 |

3/4 poles breaker


| Terminal block | Combinations of accessories | Terminal code | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | ① | ② | ③ | ④ | ⑤ | ⑥ | ⑲ | ⑳ | ㉑ | ㉒ | ㉓ | ㉔ |
| 3 terminals | AX1C | | | | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL1C | | | | ALb1 | ALa1 | ALc1 | | | | | | |
| | SH | | | | | | | | | | C1 | | C2 |
| | UV | | | | | | | | | | D1 | | D2 |
| | PTA | PALa | | PALc | | | | | | | | | |
| 6 terminals | AX2C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL2C | | | | ALb1 | ALa1 | ALc1 | | | | ALb2 | ALa2 | ALc2 |
| | AX1C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| | AX1C+SH | | | | AXb1 | AXa1 | AXc1 | | | | C1 | | C2 |
| | AL1C+SH | | | | ALb1 | ALa1 | ALc1 | | | | C1 | | C2 |
| | AX1C+UV | | | | AXb1 | AXa1 | AXc1 | | | | D1 | | D2 |
| | AL1C+UV | | | | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| | AX1C+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL1C+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | | | | | | |
| 9 terminals | AX3C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | AXb3 | AXa3 | AXc3 |
| | AX1C+AL2C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | ALb2 | ALa2 | ALc2 |
| | AX2C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | AXb2 | AXa2 | AXc2 |
| | AX2C+SH | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | C1 | | C2 |
| | AX1C+AL1C+SH | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | C1 | | C2 |
| | AX2C+UV | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | D1 | | D2 |
| | AX1C+AL1C+UV | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| | AX1C+AL1C+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | | | | AXb1 | AXa1 | AXc1 |
| | AX1C+SH+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | | | | C1 | | C2 |
| | AL1C+UV+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| 12 terminals | AX4C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | AXb4 | AXa4 | AXc4 | AXb3 | AXa3 | AXc3 |
| | AX2C+AL2C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | AXb2 | AXa2 | AXc2 | ALb2 | ALa2 | ALc2 |
| | AX3C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 |
| | AX1C+AL1C+SH+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | AXb1 | AXa1 | AXc1 | C1 | | C2 |
| | AX1C+AL1C+UV+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | AXb1 | AXa1 | AXc1 | D1 | | D2 |
| | AX1C+AL2C+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | AXb1 | AXa1 | AXc1 | ALb2 | ALa2 | ALc2 |
| | AX2C+SH+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | AXb2 | AXa2 | AXc2 | C1 | | C2 |
| | AX2C+UV+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | AXb2 | AXa2 | AXc2 | D1 | | D2 |
| | AX2C+AL1C+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX3C+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 |

# 10. Flush-mounted (flush plate) auxiliary circuit terminal block (TB)

### Applicable breakers

| Frame size (A) | Types of breakers |
|---|---|
| | MCCB |
| 225, 250 | **E250-SF, S250-SF, S250-SM/SN** |
| | **PS250-PF/NN, PS250-NE/PE** |

The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㉔ in the table are connected to the terminals numbered ① to ㉔ on the rear of the circuit breaker.




3/4 poles breaker

| Terminal block | Combinations of accessories | Terminal code | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | ① | ② | ③ | ④ | ⑤ | ⑥ | ⑲ | ⑳ | ㉑ | ㉒ | ㉓ | ㉔ |
| 3 terminals | AX1C | | | | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL1C | | | | ALb1 | ALa1 | ALc1 | | | | | | |
| | SH | | | | | | | | | | C1 | | C2 |
| | UV | | | | | | | | | | D1 | | D2 |
| | PTA | PALa | | PALc | | | | | | | | | |
| 6 terminals | AX2C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL2C | | | | ALb1 | ALa1 | ALc1 | | | | ALb2 | ALa2 | ALc2 |
| | AX1C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| | AX1C+SH | | | | AXb1 | AXa1 | AXc1 | | | | C1 | | C2 |
| | AL1C+SH | | | | ALb1 | ALa1 | ALc1 | | | | C1 | | C2 |
| | AX1C+UV | | | | AXb1 | AXa1 | AXc1 | | | | D1 | | D2 |
| | AL1C+UV | | | | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| | AX1C+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL1C+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | | | | | | |
| 9 terminals | AX3C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | AXb3 | AXa3 | AXc3 |
| | AX1C+AL2C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | ALb2 | ALa2 | ALc2 |
| | AX2C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | AXb2 | AXa2 | AXc2 |
| | AX2C+SH | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | C1 | | C2 |
| | AX1C+AL1C+SH | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | C1 | | C2 |
| | AX2C+UV | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | D1 | | D2 |
| | AX1C+AL1C+UV | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| | AX1C+AL1C+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | | | | AXb1 | AXa1 | AXc1 |
| | AX1C+SH+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | | | | C1 | | C2 |
| | AL1C+UV+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| 12 terminals | AX4C | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | AXb4 | AXa4 | AXc4 | AXb3 | AXa3 | AXc3 |
| | AX2C+AL2C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | AXb2 | AXa2 | AXc2 | ALb2 | ALa2 | ALc2 |
| | AX3C+AL1C | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 |
| | AX2C+AL1C+SH | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | AXb2 | AXa2 | AXc2 | C1 | | C2 |
| | AX2C+AL1C+UV | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | AXb2 | AXa2 | AXc2 | D1 | | D2 |
| | AX1C+AL1C+SH+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | AXb1 | AXa1 | AXc1 | C1 | | C2 |
| | AX1C+AL1C+UV+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | AXb1 | AXa1 | AXc1 | D1 | | D2 |
| | AX1C+AL2C+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | AXb1 | AXa1 | AXc1 | ALb2 | ALa2 | ALc2 |
| | AX2C+SH+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | AXb2 | AXa2 | AXc2 | C1 | | C2 |
| | AX2C+UV+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | AXb2 | AXa2 | AXc2 | D1 | | D2 |
| | AX2C+AL1C+PTA | PALa | | PALc | ALb1 | ALa1 | ALc1 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX3C+PTA | PALa | | PALc | AXb1 | AXa1 | AXc1 | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 |


H : Handle Frame Centre Line
℄ : Handle Centre Line

### Applicable breakers

| Frame size (A) | Types of breakers |
|---|---|
| | MCCB |
| 400 | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF/CE** |
| 600, 630 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF/CE** |

The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㊱ in the table are connected to the terminals numbered ① to ㊱ on the rear of the circuit breaker.

: Handle Frame Centre Line
: Handle Centre Line




3/4 poles breaker

| Terminal block | Combinations of accessories | Terminal code | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | ① | ② | ③ | ④ | ⑤ | ⑥ | ⑦ | ⑧ | ⑨ | ⑩ | ⑪ | ⑫ | ㉛ | ㉜ | ㉝ | ㉞ | ㉟ | ㊱ |
| 3 terminals | AX1C | | | | | | | | | | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL1C | | | | | | | | | | ALb1 | ALa1 | ALc1 | | | | | | |
| | SH | | | | | | | | | | | | | | | | C1 | | C2 |
| | UV | | | | | | | | | | | | | | | | D1 | | D2 |
| | PTA | | | | | | | | | | | | | | | | PALa | | PALc |
| 6 terminals | AX2C | | | | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL2C | | | | | | | | | | ALb1 | ALa1 | ALc1 | | | | ALb2 | ALa2 | ALc2 |
| | AX1C+AL1C | | | | | | | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| 9 terminals | AX3C | | | | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AX1C+AL1C+SH | | | | | | | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | C1 | | C2 |
| | AX1C+AL1C+UV | | | | | | | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | D1 | | D2 |
| | AX1C+AL1C+PTA | | | | | | | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | PALa | | PALc |
| 12 terminals | AX1C+AL2C+PTA | | | | | | | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | PALa | | PALc | ALb2 | ALa2 | ALc2 |
| | AX2C+AL1C+PTA | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | PALa | | PALc | | | |
| | AX3C+AL1C | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| 15 terminals | AX2C+AL1C+SH+PTA | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | PALa | | PALc | C1 | | C2 |
| | AX2C+AL1C+UV+PTA | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | PALa | | PALc | D1 | | D2 |
| | AX3C+SH+PTA | | | | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | PALa | | PALc | C1 | | C2 |
| | AX3C+UV+PTA | | | | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | PALa | | PALc | D1 | | D2 |
| 18 terminals | AX3C+AL1C+SH+PTA | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | PALa | | PALc | C1 | | C2 |
| | AX3C+AL1C+UV+PTA | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | PALa | | PALc | D1 | | D2 |
| | AX3C+AL2C+PTA | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | PALa | | PALc | ALb2 | ALa2 | ALc2 |


# 10. Flush-mounted (flush plate) auxiliary circuit terminal block (TB)

### Applicable breakers

| Frame size (A) | Types of breakers | | A (mm) |
|---|---|---|---|
| | MCCB | ELCB | |
| 400 | **ZAE400-NF, ZAS400-NF, ZAS400-GF, E400-NF** | **ZE400-NF, ZS400-NF, ZS400-GF** | 102.4 |
| | **H400-NE, L400-NE** | | 139.4 |

The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㊱ in the table are connected to the terminals numbered ① to ㊱ on the rear of the circuit breaker.

: Handle Frame Centre Line
: Handle Centre Line




3/4 poles breaker


| Terminal block | Combinations of accessories | Terminal code | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | ① | ② | ③ | ④ | ⑤ | ⑥ | ⑦ | ⑧ | ⑨ | ⑩ | ⑪ | ⑫ | ㉛ | ㉜ | ㉝ | ㉞ | ㉟ | ㊱ |
| 3 terminals | AX1C | | | | | | | | | | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL1C | | | | | | | | | | ALb1 | ALa1 | ALc1 | | | | | | |
| | SH | | | | | | | | | | | | | | | | C1 | | C2 |
| | UV | | | | | | | | | | | | | | | | D1 | | D2 |
| | EL1C | | | | | | | | | | | | | | | | ELb1 | ELa1 | ELc1 |
| | TL | | | | | | | | | | | | | | | | TL | | TL |
| | PTA | | | | | | | | | | | | | | | | PALa | | PALc |
| 6 terminals | AX2C | | | | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AX1C+AL1C | | | | | | | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| | EL1C+SH | | | | | | | | | | | | | ELb1 | ELa1 | ELc1 | C1 | | C2 |
| | PTA+SH | | | | | | | | | | | | | PALa | | PALc | C1 | | C2 |
| | PTA+UV | | | | | | | | | | | | | PALa | | PALc | D1 | | D2 |
| 9 terminals | AX3C | | | | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AX2C+AL1C | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| 12 terminals | AX3C+AL1C | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |

### Applicable breakers

| Frame size (A) | Types of breakers | | A (mm) |
|---|---|---|---|
| | MCCB | ELCB | |
| 630 | **S630-CF, S630-NF, S630-NE, S630-GN, ZAS630-CF, ZAS630-NF** | **ZS630-CF, ZS630-NF** | 106.2 |
| | **H630-NE, L630-NE** | | 143.2 |
| 800 | **S800-CF, S800-NF, S800-RF, S800-PF, S800-NE, S800-RE, S800-PE, S800-NN, ZAS800-CF, ZAS800-NF** | **ZS800-CF, ZS800-NF** | 106.2 |
| | **H800-NE, L800-NE** | | 143.2 |
| 1000 | **S1000-CE** | | 106.2 |

The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㊱ in the table are connected to the terminals numbered ① to ㊱ on the rear of the circuit breaker.

卄 : Handle Frame Centre Line
℄ : Handle Centre Line




3/4 poles breaker

| Terminal block | Combinations of accessories | Terminal code | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | ① | ② | ③ | ④ | ⑤ | ⑥ | ⑦ | ⑧ | ⑨ | ⑩ | ⑪ | ⑫ | ㉛ | ㉜ | ㉝ | ㉞ | ㉟ | ㊱ |
| 3 terminals | AX1C | | | | | | | | | | AXb1 | AXa1 | AXc1 | | | | | | |
| | AL1C | | | | | | | | | | ALb1 | ALa1 | ALc1 | | | | | | |
| | SH | | | | | | | | | | | | | | | | C1 | | C2 |
| | UV | | | | | | | | | | | | | | | | D1 | | D2 |
| | EL1C | | | | | | | | | | | | | | | | ELb1 | ELa1 | ELc1 |
| | TL | | | | | | | | | | | | | | | | TL | | TL |
| | PTA | | | | | | | | | | | | | | | | PALa | | PALc |
| 6 terminals | AX2C | | | | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AX1C+AL1C | | | | | | | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| | EL1C+SH | | | | | | | | | | | | | ELb1 | ELa1 | ELc1 | C1 | | C2 |
| | PTA+SH | | | | | | | | | | | | | PALa | | PALc | C1 | | C2 |
| | PTA+UV | | | | | | | | | | | | | PALa | | PALc | D1 | | D2 |
| 9 terminals | AX3C | | | | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | | | | | | |
| | AX2C+AL1C | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |
| 12 terminals | AX3C+AL1C | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 | ALb1 | ALa1 | ALc1 | | | | | | |

# 10. Flush-mounted (flush plate) auxiliary circuit terminal block (TB)

### Applicable breakers

| Frame size (A) | Types of breakers MCCB | Fig. |
|---|---|---|
| 1250 | **S1250-NE, S1250-GE, S1250-NN** | Fig. 1 |
| 1600 | **S1600-NE, S1600-NN** | Fig. 2 |

The terminal arrangement below is the auxiliary circuit terminal arrangement when viewing the flush-mounted circuit breaker from the rear side.
The terminals of the accessories shown in ① to ㊱ in the table are connected to the terminals numbered ① to ㊱ on the rear of the circuit breaker.

Fig. 1






Fig. 2





H : Handle Frame Centre Line
℄ : Handle Centre Line

3/4 poles breaker

| Terminal block | Combinations of accessories | Terminal code ① | ② | ③ | ④ | ⑤ | ⑥ | ㉕ | ㉖ | ㉗ | ㉘ | ㉙ | ㉚ | ㉛ | ㉜ | ㉝ | ㉞ | ㉟ | ㊱ |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 3 terminals | AX1C | | | | | | | | | | | | | | | | AXb1 | AXa1 | AXc1 |
| | AL1C | | | | | | | | | | | | | | | | ALb1 | ALa1 | ALc1 |
| | SH | | | | C1 | | C2 | | | | | | | | | | | | |
| | UV | | | | D1 | | D2 | | | | | | | | | | | | |
| | PTA | | | | PALa | | PALc | | | | | | | | | | | | |
| 6 terminals | AX2C | | | | | | | | | | | | | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AL2C | | | | | | | | | | | | | ALb2 | ALa2 | ALc2 | ALb1 | ALa1 | ALc1 |
| | AX1C+AL1C | | | | | | | | | | | | | ALb1 | ALa1 | ALc1 | AXb1 | AXa1 | AXc1 |
| | PTA+SH | PALa | | PALc | C1 | | C2 | | | | | | | | | | | | |
| | PTA+UV | PALa | | PALc | D1 | | D2 | | | | | | | | | | | | |
| 9 terminals | AX3C | | | | | | | | | | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX2C+AL1C | | | | | | | | | | ALb1 | ALa1 | ALc1 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX1C+AL2C | | | | | | | | | | ALb2 | ALa2 | ALc2 | ALb1 | ALa1 | ALc1 | AXb1 | AXa1 | AXc1 |
| 12 terminals | AX4C | | | | | | | AXb4 | AXa4 | AXc4 | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX3C+AL1C | | | | | | | ALb1 | ALa1 | ALc1 | AXb3 | AXa3 | AXc3 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |
| | AX2C+AL2C | | | | | | | ALb2 | ALa2 | ALc2 | AXb1 | AXa1 | AXc1 | AXb2 | AXa2 | AXc2 | AXb1 | AXa1 | AXc1 |

**Note:** The combinations in the table above are reference examples.

# 11. Plug-in auxiliary circuit terminal block (PMC)




Five auxiliary circuit terminals (self-engaging) constitute a terminal block.
Shown in the table below are standard terminal arrangements as seen from the rear of the plug-in base for standard type.
Contact us for non-standard arrangements.

| Breaker | PE30-NF, PE50-NF, PE60-NF, PE125-NF, PS30-NF, PS50-NF, PS60-NF, S50-SF, S125-SF | PE30-NF/NN, PE50-NF/NN, PE60-NF, PE125-NF/NN, PS30-NF, PS50-NF, PS60-NF, S50-SF, S125-SF/SN | H400-NE, L400-NE |
|---|---|---|---|
| | 2P ① | 3P ② | 3P |
| Number of auxiliary circuit terminals (Max allowable) | | | |
| Arrangement 1 | C1 C2 | AXc1 AXa1 AXb1 C1 C2<br>ALc1 ALa1 ALb1 C1 C2 | AXc1 AXa1 AXb1 AXc2 AXa2 / AXb2 C1 C2<br>AXc2 AXa2 AXb2 ALc1 ALa1 / ALb1 C1 C2 |
| Arrangement 2 | D1 D2 | AXc1 AXa1 AXb1 D1 D2<br>ALc1 ALa1 ALb1 D1 D2 | AXc1 AXa1 AXb1 AXc2 AXa2 / AXb2 D1 D2<br>AXc1 AXa1 AXb1 ALc1 ALa1 / ALb1 D1 D2 |
| Arrangement 3 | AXc1 AXa1 AXb1<br>ALc1 ALa1 ALb1 | AXc1 AXa1 AXb1 ALc1 ALa1 | AXc1 AXa1 AXb1 PALc PALa / OP1 OP2 C1 C2 (*1)<br>AXc1 AXa1 AXb1 PALc PALa / OP1 OP2 D1 D2 (*1) |

**Notes:**
①: This is the terminal arrangement of the plug-in base for the distribution board.
②: The terminal arrangement of the plug-in base for the distribution board is the same as that of the plug-in base for the switchboard.
＊1: If the OCR controller is installed separately, substitute OS1 and OS2 for OP1 and OP2 and connect these terminals to the controller terminals having the same numbers.

# 11. Plug-in auxiliary circuit terminal block (PMC)




Five auxiliary circuit terminals (self-engaging) constitute a terminal block.
Shown in the table below are standard terminal arrangements as seen from the rear of the plug-in base for standard type.
Contact us for non-standard arrangements.

* The auxiliary circuit terminals cannot be used with the XM30PB plug-in type.
* If the number of auxiliary circuit terminals (self-engaging) is insufficient for S1250-NE/GE/NN, lead wires are to be used along with the auxiliary circuit terminals. Please state the accessories for which lead wires are used, when ordering.

| Breaker | S100-GF, S125-GF, H100-NF, L100-NF, H125-NF, L125-NF, H225-NF, L225-NF | S630-CF/NF/NE/GN, S800-CF/NF/NE/RF/RE/PF/PE/NN, S1250-NE/GE/NN, H630-NE, L630-NE, H800-NE, L800-NE | TL-1000NE, TL-1200NE |
|---|---|---|---|
| | 3P | 3P | 3P, 4P |
| Number of auxiliary circuit terminals (Max allowable) | 5 | 10<br>5 | 10<br>5 |
| Arrangement 1 | AXc1 AXa1 AXb1 C1 C2<br>ALc1 ALa1 ALb1 C1 C2 | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 OP1 OP2 D1 D2 (OP1 OP2 *1)<br>AXc2 AXa2 AXb2 PALc PALa | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 OP1 OP2 U1 U2 (OP1 OP2 *1)<br>AXc2 AXa2 AXb2 PALc PALa |
| Arrangement 2 | AXc1 AXa1 AXb1 D1 D2<br>ALc1 ALa1 ALb1 D1 D2 | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 OP1 OP2 C1 C2 (OP1 OP2 *1)<br>AXc2 AXa2 AXb2 PALc PALa | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 OP1 OP2 P1 P2 (OP1 OP2 *1) (P1 P2 *2)<br>AXc2 AXa2 AXb2 PALc PALa |
| Arrangement 3 | AXc1 AXa1 AXb1 ALc1 ALa1 | | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 OP1 OP2 S1 S2 (OP1 OP2 *1) (S1 S2 *2)<br>AXc2 AXa2 AXb2 PALc PALa |

* 1: If the OCR controller is installed separately, substitute OS1 and OS2 for OP1 and OP2 and connect these terminals to the controller terminals having the same numbers.
* 2: If the UVT controller is installed separately, substitute UC1 and UC2 for P1 and P2 and connect these terminals to the UC1 and UC2 terminals of the controller.




Five auxiliary circuit terminals (self-engaging) constitute a terminal block.
Shown in the table below are standard terminal arrangements as seen from the rear of the plug-in base for standard type.
Contact us for non-standard arrangements.

| Breaker | PS50-PF, PS125-NF/PF | PS50-PF, PS125-NF/PF, PS125-NE/PE/NN, PS250-PF/NN, PS250-NE/PE, E250-SF, S250-SF, S250-SN | PS400-CF/NF/NE/GF/GE/NN, PS630-CF/NF/NE/GF/GE/NN, PH400-CF/CE, PH630-CF/CE |
|---|---|---|---|
| | 2P | 3P, 4P ③ | 3P |
| Number of auxiliary circuit terminals (Max allowable) | ☐ ☐ ☐ | ☐ ☐ ☐ ☐ ☐ | ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ |
| Arrangement 1 | AXc1 AXa1 AXb1 | AXc1 AXa1 AXb1 C1 C2 | AXc1 AXa1 AXb1 AXc2 AXa2 AXb2 ＼ AXc3 AXa3 AXb3 |
| Arrangement 2 | ALc1 ALa1 ALb1 | AXc1 AXa1 AXb1 D1 D2 | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 ＼ ALc2 ALa2 ALb2 |
| Arrangement 3 | ＼ C1 C2 | ALc1 ALa1 ALb1 C1 C2 | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 ＼ AXc2 AXa2 AXb2 |
| Arrangement 4 | ＼ D1 D2 | ALc1 ALa1 ALb1 D1 D2 | AXc1 AXa1 AXb1 AXc2 AXa2 AXb2 PALc PALa C1 C2 |
| Arrangement 5 | | AXc1 AXa1 AXb1 ALc1 ALa1 | AXc1 AXa1 AXb1 AXc2 AXa2 AXb2 PALc PALa D1 D2 |
| Arrangement 6 | | ＼ ＼ ＼ PALc PALa | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 PALc PALa C1 C2 |
| Arrangement 7 | | AXc1 AXa1 AXb1 PALc PALa | AXc1 AXa1 AXb1 ALc1 ALa1 ALb1 PALc PALa D1 D2 |
| Arrangement 8 | | ALc1 ALa1 ALb1 PALc PALa | ALc1 ALa1 ALb1 ALc2 ALa2 ALb2 PALc PALa ＼ ＼ |
| Arrangement 9 | | PALc PALa ＼ C1 C2 | ALc1 ALa1 ALb1 ＼ ＼ ＼ PALc PALa C1 C2 |
| Arrangement 10 | | PALc PALa ＼ D1 D2 | ALc1 ALa1 ALb1 ＼ ＼ ＼ PALc PALa D1 D2 |

Note ③: 4P can only be used with S250-SN.


# 11. Plug-in auxiliary circuit terminal block (PMB)



Auxiliary circuit terminals are of self-engaging type.
Shown in the table below are standard terminal arrangements as seen from the front of the plugin base for standard type.
Contact us for non-standard arrangements.

Terminal screw: M3.5
Suitable wire size: 0.5 – 0.75mm$^2$

| Breaker | S100-GF, S125-GF | S100-GF, S125-GF, H100-NF, H125-NF, H225-NF, L100-NF, L125-NF, L225-NF | S630-CF/NF/NE/GN, S800-CF/NF/NE/RF/RE/PF/PE/NN, H400-NE, L400-NE, H630-NE, L630-NE, H800-NE, L800-NE |
|---|---|---|---|
| | 2P | 3P, 4P | 3P, 4P |
| Number of auxiliary circuit terminals (Max allowable) | | | |
| Arrangement 1 | C1 / C2 | AXa1 AXa2 ALa1 C1 / AXb1 AXb2 ALb1 / AXc1 AXc2 ALc1 C2 | AXa1 AXa2 AXa3 ALa1 / AXb1 AXb2 AXb3 ALb1 / AXc1 AXc2 AXc3 ALc1 / C1 / C2 |
| Arrangement 2 | D1 / D2 | AXa1 AXa2 ALa1 D1 / AXb1 AXb2 ALb1 / AXc1 AXc2 ALc1 D2 | AXa1 AXa2 AXa3 ALa1 / AXb1 AXb2 AXb3 ALb1 / AXc1 AXc2 AXc3 ALc1 / D1 / D2 |
| Arrangement 3 | AXa1 AXa2 / AXb1 AXb2 / AXc1 AXc2 | | |
| Arrangement 4 | AXa1 ALa1 / AXb1 ALb1 / AXc1 ALc1 | | |



Auxiliary circuit terminals are of self-engaging type.
Shown in the table below are standard terminal arrangements as seen from the front of the plugin base for standard type.
Contact us for non-standard arrangements.

Terminal screw: M3.5
Suitable wire size: 0.5 – 0.75mm$^2$

| Breaker | PS50-PF, PS125-NF/PF, PS125-NE/PE/NN | PS250-PF/NN, PS250-NE/PE | PS400-CF/NF/NE/GF/GE/NN, PS630-CF/NF/NE/GF/GE/NN, PH400-CF/CE, PH630-CF/CE |
|---|---|---|---|
| | 3P, 4P | 3P, 4P | 3P, 4P |
| Number of auxiliary circuit terminals (Max allowable) | | | |
| Arrangement 1 | AXa1 AXa2 C1<br>Axb1 Axb2<br>AXc1 AXc2 C2 | AXa1 AXa2 ALa1 C1<br>AXb1 AXb2 ALb1<br>AXc1 AXc2 ALc1 C2 | AXa1 AXa2 ALa1 AXa3 C1<br>Axb1 Axb2 ALb1 Axb3<br>AXc1 AXc2 ALc1 AXc3 C2 |
| Arrangement 2 | AXa1 AXa2 D1<br>Axb1 Axb2<br>AXc1 AXc2 D2 | AXa1 AXa2 ALa1 D1<br>AXb1 AXb2 ALb1<br>AXc1 AXc2 ALc1 D2 | AXa1 AXa2 ALa1 AXa3 D1<br>Axb1 Axb2 ALb1 Axb3<br>AXc1 AXc2 ALc1 AXc3 D2 |
| Arrangement 3 | AXa1 ALa1 C1<br>Axb1 ALb1<br>AXc1 ALc1 C2 | | |
| Arrangement 4 | AXa1 ALa1 D1<br>Axb1 ALb1<br>AXc1 ALc1 D2 | | |


**Note:** Optional cable for the preferential trip alarm (PTA) is lead wire draw-in.

# 12. DIN rail adapter


The circuit breaker can easily be mounted on a 35 mm wide DIN rail by mounting the DIN rail adapter on the rear of the circuit breaker.

## ■ Applicable breakers


| Frame size (A) | MCCB | ELCB | Number of poles | DIN rail adaptor Order code |
|---|---|---|---|---|
| 30, 50 | **PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, ZS50-SF** | 3P | T2DA16L |
| | **S50-SF** | | 3P, 4P | |
| | **PS50-PF** | | 3P, 4P | TPDA16 |
| 60, 100, 125 | **PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN, ZAS125-SF, NS125-SF** | **PZE60-NF, PZS60-NF, PZE125-NF/NFN, ZS125-SF, ZS100-SM, ZNS125-SF** | 3P | T2DA16L |
| | **S125-SF, S125-SN** | | 3P, 4P | |
| | **PS125-NM** | | 3P | TPDA16 |
| | **PS125-NF/PF/NN, PS125-NE/PE** | | 3P, 4P | |
| | **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | 3P, 4P | T2DA12 |




T2DA12



T2DA16L



TPDA16



# 13. Door Flange (DF)

Door flanges are recommended to be used to cover the cutout of a switchboard panel.

Fig. 1






Fig. 2




**Dimensions, mm**

| Frame size (A) | Types of breakers | | Order codes | Fig. | A | B | C | D | E | F | | G | | H | | K | d | t |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | MCCB | ELCB | | | | | | | | Min | Max | Min | Max | Min | Max | | | |
| 30, 50, 60, 100, 125 | **PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN** | T2DF25 | 1 ① | 65 | 65 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| | **S50-SF, S125-SF/SN, ZAS125-SF, NAE125-SF, NAS125-SF, NS125-SF** | **ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF** | T2DF25 | 1 ① | 65 | 65 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| | **PS50-PF, PS125-NF/PF/NM/NN, PS125-NE/PE** | | T2DF25 | 1 ① | 65 | 65 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| | **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | T2DF25 | 1 ① | 77.5 | 77.5 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| | **H100-NF, H125-NF, L100-NF, L125-NF** | | T2DF25 | 1 ① | 82.5 | 82.5 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| 225, 250 | **ZAS225-GF, ZAS250-GF** | **ZS225-GF, ZS250-GF** | T2DF25 | 1 ① | 82.5 | 82.5 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| | **E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF** | **ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF** | T2DF25 | 1 ① | 82.5 | 82.5 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| | **PS250-PF/NN, PS250-NE/PE** | | T2DF25 | 1 ① | 82.5 | 82.5 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| | **H225-NF/NE, H250-NF, L225-NF, L250-NF** | | T2DF25 | 1 ① | 82.5 | 82.5 | 105 | 50 | 92 | 37 | 42 | 37 | 42 | 32 | 45 | — | M3×0.5 | 2 |
| 400, 600, 630, 800 | **E400-NF, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF** | **ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | T2DF40 | 2 ① | 130 | 130 | 135 | 95 | 120 | 48 | 56 | 48 | 56 | 57 | 90 | 80 | M3×0.5 | 2 |
| | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | | T2DF40 | 2 ① | 130 | 130 | 135 | 95 | 120 | 48 | 56 | 48 | 56 | 57 | 90 | 80 | M3×0.5 | 2 |
| | **H400-NE, L400-NE** | | T2DF40 | 2 ① | 130 | 130 | 135 | 95 | 120 | 48 | 56 | 48 | 56 | 57 | 90 | 80 | M3×0.5 | 2 |
| | **S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NN, ZAS630-CF/NF, ZAS800-CF/NF, NS630-NF, NS800-NF, S800-NE/RE/PE, H630-NE, L630-NE, H800-NE, L800-NE** | **ZS630-CF/NF, ZS800-CF/NF** | T2DF40 | 2 ② | 132 | 141 | 135 | 95 | 120 | 48 | 56 | 48 | 56 | 57 | 90 | 80 | M3×0.5 | 2 |
| 1000, 1200 | **S1000-CE/NN** | | T2DF40 | 2 ② | 132 | 141 | 135 | 95 | 120 | 48 | 56 | 48 | 56 | 57 | 90 | 80 | M3×0.5 | 2 |
| | **TL-1000NE, TL-1200NE** | | TAA-5 | 2 ② | 170 | 200 | 150 | 120 | 135 | 51 | 63.5 | 51 | 63.5 | 85 | 115 | 80 | M3×0.5 | 5 |
| 1250, 1600 | **S1250-NE/GE/NN, S1600-NE/NN** | | T2DFX6 | 2 ② | 170 | 200 | 150 | 120 | 135 | 51 | 63.5 | 51 | 63.5 | 85 | 115 | 80 | M3×0.5 | 2 |
| 2000, 2500, 3200 | **XS2000NE/NN, XS2500NE/NN, XS3200NE/NN** | | TAA-10 | 2 ② | 193 | 257 | 200 | 175 | 175 | 74 | 83.5 | 74 | 83.5 | 123 | 170 | 150 | M4×0.7 | 5 |

**Notes:**
①: ℄ Handle centre line is applied.
②: ASL Arrangement standard line is applied.

# 7 Characteristics and Outline Dimensions

## Moulded Case Circuit Breakers


- PE30-NF, PE50-NF, PS30-NF, PS50-NF ····· 7-4
- S50-SF ····· 7-6
- PE60-NF, PS60-NF, PE125-NF ····· 7-8
- S125-SF ····· 7-10
- PS125-NF ····· 7-12
- PS50-PF, PS125-PF ····· 7-14
- PS125-NE ····· 7-16
- PS125-PE ····· 7-18
- S100-GF ····· 7-20
- S125-GF ····· 7-22
- H100-NF, L100-NF ····· 7-24
- H125-NF, L125-NF ····· 7-26
- E250-SF ····· 7-28
- S250-SF ····· 7-30
- PS250-PF ····· 7-32
- PS250-NE, PS250-PE ····· 7-34
- H225-NF, L225-NF ····· 7-36
- H250-NF, L250-NF ····· 7-38
- H225-NE ····· 7-40
- E400-NF ····· 7-42
- PS400-CF, PS400-NF, PS400-GF ····· 7-44
- PS400-NE, PS400-GE ····· 7-46
- PH400-CF ····· 7-48
- PH400-CE ····· 7-50
- H400-NE, L400-NE ····· 7-52
- S630-CF, S630-NF ····· 7-54
- S630-NE ····· 7-56
- PS630-CF, PS630-NF, PS630-GF ····· 7-58
- PS630-NE, PS630-GE ····· 7-60
- PH630-CF ····· 7-62
- PH630-CE ····· 7-64
- H630-NE, L630-NE ····· 7-66
- S800-CF, S800-NF, S800-RF, S800-PF ····· 7-68
- S800-NE, S800-RE, S800-PE ····· 7-70
- H800-NE, L800-NE ····· 7-72
- S1000-CE ····· 7-74
- S1250-NE, S1250-GE ····· 7-76
- TL-1000NE, TL-1200NE ··· 7-78
- S1600-NE ····· 7-80
- XS2000NE ····· 7-82
- XS2500NE ····· 7-84
- XS3200NE ····· 7-86


## Moulded Case Circuit Breakers for motor protection


- E30-NM, E50-NM, S30-NM, S50-NM ····· 7-88
- E100-NM ····· 7-90
- S250-SM ····· 7-92


## Switch-disconnectors


- PE30-NN, PE50-NN ····· 7-94
- PE125-NN ····· 7-96
- S125-SN ····· 7-98
- PS125-NN ····· 7-100
- S250-SN ····· 7-102
- PS250-NN ····· 7-104
- PS400-NN ····· 7-106
- PS630-NN ····· 7-108
- S630-GN, S800-NN, S1000-NN ····· 7-110
- S1250-NN ····· 7-112
- S1600-NN ····· 7-114


## Non-automatic trip breakers


- XS2000NN ····· 7-116
- XS2500NN, XS3200NN ··· 7-118

## Circuit Breaker with earth leakage alarm


- PE50-NFZ, PS50-NFZ, PE125-NFZ ····· 7-120
- ZAS125-SF ····· 7-122
- ZAS50-GF, ZAS100-GF ··· 7-124
- ZAS125-GF ····· 7-126
- ZAE250-SF, ZAS250-SF ··· 7-128
- ZAS225-GF ····· 7-130
- ZAS250-GF ····· 7-132
- ZAE400-NF, ZAS400-NF, ZAS400-GF ····· 7-134
- ZAS630-CF, ZAS630-NF ··· 7-136
- ZAS800-CF, ZAS800-NF ··· 7-138


## Circuit Breaker with earth leakage alarm for distribution boards and control boards


- TB50KSL ····· 7-140
- TB50KSZ, TB100KSZ ··· 7-142


## Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm


- NAE125-SF, NAS125-SF ····· 7-144
- NAE250-SF, NAS250-SF ····· 7-146
- NAE400-NF, NAS400-NF ····· 7-148


## Single phase 3-wire circuit breakers with neutral phase open protection


- PE50-NFN, PE125-NFN ··· 7-150
- NS125-SF ····· 7-152
- NE250-SF, NS250-SF ··· 7-154
- NE400-NF, NS400-NF ··· 7-156
- NS630-NF ····· 7-158
- NS800-NF ····· 7-160


## Circuit Breaker for distribution boards


- TB-5S ····· 7-162
- TB-5P ····· 7-164
- TB-5D ····· 7-166
- TB-51C, TB-52C ····· 7-168
- Plug-in base for Distribution boards / Branching bars··· 7-170


## Earth Leakage Circuit Breakers


- PZE30-NF, PZE50-NF, PZS30-NF, PZS50-NF ··· 7-174
- ZS50-SF ····· 7-176
- PZE60-NF, PZS60-NF, PZE125-NF ····· 7-178
- ZS125-SF ····· 7-180
- ZS100-GF ····· 7-182
- ZS125-GF ····· 7-184
- ZE250-SF, ZS250-SF ····· 7-186
- ZS225-GF ····· 7-188
- ZS250-GF ····· 7-190
- ZE400-NF, ZS400-NF, ZS400-GF ····· 7-192
- ZS630-CF, ZS630-NF ··· 7-194
- ZS800-CF, ZS800-NF ··· 7-196


## Earth Leakage Circuit Breakers for motor protection


- ZE30-NM, ZE50-NM, ZS30-NM, ZS50-CM ····· 7-198
- ZE100-NM ····· 7-200
- ZS100-SM ····· 7-202
- ZS250-SM ····· 7-204


## Single phase 3-wire earth leakage circuit breakers with neutral phase open protection


- PZE50-NFN, PZE125-NFN ····· 7-206
- ZNS125-SF ····· 7-208
- ZNE250-SF, ZNS250-SF ··· 7-210
- ZNE400-NF, ZNS400-NF ··· 7-212

## Earth Leakage Circuit Breaker for distribution boards and control boards


- TZ30EC, TZ50EE ····· 7-214
- TZ100EC ····· 7-216
- TZ-51C, TZ-52C ····· 7-218


## Special Breakers


- High-Performance Electronic Smart Circuit Breaker (TPOU type OCR) ····· 7-220
- High-Performance Electronic Circuit Breaker (XOW type OCR) ····· 7-222
- 690V AC Circuit Breaker ··· 7-224
- Special Mounting Dimensions 400A Frame Circuit Breaker 7-230
- Heat Resistant Circuit Breaker for Emergency Power Supplies ····· 7-242


## Earth Leakage Relays


- TZS series ····· 7-243


## Circuit Breaker with motor operators


- S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF, ZS100-GF, ZS125-GF ····· 7-244
- PS50-PF, PS125-NF/PF/NE/PE /NM/NN ····· 7-245
- ZAS225-GF, ZAS250-GF, ZS225-GF, ZS250-GF ··· 7-246
- E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF, ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF ····· 7-247
- PS250-PF/NE/PE/NN ····· 7-248
- H100-NF, L100-NF, H125-NF, L125-NF, H225-NF/NE, L225-NF, H250-NF, L250-NF ····· 7-249
- E400-NF, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF, ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF ····· 7-250
- PS400-CF/NF/GF/NE/GE/NN, PH400-CF/CE ····· 7-251
- PS630-CF/NF/GF/NE/GE/NN, PH630-CF/CE ····· 7-252
- H400-NE, L400-NE ····· 7-253
- S630-CF/NF/NE/GN, ZAS630-CF/NF, NS630-NF, ZS630-CF/NF, S800-CF/NF/NE/RF/RE/PF/PE/NN, ZAS800-CF/NF, NS800-NF, ZS800-CF/NF ····· 7-254
- S1000-CE/NN ····· 7-255
- H630-NE, L630-NE ····· 7-256
- H800-NE, L800-NE ····· 7-257
- S1250-NE/GE/NN ····· 7-258
- TL-1000NE, TL-1200NE ··· 7-259
- S1600-NE/NN ····· 7-260



# 7 Characteristics and Outline Dimensions TemBreak PRO

## Moulded Case Circuit Breakers

## PE30-NF, PE50-NF, PS30-NF, PS50-NF


## Ratings and Specifications

| Frame size (A) | | | | 30 | | 50 | | 30 | | 50 | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | PE30-NF | | PE50-NF | | PS30-NF | | PS50-NF | |
| Number of poles | | | | 2 | 3 | 2 | 3 | 2 | 3 | 2 | 3 |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | | 3 | 15 | 15 | 40 | 3 | 15 | 15 | 40 |
| Calibrated at 40°C | | | | 5 | 20 | 20 | 50 | 5 | 20 | 20 | 50 |
| 45°C | | | | 10 | 30 | 30 | | 10 | 30 | 30 | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | 690 | | 690 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | | — | | — | |
| Utilization Category | | | | A | | A | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | — | | — | | — | | — | |
| IEC 60947-2 | | | 500V | — | | 2.5/2.5 | | 2.5/2.5 | | 7.5/7.5 | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 1.5/1.5 | | 2.5/2.5 | | 2.5/2.5 | | 7.5/7.5 | |
| | | | 415V | 1.5/1.5 | | 2.5/2.5 | | 2.5/2.5 | | 7.5/7.5 | |
| | | | 380V | 1.5/1.5 | | 5/5 | | 5/5 | | 7.5/7.5 | |
| | | | 240V | 2.5/2.5 | | 7.5/7.5 | | 7.5/7.5 | | 15/15 | |
| | ① | DC | 250V | — | | 2.5/2.5 ⑰ ㉗ | | 2.5/2.5 ⑰ ⑲ ㉗ | | 7.5/7.5 ⑰ ㉗ | |
| | | | 125V | — | | 2.5/2.5 ⑰ ㉗ | | 2.5/2.5 ⑰ ⑲ ㉗ | | 7.5/7.5 ⑰ ㉗ | |
| NK | | AC | 690V | — | | — | | — | | — | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 1.5/1.5 | | 2.5/2.5 | | 2.5/2.5 | | 7.5/7.5 | |
| | | | 240V | 2.5/2.5 | | 7.5/7.5 | | 7.5/7.5 | | 15/15 | |
| | ① | DC | 250V | — | | 2.5/2.5 ⑰ ㉗ | | 2.5/2.5 ⑰ ⑲ ㉗ | | 7.5/7.5 ⑰ ㉗ | |
| Weight (◉ marked standard type) kg | | | | 0.5 | 0.7 | 0.5 | 0.7 | 0.5 | 0.7 | 0.5 | 0.7 |
| ■Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ ㊺ | | ◉ ㊺ | | ◉ ㊺ | | ◉ ㊺ | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | | — | | — | |
| | Standard (PMC) | | | — | ○ | — | ○ | — | ○ | — | ○ |
| For distribution boards (PMD) ㊽ | | | | ○ | | ○ | | ○ | | ○ | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | | — | | — | | — | | — | |
| TemPlug70 (PG) | | | | — | | — | | — | | — | |
| DIN rail mount | | | | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ |
| ■Accessories (optional) | | | Symbol | | | | | | | | |
| Externally mounted: Motor operator | | | M C | — | | — | | — | | — | |
| External operating handle: Breaker-mounted | | | H B | — | ● | — | ● | — | ● | — | ● |
| External operating handle: Door-mounted (variable depth) | | | H P | — | ● | — | ● | — | ● | — | ● |
| Toggle extension | | | H A | — | | — | | — | | — | |
| Mechanical interlock: Slide type | | | M S | — | ● | — | ● | — | ● | — | ● |
| Mechanical interlock: Rear-connected type | | | M B | — | | — | | — | | — | |
| Mechanical interlock: Link type | | | M L | — | | — | | — | | — | |
| Mechanical interlock: Wire type | | | M W | — | | — | | — | | — | |
| Toggle holder | | | H H | ● | | ● | | ● | | ● | |
| Toggle lock | | | H L | ● | | ● | | ● | | ● | |
| Terminal cover: For front-connected | | | C F | ● | | ● | | ● | | ● | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | ● | | ● | | ● | |
| Terminal block for lead | | | T F | ● | | ● | | ● | | ● | |
| Door flange | | | D F | ● | | ● | | ● | | ● | |
| CE marking | | | | Yes | | Yes | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Thermal-magnetic ⑦ | | Thermal-magnetic | | Thermal-magnetic ⑦ | | Thermal-magnetic | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | | Yes ⑫ | | Yes | | Yes ⑫ | | Yes | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC. ⑦ : Hydraulic-magnetic type for below 10A rating.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ⑲ : Only applicable for 15A and above.
㉗ : Applicable to only 2 poles breakers. ㊺ : A wire clamping terminal is provided.
㊸ : For the extension bars, please place the order separately in parts.
⑫ : There are some limitations. See page 5-23 for details. ㊽ : See page 7-172 for the outline dimensions.

## Time/Current characteristic curves





## Ambient compensating curves

(3—10A)




(15—50A)




## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 2 | | | | | | | | | | | |
| 3 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PE30-NF, PE50-NF, PS30-NF, PS50-NF


## Front-connected




## Rear-connected





| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 3-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)




## Flush-mounted




| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 3-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |

Please check the rear side for a detailed outline drawing of the terminals.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

# Moulded Case Circuit Breakers


## S50-SF




## Ratings and Specifications

| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 50 | | | | | | | | |
| Type | | | | S50-SF | | | | | | | | |
| Number of poles | | | | 2 | 3 | 4 | | | | | | |
| ■ Ratings | | | | | | | | | | | | |
| Rated current, A | | | | 15 | 40 | | | | | | | |
| Calibrated at 40°C | | | | 20 | 50 | | | | | | | |
| 45°C | | | | 30 | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | | | | | | |
| Utilization Category | | | | A | | | | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/3 | | | | | | | | |
| IEC 60947-2 | | | 500V | 12/6 | | | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 25/13 | | | | | | | | |
| | | | 415V | 30/15 | | | | | | | | |
| | | | 380V | 30/15 | | | | | | | | |
| | | | 240V | 50/25 | | | | | | | | |
| | | ① DC | 250V | 25/13 ⑰ ㉗ | | | | | | | | |
| | | | 125V | 40/20 ⑰ ㉗ | | | | | | | | |
| NK | | AC | 690V | — | | | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 25/13 | | | | | | | | |
| | | | 240V | 50/25 | | | | | | | | |
| | | ① DC | 250V | 25/13 ⑰ ㉗ | | | | | | | | |
| Weight (◉ marked standard type) kg | | | | 0.6 | 0.8 | 1.0 | | | | | | |
| ■ Connections and Mountings | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ ㊺ | | | | | | | | |
| | With extension bars | | | ○ ㊸ | | | | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | | | | | | | |
| | Standard (PMC) | | | — | ○ | — | | | | | | |
| For distribution boards (PMD) ㊽ | | | | ○ | | — | | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | — | | | | | | |
| Draw-out type (DR) | | | | — | | | | | | | | |
| TemPlug70 (PG) | | | | ○ | | — | | | | | | |
| DIN rail mount | | | | — | ○ ⑪ | | | | | | | |
| ■ Accessories (optional) | | | Symbol | | | | | | | | | |
| Externally mounted: Motor operator | | | M C | — | | | | | | | | |
| External operating handle | Breaker-mounted | | H B | — | ● | | | | | | | |
| | Door-mounted (variable depth) | | H P | — | ● | | | | | | | |
| Toggle extension | | | H A | — | | | | | | | | |
| Mechanical interlock | Slide type | | M S | — | ● | | | | | | | |
| | Rear-connected type | | M B | — | | | | | | | | |
| | Link type | | M L | — | | | | | | | | |
| | Wire type | | M W | — | | | | | | | | |
| Toggle holder | | | H H | ● | | | | | | | | |
| Toggle lock | | | H L | ● | | | | | | | | |
| Terminal cover | For front-connected | | C F | ● | | | | | | | | |
| | For rear-connected and plug-in | | C R | ● | | | | | | | | |
| Terminal block for lead | | | T F | ● | | | | | | | | |
| Door flange | | | D F | ● | | | | | | | | |
| CE marking | | | | Yes | | | | | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | | | | | | |
| Colour of cover | | | | Grey Blue | | | | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | | | | | | |
| Suitability for isolation | | | | Yes | | | | | | | | |
| Reverse connection | | | | Yes | | | | | | | | |

## Time/Current characteristic curves




## Ambient compensating curves




**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㉗ : Applicable to only 2 poles breakers.
㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts.
㊽ : See page 7-172 for the outline dimensions.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX (Auxiliary switch) | AL (Alarm switch) | SH (Shunt trip) | UV (Under voltage trip) | AX + AL | AX + SH | AX + UV | AL + SH | AL + UV | AX + AL + SH | AX + AL + UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 2 | | | | | | | | | | | |
| 3 4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) S50-SF

## Front-connected




## Rear-connected





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |


Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)

Detail of connecting part





Panel cutout B (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted




① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

# Moulded Case Circuit Breakers

# PE60-NF, PS60-NF, PE125-NF




## Ratings and Specifications

| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 60 | | 60 | | 100 | | 125 | |
| Type | | | | PE60-NF | | PS60-NF | | PE125-NF | | | |
| Number of poles | | | | 2 | 3 | 2 | 3 | 2 | 3 | 2 | 3 |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | | 60 | | 60 | | 60 | | 125 | |
| Calibrated at 40°C | | | | | | | | 75 | | | |
| 45°C | | | | | | | | 100 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | 690 | | 690 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | | — | | — | |
| Utilization Category | | | | A | | A | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | — | | — | | — | | — | |
| IEC 60947-2 | | | 500V | 2.5/2.5 | | 7.5/4 | | 7.5/4 | | 7.5/4 | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 2.5/2.5 | | 10/5 | | 10/5 | | 10/5 | |
| | | | 415V | 2.5/2.5 | | 10/5 | | 10/5 | | 10/5 | |
| | | | 380V | 5/5 | | 10/5 | | 10/5 | | 10/5 | |
| | | | 240V | 7.5/7.5 | | 30/15 | | 30/15 | | 30/15 | |
| | | ① DC | 250V | 2.5/2.5 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | |
| | | | 125V | 2.5/2.5 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | |
| NK | | AC | 690V | — | | — | | — | | — | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 2.5/2.5 | | 10/5 | | 10/5 | | 10/5 | |
| | | | 240V | 7.5/7.5 | | 30/15 | | 30/15 | | 30/15 | |
| | | ① DC | 250V | 2.5/2.5 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | | 7.5/4 ⑰ ㉗ | |
| Weight (◉ marked standard type) kg | | | | 0.6 | 0.8 | 0.6 | 0.8 | 0.6 | 0.8 | 0.6 | 0.8 |
| ■Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | ◉ | | ◉ | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | | — | | — | |
| | Standard (PMC) | | | — | ○ | — | ○ | — | ○ | — | ○ |
| For distribution boards (PMD) ㊺ | | | | ○ | | ○ | | ○ | | ○ | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | | — | | — | | — | | — | |
| TemPlug70 (PG) | | | | — | | — | | — | | — | |
| DIN rail mount | | | | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ | — | ○ ⑪ |
| ■Accessories (optional) | | | Symbol | | | | | | | | |
| Externally mounted: Motor operator | | | M C | — | | — | | — | | — | |
| External operating handle: Breaker-mounted | | | H B | — | ● | — | ● | — | ● | — | ● |
| External operating handle: Door-mounted (variable depth) | | | H P | — | ● | — | ● | — | ● | — | ● |
| Toggle extension | | | H A | — | | — | | — | | — | |
| Mechanical interlock: Slide type | | | M S | — | ● | — | ● | — | ● | — | ● |
| Mechanical interlock: Rear-connected type | | | M B | — | | — | | — | | — | |
| Mechanical interlock: Link type | | | M L | — | | — | | — | | — | |
| Mechanical interlock: Wire type | | | M W | — | | — | | — | | — | |
| Toggle holder | | | H H | ● | | ● | | ● | | ● | |
| Toggle lock | | | H L | ● | | ● | | ● | | ● | |
| Terminal cover: For front-connected | | | C F | ● | | ● | | ● | | ● | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | ● | | ● | | ● | |
| Terminal block for lead | | | T F | ● | | ● | | ● | | ● | |
| Door flange | | | D F | ● | | ● | | ● | | ● | |
| CE marking | | | | Yes | | Yes | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | | Thermal-magnetic | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | | Yes | | Yes | | Yes | | Yes | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㉗ : Applicable to only 2 poles breakers.
㊸ : For the extension bars, please place the order separately in parts.
㊺ : See page 7-172 for the outline dimensions.


## Time/Current characteristic curves




## Ambient compensating curves




## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.


# Outline dimensions (mm)

**PE60-NF, PS60-NF, PE125-NF**

## Front-connected




## Rear-connected




① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.


Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

Detail of connecting part


| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)




## Flush-mounted




① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Please check the rear side for a detailed outline drawing of the terminals.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

# Moulded Case Circuit Breakers


# S125-SF




## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | | 125 | | | | |
| Type | | | | S125-SF | | | | | | | |
| Number of poles | | | | 2 | 3 | 4 | 2 | 3 | 4 | | |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | | 15 | 50 | | 125 | | | | |
| Calibrated at 40°C | | | | 20 | 60 | | | | | | |
| 45°C | | | | 30 | 75 | | | | | | |
| | | | | 40 | 100 | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | | 690 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | 8 | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | — | | | | |
| Utilization Category | | | | A | | | A | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/3 | | | 6/3 | | | | |
| IEC 60947-2 | | | 500V | 12/6 | | | 12/6 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 25/13 | | | 25/13 | | | | |
| | | | 415V | 30/15 | | | 30/15 | | | | |
| | | | 380V | 30/15 | | | 30/15 | | | | |
| | | | 240V | 50/25 | | | 50/25 | | | | |
| | | ① DC | 250V | 25/13 ⑰ ㉗ | | | 25/13 ⑰ ㉗ | | | | |
| | | | 125V | 40/20 ⑰ ㉗ | | | 40/20 ⑰ ㉗ | | | | |
| NK | | AC | 690V | — | | | — | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 25/13 | | | 25/13 | | | | |
| | | | 240V | 50/25 | | | 50/25 | | | | |
| | | ① DC | 250V | 25/13 ⑰ ㉗ | | | 25/13 ⑰ ㉗ | | | | |
| Weight (◉ marked standard type) kg | | | | 0.6 | 0.8 | 1.0 | 0.6 | 0.8 | 1.0 | | |
| ■Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ ④ | | | ◉ | | | | |
| | With extension bars | | | ○ ㊸ | | | ○ ㊸ | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | | — | | | | |
| | Standard (PMC) | | | — | ○ | — | — | ○ | — | | |
| For distribution boards (PMD) ㊺ | | | | ○ | | — | ○ | | — | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | — | ○ | | — | | |
| Draw-out type (DR) | | | | — | | | — | | | | |
| TemPlug70 (PG) | | | | ○ | | — | ○ | | — | | |
| DIN rail mount | | | | — | ○ ⑪ | | — | ○ ⑪ | | | |
| ■Accessories (optional) | | | Symbol | | | | | | | | |
| Externally mounted: Motor operator | | | M C | — | | | — | | | | |
| External operating handle: Breaker-mounted | | | H B | — | ● | | — | ● | | | |
| External operating handle: Door-mounted (variable depth) | | | H P | — | ● | | — | ● | | | |
| Toggle extension | | | H A | — | | | — | | | | |
| Mechanical interlock: Slide type | | | M S | — | ● | | — | ● | | | |
| Mechanical interlock: Rear-connected type | | | M B | — | | | — | | | | |
| Mechanical interlock: Link type | | | M L | — | | | — | | | | |
| Mechanical interlock: Wire type | | | M W | — | | | — | | | | |
| Toggle holder | | | H H | ● | | | ● | | | | |
| Toggle lock | | | H L | ● | | | ● | | | | |
| Terminal cover: For front-connected | | | C F | ● | | | ● | | | | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | | ● | | | | |
| Terminal block for lead | | | T F | ● | | | ● | | | | |
| Door flange | | | D F | ● | | | ● | | | | |
| CE marking | | | | Yes | | | Yes | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | Thermal-magnetic | | | | |
| Colour of cover | | | | Grey Blue | | | Grey Blue | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | Yes (Red) | | | | |
| Suitability for isolation | | | | Yes | | | Yes | | | | |
| Reverse connection | | | | Yes | | | Yes | | | | |

## Time/Current characteristic curves





## Ambient compensating curves




**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC. ④ : 50A or less is the M5 wire clamping terminal.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑰ : See page 4-7 for the instantaneous trip value when using with DC.
㉗ : Applicable to only 2 poles breakers. ㊸ : For the extension bars, please place the order separately in parts.
㊺ : See page 7-172 for the outline dimensions.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) S125-SF

## Front-connected




## Rear-connected





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |


Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted




① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.





# Moulded Case Circuit Breakers

## PS125-NF

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | | 125 | | | | |
| Type | | | | PS125-NF | | | | | | | |
| Number of poles | | | | 2 | 3 | 4 | 2 | 3 | 4 | | |
| **■ Ratings** | | | | | | | | | | | |
| Rated current, A | | | | 15 | 50 | | 125 | | | | |
| Calibrated at 40°C | | | | 20 | 60 | | | | | | |
| 45°C | | | | 30 | 75 | | | | | | |
| | | | | 40 | 100 | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | | 800 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | 8 | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | — | | | | |
| Utilization Category | | | | A | | | A | | | | |
| **■ Rated breaking capacity, kA** | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/6 | | | 6/6 | | | | |
| IEC 60947-2 | | | 500V | 22/22 | | | 22/22 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 25/25 | | | 25/25 | | | | |
| | | | 415V | 36/36 | | | 36/36 | | | | |
| | | | 380V | 36/36 | | | 36/36 | | | | |
| | | | 240V | 50/50 | | | 50/50 | | | | |
| | | ① DC | 250V | 25/19 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | | | |
| | | | 125V | 25/19 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | | | |
| NK | | AC | 690V | 6/6 | | | 6/6 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 25/25 | | | 25/25 | | | | |
| | | | 240V | 50/50 | | | 50/50 | | | | |
| | | ① DC | 250V | 25/19 ⑰ ㉗ | | | 25/19 ⑰ ㉗ | | | | |
| Weight (◉ marked standard type) kg | | | | 0.7 | 1.0 | 1.3 | 0.7 | 1.0 | 1.3 | | |
| **■ Connections and Mountings** | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | ◉ | | | | |
| | With extension bars | | | ○ ㊸ | | | ○ ㊸ | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | ○ | | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | ○ ㊿ | | — | ○ ㊿ | | | |
| | | Standard (PMC) | | ○ | | — | ○ | | — | | |
| | For distribution boards (PMD) ㊸ | | | — | ○ | — | — | ○ | — | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | ○ | | | | |
| Draw-out type (DR) | | | | — | | | — | | | | |
| TemPlug70 (PG) | | | | ○ | | — | ○ | | — | | |
| DIN rail mount | | | | — | ○ ⑪ | | — | ○ ⑪ | | | |
| **■ Accessories (optional)** | | | | | | Symbol | | | | | |
| Externally mounted | Motor operator | | | | | M C | — | ● | | — | ● | | | |
| | External operating handle | Breaker-mounted | | | | H B | — | ● | | — | ● | | | |
| | | Door-mounted (variable depth) | | | | H P | — | ● | | — | ● | | | |
| | Toggle extension | | | | | H A | — | | | — | | | | |
| | Mechanical interlock | Slide type | | | | M S | — | ● | | — | ● | | | |
| | | Rear-connected type | | | | M B | — | | | — | | | | |
| | | Link type | | | | M L | — | ● | | — | ● | | | |
| | | Wire type | | | | M W | — | ● | | — | ● | | | |
| | Toggle holder | | | | | H H | ● | | | ● | | | | |
| | Toggle lock | | | | | H L | ● | | | ● | | | | |
| | Terminal cover | For front-connected | | | | C F | ● | | | ● | | | | |
| | | For rear-connected and plug-in | | | | C R | ● | | | ● | | | | |
| | Terminal block for lead | | | | | T F | ● | | | ● | | | | |
| | Door flange | | | | | D F | ● | | | ● | | | | |
| CE marking | | | | | | | Yes | | | Yes | | | | |
| Overcurrent trip mechanism | | | | | | | Thermal-magnetic | | | Thermal-magnetic | | | | |
| Colour of cover | | | | | | | Grey Blue | | | Grey Blue | | | | |
| Trip button (Colour) | | | | | | | Yes (Red) | | | Yes (Red) | | | | |
| Suitability for isolation | | | | | | | Yes | | | Yes | | | | |
| Reverse connection | | | | | | | Yes | | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

① : DC is a special specification. When ordering, please specify DC.


⑪ : Please order the DIN rail adapter separately. See page 6-152.


⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㉗ : Applicable to only 2 poles breakers.

㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts.


㉝ : See page 7-171 for the outline dimensions.

## Time/Current characteristic curves





## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS125-NF

## Front-connected





## Rear-connected





| rated current[A] | A | B | C |
|---|---|---|---|
| 15 — 50 | 12.5 | ø8.5 | 4 |
| 60 — 125 | 12.5 | ø8.5 | 5 |

Note) For 2P, the distance between ⊬ and ℄ is 14.2mm. The distance between the stud centreline and ℄ is 15mm.
Note) Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in(High-performance)




## Flush-mounted




| rated current[A] | A | B | C |
|---|---|---|---|
| 15 — 50 | 12.5 | ø8.5 | 4 |
| 60 — 125 | 12.5 | ø8.5 | 5 |

Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions

TemBreak PRO

## Moulded Case Circuit Breakers

## PS50-PF, PS125-PF

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 50 | | | 100 | | | 125 | |
| Type | | | | PS50-PF | | | PS125-PF | | | | |
| Number of poles | | | | 2 | 3 | 4 | 2 | 3 | 4 | 2 | 3 | 4 |
| **■ Ratings** | | | | | | | | | | | |
| Rated current, A | | | | 15 | 50 | | 15 | 50 | | 125 | |
| Calibrated at 40°C | | | | 20 | | | 20 | 60 | | | |
| 45°C | | | | 30 | | | 30 | 75 | | | |
| | | | | 40 | | | 40 | 100 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | | 800 | | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | 8 | | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | — | | | — | |
| Utilization Category | | | | A | | | A | | | A | |
| **■ Rated breaking capacity, kA** | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/6 | | | 6/6 | | | 6/6 | |
| IEC 60947-2 | | | 500V | 30/22 | | | 30/22 | | | 30/22 | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 50/35 | | | 50/35 | | | 50/35 | |
| | | | 415V | 70/50 | | | 70/50 | | | 70/50 | |
| | | | 380V | 70/50 | | | 70/50 | | | 70/50 | |
| | | | 240V | 85/85 | | | 85/85 | | | 85/85 | |
| | | ① DC | 250V | 40/40 ⑰ ㉗ | | | 40/40 ⑰ ㉗ | | | 40/40 ⑰ ㉗ | |
| | | | 125V | 40/40 ⑰ ㉗ | | | 40/40 ⑰ ㉗ | | | 40/40 ⑰ ㉗ | |
| NK | | AC | 690V | 6/6 | | | 6/6 | | | 6/6 | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 50/35 | | | 50/35 | | | 50/35 | |
| | | | 240V | 85/85 | | | 85/85 | | | 85/85 | |
| | | ① DC | 250V | 40/40 ⑰ ㉗ | | | 40/40 ㉗ | | | 40/40 ㉗ | |
| Weight (◉ marked standard type) kg | | | | 0.7 | 1.0 | 1.3 | 0.7 | 1.0 | 1.3 | 0.7 | 1.0 | 1.3 |
| **■ Connections and Mountings** | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | ◉ | | | ◉ | |
| | With extension bars | | | ○ ㊸ | | | ○ ㊸ | | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | ○ | | | ○ | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | ○ ㊿ | | — | ○ ㊿ | | — | ○ ㊿ | |
| | | Standard (PMC) | | ○ | | — | ○ | | — | ○ | | — |
| | For distribution boards (PMD) ㉓ | | | — | ○ | — | — | ○ | — | — | ○ | — |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | ○ | | | ○ | |
| Draw-out type (DR) | | | | — | | | — | | | — | |
| TemPlug70 (PG) | | | | ○ | | — | ○ | | — | ○ | | — |
| DIN rail mount | | | | — | ○ ⑪ | | — | ○ ⑪ | | — | ○ ⑪ | |
| **■ Accessories (optional)** | | | Symbol | | | | | | | | | |
| Externally mounted: Motor operator | | | M C | — | ● | | — | ● | | — | ● | |
| External operating handle | Breaker-mounted | | H B | — | ● | | — | ● | | — | ● | |
| | Door-mounted (variable depth) | | H P | — | ● | | — | ● | | — | ● | |
| Toggle extension | | | H A | — | | | — | | | — | | |
| Mechanical interlock | Slide type | | M S | — | ● | | — | ● | | — | ● | |
| | Rear-connected type | | M B | — | | | — | | | — | | |
| | Link type | | M L | — | ● | | — | ● | | — | ● | |
| | Wire type | | M W | — | ● | | — | ● | | — | ● | |
| Toggle holder | | | H H | ● | | | ● | | | ● | | |
| Toggle lock | | | H L | ● | | | ● | | | ● | | |
| Terminal cover | For front-connected | | C F | ● | | | ● | | | ● | | |
| | For rear-connected and plug-in | | C R | ● | | | ● | | | ● | | |
| Terminal block for lead | | | T F | ● | | | ● | | | ● | | |
| Door flange | | | D F | ● | | | ● | | | ● | | |
| CE marking | | | | Yes | | | Yes | | | Yes | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | Thermal-magnetic | | | Thermal-magnetic | | |
| Colour of cover | | | | Grey Blue | | | Grey Blue | | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | | Yes (Red) | | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | | Yes | | | Yes | | |
| Reverse connection | | | | Yes | | | Yes | | | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

① : DC is a special specification. When ordering, please specify DC.


⑪ : Please order the DIN rail adapter separately. See page 6-152.


⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㉗ : Applicable to only 2 poles breakers.

㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts.


㉓ : See page 7-171 for the outline dimensions.

## Time/Current characteristic curves





## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS50-PF, PS125-PF

## Front-connected





## Rear-connected





| Rated current[A] | A | B | C |
|---|---|---|---|
| 15 — 50 | 12.5 | ø8.5 | 4 |
| 60 — 125 | 12.5 | ø8.5 | 5 |

Note) For 2P, the distance between ⊬ and ℄ is 14.2mm. The distance between the stud centreline and ℄ is 15mm.
Note) Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




| Rated current[A] | A | B | C |
|---|---|---|---|
| 15 — 50 | 12.5 | ø8.5 | 4 |
| 60 — 125 | 12.5 | ø8.5 | 5 |

Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions

TemBreak PRO

# Moulded Case Circuit Breakers

# PS125-NE

## Ratings and Specifications


| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | | 125 | |
| Type | | | PS125-NE | | | |
| Number of poles | | | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | |
| Rated current, A | | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | $I_n$=100 | | $I_n$=125 | |
| 45°C | | | 40 63 | | 125 | |
| ㊽ | | | 50 75 | | | |
| | | | 60 100 ㊶ | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 800 | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | — | |
| Utilization Category | | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 6/6 | | 6/6 | |
| IEC 60947-2 | | 500V | 22/22 | | 22/22 | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | 25/25 | | 25/25 | |
| | | 415V | 36/36 | | 36/36 | |
| | | 380V | 36/36 | | 36/36 | |
| | | 240V | — | | — | |
| | DC | 250V | — | | — | |
| | | 125V | — | | — | |
| NK | AC | 690V | 6/6 | | 6/6 | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | 25/25 | | 25/25 | |
| | | 240V | 50/50 | | 50/50 | |
| | DC | 250V | — | | — | |
| Weight (◉ marked standard type) kg | | | 1.0 | 1.3 | 1.0 | 1.3 |
| ■Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | |
| | With extension bars | | ○ ㊸ | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㊿ | | ○ ㊿ | |
| | Standard (PMC) | | ○ | — | ○ | — |
| For distribution boards (PMD) ㊸ | | | ○ | — | ○ | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | |
| Draw-out type (DR) | | | — | | — | |
| TemPlug70 (PG) | | | ○ | — | ○ | — |
| DIN rail mount | | | ○ ⑪ | | ○ ⑪ | |

| | | | Symbol | | |
|---|---|---|---|---|---|
| ■Accessories (optional) | | | | | |
| Externally mounted | Motor operator | | M C | ● | ● |
| | External operating handle | Breaker-mounted | H B | ● | ● |
| | | Door-mounted (variable depth) | H P | ● | ● |
| | Toggle extension | | H A | — | — |
| | Mechanical interlock | Slide type | M S | ● | ● |
| | | Rear-connected type | M B | — | — |
| | | Link type | M L | ● | ● |
| | | Wire type | M W | ● | ● |
| | Toggle holder | | H H | ● | ● |
| | Toggle lock | | H L | ● | ● |
| | Terminal cover | For front-connected | C F | ● | ● |
| | | For rear-connected and plug-in | C R | ● | ● |
| | Terminal block for lead | | T F | ● | ● |
| | Door flange | | D F | ● | ● |
| CE marking | | | | Yes | Yes |
| Overcurrent trip mechanism | | | | Electronic | Electronic |
| Colour of cover | | | | Grey Blue | Grey Blue |
| Trip button (Colour) | | | | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | | Yes | Yes |
| Reverse connection | | | | Yes | Yes |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available". ⑪ : Please order the DIN rail adapter separately. See page 6-152.
㊿ : A safety trip function is provided. ㊸ : For the extension bars, please place the order separately in parts. ㊶ : Does not comply with Electrical Appliances and Materials Safety Act at rated current 100A or less because it is an adjustable product. Also, it cannot be used at voltages other than rated operational voltage 380V to 690V AC. Please contact us for details. ㊽ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.
㊸ : See page 7-171 for the outline dimensions.

## Time/Current characteristic curves

• Long time/Short time trip characteristics • Instantaneous trip characteristics




Note: See page 6-4 for ground fault trip and preferential trip alarm characteristics.


## Overcurrent tripping characteristics

TPOP OCR (LSIG) ($I_n$)=100A, 125A

| | |
|---|---|
| Rated current settings (A) ($I_r$)=($I_r$1)×($I_r$2) | When ($I_n$)=100A ($I_r$1) (A)=40, 50, 60, 63, 75, 100 adjustable<br>When ($I_n$)=125A ($I_r$1) (A)=125 adjustable |
| | ($I_r$2)= 0.91, 0.92, 0.93, 0.94, 0.95, 0.96, 0.97, 0.98, 0.99, 1.00 |
| Long time-delay time settings (s) : ($t_r$) | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable<br>at ($I_r$)×600% |
| | Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF |
| | Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | 50, 100, 200, 300, 400 adjustable |
| | Ramp characteristics I²t: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more |
| | When ($t_{sd}$)=50ms Time-delay setting tolerance –30ms or more +30ms or less<br>When ($t_{sd}$)=100ms to 400ms Time-delay setting tolerance –20ms or more +50ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | When ($I_n$)=100A ($I_n$)×3, 4, 5, 6, 7, 8, 10, 12, 15 adjustable |
| | When ($I_n$)=125A ($I_n$)×3, 4, 5, 6, 7, 8, 9, 10, 11 adjustable |
| | Current setting tolerance within ±15% |
| Ground fault trip pick-up current (A) : ($I_g$) | 3P for 3ø3W (3P 3ø4W not supported)<br>($I_n$)×20% or OFF<br>Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | 200<br>Time-delay setting tolerance –20ms or more +50ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | ($I_r$)×80%<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | ($t_r$)×50%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |

Note 1: If not otherwise specified, the product will be delivered with the underlined standard setting values.
Note 2: The TPOT type OCR (LSI) only has long time-delay trip, short time-delay trip, instantaneous trip, and preferential trip alarm.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS125-NE


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions

TemBreak PRO

## Moulded Case Circuit Breakers

## PS125-PE

## Ratings and Specifications


| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | | 125 | |
| Type | | | PS125-PE | | | |
| Number of poles | | | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | |
| Rated current, A | | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | $I_n$=100 | | $I_n$=125 | |
| 45°C | | | 40 | 63 | 125 | |
| ⑧⓪ | | | 50 | 75 | | |
| | | | 60 | 100 ⑥① | | |
| Rated insulation voltage〔$U_i$〕 V | | | 800 | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | — | |
| Utilization Category | | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 6/6 | | 6/6 | |
| IEC 60947-2 | | 500V | 30/22 | | 30/22 | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 50/35 | | 50/35 | |
| | | 415V | 70/50 | | 70/50 | |
| | | 380V | 70/50 | | 70/50 | |
| | | 240V | — | | — | |
| | DC | 250V | — | | — | |
| | | 125V | — | | — | |
| NK | AC | 690V | 6/6 | | 6/6 | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 50/35 | | 50/35 | |
| | | 240V | 85/85 | | 85/85 | |
| | DC | 250V | — | | — | |
| Weight (◉ marked standard type) kg | | | 1.0 | 1.3 | 1.0 | 1.3 |
| ■Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | |
| | With extension bars | | ○ ⑤③ | | ○ ⑤③ | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ⑤⓪ | | ○ ⑤⓪ | |
| | Standard (PMC) | | ○ | — | ○ | — |
| For distribution boards (PMD) ⑧③ | | | ○ | — | ○ | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | |
| Draw-out type (DR) | | | — | | — | |
| TemPlug70 (PG) | | | ○ | — | ○ | — |
| DIN rail mount | | | ○ ⑪ | | ○ ⑪ | |

| | | | Symbol | | |
|---|---|---|---|---|---|
| ■Accessories (optional) | | | | | |
| Externally mounted | Motor operator | | M C | ● | ● |
| | External operating handle | Breaker-mounted | H B | ● | ● |
| | | Door-mounted (variable depth) | H P | ● | ● |
| | Toggle extension | | H A | — | — |
| | Mechanical interlock | Slide type | M S | ● | ● |
| | | Rear-connected type | M B | — | — |
| | | Link type | M L | ● | ● |
| | | Wire type | M W | ● | ● |
| | Toggle holder | | H H | ● | ● |
| | Toggle lock | | H L | ● | ● |
| | Terminal cover | For front-connected | C F | ● | ● |
| | | For rear-connected and plug-in | C R | ● | ● |
| | Terminal block for lead | | T F | ● | ● |
| | Door flange | | D F | ● | ● |
| CE marking | | | | Yes | Yes |
| Overcurrent trip mechanism | | | | Electronic | Electronic |
| Colour of cover | | | | Grey Blue | Grey Blue |
| Trip button (Colour) | | | | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | | Yes | Yes |
| Reverse connection | | | | Yes | Yes |


**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".
⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑤⓪ : A safety trip function is provided. ⑤③ : For the extension bars, please place the order separately in parts. ⑥① : Does not comply with Electrical Appliances and Materials Safety Act at rated current 100A or less because it is an adjustable product. Also, it cannot be used at voltages other than rated operational voltage 380V to 690V AC. Please contact us for details. ⑧⓪ : If the ambient temperature exceeds 45°C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.
⑧③ : See page 7-171 for the outline dimensions.

## Time/Current characteristic curves

• Long time/Short time trip characteristics




• Instantaneous trip characteristics




Note: See page 6-4 for ground fault trip and preferential trip alarm characteristics.


## Overcurrent tripping characteristics

TPOP OCR (LSIG) ($I_n$)=100A, 125A

| | |
|---|---|
| Rated current settings (A) ($I_r$)=($I_r$1)×($I_r$2) | When ($I_n$)=100A ($I_r$1) (A)=40, 50, 60, 63, 75, 100 adjustable<br>When ($I_n$)=125A ($I_r$1) (A)=125 adjustable |
| | ($I_r$2)= 0.91, 0.92, 0.93, 0.94, 0.95, 0.96, 0.97, 0.98, 0.99, 1.00 |
| Long time-delay time settings (s) : ($t_r$) | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable<br>at ($I_r$)×600% |
| | Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF |
| | Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | 50, 100, 200, 300, 400 adjustable |
| | Ramp characteristics I²t: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more |
| | When ($t_{sd}$)=50ms Time-delay setting tolerance –30ms or more +30ms or less<br>When ($t_{sd}$)=100ms to 400ms Time-delay setting tolerance –20ms or more +50ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | When ($I_n$)=100A ($I_n$)×3, 4, 5, 6, 7, 8, 10, 12, 15 adjustable |
| | When ($I_n$)=125A ($I_n$)×3, 4, 5, 6, 7, 8, 9, 10, 11 adjustable |
| | Current setting tolerance within ±15% |
| Ground fault trip pick-up current (A) : ($I_g$) | 3P for 3ø3W (3P 3ø4W not supported)<br>($I_n$)×20% or OFF<br>Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | 200<br>Time-delay setting tolerance –20ms or more +50ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | ($I_r$)×80%<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | ($t_r$)×50%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |

Note 1: If not otherwise specified, the product will be delivered with the underlined standard setting values.
Note 2: The TPOT type OCR (LSI) only has long time-delay trip, short time-delay trip, instantaneous trip, and preferential trip alarm.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS125-PE


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

# Moulded Case Circuit Breakers

# S100-GF



## Ratings and Specifications

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | | | | | |
| Type | | | | S100-GF | | | | | | |
| Number of poles | | | | 2 | 3 | 4 | | | | |
| ■ Ratings | | | | | | | | | | |
| Rated current, A | | | | 15 | 50 | | | | | |
| Calibrated at 40°C | | | | 20 | 60 | | | | | |
| 45°C | | | | 30 | 75 | | | | | |
| | | | | 40 | 100 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | | | | |
| Utilization Category | | | | A | | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/6 | | | | | | |
| IEC 60947-2 | | | 500V | 25/22 | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 50/25 | | | | | | |
| | | | 415V | 65/33 | | | | | | |
| | | | 380V | 65/33 | | | | | | |
| | | | 240V | 85/85 | | | | | | |
| | | ① DC | 250V | 40/40 ㉗ | | | | | | |
| | | | 125V | 40/40 ㉗ | | | | | | |
| NK | | AC | 690V | 6/6 | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 50/25 | | | | | | |
| | | | 240V | 85/85 | | | | | | |
| | | ① DC | 250V | 40/40 ㉗ | | | | | | |
| Weight (◉ marked standard type) kg | | | | 0.7 | 1.1 | 1.4 | | | | |
| ■ Connections and Mountings | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | | | | |
| | With extension bars | | | ○ ㊸ | | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊶ | | | | | | |
| | Standard (PMC) | | | — | ○ | — | | | | |
| For distribution boards (PMD) ㊼ | | | | — | | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | | | | |
| Draw-out type (DR) | | | | — | | | | | | |
| TemPlug70 (PG) | | | | ○ | | — | | | | |
| DIN rail mount | | | | — | ○ ⑪ | | | | | |
| ■ Accessories (optional) | | | | Symbol | | | | | | |
| Externally mounted: Motor operator | | | | M C | — | ● | | | | |
| External operating handle: Breaker-mounted | | | | H B | — | ● | | | | |
| External operating handle: Door-mounted (variable depth) | | | | H P | — | ● | | | | |
| Toggle extension | | | | H A | — | | | | | |
| Mechanical interlock: Slide type | | | | M S | — | ● | | | | |
| Mechanical interlock: Rear-connected type | | | | M B | — | | | | | |
| Mechanical interlock: Link type | | | | M L | — | ● | | | | |
| Mechanical interlock: Wire type | | | | M W | — | ● | | | | |
| Toggle holder | | | | H H | ● | | | | | |
| Toggle lock | | | | H L | ● | | | | | |
| Terminal cover: For front-connected | | | | C F | ● | | | | | |
| Terminal cover: For rear-connected and plug-in | | | | C R | ● | | | | | |
| Terminal block for lead | | | | T F | ● | | | | | |
| Door flange | | | | D F | ● | | | | | |
| CE marking | | | | | Yes | | | | | |
| Overcurrent trip mechanism | | | | | Thermal-magnetic | | | | | |
| Colour of cover | | | | | Grey Blue | | | | | |
| Trip button (Colour) | | | | | Yes (Red) | | | | | |
| Suitability for isolation | | | | | Yes | | | | | |
| Reverse connection | | | | | Yes | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


① : DC is a special specification. When ordering, please specify DC.

⑪ : Please order the DIN rail adapter separately. See page 6-152. ㉗ : Applicable to only 2 poles breakers.


㊶ : A safety lock function is provided. ㊸ : For the extension bars, please place the order separately in parts.

㊼ : See page 7-173 for the outline dimensions.

## Time/Current characteristic curves




## Ambient compensating curves




## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX (Auxiliary switch) | AL (Alarm switch) | SH (Shunt trip) | UV (Under voltage trip) | AX + AL | AX + SH | AX + UV | AL + SH | AL + UV | AX + AL + SH | AX + AL + UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 2 | | | | | | | | | | | |
| 3·4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


NOTE: 2-pole type breaker may incorporate only one combination of AX (max.2C), AL, SH, UV, AX (max.2C) — AL into the right pole.

# Outline dimensions (mm) S100-GF

## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

# Moulded Case Circuit Breakers

# S125-GF



## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 125 | | | | |
| Type | | | | S125-GF | | | | |
| Number of poles | | | | 2 | 3 | 4 | | |
| ■ Ratings | | | | | | | | |
| Rated current, A | | | | 125 | | | | |
| Calibrated at 40°C | | | | | | | | |
| 45°C | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | | |
| Utilization Category | | | | A | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/6 | | | | |
| IEC 60947-2 | | | 500V | 25/22 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 50/25 | | | | |
| | | | 415V | 65/33 | | | | |
| | | | 380V | 65/33 | | | | |
| | | | 240V | 85/85 | | | | |
| | | ① DC | 250V | 40/40 ㉗ | | | | |
| | | | 125V | 40/40 ㉗ | | | | |
| NK | | AC | 690V | 6/6 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 50/25 | | | | |
| | | | 240V | 85/85 | | | | |
| | | ① DC | 250V | 40/40 ㉗ | | | | |
| Weight (◉ marked standard type) kg | | | | 0.7 | 1.1 | 1.4 | | |
| ■ Connections and Mountings | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | | |
| | With extension bars | | | ○ ㊸ | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊶ | | | | |
| | Standard (PMC) | | | — | ○ | — | | |
| For distribution boards (PMD) ㊼ | | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | | |
| Draw-out type (DR) | | | | — | | | | |
| TemPlug70 (PG) | | | | ○ | | — | | |
| DIN rail mount | | | | — | ○ ⑪ | | | |
| ■ Accessories (optional) | | | Symbol | | | | | |
| Externally mounted: Motor operator | | | M C | — | ● | | | |
| External operating handle: Breaker-mounted | | | H B | — | ● | | | |
| External operating handle: Door-mounted (variable depth) | | | H P | — | ● | | | |
| Toggle extension | | | H A | — | | | | |
| Mechanical interlock: Slide type | | | M S | — | ● | | | |
| Mechanical interlock: Rear-connected type | | | M B | — | | | | |
| Mechanical interlock: Link type | | | M L | — | ● | | | |
| Mechanical interlock: Wire type | | | M W | — | ● | | | |
| Toggle holder | | | H H | ● | | | | |
| Toggle lock | | | H L | ● | | | | |
| Terminal cover: For front-connected | | | C F | ● | | | | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | | | |
| Terminal block for lead | | | T F | ● | | | | |
| Door flange | | | D F | ● | | | | |
| CE marking | | | | Yes | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | | |
| Colour of cover | | | | Grey Blue | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | | |
| Suitability for isolation | | | | Yes | | | | |
| Reverse connection | | | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


① : DC is a special specification. When ordering, please specify DC.

⑪ : Please order the DIN rail adapter separately. See page 6-152. ㉗ : Applicable to only 2 poles breakers.


㊶ : A safety lock function is provided. ㊸ : For the extension bars, please place the order separately in parts.

㊼ : See page 7-173 for the outline dimensions.

## Time/Current characteristic curves




## Ambient compensating curves




## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX (Auxiliary switch) | AL (Alarm switch) | SH (Shunt trip) | UV (Under voltage trip) | AX – AL | AX – SH | AX – UV | AL – SH | AL – UV | AX – AL – SH | AX – AL – UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 2 | | | | | | | | | | | |
| 3·4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


NOTE: 2-pole type breaker may incorporate only one combination of AX (max.2C), AL, SH, UV, AX (max.2C)—AL into the right pole.

# Outline dimensions (mm) S125-GF

## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions TemBreak PRO

## Moulded Case Circuit Breakers

## H100-NF, L100-NF

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | 100 | | | | | |
| Type | | | | H100-NF | | L100-NF | | | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | | 15 | 50 | 15 | 50 | | | | |
| Calibrated at 40°C | | | | 20 | 60 | 20 | 60 | | | | |
| 45°C | | | | 30 | 75 | 30 | 75 | | | | |
| | | | | 40 | 100 | 40 | 100 | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | | | | | |
| Utilization Category | | | | A | | A | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 20/15 | | 25/20 | | | | | |
| IEC 60947-2 | | | 500V | 45/45 | | 65/65 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 120/80 | | 180/135 | | | | | |
| | | | 415V | 125/85 | | 200/150 | | | | | |
| | | | 380V | 125/85 | | 200/150 | | | | | |
| | | | 240V | 150/150 | | 200/150 | | | | | |
| | | ① DC | 250V | 40/40 | | 40/40 | | | | | |
| | | | 125V | 40/40 | | 40/40 | | | | | |
| NK | | AC | 690V | 20/15 | | 25/20 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 120/80 | | 180/135 | | | | | |
| | | | 240V | 150/150 | | 200/150 ㉛ | | | | | |
| | | ① DC | 250V | — | | — | | | | | |
| Weight (◉ marked standard type) kg | | | | 2.4 | 3.2 | 2.4 | 3.2 | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | | | | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊶ | | ○ ㊶ | | | | | |
| | Standard (PMC) | | | ○ | — | ○ | — | | | | |
| For distribution boards (PMD) | | | | — | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | | | | |
| Draw-out type (DR) | | | | — | | — | | | | | |
| TemPlug70 (PG) | | | | ▲ ㊶ | — | — | | | | | |
| DIN rail mount | | | | — | | — | | | | | |
| ■ Accessories (optional) | | | | | Symbol | | | | | | |
| Externally mounted: Motor operator | | | | ● | | ● | | | | | |
| External operating handle: Breaker-mounted | | | | ● | | ● | | | | | |
| External operating handle: Door-mounted (variable depth) | | | | ● | | ● | | | | | |
| Toggle extension | | | | — | | — | | | | | |
| Mechanical interlock: Slide type | | | | ● | | ● | | | | | |
| Mechanical interlock: Rear-connected type | | | | — | | — | | | | | |
| Mechanical interlock: Link type | | | | ● | | ● | | | | | |
| Mechanical interlock: Wire type | | | | ● | | ● | | | | | |
| Toggle holder | | | | ● | | ● | | | | | |
| Toggle lock | | | | ● | | ● | | | | | |
| Terminal cover: For front-connected | | | | ● | | ● | | | | | |
| Terminal cover: For rear-connected and plug-in | | | | ● | | ● | | | | | |
| Terminal block for lead | | | | ● | | ● | | | | | |
| Door flange | | | | ● | | ● | | | | | |
| CE marking | | | | Yes | | Yes | | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | | | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | | | |
| Suitability for isolation | | | | Yes | | Yes | | | | | |
| Reverse connection | | | | Yes ㉒ | | Yes ㉒ | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

① : DC is a special specification. When ordering, please specify DC.

㉛ : Also applicable to 415V AC.


㊶ : A safety lock function is provided.

㊸ : For the extension bars, please place the order separately in parts.


㉒ : There are some limitations. See page 5-23 for details.

㊶ : They cannot be applied to circuits with a short circuit breaking current exceeding 85kA.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) H100-NF, L100-NF


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

# Moulded Case Circuit Breakers

## H125-NF, L125-NF




## Ratings and Specifications

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 125 | | 125 | | | |
| Type | | | | H125-NF | | L125-NF | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | |
| ■ Ratings | | | | | | | | | |
| Rated current, A | | | | 125 | | 125 | | | |
| Calibrated at 40°C | | | | | | | | | |
| 45°C | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | — | | — | | | |
| Utilization Category | | | | A | | A | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 20/15 | | 25/20 | | | |
| IEC 60947-2 | | | 500V | 45/45 | | 65/65 | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 120/80 | | 180/135 | | | |
| | | | 415V | 125/85 | | 200/150 | | | |
| | | | 380V | 125/85 | | 200/150 | | | |
| | | | 240V | 150/150 | | 200/150 | | | |
| | | ① DC | 250V | 40/40 | | 40/40 | | | |
| | | | 125V | 40/40 | | 40/40 | | | |
| NK | | AC | 690V | 20/15 | | 25/20 | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 120/80 | | 180/135 | | | |
| | | | 240V | 150/150 | | 200/150 ㉛ | | | |
| | | ① DC | 250V | — | | — | | | |
| Weight (◉ marked standard type) kg | | | | 2.4 | 3.2 | 2.4 | 3.2 | | |
| ■ Connections and Mountings | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊶ | | ○ ㊶ | | | |
| | Standard (PMC) | | | ○ | — | ○ | — | | |
| For distribution boards (PMD) | | | | — | | — | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | | |
| Draw-out type (DR) | | | | — | | — | | | |
| TemPlug70 (PG) | | | | ▲ ㊶ | — | — | | | |
| DIN rail mount | | | | — | | — | | | |
| ■ Accessories (optional) | | | Symbol | | | | | | |
| Externally mounted: Motor operator | | | M C | ● | | ● | | | |
| External operating handle: Breaker-mounted | | | H B | ● | | ● | | | |
| External operating handle: Door-mounted (variable depth) | | | H P | ● | | ● | | | |
| Toggle extension | | | H A | — | | — | | | |
| Mechanical interlock: Slide type | | | M S | ● | | ● | | | |
| Mechanical interlock: Rear-connected type | | | M B | — | | — | | | |
| Mechanical interlock: Link type | | | M L | ● | | ● | | | |
| Mechanical interlock: Wire type | | | M W | ● | | ● | | | |
| Toggle holder | | | H H | ● | | ● | | | |
| Toggle lock | | | H L | ● | | ● | | | |
| Terminal cover: For front-connected | | | C F | ● | | ● | | | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | ● | | | |
| Terminal block for lead | | | T F | ● | | ● | | | |
| Door flange | | | D F | ● | | ● | | | |
| CE marking | | | | Yes | | Yes | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | | Yes | | Yes | | | |
| Reverse connection | | | | Yes ㉒ | | Yes ㉒ | | | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
㉛ : Also applicable to 415V AC.
㊶ : A safety lock function is provided.
㊸ : For the extension bars, please place the order separately in parts.
㉒ : There are some limitations. See page 5-23 for details.
㊶ : They cannot be applied to circuits with a short circuit breaking current exceeding 85kA.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)





# Outline dimensions (mm) H125-NF, L125-NF

## Front-connected





## Rear-connected






## Plug-in(Standard)




## Plug-in (High-performance)




## Flush-mounted



# Moulded Case Circuit Breakers

# E250-SF




## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 225 | | 250 | | | | | |
| Type | | | | E250-SF | | | | | | | |
| Number of poles | | | | 2* | 3 | 2* | 3 | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | | 125 | | 250 | | | | | |
| Calibrated at 40°C | | | | 150 | | | | | | | |
| 45°C | | | | 175 | | | | | | | |
| | | | | 200 | | | | | | | |
| * 2 poles breakers use the terminals of both ends of 3 poles breakers. | | | | 225 | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | | | | | |
| Utilization Category | | | | A | | A | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | — | | — | | | | | |
| IEC 60947-2 | | | 500V | 10/7.5 | | 10/7.5 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 15/12 | | 15/12 | | | | | |
| | | | 415V | 25/19 | | 25/19 | | | | | |
| | | | 380V | 25/19 | | 25/19 | | | | | |
| | | | 240V | 35/27 | | 35/27 | | | | | |
| | | ① DC | 250V | 15/12 ⑧⑨ | | 15/12 ⑧⑨ | | | | | |
| | | | 125V | 25/19 ⑧⑨ | | 25/19 ⑧⑨ | | | | | |
| NK | | AC | 690V | — | | — | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 15/12 | | 15/12 | | | | | |
| | | | 240V | 35/27 | | 35/27 | | | | | |
| | | ① DC | 250V | — | | — | | | | | |
| Weight (◉ marked standard type) kg | | | | 1.5 | 1.5 | 1.5 | 1.5 | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | | | | |
| | With extension bars | | | ○ ⑤③ | | ○ ⑤③ | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | | | | | |
| | Standard (PMC) | | | ○ | | ○ | | | | | |
| For distribution boards (PMD) | | | | — | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | | | | |
| Draw-out type (DR) | | | | — | | — | | | | | |
| TemPlug70 (PG) | | | | — | ○ | — | ○ | | | | |
| DIN rail mount | | | | — | | — | | | | | |
| ■ Accessories (optional) | | | | Symbol | | | | | | | |
| Externally mounted: Motor operator | | | | M C | | ● | | ● | | | |
| External operating handle: Breaker-mounted | | | | H B | | ● | | ● | | | |
| Door-mounted (variable depth) | | | | H P | | ● | | ● | | | |
| Toggle extension | | | | H A | | — | | — | | | |
| Mechanical interlock: Slide type | | | | M S | | ● | | ● | | | |
| Rear-connected type | | | | M B | | — | | — | | | |
| Link type | | | | M L | | ● | | ● | | | |
| Wire type | | | | M W | | ● | | ● | | | |
| Toggle holder | | | | H H | | ● | | ● | | | |
| Toggle lock | | | | H L | | ● | | ● | | | |
| Terminal cover: For front-connected | | | | C F | | ● | | ● | | | |
| For rear-connected and plug-in | | | | C R | | ● | | ● | | | |
| Terminal block for lead | | | | T F | | ● | | ● | | | |
| Door flange | | | | D F | | ● | | ● | | | |
| CE marking | | | | Yes | | Yes | | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | | | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | | | |
| Suitability for isolation | | | | Yes | | Yes | | | | | |
| Reverse connection | | | | Yes | | Yes | | | | | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑤③ : For the extension bars, please place the order separately in parts.
⑧⑨ : DC is a 2-pole product that uses both ends of a 3-pole circuit breaker.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.


# Outline dimensions (mm) E250-SF

## Front-connected





Preparation of conductor





With extension bars (optional)*





Drilling plan (front view)





*For the extension bars,
straight bars or spread bars can be supplied.


## Rear-connected




(Bottom view)





Drilling plan (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A
(front view)





Panel cutout B
(front view)





Panel cutout dimensions shown give an allowance of
1.0mm around the handle escutcheon.


## Plug-in (Standard)

Detail of connecting part






Mounting base (rear view)





Drilling plan (front view)





## Flush-mounted




Drilling plan (front view)







# Moulded Case Circuit Breakers

# S250-SF


## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 225 | | | 250 | | | | |
| Type | | | | S250-SF | | | | | | | |
| Number of poles | | | | 2＊ | 3 | 4 | 2＊ | 3 | 4 | | |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | | 125 | | | 250 | | | | |
| Calibrated at 40°C | | | | 150 | | | | | | | |
| 45°C | | | | 175 | | | | | | | |
| | | | | 200 | | | | | | | |
| ＊2 poles breakers use the terminals of both ends of 3 poles breakers. | | | | 225 | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | | 690 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | 8 | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | — | | | | |
| Utilization Category | | | | A | | | A | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 4/4 | | | 4/4 | | | | |
| IEC 60947-2 | | | 500V | 25/13 | | | 25/13 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 30/15 | | | 30/15 | | | | |
| | | | 415V | 40/20 | | | 40/20 | | | | |
| | | | 380V | 40/20 | | | 40/20 | | | | |
| | | | 240V | 85/43 | | | 85/43 | | | | |
| | | ① DC | 250V | 25/13 ⑧⑨ | | | 25/13 ⑧⑨ | | | | |
| | | | 125V | 40/20 ⑧⑨ | | | 40/20 ⑧⑨ | | | | |
| NK | | AC | 690V | — | | | — | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 30/15 | | | 30/15 | | | | |
| | | | 240V | 85/43 | | | 85/43 | | | | |
| | | ① DC | 250V | 25/13 ⑧⑨ | | | 25/13 ⑧⑨ | | | | |
| Weight (◉ marked standard type) kg | | | | 1.5 | 1.5 | 1.9 | 1.5 | 1.5 | 1.9 | | |
| ■Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | ◉ | | | | |
| | With extension bars | | | ○ ⑤③ | | | ○ ⑤③ | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | | — | | | | |
| | Standard (PMC) | | | ○ | | | ○ | | | | |
| For distribution boards (PMD) | | | | — | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | ○ | | | | |
| Draw-out type (DR) | | | | — | | | — | | | | |
| TemPlug70 (PG) | | | | — | ○ | — | — | ○ | — | | |
| DIN rail mount | | | | — | | | — | | | | |
| ■Accessories (optional) | | | | | | Symbol | | | | | |
| Externally mounted: Motor operator | | | | | | M C | ● | | | | |
| External operating handle: Breaker-mounted | | | | | | H B | ● | | | | |
| External operating handle: Door-mounted (variable depth) | | | | | | H P | ● | | | | |
| Toggle extension | | | | | | H A | — | | | | |
| Mechanical interlock ⑨: Slide type | | | | | | M S | ● | | | | |
| Mechanical interlock ⑨: Rear-connected type | | | | | | M B | — | | | | |
| Mechanical interlock ⑨: Link type | | | | | | M L | ● | | | | |
| Mechanical interlock ⑨: Wire type | | | | | | M W | ● | | | | |
| Toggle holder | | | | | | H H | ● | | | | |
| Toggle lock | | | | | | H L | ● | | | | |
| Terminal cover: For front-connected | | | | | | C F | ● | | | | |
| Terminal cover: For rear-connected and plug-in | | | | | | C R | ● | | | | |
| Terminal block for lead | | | | | | T F | ● | | | | |
| Door flange | | | | | | D F | ● | | | | |
| CE marking | | | | Yes | | | Yes | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | Thermal-magnetic | | | | |
| Colour of cover | | | | Grey Blue | | | Grey Blue | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | Yes (Red) | | | | |
| Suitability for isolation | | | | Yes | | | Yes | | | | |
| Reverse connection | | | | Yes | | | Yes | | | | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑤③ : For the extension bars, please place the order separately in parts.
⑧⑨ : DC is a 2-pole product that uses both ends of a 3-pole circuit breaker.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) S250-SF

## Front-connected





*For the extension bars, straight bars or spread bars can be supplied.

## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)




## Flush-mounted



# Moulded Case Circuit Breakers

# PS250-PF




## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 225 | | | 250 | | | | |
| Type | | | | PS250-PF | | | | | | | |
| Number of poles | | | | 2* | 3 | 4 | 2* | 3 | 4 | | |
| **■ Ratings** | | | | | | | | | | | |
| Rated current, A | | | | 125 | | | 250 | | | | |
| Calibrated at 40°C | | | | 150 | | | | | | | |
| 45°C | | | | 175 | | | | | | | |
| | | | | 200 | | | | | | | |
| * 2 poles breakers use the terminals of both ends of 3 poles breakers. | | | | 225 | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | | 800 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | 8 | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | — | | | | |
| Utilization Category | | | | A | | | A | | | | |
| **■ Rated breaking capacity, kA** | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/6 | | | 6/6 | | | | |
| IEC 60947-2 | | | 500V | 35/30 | | | 35/30 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 50/40 | | | 50/40 | | | | |
| | | | 415V | 70/50 | | | 70/50 | | | | |
| | | | 380V | 70/50 | | | 70/50 | | | | |
| | | | 240V | 85/85 | | | 85/85 | | | | |
| | | ① DC | 250V | 40/40 ⑰ ⑧⑨ | | | 40/40 ⑰ ⑧⑨ | | | | |
| | | | 125V | 40/40 ⑰ ⑧⑨ | | | 40/40 ⑰ ⑧⑨ | | | | |
| NK | | AC | 690V | 6/6 | | | 6/6 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 50/35 | | | 50/35 | | | | |
| | | | 240V | 85/85 | | | 85/85 | | | | |
| | | ① DC | 250V | 40/40 ⑰ ⑧⑨ | | | 40/40 ⑰ ⑧⑨ | | | | |
| Weight (◉ marked standard type) kg | | | | 1.5 | 1.5 | 2.0 | 1.5 | 1.5 | 2.0 | | |
| **■ Connections and Mountings** | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | ◉ | | | | |
| | With extension bars | | | ○ ⑤③ | | | ○ ⑤③ | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ⑤⑩ | | | ○ ⑤⑩ | | | | |
| | Standard (PMC) | | | ○ | | — | ○ | | — | | |
| For distribution boards (PMD) | | | | — | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | ○ | | | | |
| Draw-out type (DR) | | | | ▲ | | | ▲ | | | | |
| TemPlug70 (PG) | | | | — | ○ | — | — | ○ | — | | |
| DIN rail mount | | | | — | | | — | | | | |
| **■ Accessories (optional)** | | | | | | Symbol | | | | | |
| Externally mounted: Motor operator | | | | ● | | M C | ● | | | | |
| External operating handle: Breaker-mounted | | | | ● | | H B | ● | | | | |
| External operating handle: Door-mounted (variable depth) | | | | ● | | H P | ● | | | | |
| Toggle extension | | | | — | | H A | — | | | | |
| Mechanical interlock ⑨: Slide type | | | | ● | | M S | ● | | | | |
| Mechanical interlock ⑨: Rear-connected type | | | | — | | M B | — | | | | |
| Mechanical interlock ⑨: Link type | | | | ● | | M L | ● | | | | |
| Mechanical interlock ⑨: Wire type | | | | ● | | M W | ● | | | | |
| Toggle holder | | | | ● | | H H | ● | | | | |
| Toggle lock | | | | ● | | H L | ● | | | | |
| Terminal cover: For front-connected | | | | ● | | C F | ● | | | | |
| Terminal cover: For rear-connected and plug-in | | | | ● | | C R | ● | | | | |
| Terminal block for lead | | | | ● | | T F | ● | | | | |
| Door flange | | | | ● | | D F | ● | | | | |
| CE marking | | | | Yes | | | Yes | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | Thermal-magnetic | | | | |
| Colour of cover | | | | Grey Blue | | | Grey Blue | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | Yes (Red) | | | | |
| Suitability for isolation | | | | Yes | | | Yes | | | | |
| Reverse connection | | | | Yes | | | Yes | | | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑰ : See page 4-7 for the instantaneous trip value when using with DC.
⑤⑩ : A safety trip function is provided. ⑤③ : For the extension bars, please place the order separately in parts.
⑧⑨ : DC is a 2-pole product that uses both ends of a 3-pole circuit breaker.

## Time/Current characteristic curves





| Rated Current (A) | Magnetic trip current AC (A) |
|---|---|
| 125 | 1625±325 |
| 150 | 1950±390 |
| 175 | 2275±455 |
| 200 | 2400±480 |
| 225 | 2475±495 |
| 250 | 2500±500 |

## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS250-PF


## Front-connected





## Rear-connected





## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted



# Moulded Case Circuit Breakers

# PS250-NE, PS250-PE



## Ratings and Specifications

| Frame size (A) | | | | 250 | | 250 | |
|---|---|---|---|---|---|---|---|
| Type | | | | PS250-NE | | PS250-PE | |
| Number of poles | | | | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | |
| Rated current, A | | | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | | $I_n$=250 | | $I_n$=250 | |
| 45°C | | | | 125 | 200 | 125 | 200 |
| ⑧⓪ | | | | 150 | 225 | 150 | 225 |
| | | | | 175 | 250 | 175 | 250 |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | |
| Utilization Category | | | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 6/6 | | 6/6 | |
| IEC 60947-2 | | | 500V | 22/22 | | 35/30 | |
| $I_{cu}$/$I_{cs}$(sym) | | | 440V | 25/25 | | 50/40 | |
| | | | 415V | 36/36 | | 70/50 | |
| | | | 380V | 36/36 | | 70/50 | |
| | | | 240V | 50/50 | | 85/85 | |
| | | DC | 250V | — | | — | |
| | | | 125V | — | | — | |
| NK | | AC | 690V | 6/6 | | 6/6 | |
| $I_{cu}$/$I_{cs}$(sym) | | | 450V | 25/25 | | 50/35 | |
| | | | 240V | 50/50 | | 85/85 | |
| | | DC | 250V | — | | — | |
| Weight (◉ marked standard type) kg | | | | 1.5 | 2.0 | 1.5 | 2.0 |
| ■Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | |
| | With extension bars | | | ○ ⑤③ | | ○ ⑤③ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ⑤⓪ | | ○ ⑤⓪ | |
| | Standard (PMC) | | | ○ | — | ○ | — |
| For distribution boards (PMD) | | | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | |
| Draw-out type (DR) | | | | ▲ | | ▲ | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — |
| DIN rail mount | | | | — | | — | |


| ■Accessories (optional) | | | Symbol | | | |
|---|---|---|---|---|---|---|
| Externally mounted | Motor operator | | | M C | ● | ● |
| | External operating handle | Breaker-mounted | | H B | ● | ● |
| | | Door-mounted (variable depth) | | H P | ● | ● |
| | Toggle extension | | | H A | — | — |
| | Mechanical interlock ⑨ | Slide type | | M S | ● | ● |
| | | Rear-connected type | | M B | — | — |
| | | Link type | | M L | ● | ● |
| | | Wire type | | M W | ● | ● |
| | Toggle holder | | | H H | ● | ● |
| | Toggle lock | | | H L | ● | ● |
| | Terminal cover | For front-connected | | C F | ● | ● |
| | | For rear-connected and plug-in | | C R | ● | ● |
| | Terminal block for lead | | | T F | ● | ● |
| | Door flange | | | D F | ● | ● |
| CE marking | | | | | Yes | Yes |
| Overcurrent trip mechanism | | | | | Electronic | Electronic |
| Colour of cover | | | | | Grey Blue | Grey Blue |
| Trip button (Colour) | | | | | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | | | Yes | Yes |
| Reverse connection | | | | | Yes | Yes |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑤⓪ : A safety trip function is provided.
⑤③ : For the extension bars, please place the order separately in parts.
⑧⓪ : If the ambient temperature exceeds 45°C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves

• Long time/Short time trip characteristics




• Instantaneous trip characteristics




Note: See page 6-4 for Neutral protection, ground fault trip and preferential trip alarm characteristics.

## Overcurrent tripping characteristics

TPOP OCR (LSIG) ($I_n$)=250A

| | |
|---|---|
| Rated current settings (A) ($I_r$) = ($I_r1$)×($I_r2$) | ($I_r1$) (A)=125, 150, 175, 200, 225, 250 adjustable |
| | ($I_r2$)=0.91, 0.92, 0.93, 0.94, 0.95, 0.96, 0.97, 0.98, 0.99, 1.00 adjustable |
| Long time-delay time settings (s) : ($t_r$) | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable at ($I_r$)×600% |
| | Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF ①② |
| | Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | 50, 100, 200, 300, 400 adjustable |
| | Ramp characteristics I²t: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more |
| | When ($t_{sd}$)=50ms Time-delay setting tolerance –30ms or more +30ms or less<br>When ($t_{sd}$)=100ms to 400ms Time-delay setting tolerance –20ms or more +50ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | ($I_n$)×3, 4, 5, 6, 7, 8, 9, 10, 11 adjustable |
| | Current setting tolerance within ±15% |
| Neutral protection pick-up current (A) : ($I_N$) | For 3P OFF fixed |
| | For 4P ($I_r$)×50%, 100% or OFF |
| Neutral protection time settings (s) : ($t_N$) | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip |
| Ground fault trip pick-up current (A) : ($I_g$) | 3P for 3ø3W, 4P for 3ø4W (3P 3ø4W not supported) or OFF<br>($I_n$)×20% Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | 200<br>Time-delay setting tolerance –20ms or more +50ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | ($I_r$)×80%<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | ($t_r$)×50%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |


**Remarks:**

1: If not otherwise specified, the product will be delivered with the underlined standard setting values.
2: The TPOT type OCR (LSI) only has long time-delay trip, short time-delay trip, instantaneous trip, and preferential trip alarm.

**Notes:**

①: When $I_r$=225A or more and $t_r$=16s is set, the device operates with Isd=$I_r$ × 9 even if the max. Isd=$I_r$ × 10 is set.
②: When $I_{sd}$=OFF is set, the long time-delay will become ramp characteristics last to 2s at Max 2,750A in the area of 2000A or more of conduction current. If long time-delay time setting is faster than the ramp characteristic time then the device operates with the long time-delay time setting.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS250-NE, PS250-PE


## Front-connected





## Rear-connected





## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted







# Moulded Case Circuit Breakers

## H225-NF, L225-NF

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 225 | | 225 | | | | | |
| Type | | | | H225-NF | | L225-NF | | | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | | 125 | 225 | 125 | 225 | | | | |
| Calibrated at 40°C | | | | 150 | | 150 | | | | | |
| 45°C | | | | 175 | | 175 | | | | | |
| | | | | 200 | | 200 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | | | | | |
| Utilization Category | | | | A | | A | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 20/15 | | 25/20 | | | | | |
| IEC 60947-2 | | | 500V | 45/45 | | 65/65 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 120/80 | | 180/135 | | | | | |
| | | | 415V | 125/85 | | 200/150 | | | | | |
| | | | 380V | 125/85 | | 200/150 | | | | | |
| | | | 240V | 150/150 | | 200/150 | | | | | |
| | | ① DC | 250V | 40/40 | | 40/40 | | | | | |
| | | | 125V | 40/40 | | 40/40 | | | | | |
| NK | | AC | 690V | 20/15 | | 25/20 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 120/80 | | 180/135 | | | | | |
| | | | 240V | 150/150 | | 200/150 ㉛ | | | | | |
| | | DC | 250V | — | | — | | | | | |
| Weight (◉ marked standard type) kg | | | | 2.4 | 3.2 | 2.4 | 3.2 | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | | | | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊶ | | ○ ㊶ | | | | | |
| | Standard (PMC) | | | ○ | — | ○ | — | | | | |
| For distribution boards (PMD) | | | | — | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | | | | |
| Draw-out type (DR) | | | | — | | — | | | | | |
| TemPlug70 (PG) | | | | ▲ ㊶ | — | — | | | | | |
| DIN rail mount | | | | — | | — | | | | | |
| ■ Accessories (optional) | | | | | Symbol | | | | | | |
| Externally mounted: Motor operator | | | | ● | | ● | | | | | |
| External operating handle: Breaker-mounted | | | | ● | | ● | | | | | |
| External operating handle: Door-mounted (variable depth) | | | | ● | | ● | | | | | |
| Toggle extension | | | | — | | — | | | | | |
| Mechanical interlock: Slide type | | | | ● | | ● | | | | | |
| Mechanical interlock: Rear-connected type | | | | — | | — | | | | | |
| Mechanical interlock: Link type | | | | ● | | ● | | | | | |
| Mechanical interlock: Wire type | | | | ● | | ● | | | | | |
| Toggle holder | | | | ● | | ● | | | | | |
| Toggle lock | | | | ● | | ● | | | | | |
| Terminal cover: For front-connected | | | | ● | | ● | | | | | |
| Terminal cover: For rear-connected and plug-in | | | | ● | | ● | | | | | |
| Terminal block for lead | | | | ● | | ● | | | | | |
| Door flange | | | | ● | | ● | | | | | |
| CE marking | | | | Yes | | Yes | | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | | | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | | | |
| Suitability for isolation | | | | Yes | | Yes | | | | | |
| Reverse connection | | | | Yes ㉒ | | Yes ㉒ | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"

① : DC is a special specification. When ordering, please specify DC.

㉛ : Also applicable to 415V AC.


㊶ : A safety lock function is provided.

㊸ : For the extension bars, please place the order separately in parts.


㉒ : There are some limitations. See page 5-23 for details.

㊶ : They cannot be applied to circuits with a short circuit breaking current exceeding 85kA.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) H225-NF, L225-NF

## Front-connected





*Spread extension bars for 3 poles.
Staraight extension bars for 4 poles.

## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view) Panel cutout B (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in(Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.





# Moulded Case Circuit Breakers

# H250-NF, L250-NF

## Ratings and Specifications

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 250 | | 250 | | | |
| Type | | | | H250-NF | | L250-NF | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | |
| ■ Ratings | | | | | | | | | |
| Rated current, A | | | | 250 | | 250 | | | |
| Calibrated at 40°C | | | | | | | | | |
| 45°C | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | | | |
| Utilization Category | | | | A | | A | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 20/15 | | 25/20 | | | |
| IEC 60947-2 | | | 500V | 45/45 | | 65/65 | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 120/80 | | 180/135 | | | |
| | | | 415V | 125/85 | | 200/150 | | | |
| | | | 380V | 125/85 | | 200/150 | | | |
| | | | 240V | 150/150 | | 200/150 | | | |
| | | ① DC | 250V | 40/40 | | 40/40 | | | |
| | | | 125V | 40/40 | | 40/40 | | | |
| NK | | AC | 690V | — | | — | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | — | | — | | | |
| | | | 240V | — | | — | | | |
| | | DC | 250V | — | | — | | | |
| Weight (◉ marked standard type) kg | | | | 2.4 | 3.2 | 2.4 | 3.2 | | |
| ■ Connections and Mountings | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | | | |
| | Standard (PMC) | | | — | | — | | | |
| For distribution boards (PMD) | | | | — | | — | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | | |
| Draw-out type (DR) | | | | — | | — | | | |
| TemPlug70 (PG) | | | | — | | — | | | |
| DIN rail mount | | | | — | | — | | | |
| ■ Accessories (optional) | | | | Symbol | | | | | |
| Externally mounted: Motor operator | | | | M C | | ● | | | |
| External operating handle: Breaker-mounted | | | | H B | | ● | | | |
| External operating handle: Door-mounted (variable depth) | | | | H P | | ● | | | |
| Toggle extension | | | | H A | | — | | | |
| Mechanical interlock: Slide type | | | | M S | | ● | | | |
| Mechanical interlock: Rear-connected type | | | | M B | | — | | | |
| Mechanical interlock: Link type | | | | M L | | ● | | | |
| Mechanical interlock: Wire type | | | | M W | | ● | | | |
| Toggle holder | | | | H H | | ● | | | |
| Toggle lock | | | | H L | | ● | | | |
| Terminal cover: For front-connected | | | | C F | | ● | | | |
| Terminal cover: For rear-connected and plug-in | | | | C R | | ● | | | |
| Terminal block for lead | | | | T F | | ● | | | |
| Door flange | | | | D F | | ● | | | |
| CE marking | | | | Yes | | Yes | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | | Yes | | Yes | | | |
| Reverse connection | | | | Yes ㉒ | | Yes ㉒ | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"

① : DC is a special specification. When ordering, please specify DC.


㊸ : For the extension bars, please place the order separately in parts.

㉒ : There are some limitations. See page 5-23 for details.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)




## Outline dimensions (mm) H250-NF, L250-NF


### Front-connected




### Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions TemBreak PRO


## Moulded Case Circuit Breakers

## H225-NE

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 225 | | | | | |
| Type | | | **H225-NE** | | | | | |
| Number of poles | | | 3 | 4 | | | | |
| **■ Ratings** | | | | | | | | |
| Rated current, A | | | (Adjustable) | | | | | |
| Calibrated at 40°C | | | 125 | | | | | |
| 45°C | | | 150 | | | | | |
| ⑧⓪ | | | 175 | | | | | |
| | | | 200 | | | | | |
| | | | 225 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | | | | |
| Utilization Category | | | A | | | | | |
| **■ Rated breaking capacity, kA** | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 20/15 | | | | | |
| IEC 60947-2 | | 500V | 45/45 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 120/80 | | | | | |
| | | 415V | 125/85 | | | | | |
| | | 380V | 125/85 | | | | | |
| | | 240V | 150/150 | | | | | |
| | DC | 250V | — | | | | | |
| | | 125V | — | | | | | |
| NK | AC | 690V | — | | | | | |
| $I_{cu}/I_{cs}$(sym) | | 450V | — | | | | | |
| | | 240V | — | | | | | |
| | DC | 250V | — | | | | | |
| Weight (◉ marked standard type) kg | | | 2.5 | 3.3 | | | | |
| **■ Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | | | |
| | With extension bars | | ○ ⑤③ | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | | |
| | Standard (PMC) | | — | | | | | |
| For distribution boards (PMD) | | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | | |
| Draw-out type (DR) | | | — | | | | | |
| TemPlug70 (PG) | | | — | | | | | |
| DIN rail mount | | | — | | | | | |
| **■ Accessories (optional)** | | | Symbol | | | | | |
| Externally mounted: Motor operator | | | M C | ● | | | | |
| External operating handle: Breaker-mounted | | | H B | ● | | | | |
| External operating handle: Door-mounted (variable depth) | | | H P | ● | | | | |
| Toggle extension | | | H A | — | | | | |
| Mechanical interlock: Slide type | | | M S | ● | | | | |
| Mechanical interlock: Rear-connected type | | | M B | — | | | | |
| Mechanical interlock: Link type | | | M L | ● | | | | |
| Mechanical interlock: Wire type | | | M W | ● | | | | |
| Toggle holder | | | H H | ● | | | | |
| Toggle lock | | | H L | ● | | | | |
| Terminal cover: For front-connected | | | C F | ● | | | | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | | | |
| Terminal block for lead | | | T F | ● | | | | |
| Door flange | | | D F | ● | | | | |
| CE marking | | | | Yes | | | | |
| Overcurrent trip mechanism | | | | Electronic ⑳ | | | | |
| Colour of cover | | | | Grey Blue | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | | |
| Suitability for isolation | | | | Yes | | | | |
| Reverse connection | | | | Yes ⑦② | | | | |

## Time/Current characteristic curves




## Overcurrent tripping characteristics

| Characteristics No. | 1 | 2 | 3 | 4 | 5 |
|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | CT rated current : ($I_{CT}$) = 250A<br>125, 150, 175, 200, 225 | | | | |
| Long time-delay time settings (s) : ($t_r$) | 11 | 21 | 21 | 5 | 7.5 |
| | at ($I_r$)×200% | | | at ($I_r$)×600% | |
| | Setting tolerance ±20% | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 |
| | Setting tolerance ±15% | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 |
| | Total clearing time +50ms, resettable time –20ms | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | ($I_r$)×1400%<br>Setting tolerance ±20% | | | | |
| Option: Preferential trip alarm | | | | | |
| Pick-up current (A) : ($I_p$) | ($I_r$)×80% Setting tolerance ±10% | | | | |
| Time settings (s) : ($t_p$) | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | |
| Option: Neutral protection | | | | | |
| Pick-up current (A) : ($I_N$) | ($I_r$)×100% | | | | |
| Time settings (s) : ($t_N$) | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available".


⑳ : Optional preferential trip alarm function available on request.

⑤③ : For the extension bars, please place the order separately in parts.

⑦② : There are some limitations. See page 5-23 for details.


⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Combinations of Internally Mounted Accessories (Optional)




## Outline dimensions (mm) H225-NE

### Front-connected





*Spread extension bars for 3 poles.
Staraight extension bars for 4 poles.

### Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view) Panel cutout B (front view)



Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

# Moulded Case Circuit Breakers

# E400-NF



## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 400 | | | | |
| Type | | | | E400-NF | | | | |
| Number of poles | | | | 3 | | | | |
| ■ Ratings | | | | | | | | |
| Rated current, A | | | | 250 | | | | |
| Calibrated at 40°C | | | | 300 | | | | |
| 45°C | | | | 350 | | | | |
| | | | | 400 | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | | |
| Utilization Category | | | | A | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | — | | | | |
| IEC 60947-2 | | | 500V | 15/15 | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 22/22 | | | | |
| | | | 415V | 25/25 | | | | |
| | | | 380V | 25/25 | | | | |
| | | | 240V | 35/35 | | | | |
| | | ① DC | 250V | 25/19 | | | | |
| | | | 125V | 40/30 | | | | |
| NK | | AC | 690V | — | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | — | | | | |
| | | | 240V | — | | | | |
| | | ① DC | 250V | — | | | | |
| Weight (◉ marked standard type) kg | | | | 4.2 | | | | |
| ■ Connections and Mountings | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | | |
| | With extension bars | | | ○ | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | | | |
| | Standard (PMC) | | | — | | | | |
| For distribution boards (PMD) | | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | | |
| Draw-out type (DR) | | | | — | | | | |
| TemPlug70 (PG) | | | | ○ | | | | |
| DIN rail mount | | | | — | | | | |
| ■ Accessories (optional) | | | Symbol | | | | | |
| Externally mounted: Motor operator | | | M C | ● | | | | |
| External operating handle: Breaker-mounted | | | H B | ● | | | | |
| External operating handle: Door-mounted (variable depth) | | | H P | ● | | | | |
| Toggle extension | | | H A | ● | | | | |
| Mechanical interlock: Slide type | | | M S | ● | | | | |
| Mechanical interlock: Rear-connected type | | | M B | — | | | | |
| Mechanical interlock: Link type | | | M L | ● | | | | |
| Mechanical interlock: Wire type | | | M W | ● | | | | |
| Toggle holder | | | H H | ● | | | | |
| Toggle lock | | | H L | | | | | |
| Terminal cover: For front-connected | | | C F | ● | | | | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | | | |
| Terminal block for lead | | | T F | ● | | | | |
| Door flange | | | D F | ● | | | | |
| CE marking | | | | Yes | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | | |
| Colour of cover | | | | Grey Blue | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | | |
| Suitability for isolation | | | | Yes | | | | |
| Reverse connection | | | | Yes | | | | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

① : DC is a special specification. When ordering, please specify DC.

## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) | Magnetic trip pick-up current (A) $I_n \times$ 10 |
|---|---|
| 250 | 2500 |
| 300 | 3000 |
| 350 | 3500 |
| 400 | 4000 |

**Note**(1): Setting tolerance: ±10%.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) E400-NF


## Front-connected





Preparation of conductor





With extension bars (optional)




Drilling plan (front view)





## Rear-connected





Detail of connecting part


(Bottom view)




Drilling plan (front view)





Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Flush-mounted





Detail of connecting part




Drilling plan (front view)




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions TemBreak PRO

## Moulded Case Circuit Breakers

## PS400-CF, PS400-NF, PS400-GF

## Ratings and Specifications

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | | 400 | | 400 | | |
| Type | | | PS400-CF | | PS400-NF | | PS400-GF | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | |
| ■Ratings | | | | | | | | | |
| Rated current, A | | | 225 | | 225 | | 225 | | |
| Calibrated at 40°C | | | 250 | | 250 | | 250 | | |
| 45°C | | | 300 | | 300 | | 300 | | |
| | | | 350 | | 350 | | 350 | | |
| | | | 400 | | 400 | | 400 | | |
| Rated insulation voltage〔$U_i$〕 V | | | 800 | | 800 | | 800 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | — | | — | | |
| Utilization Category | | | A | | A | | A | | |
| ■Rated breaking capacity, kA | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 7/7 | | 12/12 | | 12/12 | | |
| IEC 60947-2 | | 500V | 25/25 | | 30/30 | | 50/50 | | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 30/30 | | 45/45 | | 65/65 | | |
| | | 415V | 36/36 | | 50/50 | | 70/70 | | |
| | | 380V | 36/36 | | 50/50 | | 70/70 | | |
| | | 240V | 50/50 | | 85/85 | | 100/100 | | |
| | ① DC | 250V | 25/25 ⑰ | | 50/50 ⑰ | | 50/50 ⑰ | | |
| | | 125V | 40/40 ⑰ | | 50/50 ⑰ | | 50/50 ⑰ | | |
| NK | AC | 690V | 7/7 | | 12/12 | | 12/12 | | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 30/30 | | 45/45 | | 65/65 | | |
| | | 240V | 50/50 | | 85/85 | | 100/100 | | |
| | ① DC | 250V | 25/25 ⑰ | | 50/50 ⑰ | | 50/50 ⑰ | | |
| Weight (◉ marked standard type) kg | | | 5.5 | 7.3 | 5.5 | 7.3 | 5.5 | 7.3 | |
| ■Connections and Mountings | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | | ◉ | | |
| | With extension bars | | ○ | | ○ | | ○ | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ⑤⓪ | | ○ ⑤⓪ | | ○ ⑤⓪ | | |
| | Standard (PMC) | | ○ | — | ○ | — | ○ | — | |
| For distribution boards (PMD) | | | — | | — | | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | |
| Draw-out type (DR) | | | ▲ | | ▲ | | ▲ | | |
| TemPlug70 (PG) | | | ○ | — | ○ | — | ○ | — | |
| DIN rail mount | | | — | | — | | — | | |
| ■Accessories (optional) | | Symbol | | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | ● | | ● | | |
| External operating handle: Breaker-mounted | | H B | ● | | ● | | ● | | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | | ● | | ● | | |
| Toggle extension | | H A | ● | | ● | | ● | | |
| Mechanical interlock ⑨: Slide type | | M S | ● | | ● | | ● | | |
| Mechanical interlock ⑨: Rear-connected type | | M B | — | | — | | — | | |
| Mechanical interlock ⑨: Link type | | M L | ● | | ● | | ● | | |
| Mechanical interlock ⑨: Wire type | | M W | ● | | ● | | ● | | |
| Toggle holder | | H H | ● | | ● | | ● | | |
| Toggle lock | | H L | | | | | | | |
| Terminal cover | For front-connected | C F | ● | | ● | | ● | | |
| | For rear-connected and plug-in | C R | ● | | ● | | ● | | |
| Terminal block for lead | | T F | ● | | ● | | ● | | |
| Door flange | | D F | ● | | ● | | ● | | |
| CE marking | | | Yes | | Yes | | Yes | | |
| Overcurrent trip mechanism | | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | |
| Reverse connection | | | Yes | | Yes | | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".


① : DC is a special specification. When ordering, please specify DC.

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).


⑰ : See page 4-7 for the instantaneous trip value when using with DC.

⑤⓪ : A safety trip function is provided.

## Time/Current characteristic curves




## Ambient compensating curves




## Magnetic trip pick-up current

| Rated current (A) | $I_n$ × | Magnetic trip pick-up current (adjustable range) (A) 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|---|
| 225 | | 2250 | 2025 | 1800 | 1575 | 1350 | 1125 |
| 250 | | 2500 | 2250 | 2000 | 1750 | 1500 | 1250 |
| 300 | | 3000 | 2700 | 2400 | 2100 | 1800 | 1500 |
| 350 | | 3500 | 3150 | 2800 | 2450 | 2100 | 1750 |
| 400 | | 4000 | 3600 | 3200 | 2800 | 2400 | 2000 |


**Note** (1): Setting tolerance: ±20%.

**Remarks:**

(1): Unless otherwise stated when ordering, the selector dial is factory set to position "10".

(2): The trip pick-up current of DC models is not adjustable.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS400-CF, PS400-NF, PS400-GF


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted







# Moulded Case Circuit Breakers

# PS400-NE, PS400-GE

## Ratings and Specifications


| Frame size (A) | | | | 400 | | 400 | |
|---|---|---|---|---|---|---|---|
| Type | | | | PS400-NE | | PS400-GE | |
| Number of poles | | | | 3 | 4 | 3 | 4 |
| **■ Ratings** | | | | | | | |
| Rated current, A | | | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | | $I_n$=250 | $I_n$=400 | $I_n$=250 | $I_n$=400 |
| 45°C | | | | 125 | 175 | 125 | 175 |
| ⑧⓪ | | | | 150 | 200 | 150 | 200 |
| | | | | 175 | 225 | 175 | 225 |
| | | | | 200 | 250 | 200 | 250 |
| | | | | 225 | 300 | 225 | 300 |
| | | | | 250 | 350 | 250 | 350 |
| | | | | | 400 | | 400 |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | 5 (0.4sec.) | | 5 (0.4sec.) | |
| Utilization Category | | | | B | | B | |
| **■ Rated breaking capacity, kA** | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 12/12 | | 12/12 | |
| IEC 60947-2 | | | 500V | 30/30 | | 50/50 | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 45/45 | | 65/65 | |
| | | | 415V | 50/50 | | 70/70 | |
| | | | 380V | 50/50 | | 70/70 | |
| | | | 240V | 85/85 | | 100/100 | |
| | | DC | 250V | — | | — | |
| | | | 125V | — | | — | |
| NK | | AC | 690V | 12/12 | | 12/12 | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 45/45 | | 65/65 | |
| | | | 240V | 85/85 | | 100/100 | |
| | | DC | 250V | — | | — | |
| Weight (◉ marked standard type) kg | | | | 5.7 | 7.5 | 5.7 | 7.5 |
| **■ Connections and Mountings** | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | |
| | With extension bars | | | ○ | | ○ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | ○ ⑤⓪ | | ○ ⑤⓪ | |
| | | Standard (PMC) | | ○ | — | ○ | — |
| | For distribution boards (PMD) | | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | |
| Draw-out type (DR) | | | | ▲ | | ▲ | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — |
| DIN rail mount | | | | — | | — | |

| ■ Accessories (optional) | | | Symbol | | |
|---|---|---|---|---|---|
| Externally mounted | Motor operator | | M C | ● | ● |
| | External operating handle | Breaker-mounted | H B | ● | ● |
| | | Door-mounted (variable depth) | H P | ● | ● |
| | Toggle extension | | H A | ● | ● |
| | Mechanical interlock ⑨ | Slide type | M S | ● | ● |
| | | Rear-connected type | M B | — | — |
| | | Link type | M L | ● | ● |
| | | Wire type | M W | ● | ● |
| | Toggle holder | | H H | ● | ● |
| | Toggle lock | | H L | | |
| | Terminal cover | For front-connected | C F | ● | ● |
| | | For rear-connected and plug-in | C R | ● | ● |
| | Terminal block for lead | | T F | ● | ● |
| | Door flange | | D F | ● | ● |
| CE marking | | | | Yes | Yes |
| Overcurrent trip mechanism | | | | Electronic | Electronic |
| Colour of cover | | | | Grey Blue | Grey Blue |
| Trip button (Colour) | | | | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | | Yes | Yes |
| Reverse connection | | | | Yes | Yes |


**Notes:**
◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available". ⑨ : Mechanical interlocks cannot be applied to draw-out type (DR). ⑤⓪ : A safety trip function is provided. ⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves

• Long time/Short time trip characteristics




• Instantaneous trip characteristics




Note: See page 6-4 for Neutral protection, ground fault trip and preferential trip alarm characteristics.

## Overcurrent tripping characteristics

TPOP OCR (LSIG) ($I_n$)=250A, 400A

| | |
|---|---|
| Rated current settings (A) ($I_r$) = ($I_r1$)×($I_r2$) | When ($I_n$)=250A ($I_r1$) (A)=125, 150, 175, 200, 225, 250 adjustable<br>When ($I_n$)=400A ($I_r1$) (A)=175, 200, 225, 250, 300, 350, 400 adjustable |
| | ($I_r2$)=0.91, 0.92, 0.93, 0.94, 0.95, 0.96, 0.97, 0.98, 0.99, 1.00 |
| Long time-delay time settings (s) : ($t_r$) | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable<br>at ($I_r$)×600% |
| | Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF |
| | Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | 50, 100, 200, 300, 400 adjustable |
| | Ramp characteristics I²t: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more |
| | When ($t_{sd}$)=50ms Time-delay setting tolerance –30ms or more +30ms or less<br>When ($t_{sd}$)=100ms to 400ms Time-delay setting tolerance –20ms or more +50ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | ($I_n$)×3, 4, 5, 6, 7, 8, 10, 11, 12 adjustable |
| | Current setting tolerance within ±15% |
| Neutral protection pick-up current (A) : ($I_N$) | For 3P OFF fixed |
| | For 4P ($I_r$)×50%, 100% or OFF |
| Neutral protection time settings (s) : ($t_N$) | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip |
| Ground fault trip pick-up current (A) : ($I_g$) | 3P for 3ø3W, 4P for 3ø4W (3P 3ø4W not supported) or OFF<br>($I_n$)×20% Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | 200<br>Time-delay setting tolerance –20ms or more +50ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | ($I_r$)×80%<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | ($t_r$)×50%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |

**Notes:**
1: If not otherwise specified, the product will be delivered with the underlined standard setting values.
2: The TPOT type OCR (LSI) only has long time-delay trip, short time-delay trip, instantaneous trip, and preferential trip alarm.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3 4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS400-NE, PS400-GE

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted





# 7 Characteristics and Outline Dimensions TemBreak PRO

# Moulded Case Circuit Breakers

# PH400-CF

## Ratings and Specifications


| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 400 | | | | | | | |
| Type | | | | PH400-CF | | | | | | | |
| Number of poles | | | | 3 | 4 | | | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | | 225 | | | | | | | |
| Calibrated at 40°C | | | | 250 | | | | | | | |
| 45°C | | | | 300 | | | | | | | |
| | | | | 350 | | | | | | | |
| | | | | 400 | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | | | | | |
| Utilization Category | | | | A | | | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 12/12 | | | | | | | |
| IEC 60947-2 | | | 500V | 65/65 | | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 100/100 | | | | | | | |
| | | | 415V | 110/110 | | | | | | | |
| | | | 380V | 110/110 | | | | | | | |
| | | | 240V | 125/125 | | | | | | | |
| | | ① DC | 250V | 50/50 ⑰ | | | | | | | |
| | | | 125V | 50/50 ⑰ | | | | | | | |
| NK | | AC | 690V | 12/12 | | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 100/100 | | | | | | | |
| | | | 240V | 125/125 | | | | | | | |
| | | ① DC | 250V | 50/50 ⑰ | | | | | | | |
| Weight (◉ marked standard type) kg | | | | 5.5 | 7.3 | | | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | | | | | | |
| | With extension bars | | | ○ | | | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ⑤⓪ | | | | | | | |
| | Standard (PMC) | | | ○ | — | | | | | | |
| For distribution boards (PMD) | | | | — | | | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | | | | | |
| Draw-out type (DR) | | | | ▲ | | | | | | | |
| TemPlug70 (PG) | | | | ▲ ⑧① | — | | | | | | |
| DIN rail mount | | | | — | | | | | | | |

| ■ Accessories (optional) | | | Symbol | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Externally mounted | Motor operator | | M C | ● | | | | | | | |
| | External operating handle | Breaker-mounted | H B | ● | | | | | | | |
| | | Door-mounted (variable depth) | H P | ● | | | | | | | |
| | Toggle extension | | H A | ● | | | | | | | |
| | Mechanical interlock ⑨ | Slide type | M S | ● | | | | | | | |
| | | Rear-connected type | M B | — | | | | | | | |
| | | Link type | M L | ● | | | | | | | |
| | | Wire type | M W | ● | | | | | | | |
| | Toggle holder | | H H | ● | | | | | | | |
| | Toggle lock | | H L | | | | | | | | |
| | Terminal cover | For front-connected | C F | ● | | | | | | | |
| | | For rear-connected and plug-in | C R | ● | | | | | | | |
| | Terminal block for lead | | T F | ● | | | | | | | |
| | Door flange | | D F | ● | | | | | | | |
| CE marking | | | | Yes | | | | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic (adjustable) | | | | | | | |
| Colour of cover | | | | Grey Blue | | | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | | | | | |
| Suitability for isolation | | | | Yes | | | | | | | |
| Reverse connection | | | | Yes | | | | | | | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑰ : See page 4-7 for the instantaneous trip value when using with DC.
⑤⓪ : A safety trip function is provided.
⑧① : They cannot be applied to circuits with a short circuit breaking current exceeding 85kA.

## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) | | | | | |
|---|---|---|---|---|---|---|
| $I_n$ × | 10 | 9 | 8 | 7 | 6 | 5 |
| 225 | 2250 | 2025 | 1800 | 1575 | 1350 | 1125 |
| 250 | 2500 | 2250 | 2000 | 1750 | 1500 | 1250 |
| 300 | 3000 | 2700 | 2400 | 2100 | 1800 | 1500 |
| 350 | 3500 | 3150 | 2800 | 2450 | 2100 | 1750 |
| 400 | 4000 | 3600 | 3200 | 2800 | 2400 | 2000 |

**Note** (1): Setting tolerance: ±20%.
**Remarks:**
(1): Unless otherwise stated when ordering, the selector dial is factory set to position "10".
(2): The trip pick-up current of DC models is not adjustable.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PH400-CF

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted



# Moulded Case Circuit Breakers

# PH400-CE




## Ratings and Specifications

| | | | | | |
|---|---|---|---|---|---|
| Frame size (A) | | | | 400 | |
| Type | | | | PH400-CE | |
| Number of poles | | | | 3 | 4 |
| ■Ratings | | | | | |
| Rated current, A | | | | Adjustable | |
| Calibrated at 40°C | | | | $I_n$=250 | $I_n$=400 |
| 45°C | | | | 125 | 175 |
| ⑧⓪ | | | | 150 | 200 |
| | | | | 175 | 225 |
| | | | | 200 | 250 |
| | | | | 225 | 300 |
| | | | | 250 | 350 |
| | | | | | 400 |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | 5 (0.4sec.) | |
| Utilization Category | | | | B | |
| ■Rated breaking capacity, kA | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | | 12/12 | |
| IEC 60947-2 | | 500V | | 65/65 | |
| $I_{cu}/I_{cs}$(sym) | | 440V | | 100/100 | |
| | | 415V | | 110/110 | |
| | | 380V | | 110/110 | |
| | | 240V | | 125/125 | |
| | DC | 250V | | — | |
| | | 125V | | — | |
| NK | AC | 690V | | 12/12 | |
| $I_{cu}/I_{cs}$(sym) | | 450V | | 100/100 | |
| | | 240V | | 125/125 | |
| | DC | 250V | | — | |
| Weight (◉ marked standard type) kg | | | | 5.7 | 7.5 |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | |
| | With extension bars | | | ○ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | ○ ⑤⓪ | |
| | | Standard (PMC) | | ○ | — |
| | For distribution boards (PMD) | | | — | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | |
| Draw-out type (DR) | | | | ▲ | |
| TemPlug70 (PG) | | | | ▲ ⑧① | — |
| DIN rail mount | | | | — | |
| ■Accessories (optional) | | | Symbol | | |
| Externally mounted: Motor operator | | | M C | ● | |
| External operating handle | Breaker-mounted | | H B | ● | |
| | Door-mounted (variable depth) | | H P | ● | |
| Toggle extension | | | H A | ● | |
| Mechanical interlock ⑨ | Slide type | | M S | ● | |
| | Rear-connected type | | M B | — | |
| | Link type | | M L | ● | |
| | Wire type | | M W | ● | |
| Toggle holder | | | H H | ● | |
| Toggle lock | | | H L | | |
| Terminal cover | For front-connected | | C F | ● | |
| | For rear-connected and plug-in | | C R | ● | |
| Terminal block for lead | | | T F | ● | |
| Door flange | | | D F | ● | |
| CE marking | | | | Yes | |
| Overcurrent trip mechanism | | | | Electronic | |
| Colour of cover | | | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | |
| Suitability for isolation | | | | Yes | |
| Reverse connection | | | | Yes | |


**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering. ▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available". ⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑤⓪ : A safety trip function is provided. ⑧⓪ : If the ambient temperature exceeds 45°C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8. ⑧① : They cannot be applied to circuits with a short circuit breaking current exceeding 85kA.

## Time/Current characteristic curves

• Long time/Short time trip characteristics




• Instantaneous trip characteristics




Note: See page 6-4 for Neutral protection, ground fault trip and preferential trip alarm characteristics.

## Overcurrent tripping characteristics

TPOP OCR (LSIG) ($I_n$)=250A, 400A

| | |
|---|---|
| Rated current settings (A) ($I_r$) = ($I_r1$)×($I_r2$) | When ($I_n$)=250A ($I_r1$) (A)=125, 150, 175, 200, 225, 250 adjustable<br>When ($I_n$)=400A ($I_r1$) (A)=175, 200, 225, 250, 300, 350, 400 adjustable |
| | ($I_r2$)=0.91, 0.92, 0.93, 0.94, 0.95, 0.96, 0.97, 0.98, 0.99, 1.00 |
| Long time-delay time settings (s) : ($t_r$) | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable<br>at ($I_r$)×600% |
| | Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF |
| | Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | 50, 100, 200, 300, 400 adjustable |
| | Ramp characteristics I²t: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more |
| | When ($t_{sd}$)=50ms Time-delay setting tolerance –30ms or more +30ms or less<br>When ($t_{sd}$)=100ms to 400ms Time-delay setting tolerance –20ms or more +50ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | ($I_n$)×3, 4, 5, 6, 7, 8, 10, 11, 12 adjustable |
| | Current setting tolerance within ±15% |
| Neutral protection pick-up current (A) : ($I_N$) | For 3P OFF fixed |
| | For 4P ($I_r$)×50%, 100% or OFF |
| Neutral protection time settings (s) : ($t_N$) | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip |
| Ground fault trip pick-up current (A) : ($I_g$) | 3P for 3ø3W, 4P for 3ø4W (3P 3ø4W not supported) or OFF<br>($I_n$)×20% Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | 200<br>Time-delay setting tolerance –20ms or more +50ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | ($I_r$)×80%<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | ($t_r$)×50%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |

**Notes:**
1: If not otherwise specified, the product will be delivered with the underlined standard setting values.
2: The TPOT type OCR (LSI) only has long time-delay trip, short time-delay trip, instantaneous trip, and preferential trip alarm.


## Combinations of Internally Mounted Accessories (Optional)

| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3<br>4 | | | | | | | | | | | |


Toggle — Left pole, Right pole

# Outline dimensions (mm) PH400-CE

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted





# 7 Characteristics and Outline Dimensions

TemBreak PRO

## Moulded Case Circuit Breakers

## H400-NE, L400-NE

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | | | 400 | | | | | |
| Type | | | H400-NE | | | L400-NE | | | | | |
| Number of poles | | | 3 | 4 | | 3 | 4 | | | | |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | Adjustable | | | Adjustable | | | | | |
| Calibrated at 40°C | | | $I_{CT}$=250 | $I_{CT}$=400 | | $I_{CT}$=250 | $I_{CT}$=400 | | | | |
| 45°C | | | 125 | 175 350 | | 125 | 175 350 | | | | |
| ㊽ | | | 150 | 200 400 | | 150 | 200 400 | | | | |
| | | | 175 | 225 | | 175 | 225 | | | | |
| | | | 200 | 250 | | 200 | 250 | | | | |
| | | | 225 | 300 | | 225 | 300 | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | 690 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | 8 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 5 (0.3sec.) | | | 5 (0.3sec.) | | | | | |
| Utilization Category | | | B | | | B | | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 35/35 | | | 50/50 | | | | | |
| IEC 60947-2 | | 500V | 45/45 | | | 65/65 | | | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | 120/80 | | | 180/135 | | | | | |
| | | 415V | 125/85 | | | 200/150 | | | | | |
| | | 380V | 125/85 | | | 200/150 | | | | | |
| | | 240V | 150/150 | | | 200/150 | | | | | |
| | DC | 250V | — | | | — | | | | | |
| | | 125V | — | | | — | | | | | |
| NK | AC | 690V | 35/35 | | | 50/50 | | | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | 120/80 | | | 180/135 | | | | | |
| | | 240V | 150/150 | | | 200/150 ㉛ | | | | | |
| | DC | 250V | — | | | — | | | | | |
| Weight (◉ marked standard type) kg | | | 7.1 | 9.4 | | 7.1 | 9.4 | | | | |
| ■Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | ◉ | | | | | |
| | With extension bars | | ○ | | | ○ | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㊶ | | | ○ ㊶ | | | | | |
| | Standard (PMC) | | ○ | — | | ○ | — | | | | |
| For distribution boards (PMD) | | | — | | | — | | | | | |
| Flush-mounted (FP) With flat bar studs | | | ○ | | | ○ | | | | | |
| Draw-out type (DR) | | | — | | | — | | | | | |
| TemPlug70 (PG) | | | — | | | — | | | | | |
| DIN rail mount | | | — | | | — | | | | | |
| ■Accessories (optional) | | Symbol | | | | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | | ● | | | | | |
| External operating handle: Breaker-mounted | | H B | ● | | | ● | | | | | |
| Door-mounted (variable depth) | | H P | ● | | | ● | | | | | |
| Toggle extension | | H A | ● | | | ● | | | | | |
| Mechanical interlock: Slide type | | M S | ● | | | ● | | | | | |
| Rear-connected type | | M B | — | | | — | | | | | |
| Link type | | M L | ● | | | ● | | | | | |
| Wire type | | M W | ● | | | ● | | | | | |
| Toggle holder | | H H | ● | | | ● | | | | | |
| Toggle lock | | H L | | | | | | | | | |
| Terminal cover: For front-connected | | C F | ● | | | ● | | | | | |
| For rear-connected and plug-in | | C R | ● | | | ● | | | | | |
| Terminal block for lead | | T F | ● | | | ● | | | | | |
| Door flange | | D F | ● | | | ● | | | | | |
| CE marking | | | Yes | | | Yes | | | | | |
| Overcurrent trip mechanism | | | Electronic ⑯ | | | Electronic ⑯ | | | | | |
| Colour of cover | | | Grey Blue | | | Grey Blue | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | Yes (Red) | | | | | |
| Suitability for isolation | | | Yes | | | Yes | | | | | |
| Reverse connection | | | Yes | | | Yes | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"

⑯ : Optional preferential alarm or ground fault trip function available on request.

㉛ : Also applicable to 415V AC. ㊶ : A safety lock function is provided.

㊽ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves




## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 250A<br>125, 150, 175, 200, 225 | | | | | | |
| | | CT rated current : ($I_{CT}$) = 400A<br>175, 200, 225, 250, 300, 350, 400 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max. ($I_{CT}$)×1300%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% ① | | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| Neutral protection | | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100% or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Note ①: When ($I_{CT}$)=250A, ground fault trip cannot be used.

Note ②: When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$)×50% is set.

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.


## Combinations of Internally Mounted Accessories (Optional)

| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3<br>4 | | | | | | | | | | | |


Toggle — Left pole, Right pole

# Outline dimensions (mm) H400-NE, L400-NE

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions TemBreak PRO

# Moulded Case Circuit Breakers

# S630-CF, S630-NF

## Ratings and Specifications


| Frame size (A) | | | 600 | | 630 | | 600 | | 630 | |
|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | S630-CF | | | | S630-NF | | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | | | | |
| Rated current, A | | | 500 | | 630 | | 500 | | 630 | |
| Calibrated at 40°C | | | 600 | | | | 600 | | | |
| 45°C | | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | 690 | | 690 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | — | | — | | — | |
| Utilization Category | | | A | | A | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 10/10 | | 10/10 | | 20/20 | | 20/20 | |
| IEC 60947-2 | | 500V | 15/15 | | 15/15 | | 30/30 | | 30/30 | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 30/30 | | 30/30 | | 50/50 | | 50/50 | |
| | | 415V | 36/36 | | 36/36 | | 50/50 | | 50/50 | |
| | | 380V | 36/36 | | 36/36 | | 50/50 | | 50/50 | |
| | | 240V | 50/50 | | 50/50 | | 85/85 | | 85/85 | |
| | ① DC | 250V | 50/50 | | 50/50 | | 50/50 | | 50/50 | |
| | | 125V | 50/50 | | 50/50 | | 50/50 | | 50/50 | |
| NK | AC | 690V | 10/10 | | 10/10 | | 20/20 | | 20/20 | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 30/30 | | 30/30 | | 50/50 | | 50/50 | |
| | | 240V | 50/50 | | 50/50 | | 85/85 | | 85/85 | |
| | ① DC | 250V | — | | — | | — | | — | |
| Weight (◉ marked standard type) kg | | | 8.0 | 11.0 | 8.0 | 11.0 | 8.0 | 11.0 | 8.0 | 11.0 |
| ■Connections and Mountings | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | — | | — | |
| | With extension bars | | ◉ | | ◉ | | ◉ | | ◉ | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ⑤1 | | ○ ⑤1 | | ○ ⑤1 | | ○ ⑤1 | |
| | Standard (PMC) | | ○ | — | ○ | — | ○ | — | ○ | — |
| For distribution boards (PMD) | | | — | | — | | — | | — | |
| Flush-mounted (FP) With flat bar studs | | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | ▲ | | ▲ | | ▲ | | ▲ | |
| TemPlug70 (PG) | | | ○ | — | ○ | — | ○ | — | ○ | — |
| DIN rail mount | | | — | | — | | — | | — | |

| ■Accessories (optional) | | | Symbol | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Externally mounted | Motor operator | | M C | ● | | ● | | ● | | ● | |
| | External operating handle | Breaker-mounted | H B | ● | | ● | | ● | | ● | |
| | | Door-mounted (variable depth) | H P | ● | | ● | | ● | | ● | |
| | Toggle extension | | H A | ● | | ● | | ● | | ● | |
| | Mechanical interlock ⑨ | Slide type | M S | ● | | ● | | ● | | ● | |
| | | Rear-connected type | M B | — | | — | | — | | — | |
| | | Link type | M L | ● | | ● | | ● | | ● | |
| | | Wire type | M W | ● | | ● | | ● | | ● | |
| | Toggle holder | | H H | ● | | ● | | ● | | ● | |
| | Toggle lock | | H L | | | | | | | | |
| | Terminal cover | For front-connected | C F | ● | | ● | | ● | | ● | |
| | | For rear-connected and plug-in | C R | ● | | ● | | ● | | ● | |
| | Terminal block for lead | | T F | ● | | ● | | ● | | ● | |
| | Door flange | | D F | ● | | ● | | ● | | ● | |
| CE marking | | | | Yes | | Yes | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | | Yes | | Yes | | Yes | | Yes | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑤1 : A safety lock function is provided.

## Time/Current characteristic curves




## Ambient compensating curves




## Magnetic trip pick-up current

| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) | | | | | |
|---|---|---|---|---|---|---|
| | $I_n$ × 10 | 9 | 8 | 7 | 6 | 5 |
| 500 | 5000 | 4500 | 4000 | 3500 | 3000 | 2500 |
| 600 | 6000 | 5400 | 4800 | 4200 | 3600 | 3000 |
| 630 | 6300 | 5670 | 5040 | 4410 | 3780 | 3150 |


**Note** (1): Setting tolerance: ±20%.

**Remarks:**

(1): Unless otherwise stated when ordering, the selector dial is factory set to position "10".

(2): The trip pick-up current of DC models is not adjustable; the dial position corresponding to the trip pick-up current is marked with a white point.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) S630-CF, S630-NF

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions TemBreak PRO

# Moulded Case Circuit Breakers

# S630-NE

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 630 | | | | | |
| Type | | | S630-NE | | | | | |
| Number of poles | | | 3 | 4 | | | | |
| ■Ratings | | | | | | | | |
| Rated current, A | | | Adjustable | | | | | |
| Calibrated at 40°C | | | $I_{CT}$=630 | | | | | |
| 45°C | | | 250 | 500 | | | | |
| ⑧⓪ | | | 300 | 600 | | | | |
| | | | 350 | 630 | | | | |
| | | | 400 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 10(0.3sec.) | | | | | |
| Utilization Category | | | B | | | | | |
| ■Rated breaking capacity, kA | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 20/20 | | | | | |
| IEC 60947-2 | | 500V | 30/30 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 50/50 | | | | | |
| | | 415V | 50/50 | | | | | |
| | | 380V | 50/50 | | | | | |
| | | 240V | 85/85 | | | | | |
| | DC | 250V | — | | | | | |
| | | 125V | — | | | | | |
| NK | AC | 690V | 20/20 | | | | | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 50/50 | | | | | |
| | | 240V | 85/85 | | | | | |
| | DC | 250V | — | | | | | |
| Weight (◉ marked standard type) kg | | | 8.7 | 11.9 | | | | |
| ■Connections and Mountings | | | | | | | | |
| Front-connected (FC) Terminal screws | | | — | | | | | |
| With extension bars | | | ◉ | | | | | |
| Rear-connected (RC) Flat bar studs | | | ○ | | | | | |
| Plug-in (PM) For switchboards High-performance (PMB) | | | ○ ⑤① | | | | | |
| Standard (PMC) | | | ○ | — | | | | |
| For distribution boards (PMD) | | | — | | | | | |
| Flush-mounted (FP) With flat bar studs | | | ○ | | | | | |
| Draw-out type (DR) | | | ▲ | | | | | |
| TemPlug70 (PG) | | | ○ | — | | | | |
| DIN rail mount | | | — | | | | | |
| ■Accessories (optional) | | | Symbol | | | | | |
| Externally mounted: Motor operator | | | M C | ● | | | | |
| External operating handle: Breaker-mounted | | | H B | ● | | | | |
| Door-mounted (variable depth) | | | H P | ● | | | | |
| Toggle extension | | | H A | ● | | | | |
| Mechanical interlock ⑨: Slide type | | | M S | ● | | | | |
| Rear-connected type | | | M B | — | | | | |
| Link type | | | M L | ● | | | | |
| Wire type | | | M W | ● | | | | |
| Toggle holder | | | H H | ● | | | | |
| Toggle lock | | | H L | | | | | |
| Terminal cover: For front-connected | | | C F | ● | | | | |
| For rear-connected and plug-in | | | C R | ● | | | | |
| Terminal block for lead | | | T F | ● | | | | |
| Door flange | | | D F | ● | | | | |
| CE marking | | | | Yes | | | | |
| Overcurrent trip mechanism | | | | Electronic ⑯ | | | | |
| Colour of cover | | | | Grey Blue | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | | |
| Suitability for isolation | | | | Yes | | | | |
| Reverse connection | | | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

⑯ : Optional preferential alarm or ground fault trip function available on request. ⑤① : A safety lock function is provided.

⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves




## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 630A<br>250, 300, 350, 400, 500, 600, 630 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time −20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max. ($I_{CT}$)×1200%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% | | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time −20ms. | | | | | | |
| Neutral protection | | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100% or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

Note ②: When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$)×50% is set.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3<br>4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) S630-NE

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout B (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions

TemBreak PRO

## Moulded Case Circuit Breakers

## PS630-CF, PS630-NF, PS630-GF

## Ratings and Specifications

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 600 | | 600 | | 600 | | |
| Type | | | | PS630-CF | | PS630-NF | | PS630-GF | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | 3 | 4 | |
| ■Ratings | | | | | | | | | | |
| Rated current, A | | | | 500 | | 500 | | 500 | | |
| Calibrated at 40°C | | | | 600 | | 600 | | 600 | | |
| 45°C | | | | ⑱ | | ⑱ | | ⑱ | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | | 800 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | 8 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | | — | | |
| Utilization Category | | | | A | | A | | A | | |
| ■Rated breaking capacity, kA | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 7/7 | | 12/12 | | 12/12 | | |
| IEC 60947-2 | | | 500V | 25/25 | | 30/30 | | 50/50 | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 30/30 | | 45/45 | | 65/65 | | |
| | | | 415V | 36/36 | | 50/50 | | 70/70 | | |
| | | | 380V | 36/36 | | 50/50 | | 70/70 | | |
| | | | 240V | 50/50 | | 85/85 | | 100/100 | | |
| | | ① DC | 250V | 25/25 ⑰ | | 50/50 ⑰ | | 50/50 ⑰ | | |
| | | | 125V | 40/40 ⑰ | | 50/50 ⑰ | | 50/50 ⑰ | | |
| NK | | AC | 690V | 7/7 | | 12/12 | | 12/12 | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 30/30 | | 45/45 | | 65/65 | | |
| | | | 240V | 50/50 | | 85/85 | | 100/100 | | |
| | | ① DC | 250V | — | | — | | — | | |
| Weight (◉ marked standard type) kg | | | | 5.9 | 7.8 | 5.9 | 7.8 | 5.9 | 7.8 | |
| ■Connections and Mountings | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | | — | | |
| | With extension bars | | | ◉ | | ◉ | | ◉ | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ㊿ | | ○ ㊿ | | ○ ㊿ | | |
| | Standard (PMC) | | | ○ | — | ○ | — | ○ | — | |
| For distribution boards (PMD) | | | | — | | — | | — | | |
| lush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | ○ | | |
| Draw-out type (DR) | | | | ▲ | | ▲ | | ▲ | | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — | ○ | — | |
| DIN rail mount | | | | — | | — | | — | | |
| ■Accessories (optional) | | | Symbol | | | | | | | |
| Externally mounted: Motor operator | | | M C | ● | | ● | | ● | | |
| External operating handle: Breaker-mounted | | | H B | ● | | ● | | ● | | |
| External operating handle: Door-mounted (variable depth) | | | H P | ● | | ● | | ● | | |
| Toggle extension | | | H A | ● | | ● | | ● | | |
| Mechanical interlock ⑨: Slide type | | | M S | ● | | ● | | ● | | |
| Mechanical interlock ⑨: Rear-connected type | | | M B | — | | — | | — | | |
| Mechanical interlock ⑨: Link type | | | M L | ● | | ● | | ● | | |
| Mechanical interlock ⑨: Wire type | | | M W | ● | | ● | | ● | | |
| Toggle holder | | | H H | ● | | ● | | ● | | |
| Toggle lock | | | H L | | | | | | | |
| Terminal cover: For front-connected | | | C F | ● | | ● | | ● | | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | ● | | ● | | |
| Terminal block for lead | | | T F | ● | | ● | | ● | | |
| Door flange | | | D F | ● | | ● | | ● | | |
| CE marking | | | | Yes | | Yes | | Yes | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | |
| Reverse connection | | | | Yes | | Yes | | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".


① : DC is a special specification. When ordering, please specify DC.

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).


⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㊿ : A safety trip function is provided.

⑱ : Plug-in type (PM), draw-out type (DR), and TemPlug70 (PG) are only 500A.

## Time/Current characteristic curves




## Ambient compensating curves




## Magnetic trip pick-up current

| Rated current (A) | $I_n$ × | Magnetic trip pick-up current (adjustable range) (A) 8 | 7 | 6 | 5 | 4 |
|---|---|---|---|---|---|---|
| 500 | | 4000 | 3500 | 3000 | 2500 | 2000 |
| 600 | | 4800 | 4200 | 3600 | 3000 | 2400 |


**Note** (1) : Setting tolerance: ±20%.

**Remarks:**

(1): Unless otherwise stated when ordering, the selector dial is factory set to position "8".

(2): The trip pick-up current of DC models is not adjustable.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS630-CF, PS630-NF, PS630-GF


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted



# Moulded Case Circuit Breakers

# PS630-NE, PS630-GE




## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | | 630 | | 630 |
| Type | | | | PS630-NE | | PS630-GE |
| Number of poles | | | | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | |
| Rated current, A | | | | Adjustable | | Adjustable |
| Calibrated at 40°C | | | | $I_n$=630 | | $I_n$=630 |
| | | | | 250 | 500 | 250 | 500 |
| 45°C | | | | 300 | 600 | 300 | 600 |
| ⑧⓪ | | | | 350 | 630 | 350 | 630 |
| | | | | 400 | | 400 | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | — | |
| Utilization Category | | | | A | | A | |
| ■Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | | 12/12 | | 12/12 | |
| IEC 60947-2 | | 500V | | 30/30 | | 50/50 | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | | 45/45 | | 65/65 | |
| | | 415V | | 50/50 | | 70/70 | |
| | | 380V | | 50/50 | | 70/70 | |
| | | 240V | | 85/85 | | 100/100 | |
| | DC | 250V | | — | | — | |
| | | 125V | | — | | — | |
| NK | AC | 690V | | — | | — | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | | — | | — | |
| | | 240V | | — | | — | |
| | DC | 250V | | — | | — | |
| Weight (◉ marked standard type) kg | | | | 6.0 | 8.0 | 6.0 | 8.0 |
| ■Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | |
| | With extension bars | | | ◉ | | ◉ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | |
| | Standard (PMC) | | | — | | — | |
| For distribution boards (PMD) | | | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | |
| Draw-out type (DR) | | | | — | | — | |
| TemPlug70 (PG) | | | | — | | — | |
| DIN rail mount | | | | — | | — | |
| ■Accessories (optional) | | | Symbol | | | | |
| Externally mounted: Motor operator | | | M C | ● | | ● | |
| External operating handle: Breaker-mounted | | | H B | ● | | ● | |
| Door-mounted (variable depth) | | | H P | ● | | ● | |
| Toggle extension | | | H A | ● | | ● | |
| Mechanical interlock: Slide type | | | M S | ● | | ● | |
| Rear-connected type | | | M B | — | | — | |
| Link type | | | M L | ● | | ● | |
| Wire type | | | M W | ● | | ● | |
| Toggle holder | | | H H | ● | | ● | |
| Toggle lock | | | H L | | | | |
| Terminal cover: For front-connected | | | C F | ● | | ● | |
| For rear-connected and plug-in | | | C R | ● | | ● | |
| Terminal block for lead | | | T F | ● | | ● | |
| Door flange | | | D F | ● | | ● | |
| CE marking | | | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Electronic | | Electronic | |
| Colour of cover | | | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | |
| Reverse connection | | | | Yes | | Yes | |


**Notes:**
◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
⑤⓪ : A safety trip function is provided.
⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves

• Long time/Short time trip characteristics




• Instantaneous trip characteristics




Note: See page 6-4 for Neutral protection, ground fault trip and preferential trip alarm characteristics.


## Overcurrent tripping characteristics

TPOP OCR (LSIG) ($I_n$)=630A

| | |
|---|---|
| Rated current settings (A) ($I_r$) = ($I_r1$)×($I_r2$) | ($I_r1$) (A)=250, 300, 350, 400, 500, 600, 630 adjustable |
| | ($I_r2$)=0.91, 0.92, 0.93, 0.94, 0.95, 0.96, 0.97, 0.98, 0.99, 1.00 adjustable |
| Long time-delay time settings (s) : ($t_r$) | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable at ($I_r$)×600% |
| | Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF |
| | Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | 50, 100, 200, 300, 400 adjustable |
| | Ramp characteristics I²t: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more |
| | When ($t_{sd}$)=50ms Time-delay setting tolerance –30ms or more +30ms or less<br>When ($t_{sd}$)=100ms to 400ms Time-delay setting tolerance –20ms or more +50ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | ($I_n$)×3, 4, 5, 6, 7, 8, 9, 10, 11 adjustable |
| | Current setting tolerance within ±15% |
| Neutral protection pick-up current (A) : ($I_N$) | For 3P OFF fixed |
| | For 4P ($I_r$)×50%, 100% or OFF |
| Neutral protection time settings (s) : ($t_N$) | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip |
| Ground fault trip pick-up current (A) : ($I_g$) | 3P for 3ø3W, 4P for 3ø4W (3P 3ø4W not supported) or OFF<br>($I_n$)×20% Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | 200<br>Time-delay setting tolerance –20ms or more +50ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | ($I_r$)×80%<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | ($t_r$)×50%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |

**Notes:**
1: If not otherwise specified, the product will be delivered with the underlined standard setting values.
2: The TPOT type OCR (LSI) only has long time-delay trip, short time-delay trip, instantaneous trip, and preferential trip alarm.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS630-NE, PS630-GE


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Moulded Case Circuit Breakers

## PH630-CF


## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 600 | | | | | | | |
| Type | | | | PH630-CF | | | | | | | |
| Number of poles | | | | 3 | 4 | | | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | | 500 | | | | | | | |
| Calibrated at 40°C | | | | 600 | | | | | | | |
| 45°C | | | | ㉘ | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | | | | | | | |
| Utilization Category | | | | A | | | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 12/12 | | | | | | | |
| IEC 60947-2 | | | 500V | 65/65 | | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 100/100 | | | | | | | |
| | | | 415V | 110/110 | | | | | | | |
| | | | 380V | 110/110 | | | | | | | |
| | | | 240V | 125/125 | | | | | | | |
| | | ① DC | 250V | 50/50 ⑰ | | | | | | | |
| | | | 125V | 50/50 ⑰ | | | | | | | |
| NK | | AC | 690V | 12/12 | | | | | | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | 100/100 | | | | | | | |
| | | | 240V | 125/125 | | | | | | | |
| | | ① DC | 250V | — | | | | | | | |
| Weight (◉ marked standard type) kg | | | | 5.9 | 7.8 | | | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | | | | | | |
| | With extension bars | | | ◉ | | | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | | | | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | ○ ㊿ | | | | | | | |
| | | Standard (PMC) | | ○ | — | | | | | | |
| | For distribution boards (PMD) | | | — | | | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | | | | | | |
| Draw-out type (DR) | | | | ▲ | | | | | | | |
| TemPlug70 (PG) | | | | ▲ ㉛ | — | | | | | | |
| DIN rail mount | | | | — | | | | | | | |
| ■ Accessories (optional) | | | | Symbol | | | | | | | |
| Externally mounted: Motor operator | | | | M C | ● | | | | | | |
| External operating handle | Breaker-mounted | | | H B | ● | | | | | | |
| | Door-mounted (variable depth) | | | H P | ● | | | | | | |
| Toggle extension | | | | H A | ● | | | | | | |
| Mechanical interlock ⑨ | Slide type | | | M S | ● | | | | | | |
| | Rear-connected type | | | M B | — | | | | | | |
| | Link type | | | M L | ● | | | | | | |
| | Wire type | | | M W | ● | | | | | | |
| Toggle holder | | | | H H | ● | | | | | | |
| Toggle lock | | | | H L | | | | | | | |
| Terminal cover | For front-connected | | | C F | ● | | | | | | |
| | For rear-connected and plug-in | | | C R | ● | | | | | | |
| Terminal block for lead | | | | T F | ● | | | | | | |
| Door flange | | | | D F | ● | | | | | | |
| CE marking | | | | Yes | | | | | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic (adjustable) | | | | | | | |
| Colour of cover | | | | Grey Blue | | | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | | | | | | |
| Suitability for isolation | | | | Yes | | | | | | | |
| Reverse connection | | | | Yes | | | | | | | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.
⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑰ : See page 4-7 for the instantaneous trip value when using with DC. ㊿ : A safety trip function is provided.
㉘ : Plug-in type (PM), draw-out type (DR), and TemPlug70 (PG) are only 500A.
㉛ : They cannot be applied to circuits with a short circuit breaking current exceeding 85kA.

## Time/Current characteristic curves




## Ambient compensating curves




## Magnetic trip pick-up current

| Rated current (A) | $I_n$ × | Magnetic trip pick-up current (adjustable range) (A) | | | | |
|---|---|---|---|---|---|---|
| | | 8 | 7 | 6 | 5 | 4 |
| 500 | | 4000 | 3500 | 3000 | 2500 | 2000 |
| 600 | | 4800 | 4200 | 3600 | 3000 | 2400 |

**Note** (1) : Setting tolerance: ±20%.
**Remarks:**
(1): Unless otherwise stated when ordering, the selector dial is factory set to position "8".
(2): The trip pick-up current of DC models is not adjustable.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3, 4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PH630-CF


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted



# Moulded Case Circuit Breakers

# PH630-CE



## Ratings and Specifications

| | | | | | |
|---|---|---|---|---|---|
| Frame size (A) | | | | 630 | |
| Type | | | | PH630-CE | |
| Number of poles | | | | 3 | 4 |
| ■Ratings | | | | | |
| Rated current, A | | | | Adjustable | |
| Calibrated at 40°C | | | | $I_n$=630 | |
| 45°C | | | | 250 | 500 |
| ⑧⓪ | | | | 300 | 600 |
| | | | | 350 | 630 |
| | | | | 400 | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | — | |
| Utilization Category | | | | A | |
| ■Rated breaking capacity, kA | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 12/12 | |
| IEC 60947-2 | | | 500V | 65/65 | |
| $I_{cu}$/$I_{cs}$(sym) | | | 440V | 100/100 | |
| | | | 415V | 110/110 | |
| | | | 380V | 110/110 | |
| | | | 240V | 125/125 | |
| | | DC | 250V | — | |
| | | | 125V | — | |
| NK | | AC | 690V | — | |
| $I_{cu}$/$I_{cs}$(sym) | | | 450V | — | |
| | | | 240V | — | |
| | | DC | 250V | — | |
| Weight (◉ marked standard type) kg | | | | 6.0 | 8.0 |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) | Terminal screws | | | — | |
| | With extension bars | | | ◉ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | |
| | | Standard (PMC) | | — | |
| | For distribution boards (PMD) | | | — | |
| ush-mounted (FP) | With flat bar studs | | | ○ | |
| Draw-out type (DR) | | | | — | |
| TemPlug70 (PG) | | | | — | |
| DIN rail mount | | | | — | |
| ■Accessories (optional) | | | Symbol | | |
| Externally mounted: Motor operator | | | M C | ● | |
| External operating handle: Breaker-mounted | | | H B | ● | |
| Door-mounted (variable depth) | | | H P | ● | |
| Toggle extension | | | H A | ● | |
| Mechanical interlock: Slide type | | | M S | ● | |
| Rear-connected type | | | M B | — | |
| Link type | | | M L | ● | |
| Wire type | | | M W | ● | |
| Toggle holder | | | H H | ● | |
| Toggle lock | | | H L | | |
| Terminal cover: For front-connected | | | C F | ● | |
| For rear-connected and plug-in | | | C R | ● | |
| Terminal block for lead | | | T F | ● | |
| Door flange | | | D F | ● | |
| CE marking | | | | Yes | |
| Overcurrent trip mechanism | | | | Electronic | |
| Colour of cover | | | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | |
| Suitability for isolation | | | | Yes | |
| Reverse connection | | | | Yes | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

⑤⓪ : A safety trip function is provided.


⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves

• Long time/Short time trip characteristics




• Instantaneous trip characteristics




Note: See page 6-4 for Neutral protection, ground fault trip and preferential trip alarm characteristics.

## Overcurrent tripping characteristics

TPOP OCR (LSIG) ($I_n$)=630A

| | |
|---|---|
| Rated current settings (A) ($I_r$) = ($I_r1$)×($I_r2$) | ($I_r1$) (A)=250, 300, 350, 400, 500, 600, 630 adjustable |
| | ($I_r2$)=0.91, 0.92, 0.93, 0.94, 0.95, 0.96, 0.97, 0.98, 0.99, 1.00 adjustable |
| Long time-delay time settings (s) : ($t_r$) | 0.5, 1.5, 2.5, 5, 7.5, 9, 10, 12, 14, 16 adjustable at ($I_r$)×600% |
| | Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)×1.5, 2, 3, 4, 5, 6, 7, 8, 10 or OFF |
| | Current setting tolerance within ±10% |
| Short time-delay time settings (ms) : ($t_{sd}$) | 50, 100, 200, 300, 400 adjustable |
| | Ramp characteristics I²t: ON or OFF<br>However, definite time-delay characteristics with ($I_r$)×10 or more |
| | When ($t_{sd}$)=50ms Time-delay setting tolerance –30ms or more +30ms or less<br>When ($t_{sd}$)=100ms to 400ms Time-delay setting tolerance –20ms or more +50ms or less |
| Instantaneous trip pick-up current (A) : ($I_i$) | ($I_n$)×3, 4, 5, 6, 7, 8, 9, 10, 11 adjustable |
| | Current setting tolerance within ±15% |
| Neutral protection pick-up current (A) : ($I_N$) | For 3P OFF fixed |
| | For 4P ($I_r$)×50%, 100% or OFF |
| Neutral protection time settings (s) : ($t_N$) | Operates with long time-delay time setting ($t_r$) and short time-delay time setting ($t_{sd}$) and also operates with instantaneous trip |
| Ground fault trip pick-up current (A) : ($I_g$) | 3P for 3ø3W, 4P for 3ø4W (3P 3ø4W not supported) or OFF<br>($I_n$)×20% Current setting tolerance within ±10% |
| Ground fault trip time settings (ms) : ($t_g$) | 200<br>Time-delay setting tolerance –20ms or more +50ms or less |
| Preferential trip alarm pick-up current (A) : ($I_p$) | ($I_r$)×80%<br>Current setting tolerance within ±10% |
| Preferential trip alarm time settings (s) : ($t_p$) | ($t_r$)×50%<br>Time-delay setting tolerance –20% –20ms or more +0% +30ms or less |

**Notes:**

1: If not otherwise specified, the product will be delivered with the underlined standard setting values.

2: The TPOT type OCR (LSI) only has long time-delay trip, short time-delay trip, instantaneous trip, and preferential trip alarm.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3<br>4 | | | | | | | | | | | |

Toggle — Left pole / Right pole

Note: For auxiliary switches or alarm switches, left-hand mounting has priority.


# Outline dimensions (mm) PH630-CE

## Front-connected





## Rear-connected

Detail of connecting part (Bottom view)




Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout A (front view) Panel cutout B (front view)



Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted

Detail of connecting part (Bottom view) Drilling plan (front view)







# Moulded Case Circuit Breakers

# H630-NE, L630-NE

## Ratings and Specifications

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 630 | | 630 | | | | |
| Type | | | H630-NE | | L630-NE | | | | |
| Number of poles | | | 3 | 4 | 3 | 4 | | | |
| ■Ratings | | | | | | | | | |
| Rated current, A | | | Adjustable | | Adjustable | | | | |
| Calibrated at 40°C | | | $I_{CT}$=630 | | $I_{CT}$=630 | | | | |
| 45°C | | | 250 500 | | 250 500 | | | | |
| ⑧⓪ | | | 300 600 | | 300 600 | | | | |
| | | | 350 630 | | 350 630 | | | | |
| | | | 400 | | 400 | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 10 (0.3sec.) | | 10 (0.3sec.) | | | | |
| Utilization Category | | | B | | B | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 25/20 | | 25/20 | | | | |
| IEC 60947-2 | | 500V | 45/34 | | 45/34 | | | | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 125/94 | | 180/135 | | | | |
| | | 415V | 125/94 | | 200/150 | | | | |
| | | 380V | 125/94 | | 200/150 | | | | |
| | | 240V | 150/150 | | 200/150 | | | | |
| | DC | 250V | — | | — | | | | |
| | | 125V | — | | — | | | | |
| NK | AC | 690V | 25/20 | | 25/20 | | | | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 125/94 | | 180/135 | | | | |
| | | 240V | 150/150 | | 200/150 | | | | |
| | DC | 250V | — | | — | | | | |
| Weight (◉ marked standard type) kg | | | 13.5 | 19.6 | 13.5 | 19.6 | | | |
| ■Connections and Mountings | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | | | |
| | With extension bars | | ◉ | | ◉ | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ⑤① | | ○ ⑤① | | | | |
| | Standard (PMC) | | ○ | — | ○ | — | | | |
| For distribution boards (PMD) | | | — | | — | | | | |
| Flush-mounted (FP) With flat bar studs | | | ○ | | ○ | | | | |
| Draw-out type (DR) | | | — | | — | | | | |
| TemPlug70 (PG) | | | — | | — | | | | |
| DIN rail mount | | | — | | — | | | | |
| ■Accessories (optional) | | Symbol | | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | ● | | | | |
| External operating handle: Breaker-mounted | | H B | ● | | ● | | | | |
| Door-mounted (variable depth) | | H P | ● | | ● | | | | |
| Toggle extension | | H A | ● | | ● | | | | |
| Mechanical interlock: Slide type | | M S | ● | | ● | | | | |
| Rear-connected type | | M B | — | | — | | | | |
| Link type | | M L | ● | | ● | | | | |
| Wire type | | MW | ● | | ● | | | | |
| Toggle holder | | H H | ● | | ● | | | | |
| Toggle lock | | H L | | | | | | | |
| Terminal cover: For front-connected | | C F | ● | | ● | | | | |
| For rear-connected and plug-in | | C R | ● | | ● | | | | |
| Terminal block for lead | | T F | ● | | ● | | | | |
| Door flange | | D F | ● | | ● | | | | |
| CE marking | | | Yes | | Yes | | | | |
| Overcurrent trip mechanism | | | Electronic ⑯ | | Electronic ⑯ | | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | | | |
| Suitability for isolation | | | Yes | | Yes | | | | |
| Reverse connection | | | Yes | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

⑯ : Optional preferential alarm or ground fault trip function available on request.

⑤① : A safety lock function is provided.

⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves





## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 630A<br>250, 300, 350, 400, 500, 600, 630 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max. ($I_{CT}$)×1200%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% | | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| Neutral protection | | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100% or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

Note ②: When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$)×50% is set.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) H630-NE, L630-NE

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions TemBreak PRO

## Moulded Case Circuit Breakers

## S800-CF, S800-NF, S800-RF, S800-PF

## Ratings and Specifications

| | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 800 | | 800 | | 800 | | 800 | | | |
| Type | | | S800-CF | | S800-NF | | S800-RF | | S800-PF | | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | | |
| ■Ratings | | | | | | | | | | | | |
| Rated current, A | | | 700 | | 700 | | 700 | | 700 | | | |
| Calibrated at 40°C | | | 800 | | 800 | | 800 | | 800 | | | |
| 45°C | | | | | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | 690 | | 690 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | — | | — | | — | | | |
| Utilization Category | | | A | | A | | A | | A | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 10/10 | | 20/20 | | 25/20 | | 25/20 | | | |
| IEC 60947-2 | | 500V | 15/15 | | 30/30 | | 45/34 | | 45/34 | | | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 30/30 | | 50/50 | | 65/50 | | 85/50 | | | |
| | | 415V | 36/36 | | 50/50 | | 70/50 | | 100/50 | | | |
| | | 380V | 36/36 | | 50/50 | | 70/50 | | 100/50 | | | |
| | | 240V | 50/50 | | 85/85 | | 100/75 | | 125/125 | | | |
| | ① DC | 250V | 50/50 | | 50/50 | | 50/50 | | 50/50 | | | |
| | | 125V | 50/50 | | 50/50 | | 50/50 | | 50/50 | | | |
| NK | AC | 690V | 10/10 | | 20/20 | | — | | 25/20 | | | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 30/30 | | 50/50 | | — | | 85/50 | | | |
| | | 240V | 50/50 | | 85/85 | | — | | 125/125 | | | |
| | ① DC | 250V | — | | — | | — | | — | | | |
| Weight (◉ marked standard type) kg | | | 8.5 | 11.5 | 8.5 | 11.5 | 8.5 | 11.5 | 8.5 | 11.5 | | |
| ■Connections and Mountings | | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | — | | — | | | |
| | With extension bars | | ◉ | | ◉ | | ◉ | | ◉ | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ⑤1 | | ○ ⑤1 | | ○ ⑤1 | | ○ ⑤1 | | | |
| | Standard (PMC) | | ○ | — | ○ | — | ○ | — | ○ | — | | |
| For distribution boards | (PMC) | | — | | — | | — | | — | | | |
| | (PMD) | | — | | — | | — | | — | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | ○ | | | |
| Draw-out type (DR) | | | ▲ | | ▲ | | ▲ | | ▲ | | | |
| TemPlug70 (PG) | | | — | | — | | — | | — | | | |
| DIN rail mount | | | — | | — | | — | | — | | | |
| ■Accessories (optional) | | | | | | | | | | | Symbol | |
| Externally mounted: Motor operator | | | ● | | ● | | ● | | ● | | M C | |
| External operating handle | Breaker-mounted | | ● | | ● | | ● | | ● | | H B | |
| | Door-mounted (variable depth) | | ● | | ● | | ● | | ● | | H P | |
| Toggle extension | | | ● | | ● | | ● | | ● | | H A | |
| Mechanical interlock ⑨ | Slide type | | ● | | ● | | ● | | ● | | M S | |
| | Rear-connected type | | — | | — | | — | | — | | M B | |
| | Link type | | ● | | ● | | ● | | ● | | M L | |
| | Wire type | | ● | | ● | | ● | | ● | | M W | |
| Toggle holder | | | ● | | ● | | ● | | ● | | H H | |
| Toggle lock | | | | | | | | | | | H L | |
| Terminal cover | For front-connected | | ● | | ● | | ● | | ● | | C F | |
| | For rear-connected and plug-in | | ● | | ● | | ● | | ● | | C R | |
| Terminal block for lead | | | ● | | ● | | ● | | ● | | T F | |
| Door flange | | | ● | | ● | | ● | | ● | | D F | |
| CE marking | | | Yes | | Yes | | Yes | | Yes | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | | |
| Reverse connection | | | Yes | | Yes | | Yes | | Yes | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

① : DC is a special specification. When ordering, please specify DC.


⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

⑤1 : A safety lock function is provided.

## Time/Current characteristic curves




## Ambient compensating curves




## Magnetic trip pick-up current

| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) | | | | | |
|---|---|---|---|---|---|---|
| | $I_n$ × 10 | 9 | 8 | 7 | 6 | 5 |
| 700 | 7000 | 6300 | 5600 | 4900 | 4200 | 3500 |
| 800 | 8000 | 7200 | 6400 | 5600 | 4800 | 4000 |


**Note** (1) : Setting tolerance: ±20%.

**Remarks:**

(1): Unless otherwise stated when ordering, the selector dial is factory set to position "10".

(2): The trip pick-up current of DC models is not adjustable; the dial position corresponding to the trip pick-up current is marked with a white point.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) S800-CF, S800-NF, S800-RF, S800-PF

## Front-connected




## Rear-connected




Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)





Panel cutout B (front view)






Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in(Standard)


Detail of connecting part








Mounting base(rear view)






Drilling plan (front view)





## Plug-in(High-performance)


Detail of connecting part / Preparation of conductor









Mounting base (rear view)





Drilling plan (front view)





## Flush-mounted




Drilling plan (front view)




Note: Studs are factory installed in horizontal direction both on the line and load sides.





# Moulded Case Circuit Breakers

# S800-NE, S800-RE, S800-PE

## Ratings and Specifications

| | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 800 | | 800 | | 800 | | | |
| Type | | | S800-NE | | S800-RE | | S800-PE | | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | | |
| ■Ratings | | | | | | | | | | |
| Rated current, A | | | Adjustable | | Adjustable | | Adjustable | | | |
| Calibrated at 40°C | | | $I_{CT}$=800 | | $I_{CT}$=800 | | $I_{CT}$=800 | | | |
| 45°C | | | 350 | 600 | 350 | 600 | 350 | 600 | | |
| ⑧⓪ | | | 400 | 700 | 400 | 700 | 400 | 700 | | |
| | | | 450 | 800 | 450 | 800 | 450 | 800 | | |
| | | | 500 | | 500 | | 500 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | 690 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 10(0.3sec.) | | 10(0.3sec.) | | 10(0.3sec.) | | | |
| Utilization Category | | | B | | B | | B | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 20/20 | | 25/20 | | 25/20 | | | |
| IEC 60947-2 | | 500V | 30/30 | | 45/34 | | 45/34 | | | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 50/50 | | 65/50 | | 85/50 | | | |
| | | 415V | 50/50 | | 70/50 | | 100/50 | | | |
| | | 380V | 50/50 | | 70/50 | | 100/50 | | | |
| | | 240V | 85/85 | | 100/75 | | 125/125 | | | |
| | DC | 250V | — | | — | | — | | | |
| | | 125V | — | | — | | — | | | |
| NK | AC | 690V | 20/20 | | — | | 25/20 | | | |
| $I_{cu}/I_{cs}$(sym) | | 450V | 50/50 | | — | | 85/50 | | | |
| | | 240V | 85/85 | | — | | 125/125 | | | |
| | DC | 250V | — | | — | | — | | | |
| Weight (◉ marked standard type) kg | | | 9.1 | 12.3 | 9.1 | 12.3 | 9.1 | 12.3 | | |
| ■Connections and Mountings | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | — | | | |
| | With extension bars | | ◉ | | ◉ | | ◉ | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ⑤① | | ○ ⑤① | | ○ ⑤① | | | |
| | Standard (PMC) | | ○ | — | ○ | — | ○ | — | | |
| For distribution boards (PMD) | | | — | | — | | — | | | |
| Flush-mounted (FP) With flat bar studs | | | ○ | | ○ | | ○ | | | |
| Draw-out type (DR) | | | ▲ | | ▲ | | ▲ | | | |
| TemPlug70 (PG) | | | — | | — | | — | | | |
| DIN rail mount | | | — | | — | | — | | | |
| ■Accessories (optional) | | Symbol | | | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | ● | | ● | | | |
| External operating handle: Breaker-mounted | | H B | ● | | ● | | ● | | | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | | ● | | ● | | | |
| Toggle extension | | H A | ● | | ● | | ● | | | |
| Mechanical interlock ⑨: Slide type | | M S | ● | | ● | | ● | | | |
| Mechanical interlock ⑨: Rear-connected type | | M B | — | | — | | — | | | |
| Mechanical interlock ⑨: Link type | | M L | ● | | ● | | ● | | | |
| Mechanical interlock ⑨: Wire type | | M W | ● | | ● | | ● | | | |
| Toggle holder | | H H | ● | | ● | | ● | | | |
| Toggle lock | | H L | | | | | | | | |
| Terminal cover: For front-connected | | C F | ● | | ● | | ● | | | |
| Terminal cover: For rear-connected and plug-in | | C R | ● | | ● | | ● | | | |
| Terminal block for lead | | T F | ● | | ● | | ● | | | |
| Door flange | | D F | ● | | ● | | ● | | | |
| CE marking | | | Yes | | Yes | | Yes | | | |
| Overcurrent trip mechanism | | | Electronic ⑯ | | Electronic ⑯ | | Electronic ⑯ | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | | |
| Reverse connection | | | Yes | | Yes | | Yes | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

⑯ : Optional preferential alarm or ground fault trip function available on request. ⑤① : A safety lock function is provided.

⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves




## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 800A<br>350, 400, 450, 500, 600, 700, 800 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max. ($I_{CT}$)×1200%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% | | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| Neutral protection | | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100% or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

Note ②: When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$)×50% is set.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3<br>4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) S800-NE, S800-RE, S800-PE

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout B (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)


Detail of connecting part






Mounting base (rear view)



Drilling plan (front view)











## Plug-in (High-performance)


Detail of connecting part / Preparation of conductor





Mounting base (rear view)




Drilling plan (front view)








## Flush-mounted

Drilling plan (front view)






Note: Studs are factory installed in horizontal direction both on the line and load sides.





# Moulded Case Circuit Breakers

# H800-NE, L800-NE

## Ratings and Specifications

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 800 | | 800 | | | |
| Type | | | | H800-NE | | L800-NE | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | |
| ■Ratings | | | | | | | | | |
| Rated current, A | | | | Adjustable | | Adjustable | | | |
| Calibrated at 40°C | | | | $I_{CT}$=800 | | $I_{CT}$=800 | | | |
| 45°C | | | | 350 | 600 | 350 | 600 | | |
| ⑧⓪ | | | | 400 | 700 | 400 | 700 | | |
| | | | | 450 | 800 | 450 | 800 | | |
| | | | | 500 | | 500 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | 10 (0.3sec.) | | 10 (0.3sec.) | | | |
| Utilization Category | | | | B | | B | | | |
| ■Rated breaking capacity, kA | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | | 25/20 | | 25/20 | | | |
| IEC 60947-2 | | 500V | | 45/34 | | 45/34 | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | | 125/94 | | 180/135 | | | |
| | | 415V | | 125/94 | | 200/150 | | | |
| | | 380V | | 125/94 | | 200/150 | | | |
| | | 240V | | 150/150 | | 200/150 | | | |
| | DC | 250V | | — | | — | | | |
| | | 125V | | — | | — | | | |
| NK | AC | 690V | | 25/20 | | 25/20 | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | | 125/94 | | 180/135 | | | |
| | | 240V | | 150/150 | | 200/150 | | | |
| | DC | 250V | | — | | — | | | |
| Weight (◉ marked standard type) kg | | | | 14.3 | 20.3 | 14.3 | 20.3 | | |
| ■Connections and Mountings | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | | | |
| | With extension bars | | | ◉ | | ◉ | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | ○ ⑤① | | ○ ⑤① | | | |
| | Standard (PMC) | | | ○ | — | ○ | — | | |
| For distribution boards (PMD) | | | | — | | — | | | |
| Flush-mounted (FP) With flat bar studs | | | | ○ | | ○ | | | |
| Draw-out type (DR) | | | | — | | — | | | |
| TemPlug70 (PG) | | | | — | | — | | | |
| DIN rail mount | | | | — | | — | | | |
| ■Accessories (optional) | | | Symbol | | | | | | |
| Externally mounted: Motor operator | | | M C | ● | | ● | | | |
| External operating handle: Breaker-mounted | | | H B | ● | | ● | | | |
| Door-mounted (variable depth) | | | H P | ● | | ● | | | |
| Toggle extension | | | H A | ● | | ● | | | |
| Mechanical interlock: Slide type | | | M S | ● | | ● | | | |
| Rear-connected type | | | M B | — | | — | | | |
| Link type | | | M L | ● | | ● | | | |
| Wire type | | | M W | ● | | ● | | | |
| Toggle holder | | | H H | ● | | ● | | | |
| Toggle lock | | | H L | | | | | | |
| Terminal cover: For front-connected | | | C F | ● | | ● | | | |
| For rear-connected and plug-in | | | C R | ● | | ● | | | |
| Terminal block for lead | | | T F | ● | | ● | | | |
| Door flange | | | D F | ● | | ● | | | |
| CE marking | | | | Yes | | Yes | | | |
| Overcurrent trip mechanism | | | | Electronic ⑯ | | Electronic ⑯ | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | | Yes | | Yes | | | |
| Reverse connection | | | | Yes | | Yes | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

⑯ : Optional preferential alarm or ground fault trip function available on request.

⑤① : A safety lock function is provided.

⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves





## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 800A<br>350, 400, 450, 500, 600, 700, 800 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max. ($I_{CT}$)×1200%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% | | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| Neutral protection | | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100% or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

Note ②: When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$)×50% is set.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) H800-NE, L800-NE


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions

TemBreak PRO

## Moulded Case Circuit Breakers

## S1000-CE

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 1000 | | | | | | | | |
| Type | | | S1000-CE | | | | | | | | |
| Number of poles | | | 3 | 4 | | | | | | | |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | Adjustable | | | | | | | | |
| Calibrated at 40°C | | | $I_{CT}$=1000 | | | | | | | | |
| 45°C | | | 400 | 800 | | | | | | | |
| ⑧⓪ | | | 500 | 900 | | | | | | | |
| | | | 600 | 1000 | | | | | | | |
| | | | 700 | | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | | | | | | | |
| Utilization Category | | | A | | | | | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 25/19 | | | | | | | | |
| IEC 60947-2 | | 500V | 45/34 | | | | | | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | 65/50 | | | | | | | | |
| | | 415V | 65/50 | | | | | | | | |
| | | 380V | 85/50 | | | | | | | | |
| | | 240V | 100/75 | | | | | | | | |
| | DC | 250V | — | | | | | | | | |
| | | 125V | — | | | | | | | | |
| NK | AC | 690V | — | | | | | | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | — | | | | | | | | |
| | | 240V | — | | | | | | | | |
| | DC | 250V | — | | | | | | | | |
| Weight (◉ marked standard type) kg | | | 11.0 | 14.8 | | | | | | | |
| ■Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) Terminal screws | | | — | | | | | | | | |
| With extension bars | | | ◉ | | | | | | | | |
| Rear-connected (RC) Flat bar studs | | | ○ | | | | | | | | |
| Plug-in (PM) For switchboards High-performance (PMB) | | | — | | | | | | | | |
| Standard (PMC) | | | — | | | | | | | | |
| For distribution boards (PMD) | | | — | | | | | | | | |
| lush-mounted (FP) With flat bar studs | | | ○ | | | | | | | | |
| Draw-out type (DR) | | | — | | | | | | | | |
| TemPlug70 (PG) | | | — | | | | | | | | |
| DIN rail mount | | | — | | | | | | | | |
| ■Accessories (optional) | | | | | Symbol | | | | | | |
| Externally mounted: Motor operator | | | ● | | M C | | | | | | |
| External operating handle: Breaker-mounted | | | ● | | H B | | | | | | |
| Door-mounted (variable depth) | | | ● | | H P | | | | | | |
| Toggle extension | | | ● | | H A | | | | | | |
| Mechanical interlock: Slide type | | | ● | | M S | | | | | | |
| Rear-connected type | | | — | | M B | | | | | | |
| Link type | | | ● | | M L | | | | | | |
| Wire type | | | ● | | M W | | | | | | |
| Toggle holder | | | ● | | H H | | | | | | |
| Toggle lock | | | | | H L | | | | | | |
| Terminal cover: For front-connected | | | ● | | C F | | | | | | |
| For rear-connected and plug-in | | | ● | | C R | | | | | | |
| Terminal block for lead | | | ● | | T F | | | | | | |
| Door flange | | | ● | | D F | | | | | | |
| CE marking | | | Yes | | | | | | | | |
| Overcurrent trip mechanism | | | Electronic ⑯ | | | | | | | | |
| Colour of cover | | | Grey Blue | | | | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | | | | | |
| Suitability for isolation | | | Yes | | | | | | | | |
| Reverse connection | | | Yes | | | | | | | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

⑯ : Optional preferential alarm or ground fault trip function available on request.

⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves





## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 |
|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 1000A<br>400, 500, 600, 700, 800, 900,1000 | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 16 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | |
| | | Setting tolerance ±20% | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 8 | 8 | 8 |
| | | Setting tolerance ±15% | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max. ($I_{CT}$)×1000%<br>Setting tolerance ±20% | | | | | |
| Option: Preferential trip alarm | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | |
| Ground falut trip | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | |
| Neutral protection | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100% or 50% selectable ② | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

Note ②: When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$)×50% is set.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

## Outline dimensions (mm) S1000-CE


### Front-connected




### Rear-connected





Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Flush-mounted







# Moulded Case Circuit Breakers

# S1250-NE, S1250-GE

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 1250 | | 1250 | | | | | |
| Type | | | | S1250-NE | | S1250-GE | | | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | | | |
| ■Ratings | | | | | | | | | | | |
| Rated current, A | | | | Adjustable | | Adjustable | | | | | |
| Calibrated at 40°C | | | | $I_{CT}$=1250 | | $I_{CT}$=1250 | | | | | |
| | | | | 500 1000 | | 500 1000 | | | | | |
| | | | | 600 1200 | | 600 1200 | | | | | |
| | | | | 700 1250 | | 700 1250 | | | | | |
| | | | | 800 | | 800 | | | | | |
| 45°C | | | | ⑧⓪ | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | 15(0.3sec.) | | 15(0.3sec.) | | | | | |
| Utilization Category | | | | B | | B | | | | | |
| ■Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 25/20 | | 45/34 | | | | | |
| IEC 60947-2 | | | 500V | 45/34 | | 65/50 | | | | | |
| $I_{cu}$/$I_{cs}$(sym) | | | 440V | 65/50 | | 85/65 | | | | | |
| | | | 415V | 70/50 | | 85/65 | | | | | |
| | | | 380V | 85/65 | | 100/75 | | | | | |
| | | | 240V | 100/75 | | 125/94 | | | | | |
| | | DC | 250V | — | | — | | | | | |
| | | | 125V | — | | — | | | | | |
| NK | | AC | 690V | 25/20 | | 45/34 | | | | | |
| $I_{cu}$/$I_{cs}$(sym) | | | 450V | 65/50 | | 85/65 | | | | | |
| | | | 240V | 100/75 | | 125/94 | | | | | |
| | | DC | 250V | — | | — | | | | | |
| Weight (◉ marked standard type) kg | | | | 19.8 | 25.0 | 19.8 | 25.0 | | | | |
| ■Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | | | | | |
| | With extension bars | | | ◉ | | ◉ | | | | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | | | | | |
| | Standard (PMC) | | | ○ | | ○ | | | | | |
| For distribution boards (PMD) | | | | — | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | | | | |
| Draw-out type (DR) | | | | ▲ | | ▲ | | | | | |
| TemPlug70 (PG) | | | | — | | — | | | | | |
| DIN rail mount | | | | — | | — | | | | | |
| ■Accessories (optional) | | | | Symbol | | | | | | | |
| Externally mounted: Motor operator | | | | M C | ● | | ● | | | | |
| External operating handle | Breaker-mounted | | | H B | ● | | ● | | | | |
| | Door-mounted (variable depth) | | | H P | ● | | ● | | | | |
| Toggle extension | | | | H A | ● ㉔ | | ● ㉔ | | | | |
| Mechanical interlock ⑨ | Slide type | | | M S | ● | | ● | | | | |
| | Rear-connected type | | | M B | ● | | ● | | | | |
| | Link type | | | M L | — | | — | | | | |
| | Wire type | | | M W | ● | | ● | | | | |
| Toggle holder | | | | H H | ● | | ● | | | | |
| Toggle lock | | | | H L | | | | | | | |
| Terminal cover | For front-connected | | | C F | ● | | ● | | | | |
| | For rear-connected and plug-in | | | C R | — | | — | | | | |
| Terminal block for lead | | | | T F | ● | | ● | | | | |
| Door flange | | | | D F | ● | | ● | | | | |
| CE marking | | | | | Yes | | Yes | | | | |
| Overcurrent trip mechanism | | | | | Electronic ⑯ | | Electronic ⑯ | | | | |
| Colour of cover | | | | | Grey Blue | | Grey Blue | | | | |
| Trip button (Colour) | | | | | Yes (Red) | | Yes (Red) | | | | |
| Suitability for isolation | | | | | Yes | | Yes | | | | |
| Reverse connection | | | | | Yes | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".


⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

⑯ : Optional preferential alarm or ground fault trip function available on request.

㉔ : One is supplied with every five breakers. Please specify if more are required.

⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves




## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 1250A<br>500, 600, 700, 800, 1000, 1200, 1250 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max.($I_{CT}$)×1200%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% | | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| Neutral protection | | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100% or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

Note ②: When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$)×50% is set.


## Combinations of Internally Mounted Accessories (Optional)

| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3<br>4 | | | | | | | | | | | |


Toggle — Left pole / Right pole

# Outline dimensions (mm) S1250-NE, S1250-GE


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.5mm around the handle escutcheon.

## Plug-in(Standard)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions

## Moulded Case Circuit Breakers

## TL-1000NE, TL-1200NE

## Ratings and Specifications


| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 1000 | | 1200 | |
| Type | | | | TL-1000NE | | TL-1200NE | |
| Number of poles | | | | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | |
| Rated current, A | | | | Adjustable | | Adjustable | |
| Calibrated at 40°C | | | | $I_{CT}$=1000 | | $I_{CT}$=1250 | |
| 45°C | | | | 500 | 800 | 600 | 1000 |
| ⑧⓪ | | | | 600 | 900 | 700 | 1200 |
| | | | | 700 | 1000 | 800 | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | 15 (0.3sec.) | | 15(0.3sec.) | |
| Utilization Category | | | | B | | B | |
| ■Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 ⑤⑨ | AC | 690V | | 45/34 | | 45/34 | |
| IEC 60947-2 | | 500V | | 75/57 | | 75/57 | |
| $I_{cu}/I_{cs}$(sym) | | 440V | | 125/65 | | 125/65 | |
| | | 415V | | 125/65 | | 125/65 | |
| | | 380V | | 125/65 | | 125/65 | |
| | | 240V | | 150/113 | | 150/113 | |
| | DC | 250V | | — | | — | |
| | | 125V | | — | | — | |
| NK | AC | 690V | | — | | — | |
| $I_{cu}/I_{cs}$(sym) | | 450V | | 125/— ㉓ | | 125/— ㉓ | |
| | | 240V | | — | | — | |
| | DC | 250V | | — | | — | |
| Weight (◉ marked standard type) kg | | | | 26.0 | 33.7 | 26.0 | 33.7 |
| ■Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | |
| | With extension bars | | | ◉ | | ◉ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | |
| | Standard (PMC) | | | ○ | | ○ | |
| For distribution boards (PMD) | | | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | |
| Draw-out type (DR) | | | | ▲ | | ▲ | |
| TemPlug70 (PG) | | | | — | | — | |
| DIN rail mount | | | | — | | — | |
| ■Accessories (optional) | | | Symbol | | | | |
| Externally mounted: Motor operator | | | M C | ● | | ● | |
| External operating handle: Breaker-mounted | | | H B | ● | | ● | |
| External operating handle: Door-mounted (variable depth) | | | H P | ● | | ● | |
| Toggle extension | | | H A | ● ㉔ | | ● ㉔ | |
| Mechanical interlock ⑨: Slide type | | | M S | ● | | ● | |
| Mechanical interlock ⑨: Rear-connected type | | | M B | ● | | ● | |
| Mechanical interlock ⑨: Link type | | | M L | — | | — | |
| Mechanical interlock ⑨: Wire type | | | M W | — | | — | |
| Toggle holder | | | H H | ● | | ● | |
| Toggle lock | | | H L | | | | |
| Terminal cover: For front-connected | | | C F | — | | — | |
| Terminal cover: For rear-connected and plug-in | | | C R | — | | — | |
| Terminal block for lead | | | T F | ● | | ● | |
| Door flange | | | D F | ● | | ● | |
| CE marking | | | | Yes | | Yes | |
| Overcurrent trip mechanism | | | | Electronic ⑯ | | Electronic ⑯ | |
| Colour of cover | | | | Black | | Black | |
| Trip button (Colour) | | | | Yes (Brown) | | Yes (Brown) | |
| Suitability for isolation | | | | Yes | | Yes | |
| Reverse connection | | | | Yes | | Yes | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering. ▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR). ⑯ : Optional preferential alarm or ground fault trip function available on request. ㉓ : This is the value for 460V AC. ㉔ : One is supplied with every five breakers. Please specify if more are required. ⑤⑨ : TL-1000NE and TL-1200NE are JIS C 8201-2-1 Ann.2 compliant. ⑧⓪ : If the ambient temperature exceeds 45°C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves





## Overcurrent tripping characteristics

| Type | TL-1000NE | TL-1200NE |
|---|---|---|
| CT rated current(A) : ($I_{CT}$) | 1000 | 1250 |
| Rated current settings (A) : ($I_1$) (adjustable) | 500, 600, 700 800, 900, 1000 | 600, 700, 800 1000, 1200 |
| Long time-delay time settings (S) : ($T_1$) | (5–10–15–20–30) at ($I_1$)×600% current adjustable Setting tolerance ±20% | |
| Short time-delay pick-up current (A) : ($I_2$) | ($I_1$)×200, 400, 600, 800, 1000% adjustable Setting tolerance ±15% | |
| Short time-delay time settings (S) : ($T_2$) | Opening time (0.1, 0.15, 0.2, 0.25, 0.3) in the definite time-delay. Total clearing time is +50ms and resettable time –20ms for the time-delay settings | |
| Instantaneous trip pick-up current (A) : ($I_3$) | Continuously adjustable from ($I_{CT}$)×300 to 1200% Setting tolerance ±20% | |
| Preferential trip alarm pick-up current (A) : ($I_p$) (optional) | ($I_1$)×70, 80, 90, 100% adjustable Setting tolerance ±10% | |
| Preferential trip alarm time setting (S) : ($T_p$) (optional) | 40 fixed definite time-delay. Setting tolerance ±10% | |
| Ground fault trip pick-up current (A) : ($I_G$) (optional) ⑥③ | Continuously adjustable from ($I_{CT}$)×10 to 40% Setting tolerance ±15% | |
| Ground fault trip time settings (S) : ($T_G$) (optional) ⑥③ | Opening time (0.1, 0.2, 0.3, 0.4, 0.8) in the definite time- delay. Total clearing time is +50ms and resettable time –20ms for the time-delay settings | |

Remark: If not otherwise specified, the product will be delivered with the underlined standard setting values.

Note ⑥③: Cannot be used with the preferential trip alarm.


## Combinations of Internally Mounted Accessories (Optional)





Note: With AC UVT, the UVT controller is externally mounted. See page 6-25.

# Outline dimensions (mm) TL-1000NE, TL-1200NE


## Front-connected




## Rear-connected





Panel cutout B (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around the handle escutcheon.

Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Plug-in (Standard)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.



# 7 Characteristics and Outline Dimensions TemBreak PRO

# Moulded Case Circuit Breakers

# S1600-NE

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 1600 | | | | | | | | |
| Type | | | **S1600-NE** | | | | | | | | |
| Number of poles | | | 3 | 4 | | | | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | Adjustable | | | | | | | | |
| Calibrated at 40°C | | | $I_{CT}$=1600 | | | | | | | | |
| 45°C | | | 700 | 1200 | | | | | | | |
| ⑧⓪ | | | 800 | 1400 | | | | | | | |
| | | | 900 | 1500 | | | | | | | |
| | | | 1000 | 1600 | | | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 20(0.3sec.) | | | | | | | | |
| Utilization Category | | | B | | | | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 45/34 | | | | | | | | |
| IEC 60947-2 | | 500V | 65/50 | | | | | | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | 85/65 | | | | | | | | |
| | | 415V | 85/65 | | | | | | | | |
| | | 380V | 100/75 | | | | | | | | |
| | | 240V | 125/94 | | | | | | | | |
| | DC | 250V | — | | | | | | | | |
| | | 125V | — | | | | | | | | |
| NK | AC | 690V | — | | | | | | | | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | — | | | | | | | | |
| | | 240V | — | | | | | | | | |
| | DC | 250V | — | | | | | | | | |
| Weight (◉ marked standard type) kg | | | 27.0 | 35.0 | | | | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | | | | | | | |
| | With extension bars | | ○ | | | | | | | | |
| Rear-connected (RC) | Flat bar studs | | ◉ | | | | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | | | | | |
| | Standard (PMC) | | — | | | | | | | | |
| For distribution boards (PMD) | | | — | | | | | | | | |
| lush-mounted (FP) | With flat bar studs | | ○ | | | | | | | | |
| Draw-out type (DR) | | | ○ | | | | | | | | |
| TemPlug70 (PG) | | | — | | | | | | | | |
| DIN rail mount | | | — | | | | | | | | |
| ■ Accessories (optional) | | | | Symbol | | | | | | | |
| Externally mounted: Motor operator | | | ● | M C | | | | | | | |
| External operating handle: Breaker-mounted | | | ● | H B | | | | | | | |
| External operating handle: Door-mounted (variable depth) | | | ● | H P | | | | | | | |
| Toggle extension | | | ● ㉔ | H A | | | | | | | |
| Mechanical interlock ⑨: Slide type | | | ● | M S | | | | | | | |
| Mechanical interlock ⑨: Rear-connected type | | | ● | M B | | | | | | | |
| Mechanical interlock ⑨: Link type | | | — | M L | | | | | | | |
| Mechanical interlock ⑨: Wire type | | | ● | M W | | | | | | | |
| Toggle holder | | | ● | H H | | | | | | | |
| Toggle lock | | | | H L | | | | | | | |
| Terminal cover: For front-connected | | | — | C F | | | | | | | |
| Terminal cover: For rear-connected and plug-in | | | — | C R | | | | | | | |
| Terminal block for lead | | | ● | T F | | | | | | | |
| Door flange | | | ● | D F | | | | | | | |
| CE marking | | | Yes | | | | | | | | |
| Overcurrent trip mechanism | | | Electronic ⑯ | | | | | | | | |
| Colour of cover | | | Grey Blue | | | | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | | | | | |
| Suitability for isolation | | | Yes | | | | | | | | |
| Reverse connection | | | Yes | | | | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available".


⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

⑯ : Optional preferential alarm or ground fault trip function available on request.

㉔ : One is supplied with every five breakers. Please specify if more are required.

⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves




## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 1600A<br>700, 800, 900, 1000, 1200, 1400, 1500, 1600 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max.($I_{CT}$)×1200%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% | | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| Neutral protection | | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100%or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

Note ②: When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$)×50% is set.


## Combinations of Internally Mounted Accessories (Optional)

| Poles | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
| 3<br>4 | | | | | | | | | | | |


Toggle — Left pole / Right pole

# Outline dimensions (mm) S1600-NE


## Front-connected





## Rear-connected




## Draw-out




## Flush-mounted



# Moulded Case Circuit Breakers

# XS2000NE




## Ratings and Specifications

| | | | | | |
|---|---|---|---|---|---|
| Frame size (A) | | | 2000 | | |
| Type | | | XS2000NE | | |
| Number of poles | | | 3 | 4 | |
| ■Ratings | | | | | |
| Rated current, A | | | Adjustable | | |
| Calibrated at 40°C | | | $I_{CT}$=2000 | | |
| 45°C | | | 1000 | 1600 | |
| ⑧⓪ | | | 1200 | 1800 | |
| | | | 1400 | 2000 | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 42(0.3sec.) | | |
| Utilization Category | | | B | | |
| ■Rated breaking capacity, kA | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 45/42 | | |
| IEC 60947-2 | | 500V | 65/50 | | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | 85/65 | | |
| | | 415V | 85/65 | | |
| | | 380V | 100/75 | | |
| | | 240V | 125/94 | | |
| | DC | 250V | — | | |
| | | 125V | — | | |
| NK | AC | 690V | — | | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | 85/— ㉑ | | |
| | | 240V | — | | |
| | DC | 250V | — | | |
| Weight (◉ marked standard type) kg | | | 54.0 | 67.0 | |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) | Terminal screws | | — | | |
| | With extension bars | | ○ | | |
| Rear-connected (RC) | Flat bar studs | | ◉ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | |
| | Standard (PMC) | | — | | |
| For distribution boards (PMD) | | | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | |
| Draw-out type (DR) | | | ○ | | |
| TemPlug70 (PG) | | | — | | |
| DIN rail mount | | | — | | |
| ■Accessories (optional) | | Symbol | | | |
| Externally mounted: Toggle extension | | H A | ● ② | | |
| Mechanical interlock ⑨ | Rear-connected type | M B | ● | | |
| | Link type | M L | — | | |
| | Wire type | M W | — | | |
| Terminal cover | For front-connected | C F | — | | |
| | For rear-connected and plug-in | C R | — | | |
| Terminal block for lead | | T F | ● | | |
| Door flange | | D F | ● | | |
| CE marking | | | Yes | | |
| Overcurrent trip mechanism | | | Electronic ⑯ | | |
| Colour of cover | | | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | | |
| Suitability for isolation | | | Yes | | |
| Reverse connection | | | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available"
② : Supplied as standard. ⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).
⑯ : Optional preferential alarm or ground fault trip function available on request.
㉑ : This is the value for 500V AC. ⑥⑥ : Fixed depth, not adjustable.
⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves















## Overcurrent tripping characteristics

| | |
|---|---|
| CT rated current(A) : ($I_{CT}$) | 2000 |
| Rated current settings (A) : ($I_1$) (adjustable) | 1000, 1200, 1400, 1600, 1800, 2000 |
| Long time-delay time settings (S) : ($T_1$) | (5–10–15–20–30) at ($I_1$)×600% current adjustable Setting tolerance ±20% |
| Short time-delay pick-up current (A) : ($I_2$) | ($I_1$)×200, 400, 600, 800, 1000% adjustable Setting tolerance ±15% |
| Short time-delay time settings (S) : ($T_2$) | Opening time (0.1, 0.15, 0.2, 0.25, 0.3) in the definite time-delay. Total clearing time is +50ms and resettable time –20ms for the time-delay settings |
| Instantaneous trip pick-up current (A) : ($I_3$) | Continuously adjustable from ($I_{CT}$)×300 to 1200% Setting tolerance ±20% |
| Preferential trip alarm pick-up current (A) : ($I_p$) (optional) | ($I_1$)×70, 80, 90, 100% adjustable Setting tolerance ±10% |
| Preferential trip alarm time setting (S) : ($T_p$) (optional) | 40 fixed definite time-delay. Setting tolerance ±10% |
| Ground fault trip pick-up current (A) : ($I_G$) (optional) ⑥③ | Continuously adjustable from ($I_{CT}$)×10 to 40% Setting tolerance ±15% |
| Ground fault trip time settings (S) : ($T_G$) (optional) ⑥③ | Opening time (0.1, 0.2, 0.3, 0.4, 0.8) in the definite time- delay. Total clearing time is +50ms and resettable time –20ms for the time-delay settings |
| Trip indicators (optional) | See page 6-12 |

Remark: If not otherwise specified, the product will be delivered with the underlined standard setting values.
Note ⑥③: Cannot be used with the preferential trip alarm.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX | AL | SH | UV | AX + AL | AX + SH | AX + UV | AL + SH | AL + UV | AX + AL + SH | AX + AL + UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | With shunt trip anti-burn switch | Under voltage trip | | | | | | | |
| 3 4 |  |  |  |  |  |  |  |  |  |  |  |





Note: With AC UVT, the UVT controller is externally mounted. See page 6-25.


# Outline dimensions (mm) XS2000NE

## Front-connected






Drilling plan (front view)




## Rear-connected





(Bottom view)





Use non-magnetic angle (SUS 304 etc.)

Drilling plan (front view)





Use non-magnetic angle (SUS 304 etc.)


Panel cutout B (front view)





Panel cutout dimensions shown give an allowance of 2mm aroundthe handle escutcheon.

## Draw-out









Contact TERASAKI if manual connection is required.


Drilling plan (front view)




## Flush-mounted





Drilling plan (front view)




Use non-magnetic angle (SUS 304 etc.)

Panel cutout (front view)







# Moulded Case Circuit Breakers

# XS2500NE


## Ratings and Specifications

| | | | | | |
|---|---|---|---|---|---|
| Frame size (A) | | | 2500 | | |
| Type | | | XS2500NE | | |
| Number of poles | | | 3 | 4 | |
| ■Ratings | | | | | |
| Rated current, A | | | Adjustable | | |
| Calibrated at 40°C | | | $I_{CT}$=2500 | | |
| 45°C | | | 1200 2000 | | |
| ⑧⓪ | | | 1400 2500 | | |
| | | | 1600 | | |
| | | | (40℃ only) | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 42(0.3sec.) | | |
| Utilization Category | | | B | | |
| ■Rated breaking capacity, kA | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 690V | 45/42 | | |
| IEC 60947-2 | | 500V | 65/50 | | |
| $I_{cu}$/$I_{cs}$(sym) | | 440V | 85/65 | | |
| | | 415V | 85/65 | | |
| | | 380V | 100/75 | | |
| | | 240V | 125/94 | | |
| | DC | 250V | — | | |
| | | 125V | — | | |
| NK | AC | 690V | — | | |
| $I_{cu}$/$I_{cs}$(sym) | | 450V | — | | |
| | | 240V | — | | |
| | DC | 250V | — | | |
| Weight (◉ marked standard type) kg | | | 64 | 78.2 | |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) | Terminal screws | | — | | |
| | With extension bars | | — | | |
| Rear-connected (RC) | Flat bar studs | | ◉ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | |
| | Standard (PMC) | | — | | |
| For distribution boards (PMD) | | | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | |
| Draw-out type (DR) | | | — | | |
| TemPlug70 (PG) | | | — | | |
| DIN rail mount | | | — | | |
| ■Accessories (optional) | | Symbol | | | |
| Externally mounted: Toggle extension | | H A | ● ② | | |
| Mechanical interlock: Rear-connected type | | M B | ● | | |
| Mechanical interlock: Link type | | M L | — | | |
| Mechanical interlock: Wire type | | M W | — | | |
| Terminal cover: For front-connected | | C F | — | | |
| Terminal cover: For rear-connected and plug-in | | C R | — | | |
| Terminal block for lead | | T F | ● | | |
| Door flange | | D F | ● | | |
| CE marking | | | Yes | | |
| Overcurrent trip mechanism | | | Electronic ⑯ | | |
| Colour of cover | | | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | | |
| Suitability for isolation | | | Yes | | |
| Reverse connection | | | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available"
② : Supplied as standard.
⑯ : Optional preferential alarm or ground fault trip function available on request.
⑥⑥ : Fixed depth, not adjustable.
⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves





## Overcurrent tripping characteristics

| | |
|---|---|
| CT rated current(A) : ($I_{CT}$) | 2500 |
| Rated current settings (A) : ($I_1$) (adjustable) | 1200, 1400, 1600, 2000, 2500 |
| Long time-delay time settings (S) : ($T_1$) | (5–10–15–20–30) at ($I_1$)×600% current adjustable Setting tolerance ±20% |
| Short time-delay pick-up current (A) : ($I_2$) | ($I_1$)×200, 400, 600, 800, 1000% adjustable Setting tolerance ±15% |
| Short time-delay time settings (S) : ($T_2$) | Opening time (0.1, 0.15, 0.2, 0.25, 0.3) in the definite time-delay. Total clearing time is +50ms and resettable time –20ms for the time-delay settings |
| Instantaneous trip pick-up current (A) : ($I_3$) | Continuously adjustable from ($I_{CT}$)×300 to 1200% Setting tolerance ±20% |
| Preferential trip alarm pick-up current (A) : ($I_p$) (optional) | ($I_1$)×70, 80, 90, 100% adjustable Setting tolerance ±10% |
| Preferential trip alarm time setting (S) : ($T_p$) (optional) | 40 fixed definite time-delay. Setting tolerance ±10% |
| Ground fault trip pick-up current (A) : ($I_G$) (optional) ⑥③ | Continuously adjustable from ($I_{CT}$)×10 to 40% Setting tolerance ±15% |
| Ground fault trip time settings (S) : ($T_G$) (optional) ⑥③ | Opening time (0.1, 0.2, 0.3, 0.4, 0.8) in the definite time- delay. Total clearing time is +50ms and resettable time –20ms for the time-delay settings |
| Trip indicators (optional) | See page 6-12 |

Remark: If not otherwise specified, the product will be delivered with the underlined standard setting values.
Note ⑥③: Cannot be used with the preferential trip alarm.


## Combinations of Internally Mounted Accessories (Optional)





Note: With AC UVT, the UVT controller is externally mounted. See page 6-25.

## Outline dimensions (mm) XS2500NE


### Rear-connected




Panel cutout B (front view)





Drilling plan (front view)





*Use non-magnetic angle (SUS 304 etc.)

Panel cutout dimensions shown give an allowance of 2mm around the handle escutcheon.


### Flush-mounted




Panel cutout (front view)




Drilling plan (front view)




*Use non-magnetic angle (SUS 304 etc.)





# Moulded Case Circuit Breakers

# XS3200NE


## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | | 3200 | | |
| Type | | | | **XS3200NE** | | |
| Number of poles | | | | 3 | | |
| ■ Ratings | | | | | | |
| Rated current, A | | | | Adjustable | | |
| Calibrated at 40°C | | | | $I_{CT}$=3200 | | |
| 45°C | | | | 1600 2800 | | |
| ⑧⓪ | | | | 2000 3200 | | |
| | | | | 2500 | | |
| | | | | (40℃ only) | | |
| | | | | ⑦① | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | | 38(0.5sec.) | | |
| Utilization Category | | | | B | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC | 690V | 45/42 | | |
| IEC 60947-2 | | | 500V | 65/50 | | |
| $I_{cu}/I_{cs}$(sym) | | | 440V | 85/65 | | |
| | | | 415V | 85/65 | | |
| | | | 380V | 100/75 | | |
| | | | 240V | 125/94 | | |
| | | DC | 250V | — | | |
| | | | 125V | — | | |
| NK | | AC | 690V | — | | |
| $I_{cu}/I_{cs}$(sym) | | | 450V | — | | |
| | | | 240V | — | | |
| | | DC | 250V | — | | |
| Weight (◉ marked standard type) kg | | | | 65 | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | |
| | With extension bars | | | — | | |
| Rear-connected (RC) | Flat bar studs | | | ◉ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | |
| | Standard (PMC) | | | — | | |
| For distribution boards (PMD) | | | | — | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | |
| Draw-out type (DR) | | | | — | | |
| TemPlug70 (PG) | | | | — | | |
| DIN rail mount | | | | — | | |
| ■ Accessories (optional) | | | Symbol | | | |
| Externally mounted: Toggle extension | | | H A | ● ② | | |
| Mechanical interlock | Rear-connected type | | M B | ● | | |
| | Link type | | M L | — | | |
| | Wire type | | M W | — | | |
| Terminal cover | For front-connected | | C F | — | | |
| | For rear-connected and plug-in | | C R | — | | |
| Terminal block for lead | | | T F | ● | | |
| Door flange | | | D F | ● | | |
| CE marking | | | | Yes | | |
| Overcurrent trip mechanism | | | | Electronic ⑯ | | |
| Colour of cover | | | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | |
| Reverse connection | | | | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available"
② : Supplied as standard.
⑯ : Optional preferential alarm or ground fault trip function available on request.
⑥⑥ : Fixed depth, not adjustable. ⑦① : 3000A is also available as special.
⑧⓪ : If the ambient temperature exceeds 45° C, reduce the operating current in accordance with 2 Environmental operating conditions of the chapter 8.

## Time/Current characteristic curves





## Overcurrent tripping characteristics

| | |
|---|---|
| CT rated current(A) : ($I_{CT}$) | 3200 |
| Rated current settings (A) : ($I_1$) (adjustable) | 1600, 2000, 2500, 2800, 3200 |
| Long time-delay time settings (S) : ($T_1$) | (5–10–15–20–30) at ($I_1$)×600% current adjustable Setting tolerance ±20% |
| Short time-delay pick-up current (A) : ($I_2$) | ($I_1$)×200, 400, 600, 800, 1000% adjustable Setting tolerance ±15% |
| Short time-delay time settings (S) : ($T_2$) | Opening time (0.1, 0.15, 0.2, 0.25, 0.3) in the definite time-delay. Total clearing time is +50ms and resettable time –20ms for the time-delay settings |
| Instantaneous trip pick-up current (A) : ($I_3$) | Continuously adjustable from ($I_{CT}$)×300 to 1000% Setting tolerance ±20% |
| Preferential trip alarm pick-up current (A) : ($I_p$) (optional) | ($I_1$)×70, 80, 90, 100% adjustable Setting tolerance ±10% |
| Preferential trip alarm time setting (S) : ($T_p$) (optional) | 40 fixed definite time-delay. Setting tolerance ±10% |
| Ground fault trip pick-up current (A) : ($I_G$) (optional) ⑥③ | Continuously adjustable from ($I_{CT}$)×10 to 40% Setting tolerance ±15% |
| Ground fault trip time settings (S) : ($T_G$) (optional) ⑥③ | Opening time (0.1, 0.2, 0.3, 0.4, 0.8) in the definite time- delay. Total clearing time is +50ms and resettable time –20ms for the time-delay settings |
| Trip indicators (optional) | See page 6-12 |

Remark: If not otherwise specified, the product will be delivered with the underlined standard setting values.
Note ⑥③: Cannot be used with the preferential trip alarm.

## Combinations of Internally Mounted Accessories (Optional)





Note: With AC UVT, the UVT controller is externally mounted. See page 6-25.

## Outline dimensions (mm) XS3200NE


### Rear-connected

(Bottom view)





*Use non-magnetic angle (SUS 304 etc.)

Panel cutout B (front view)





Drilling plan (front view)





*Use non-magnetic angle (SUS 304 etc.)

Panel cutout dimensions shown give an allowance of 2mm around the handle escutcheon.


### Flush-mounted




Panel cutout (front view)




Drilling plan (front view)




*Use non-magnetic angle (SUS 304 etc.)



# 7 Characteristics and Outline Dimensions

TemBreak2

## Moulded Case Circuit Breakers for motor protection

## E30-NM, E50-NM, S30-NM, S50-NM

## Ratings and Specifications

| Frame size (A) | | | 30 | 50 | 30 | 50 |
|---|---|---|---|---|---|---|
| Type | | | E30-NM | E50-NM | S30-NM | S50-NM |
| Number of poles | | | 3 | 3 | 3 | 3 |
| ■ Ratings | | | | | | |
| Motor rated capacity (kW) and breaker rated current (A) | | | | | | |
| Calibrated at 40°C | | | (A) / (kW) 200/220V / 400/440V | (A) / (kW) 200/220V / 400/440V | (A) / (kW) 200/220V / 400/440V | (A) / (kW) 200/220V / 400/440V |
| 45°C | | | 1.4 / 0.2 / 0.4 | 24 / 5.5 / 11 | 0.7 / — / 0.2 | 10 / 2.2 / — |
| | | | 2.6 / 0.4 / — | 32 / 7.5 / 15 | 1.4 / 0.2 / 0.4 | 12 / — / 5.5 |
| | | | 4 / 0.75 / 1.5 | 40 / — / 18.5 | 2 / — / 0.75 | 16 / 3.7 / 7.5 |
| | | | 8 / 1.5 / 3.7 | 45 / 11 / 22 | 2.6 / 0.4 / — | 24 / 5.5 / 11 |
| | | | 10 / 2.2 / — | (40℃ only) | 4 / 0.75 / 1.5 | 32 / 7.5 / 15 |
| | | | 16 / 3.7 / 7.5 | | 5 / — / 2.2 | 40 / — / 18.5 |
| | | | 24 / 5.5 / 11 | | 8 / 1.5 / 3.7 | 45 / 11 / 22 |
| | | | 32 / 7.5 / 15 | | 10 / 2.2 / — | (40℃ only) |
| | | | (40℃ only) | | 12 / — / 5.5 | |
| | | | | | 16 / 3.7 / 7.5 | |
| | | | | | 24 / 5.5 / 11 | |
| | | | | | 32 / 7.5 / 15 | |
| | | | | | (40℃ only) | |
| Rated insulation voltage〔$U_i$〕 V | | | 500 | 690 | 690 | 690 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | 6 | 6 | 6 |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 440V | 1.5/1 | 2.5/2 | 2.5/2 | 10/5 |
| IEC 60947-2 | | 415V | 1.5/1 | 2.5/2 | 2.5/2 | 10/5 |
| $I_{cu}/I_{cs}$(sym) | | 380V | 1.5/1 | 2.5/2 | 2.5/2 | 10/5 |
| | | 240V | 2.5/2 ㊾ | 5/3 ㊾ | 5/3 ㊾ | 25/13 ㊾ |
| Weight (◉ marked standard type) kg | | | 0.5 | 0.5 | 0.5 | 0.5 |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — |
| | Standard (PMC) | | — | — | — | — |
| For distribution boards (PMD) | | | — | — | — | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | | | — | — | — | — |
| TemPlug70 (PG) | | | — | — | — | — |
| DIN rail mount | | | ◉ | ◉ | ◉ | ◉ |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | — | — | — | — |
| External operating handle | Breaker-mounted | H B | △ | △ | △ | △ |
| | Door-mounted (variable depth) | H P | △ | △ | △ | △ |
| Toggle extension | | H A | — | — | — | — |
| Mechanical interlock | Slide type | M S | ● | ● | ● | ● |
| | Rear-connected type | M B | — | — | — | — |
| | Link type | M L | — | — | — | — |
| | Wire type | M W | — | — | — | — |
| Toggle holder | | H H | — | — | — | — |
| Toggle lock | | H L | ● | ● | ● | ● |
| Terminal cover | For front-connected | C F | ● | ● | ● | ● |
| | For rear-connected and plug-in | C R | ● ② | ● ② | ● ② | ● ② |
| Terminal block for lead | | T F | ● | ● | ● | ● |
| Door flange | | D F | — | — | — | — |
| CE marking | | | Yes | Yes | Yes | Yes |
| Overcurrent trip mechanism | | | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type | Hydraulic-magnetic type |
| Colour of cover | | | Light Grey | Light Grey | Light Grey | Light Grey |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes |
| Reverse connection | | | Yes ㉒ | Yes | Yes | Yes ㉒ |

Note: Select an appropriate one depending on the total load current of the motor operator.

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

② : Supplied as standard.


㊺ : A wire clamping terminal is provided.

㊸ : For the extension bars, please place the order separately in parts.


㊾ : This is the value for 230V AC.

㉒ : There are some limitations. See page 5-23 for details.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.
Undervoltage trip is mounted on the side of the circuit breaker. In the case of flush mounted type (FP), it cannot be installed.


## Outline dimensions (mm) E30-NM, E50-NM, S30-NM, S50-NM

### Front-connected






Drilling plan (front view)





Panel cutout A (front view)





Detail of connecting part





Preparation of conductor





### Rear-connected





(Bottom view)






Drilling plan (front view)





Note: The mounting direction of the studs cannot be changed. Please specify the mounting direction when ordering. The line side and load side will be factory installed in the horizontal direction unless otherwise specified.


### Flush-mounted




Drilling plan (front view)




Note: The mounting direction of the studs cannot be changed. Please specify the mounting direction when ordering. The line side and load side will be factory installed in the horizontal direction unless otherwise specified.



# 7 Characteristics and Outline Dimensions

TemBreak2

## Moulded Case Circuit Breakers for motor protection

## E100-NM

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | | | |
| Type | | | E100-NM | | | |
| Number of poles | | | 3 | | | |
| ■ Ratings | | | | | | |
| Motor rated capacity (kW) and breaker rated current (A) | | | | | | |
| Calibrated at 40°C | | | (A) / (kW) 200/220V / 400/440V | | | |
| | | | 60 / 15 / 30 | | | |
| | | | 75 / 18.5 / 37 | | | |
| 45°C | | | 90 / 22 / 45 | | | |
| | | | (40°C only) | | | |

Note: Select an appropriate one depending on the total load current of the motor operator.

| | | | | | | |
|---|---|---|---|---|---|---|
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 440V | 10/5 | | | |
| IEC 60947-2 | | 415V | 10/5 | | | |
| $I_{cu}/I_{cs}$(sym) | | 380V | 10/5 | | | |
| | | 240V | 25/13 ㊾ | | | |
| Weight (◉ marked standard type) kg | | | 0.5 | | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | |
| | With extension bars | | ○ ㊸ | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | |
| | Standard (PMC) | | — | | | |
| For distribution boards (PMD) | | | — | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | |
| Draw-out type (DR) | | | — | | | |
| TemPlug70 (PG) | | | — | | | |
| DIN rail mount | | | ◉ | | | |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | — | | | |
| External operating handle: Breaker-mounted | | H B | △ | | | |
| External operating handle: Door-mounted (variable depth) | | H P | △ | | | |
| Toggle extension | | H A | — | | | |
| Mechanical interlock | Slide type | M S | ● | | | |
| | Rear-connected type | M B | — | | | |
| | Link type | M L | — | | | |
| | Wire type | M W | — | | | |
| Toggle holder | | H H | — | | | |
| Toggle lock | | H L | ● | | | |
| Terminal cover | For front-connected | C F | ● | | | |
| | For rear-connected and plug-in | C R | ● ② | | | |
| Terminal block for lead | | T F | ● | | | |
| Door flange | | D F | — | | | |
| CE marking | | | Yes | | | |
| Overcurrent trip mechanism | | | Hydraulic-magnetic type | | | |
| Colour of cover | | | Light Grey | | | |
| Trip button (Colour) | | | Yes (Red) | | | |
| Suitability for isolation | | | Yes | | | |
| Reverse connection | | | Yes ㉒ | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.


② : Supplied as standard.

㊸ : For the extension bars, please place the order separately in parts.


㊾ : This is the value for 230V AC.

㉒ : There are some limitations. See page 5-23 for details.

## Time/Current characteristic curves




## Ambient compensating curves




## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>With shunt trip anti-burn switch | UV<br>Under voltage trip | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|
| 3 | | | | | | |


Toggle — Left pole / Right pole

Note: For auxiliary switches or alarm switches, left-hand mounting has priority.


# Outline dimensions (mm) E100-NM

## Front-connected






Drilling plan (front view)





Panel cutout A (front view)





Detail of connecting part





Preparation of conductor





## Rear-connected





(Bottom view)






Drilling plan (front view)





Note: The mounting direction of the studs cannot be changed. Please specify the mounting direction when ordering.
The line side and load side will be factory installed in the horizontal direction unless otherwise specified.


## Flush-mounted




Drilling plan (front view)




Note: The mounting direction of the studs cannot be changed. Please specify the mounting direction when ordering.
The line side and load side will be factory installed in the horizontal direction unless otherwise specified.



# 7 Characteristics and Outline Dimensions TemBreak PRO

## Moulded Case Circuit Breakers for motor protection

## S250-SM

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 225 | | | |
| Type | | | S250-SM | | | |
| Number of poles | | | 3 | | | |
| ■ Ratings | | | | | | |
| Motor rated capacity (kW) and breaker rated current (A) | | | | | | |
| Calibrated at 40°C | | | | | | |
| 45°C | | | | | | |

| (A) | (kW) 200/220V | (kW) 400/440V |
|---|---|---|
| 125 | 30 | — |
| 150 | 37 | 75 |
| 175 | 45 | 90 |
| 225 | 55 | 110 |

Note: Select an appropriate one depending on the total load current of the motor operator.

| | | | | | | |
|---|---|---|---|---|---|---|
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | AC | 440V | 30/15 | | | |
| IEC 60947-2 | | 415V | 40/20 | | | |
| $I_{cu}/I_{cs}$(sym) | | 380V | 40/20 | | | |
| | | 240V | 85/43 | | | |
| Weight (◉ marked standard type) kg | | | 1.5 | | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | |
| | With extension bars | | ○ ㊸ | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | |
| | Standard (PMC) | | — | | | |
| For distribution boards (PMD) | | | — | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | |
| Draw-out type (DR) | | | — | | | |
| TemPlug70 (PG) | | | ○ | | | |
| DIN rail mount | | | — | | | |
| ■ Accessories (optional) | | | Symbol | | | |
| Externally mounted: Motor operator | | | M C | ● | | |
| External operating handle | Breaker-mounted | | H B | ● | | |
| | Door-mounted (variable depth) | | H P | ● | | |
| Toggle extension | | | H A | — | | |
| Mechanical interlock | Slide type | | M S | ● | | |
| | Rear-connected type | | M B | — | | |
| | Link type | | M L | ● | | |
| | Wire type | | M W | ● | | |
| Toggle holder | | | H H | ● | | |
| Toggle lock | | | H L | ● | | |
| Terminal cover | For front-connected | | C F | ● | | |
| | For rear-connected and plug-in | | C R | ● | | |
| Terminal block for lead | | | T F | ● | | |
| Door flange | | | D F | ● | | |
| CE marking | | | | Yes | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | |
| Colour of cover | | | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | |
| Reverse connection | | | | Yes | | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

㊸ : For the extension bars, please place the order separately in parts.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)




Note: For auxiliary switches or alarm switches, left-hand mounting has priority.


# Outline dimensions (mm) S250-SM

## Front-connected





*For the extension bars, straight bars or spread bars can be supplied.

## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)





Panel cutout B (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted







# Switch-disconnectors

# PE30-NN, PE50-NN

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 30 | | 50 | | | | | |
| Type | | | | PE30-NN | | PE50-NN | | | | | |
| Number of poles | | | | 2 | 3 | 2 | 3 | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | | 30 | | 50 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | | | |
| Rated operational voltage V | | | AC | 415 | | 500 | | | | | |
| | | | DC | — | | 250 ㉗ | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | | 1.5 | | 1.5 | | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | 1 (1sec.) | | 1 (1sec.) | | | | | |
| ■ Performance | | | | | | | | | | | |
| Utilization category | | | AC | AC-23A | | AC-23A | | | | | |
| JIS C 8201-3 IEC 60947-3 | | | DC | — | | DC-22A | | | | | |
| Upstream breaker (OCPD) ㉙ | | | | PE30-NF | | PE50-NF | | | | | |
| Weight (◉ marked standard type) kg | | | | 0.5 | 0.7 | 0.5 | 0.7 | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | | Terminal screws | | ◉ ㊺ | | ◉ ㊺ | | | | | |
| | | With extension bars | | ○ ㊸ | | ○ ㊸ | | | | | |
| Rear-connected (RC) | | Flat bar studs | | ○ | | ○ | | | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | | — | | | | | |
| | | Standard (PMC) | | — | ○ | — | ○ | | | | |
| | For distribution boards (PMD) ㉟ | | | ○ | | ○ | | | | | |
| Flush-mounted (FP) | | With flat bar studs | | ○ | | ○ | | | | | |
| Draw-out type (DR) | | | | — | | — | | | | | |
| TemPlug70 (PG) | | | | — | | — | | | | | |
| DIN rail mount | | | | — | ○ ⑪ | — | ○ ⑪ | | | | |
| ■ Accessories (optional) | | | Symbol | | | | | | | | |
| Externally mounted | Motor operator | | M C | — | | — | | | | | |
| | External operating handle | Breaker-mounted | H B | — | ● | — | ● | | | | |
| | | Door-mounted (variable depth) | H P | — | ● | — | ● | | | | |
| | Toggle extension | | H A | — | | — | | | | | |
| | Mechanical interlock | Slide type | M S | — | ● | — | ● | | | | |
| | | Rear-connected type | M B | — | | — | | | | | |
| | | Link type | M L | — | | — | | | | | |
| | | Wire type | M W | — | | — | | | | | |
| | Toggle holder | | H H | ● | | ● | | | | | |
| | Toggle lock | | H L | ● | | ● | | | | | |
| | Terminal cover | For front-connected | C F | ● | | ● | | | | | |
| | | For rear-connected and plug-in | C R | ● | | ● | | | | | |
| | Terminal block for lead | | T F | ● | | ● | | | | | |
| | Door flange | | D F | ● | | ● | | | | | |
| CE marking | | | | Yes | | Yes | | | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | | | |
| Suitability for isolation | | | | Yes | | Yes | | | | | |
| Reverse connection | | | | Yes | | Yes | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available"

⑪ : Please order the DIN rail adapter separately. See page 6-152.

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊺ : A wire clamping terminal is provided.

㊸ : For the extension bars, please place the order separately in parts.

㉟ : See page 7-172 for the outline dimensions.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 2 | | | | | | | | | | | |
| 3 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PE30-NN, PE50-NN


## Front-connected





Preparation of conductor





With extension bars (optional)





Drilling plan (front view)





## Rear-connected




① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.


Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.





Detail of connecting part

| A | B | C | D | E | F |
|---|---|---|---|---|---|
| 10.5 | 6.5 | 4 | 13 | 16 | 4 |


Drilling plan (front view)




Panel cutout A (front view)





Panel cutout B (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)

Detail of connecting part





Preparation of conductor






Mounting base (rear view)





Drilling plan (front view)




## Flush-mounted








① : Studs are horizontal direction as standard. They will be factory direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| A | B | C | D | E | F |
|---|---|---|---|---|---|
| 10.5 | 6.5 | 4 | 13 | 16 | 4 |

Please check the rear connected type for a detailed outline drawing of the terminals.

Drilling plan (front view)




Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

# Switch-disconnectors

## PE125-NN



## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | 125 | | | | | |
| Type | | | | PE125-NN | | | | | | | |
| Number of poles | | | | 2 | 3 | 2 | 3 | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | | 100 | | 125 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | | | |
| Rated operational voltage V | | | AC | 500 | | 500 | | | | | |
| | | | DC | 250 ㉗ | | 250 ㉗ | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | | 2.13 | | 2.13 | | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | 1.5 (0.3sec.) | | 1.5 (0.3sec.) | | | | | |
| ■ Performance | | | | | | | | | | | |
| Utilization category | | | AC | AC-23A | | AC-23A | | | | | |
| JIS C 8201-3 IEC 60947-3 | | | DC | DC-22A | | DC-22A | | | | | |
| Upstream breaker (OCPD) ㉙ | | | | PE125-NF | | PE125-NF | | | | | |
| Weight (◉ marked standard type) kg | | | | 0.5 | 0.7 | 0.5 | 0.7 | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | | Terminal screws | | ◉ | | ◉ | | | | | |
| | | With extension bars | | ○ ㊸ | | ○ ㊸ | | | | | |
| Rear-connected (RC) | | Flat bar studs | | ○ | | ○ | | | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | | — | | | | | |
| | | Standard (PMC) | | — | ○ | — | ○ | | | | |
| | For distribution boards (PMD) ㉟ | | | ○ | | ○ | | | | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | | | | |
| Draw-out type (DR) | | | | — | | — | | | | | |
| TemPlug70 (PG) | | | | — | | — | | | | | |
| DIN rail mount | | | | — | ○ ⑪ | — | ○ ⑪ | | | | |
| ■ Accessories (optional) | | | Symbol | | | | | | | | |
| Externally mounted | Motor operator | | M C | — | | — | | | | | |
| | External operating handle | Breaker-mounted | H B | — | ● | — | ● | | | | |
| | | Door-mounted (variable depth) | H P | — | ● | — | ● | | | | |
| | Toggle extension | | H A | — | | — | | | | | |
| | Mechanical interlock | Slide type | M S | — | ● | — | ● | | | | |
| | | Rear-connected type | M B | — | | — | | | | | |
| | | Link type | M L | — | | — | | | | | |
| | | Wire type | M W | — | | — | | | | | |
| | Toggle holder | | H H | ● | | ● | | | | | |
| | Toggle lock | | H L | ● | | ● | | | | | |
| | Terminal cover | For front-connected | C F | ● | | ● | | | | | |
| | | For rear-connected and plug-in | C R | ● | | ● | | | | | |
| | Terminal block for lead | | T F | ● | | ● | | | | | |
| | Door flange | | D F | ● | | ● | | | | | |
| CE marking | | | | Yes | | Yes | | | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | | | |
| Suitability for isolation | | | | Yes | | Yes | | | | | |
| Reverse connection | | | | Yes | | Yes | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available"

⑪ : Please order the DIN rail adapter separately. See page 6-152.

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊸ : For the extension bars, please place the order separately in parts.

㉟ : See page 7-172 for the outline dimensions.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 2 | | | | | | | | | | | |
| 3 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PE125-NN

## Front-connected




## Rear-connected





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.


| A | B | C | D | E | F |
|---|---|---|---|---|---|
| 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Panel cutout A (front view) / Panel cutout B (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)




## Flush-mounted




① : Studs are horizontal direction as standard. They will be factory direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| A | B | C | D | E | F |
|---|---|---|---|---|---|
| 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Please check the rear connected type for a detailed outline drawing of the terminals.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

# Switch-disconnectors

# S125-SN



## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | 125 | | | | | |
| Type | | | | S125-SN | | | | | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | | | |
| ■ Ratings | | | | | | | | | | | |
| Rated current, A | | | | 100 | | 125 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | | | |
| Rated operational voltage V | | | AC | 690 | | 690 | | | | | |
| | | | DC | 250 | | 250 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | | 2.8 | | 2.8 | | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | 2 (0.3sec.) | | 2 (0.3sec.) | | | | | |
| ■ Performance | | | | | | | | | | | |
| Utilization category | | | AC | AC-23A | | AC-23A | | | | | |
| JIS C 8201-3 IEC 60947-3 | | | DC | DC-22A | | DC-22A | | | | | |
| Upstream breaker (OCPD) ㉙ | | | | S125-SF | | S125-SF | | | | | |
| Weight (◉ marked standard type) kg | | | | 0.7 | 0.9 | 0.7 | 0.9 | | | | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | | Terminal screws | | ◉ | | ◉ | | | | | |
| | | With extension bars | | ○ ㊸ | | ○ ㊸ | | | | | |
| Rear-connected (RC) | | Flat bar studs | | ○ | | ○ | | | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | | — | | | | | |
| | | Standard (PMC) | | ○ | — | ○ | — | | | | |
| | For distribution boards (PMD) ㉟ | | | ○ | — | ○ | — | | | | |
| Flush-mounted (FP) | | With flat bar studs | | ○ | — | ○ | — | | | | |
| Draw-out type (DR) | | | | — | | — | | | | | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — | | | | |
| DIN rail mount | | | | ○ ⑪ | | ○ ⑪ | | | | | |
| ■ Accessories (optional) | | | Symbol | | | | | | | | |
| Externally mounted | Motor operator | | M C | — | | — | | | | | |
| | External operating handle | Breaker-mounted | H B | ● | | ● | | | | | |
| | | Door-mounted (variable depth) | H P | ● | | ● | | | | | |
| | Toggle extension | | H A | — | | — | | | | | |
| | Mechanical interlock | Slide type | M S | ● | | ● | | | | | |
| | | Rear-connected type | M B | — | | — | | | | | |
| | | Link type | M L | — | | — | | | | | |
| | | Wire type | M W | — | | — | | | | | |
| | Toggle holder | | H H | ● | | ● | | | | | |
| | Toggle lock | | H L | ● | | ● | | | | | |
| | Terminal cover | For front-connected | C F | ● | | ● | | | | | |
| | | For rear-connected and plug-in | C R | ● | | ● | | | | | |
| | Terminal block for lead | | T F | ● | | ● | | | | | |
| | Door flange | | D F | ● | | ● | | | | | |
| CE marking | | | | Yes | | Yes | | | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | | | |
| Suitability for isolation | | | | Yes | | Yes | | | | | |
| Reverse connection | | | | Yes | | Yes | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available"


⑪ : Please order the DIN rail adapter separately. See page 6-152.

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊸ : For the extension bars, please place the order separately in parts.

㉟ : See page 7-172 for the outline dimensions.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) S125-SN

## Front-connected





## Rear-connected





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)




## Flush-mounted




① : Studs are horizontal direction as standard. They will be factory direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

# Switch-disconnectors

# PS125-NN



## Ratings and Specifications

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | 125 | | | |
| Type | | | | PS125-NN | | | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | |
| **■ Ratings** | | | | | | | | | |
| Rated current, A | | | | 100 | | 125 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | | | |
| Rated operational voltage V | | | AC | 690 | | 690 | | | |
| | | | DC | 250 | | 250 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | | 2.8 | | 2.8 | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | 2 (1sec.) | | 2 (1sec.) | | | |
| **■ Performance** | | | | | | | | | |
| Utilization category | | | AC | AC-23A | | AC-23A | | | |
| JIS C 8201-3 IEC 60947-3 | | | DC | DC-22A | | DC-22A | | | |
| Upstream breaker (OCPD) ㉙ | | | | PS125-NF | | PS125-NF | | | |
| Weight (◉ marked standard type) kg | | | | 1.0 | 1.3 | 1.0 | 1.3 | | |
| **■ Connections and Mountings** | | | | | | | | | |
| Front-connected (FC) | | Terminal screws | | ◉ | | ◉ | | | |
| | | With extension bars | | ○ ㊸ | | ○ ㊸ | | | |
| Rear-connected (RC) | | Flat bar studs | | ○ | | ○ | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | ○ ㊿ | | ○ ㊿ | | | |
| | | Standard (PMC) | | ○ | — | ○ | — | | |
| | For distribution boards (PMD) ㊸ | | | ○ | — | ○ | — | | |
| lush-mounted (FP) | | With flat bar studs | | ○ | | ○ | | | |
| Draw-out type (DR) | | | | — | | — | | | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — | | |
| DIN rail mount | | | | ○ ⑪ | | ○ ⑪ | | | |
| **■ Accessories (optional)** | | | **Symbol** | | | | | | |
| Externally mounted | Motor operator | | M C | ● | | ● | | | |
| | External operating handle | Breaker-mounted | H B | ● | | ● | | | |
| | | Door-mounted (variable depth) | H P | ● | | ● | | | |
| | Toggle extension | | H A | — | | — | | | |
| | Mechanical interlock | Slide type | M S | ● | | ● | | | |
| | | Rear-connected type | M B | — | | — | | | |
| | | Link type | M L | ● | | ● | | | |
| | | Wire type | M W | ● | | ● | | | |
| | Toggle holder | | H H | ● | | ● | | | |
| | Toggle lock | | H L | ● | | ● | | | |
| | Terminal cover | For front-connected | C F | ● | | ● | | | |
| | | For rear-connected and plug-in | C R | ● | | ● | | | |
| | Terminal block for lead | | T F | ● | | ● | | | |
| | Door flange | | D F | ● | | ● | | | |
| CE marking | | | | Yes | | Yes | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | | Yes | | Yes | | | |
| Reverse connection | | | | Yes | | Yes | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available"

⑪ : Please order the DIN rail adapter separately. See page 6-152.

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊿ : A safety trip function is provided.

㊸ : For the extension bars, please place the order separately in parts.

㊸ : See page 7-171 for the outline dimensions.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3, 4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS125-NN

## Front-connected





## Rear-connected





| Rated current[A] | A | B | C |
|---|---|---|---|
| 15 — 50 | 12.5 | ø8.5 | 4 |
| 60 — 125 | 12.5 | ø8.5 | 5 |

Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout B (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted




| Rated current[A] | A | B | C |
|---|---|---|---|
| 15 — 50 | 12.5 | ø8.5 | 4 |
| 60 — 125 | 12.5 | ø8.5 | 5 |

Note: Studs are factory installed in horizontal direction both on the line and load sides.





# Switch-disconnectors

# S250-SN

## Ratings and Specifications

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 225 | | 250 | | | |
| Type | | | | S250-SN | | | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | |
| ■ Ratings | | | | | | | | | |
| Rated current, A | | | | 225 | | 250 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 690 | | 690 | | | |
| Rated operational voltage V | | | AC | 690 | | 690 | | | |
| | | | DC | 250 | | 250 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | | 6 | | 6 | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | 3 (0.3sec.) | | 3 (0.3sec.) | | | |
| ■ Performance | | | | | | | | | |
| Utilization category | | | AC | AC-23A | | AC-23A | | | |
| JIS C 8201-3 IEC 60947-3 | | | DC | DC-22A | | DC-22A | | | |
| Upstream breaker (OCPD) ㉙ | | | | S250-SF | | S250-SF | | | |
| Weight (◉ marked standard type) kg | | | | 1.5 | 1.9 | 1.5 | 1.9 | | |
| ■ Connections and Mountings | | | | | | | | | |
| Front-connected (FC) | | Terminal screws | | ◉ | | ◉ | | | |
| | | With extension bars | | ○ ㊸ | | ○ ㊸ | | | |
| Rear-connected (RC) | | Flat bar studs | | ○ | | ○ | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | | — | | | |
| | | Standard (PMC) | | ○ | | ○ | | | |
| | For distribution boards (PMD) | | | — | | — | | | |
| Flush-mounted (FP) | | With flat bar studs | | ○ | | ○ | | | |
| Draw-out type (DR) | | | | — | | — | | | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — | | |
| DIN rail mount | | | | — | | — | | | |
| ■ Accessories (optional) | | | Symbol | | | | | | |
| Externally mounted | Motor operator | | M C | ● | | ● | | | |
| | External operating handle | Breaker-mounted | H B | ● | | ● | | | |
| | | Door-mounted (variable depth) | H P | ● | | ● | | | |
| | Toggle extension | | H A | — | | — | | | |
| | Mechanical interlock | Slide type | M S | ● | | ● | | | |
| | | Rear-connected type | M B | — | | — | | | |
| | | Link type | M L | ● | | ● | | | |
| | | Wire type | M W | ● | | ● | | | |
| | Toggle holder | | H H | ● | | ● | | | |
| | Toggle lock | | H L | ● | | ● | | | |
| | Terminal cover | For front-connected | C F | ● | | ● | | | |
| | | For rear-connected and plug-in | C R | ● | | ● | | | |
| | Terminal block for lead | | T F | ● | | ● | | | |
| | Door flange | | D F | ● | | ● | | | |
| CE marking | | | | Yes | | Yes | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | | Yes | | Yes | | | |
| Reverse connection | | | | Yes | | Yes | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available"

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊸ : For the extension bars, please place the order separately in parts.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3<br>4 | | | | | | | | | | | |

Toggle — Left pole / Right pole

Note: For auxiliary switches or alarm switches, left-hand mounting has priority.


# Outline dimensions (mm) S250-SN

## Front-connected





*For the extension bars, straight bars or spread bars can be supplied.

## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (Standard)




## Flush-mounted







# Switch-disconnectors

# PS250-NN

## Ratings and Specifications

| | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 225 | | 250 | | | |
| Type | | | | PS250-NN | | | | | |
| Number of poles | | | | 3 | 4 | 3 | 4 | | |
| ■ Ratings | | | | | | | | | |
| Rated current, A | | | | 225 | | 250 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | | 800 | | 800 | | | |
| Rated operational voltage V | | | AC | 690 | | 690 | | | |
| | | | DC | 250 | | 250 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | | 5 | | 5 | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | | 3.6 (1sec.) | | 3.6 (1sec.) | | | |
| ■ Performance | | | | | | | | | |
| Utilization category | | | AC | AC-23A | | AC-23A | | | |
| JIS C 8201-3 IEC 60947-3 | | | DC | DC-22A | | DC-22A | | | |
| Upstream breaker (OCPD) ㉙ | | | | PS250-PF | | PS250-PF | | | |
| Weight (◉ marked standard type) kg | | | | 1.5 | 2.0 | 1.5 | 2.0 | | |
| ■ Connections and Mountings | | | | | | | | | |
| Front-connected (FC) | | Terminal screws | | ◉ | | ◉ | | | |
| | | With extension bars | | ○ ㊸ | | ○ ㊸ | | | |
| Rear-connected (RC) | | Flat bar studs | | ○ | | ○ | | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | ○ ㊿ | | ○ ㊿ | | | |
| | | Standard (PMC) | | ○ | — | ○ | — | | |
| | For distribution boards (PMD) | | | — | | — | | | |
| Flush-mounted (FP) | | With flat bar studs | | ○ | | ○ | | | |
| Draw-out type (DR) | | | | ▲ | | ▲ | | | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — | | |
| DIN rail mount | | | | — | | — | | | |
| ■ Accessories (optional) | | | Symbol | | | | | | |
| Externally mounted | Motor operator | | M C | ● | | ● | | | |
| | External operating handle | Breaker-mounted | H B | ● | | ● | | | |
| | | Door-mounted (variable depth) | H P | ● | | ● | | | |
| | Toggle extension | | H A | — | | — | | | |
| | Mechanical interlock ⑨ | Slide type | M S | ● | | ● | | | |
| | | Rear-connected type | M B | — | | — | | | |
| | | Link type | M L | ● | | ● | | | |
| | | Wire type | M W | ● | | ● | | | |
| | Toggle holder | | H H | ● | | ● | | | |
| | Toggle lock | | H L | ● | | ● | | | |
| | Terminal cover | For front-connected | C F | ● | | ● | | | |
| | | For rear-connected and plug-in | C R | ● | | ● | | | |
| | Terminal block for lead | | T F | ● | | ● | | | |
| | Door flange | | D F | ● | | ● | | | |
| CE marking | | | | Yes | | Yes | | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | | Yes | | Yes | | | |
| Reverse connection | | | | Yes | | Yes | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"


⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊿ : A safety trip function is provided.

㊸ : For the extension bars, please place the order separately in parts.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS250-NN


## Front-connected





## Rear-connected





## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted







# Switch-disconnectors

# PS400-NN

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | | | | |
| Type | | | **PS400-NN** | | | | |
| Number of poles | | | 3 | 4 | | | |
| **■ Ratings** | | | | | | | |
| Rated current, A | | | 400 | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 800 | | | | |
| Rated operational voltage V | | AC | 690 | | | | |
| | | DC | 250 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | 7.6 | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | 5 (1sec.) | | | | |
| **■ Performance** | | | | | | | |
| Utilization category | | AC | AC-23A | | | | |
| JIS C 8201-3 IEC 60947-3 | | DC | DC-22A | | | | |
| Upstream breaker (OCPD) ㉙ | | | **PS400-NF** | | | | |
| Weight (◉ marked standard type) kg | | | 5.4 | 7.2 | | | |
| **■ Connections and Mountings** | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | | |
| | With extension bars | | ○ | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㊿ | | | | |
| | Standard (PMC) | | ○ | — | | | |
| For distribution boards (PMD) | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | |
| Draw-out type (DR) | | | ▲ | | | | |
| TemPlug70 (PG) | | | ○ | — | | | |
| DIN rail mount | | | — | | | | |
| **■ Accessories (optional)** | | Symbol | | | | | |
| Externally mounted: Motor operator | | M C | ● | | | | |
| Externally mounted: External operating handle | Breaker-mounted | H B | ● | | | | |
| | Door-mounted (variable depth) | H P | ● | | | | |
| Externally mounted: Toggle extension | | H A | ● | | | | |
| Externally mounted: Mechanical interlock ⑨ | Slide type | M S | ● | | | | |
| | Rear-connected type | M B | — | | | | |
| | Link type | M L | ● | | | | |
| | Wire type | M W | ● | | | | |
| Externally mounted: Toggle holder | | H H | ● | | | | |
| Externally mounted: Toggle lock | | H L | ● | | | | |
| Externally mounted: Terminal cover | For front-connected | C F | ● | | | | |
| | For rear-connected and plug-in | C R | ● | | | | |
| Externally mounted: Terminal block for lead | | T F | ● | | | | |
| Externally mounted: Door flange | | D F | ● | | | | |
| CE marking | | | Yes | | | | |
| Colour of cover | | | Grey Blue | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | |
| Suitability for isolation | | | Yes | | | | |
| Reverse connection | | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊿ : A safety trip function is provided.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS400-NN


## Front-connected





## Rear-connected





## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted



# Switch-disconnectors

# PS630-NN



## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 600 | | | | |
| Type | | | **PS630-NN** | | | | |
| Number of poles | | | 3 | 4 | | | |
| **■ Ratings** | | | | | | | |
| Rated current, A | | | 600 ⑦⑨ | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 800 | | | | |
| Rated operational voltage V | | AC | 690 | | | | |
| | | DC | 250 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | 13 | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | 7.6 (1sec.) | | | | |
| **■ Performance** | | | | | | | |
| Utilization category JIS C 8201-3 IEC 60947-3 | | AC | AC-23A(500A) AC-22A(600A) | | | | |
| | | DC | DC-22A | | | | |
| Upstream breaker (OCPD) ㉙ | | | **PS630-NF** | | | | |
| Weight (◉ marked standard type) kg | | | 5.7 | 7.7 | | | |
| **■ Connections and Mountings** | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | | | |
| | With extension bars | | ◉ | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㊿ | | | | |
| | Standard (PMC) | | ○ | — | | | |
| For distribution boards (PMD) | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | |
| Draw-out type (DR) | | | ▲ | | | | |
| TemPlug70 (PG) | | | ○ | — | | | |
| DIN rail mount | | | — | | | | |
| **■ Accessories (optional)** | | Symbol | | | | | |
| Externally mounted: Motor operator | | M C | ● | | | | |
| External operating handle | Breaker-mounted | H B | ● | | | | |
| | Door-mounted (variable depth) | H P | ● | | | | |
| Toggle extension | | H A | ● | | | | |
| Mechanical interlock ⑨ | Slide type | M S | ● | | | | |
| | Rear-connected type | M B | — | | | | |
| | Link type | M L | ● | | | | |
| | Wire type | M W | ● | | | | |
| Toggle holder | | H H | ● | | | | |
| Toggle lock | | H L | ● | | | | |
| Terminal cover | For front-connected | C F | ● | | | | |
| | For rear-connected and plug-in | C R | ● | | | | |
| Terminal block for lead | | T F | ● | | | | |
| Door flange | | D F | ● | | | | |
| CE marking | | | Yes | | | | |
| Colour of cover | | | Grey Blue | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | |
| Suitability for isolation | | | Yes | | | | |
| Reverse connection | | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊿ : A safety trip function is provided.

⑦⑨ : Plug-in type (PM), draw-out type (DR), and TemPlug70 (PG) are only rated current 500A.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3, 4 | | | | | | | | | | | |

Toggle — Left pole / Right pole


Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) PS630-NN


## Front-connected





## Rear-connected





## Plug-in (Standard)




## Plug-in (High-performance)




## Flush-mounted







# Switch-disconnectors

# S630-GN, S800-NN, S1000-NN

## Ratings and Specifications

| | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 600 | | 630 | | 800 | | 1000 | | |
| Type | | | S630-GN | | | | S800-NN | | S1000-NN | | |
| Number of poles | | | 3 | 4 | 3 | 4 | 3 | 4 | 3 | 4 | |
| **■ Ratings** | | | | | | | | | | | |
| Rated current, A | | | 600 | | 630 | | 800 | | 1000 | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | 690 | | 690 | | |
| Rated operational voltage V | | AC | 690 | | 690 | | 690 | | 690 | | |
| | | DC | 250 | | 250 | | 250 | | 250 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | | 8 | | |
| Rated short circuit making capacity 〔$I_{cm}$〕 kA peak | | | 17 | | 17 | | 17 | | 17 | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | 10 (0.3sec.) | | 10 (0.3sec.) | | 10 (0.3sec.) | | 10 (0.3sec.) | | |
| **■ Performance** | | | | | | | | | | | |
| Utilization category | | AC | AC-23A | | AC-23A | | AC-23A | | AC-23A | | |
| JIS C 8201-3 IEC 60947-3 | | DC | DC-22A | | DC-22A | | DC-22A | | DC-22A | | |
| Upstream breaker (OCPD) ㉙ | | | S630-NF | | S630-NF | | S800-NF | | S1000-CE | | |
| Weight (◉ marked standard type) kg | | | 8.0 | 11.0 | 8.0 | 11.0 | 8.5 | 11.5 | 10.4 | 14.0 | |
| **■ Connections and Mountings** | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | — | | — | | |
| | With extension bars | | ◉ | | ◉ | | ◉ | | ◉ | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㊶ | | ○ ㊶ | | ○ ㊶ | | — | | |
| | Standard (PMC) | | ○ | — | ○ | — | ○ | — | — | | |
| For distribution boards (PMD) | | | — | | — | | — | | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | | ○ | | |
| Draw-out type (DR) | | | ▲ | | ▲ | | ▲ | | — | | |
| TemPlug70 (PG) | | | ○ | — | ○ | — | — | | — | | |
| DIN rail mount | | | — | | — | | — | | — | | |
| **■ Accessories (optional)** | | Symbol | | | | | | | | | |
| Externally mounted | Motor operator | MC | ● | | ● | | ● | | ● | | |
| | External operating handle — Breaker-mounted | HB | ● | | ● | | ● | | ● | | |
| | External operating handle — Door-mounted (variable depth) | HP | ● | | ● | | ● | | ● | | |
| | Toggle extension | HA | ● | | ● | | ● | | ● | | |
| | Mechanical interlock ⑨ — Slide type | MS | ● | | ● | | ● | | ● | | |
| | Mechanical interlock ⑨ — Rear-connected type | MB | — | | — | | — | | — | | |
| | Mechanical interlock ⑨ — Link type | ML | ● | | ● | | ● | | ● | | |
| | Mechanical interlock ⑨ — Wire type | MW | ● | | ● | | ● | | ● | | |
| | Toggle holder | HH | ● | | ● | | ● | | ● | | |
| | Toggle lock | HL | | | | | | | | | |
| | Terminal cover — For front-connected | CF | ● | | ● | | ● | | ● | | |
| | Terminal cover — For rear-connected and plug-in | CR | ● | | ● | | ● | | ● | | |
| | Terminal block for lead | TF | ● | | ● | | ● | | ● | | |
| | Door flange | DF | ● | | ● | | ● | | ● | | |
| CE marking | | | Yes | | Yes | | Yes | | Yes | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | | |
| Suitability for isolation | | | Yes | | Yes | | Yes | | Yes | | |
| Reverse connection | | | Yes | | Yes | | Yes | | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊶ : A safety lock function is provided.


## Combinations of Internally Mounted Accessories (Optional)




Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) S630-GN, S800-NN, S1000-NN


## Front-connected




| | L1 | L2 | t1 | t2 | W |
|---|---|---|---|---|---|
| S630-GN | 32 | 34 | 8 | 8 | 40 |
| S800-NN | 32 | 35 | 10 | 10 | 40 |
| S1000-NN | 32 | 37 | 14 | 14 | 45 |


## Rear-connected

Outline drawing of S630-GN and S800-NN. See S1000-CE on page 7-75 for the outline drawing of S1000-NN.




Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout A (front view) Panel cutout B (front view)



Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Plug-in (Standard)

Outline drawing of S630-GN and S800-NN.





## Plug-in (High-performance)

Outline drawing of S630-GN and S800-NN.




## Flush-mounted

Outline drawing of S630-GN and S800-NN. See S1000-CE on page 7-75 for the outline drawing of S1000-NN.




Note: Studs are factory installed in horizontal direction both on the line and load sides.

# Switch-disconnectors

# S1250-NN



## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 1250 | | | | | |
| Type | | | **S1250-NN** | | | | | |
| Number of poles | | | 3 | 4 | | | | |
| **■ Ratings** | | | | | | | | |
| Rated current, A | | | 1250 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | | | |
| Rated operational voltage V | | AC | 690 | | | | | |
| | | DC | 250 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | 32 | | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | 15 (0.3sec.) | | | | | |
| **■ Performance** | | | | | | | | |
| Utilization category | | AC | AC-23A | | | | | |
| JIS C 8201-3 IEC 60947-3 | | DC | DC-22A | | | | | |
| Upstream breaker (OCPD) ㉙ | | | **S1250-NE** | | | | | |
| Weight (◉ marked standard type) kg | | | 18.2 | 23.4 | | | | |
| **■ Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | | | | |
| | With extension bars | | ◉ | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | | |
| | Standard (PMC) | | ○ | | | | | |
| For distribution boards (PMD) | | | — | | | | | |
| lush-mounted (FP) | With flat bar studs | | ○ | | | | | |
| Draw-out type (DR) | | | ▲ | | | | | |
| TemPlug70 (PG) | | | — | | | | | |
| DIN rail mount | | | — | | | | | |
| **■ Accessories (optional)** | | Symbol | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | | | | |
| Externally mounted: External operating handle | Breaker-mounted | H B | ● | | | | | |
| | Door-mounted (variable depth) | H P | ● | | | | | |
| Externally mounted: Toggle extension | | H A | ● ㉔ | | | | | |
| Externally mounted: Mechanical interlock ⑨ | Slide type | M S | ● | | | | | |
| | Rear-connected type | M B | ● | | | | | |
| | Link type | M L | — | | | | | |
| | Wire type | M W | ● | | | | | |
| Externally mounted: Toggle holder | | H H | ● | | | | | |
| Externally mounted: Toggle lock | | H L | | | | | | |
| Externally mounted: Terminal cover | For front-connected | C F | ● | | | | | |
| | For rear-connected and plug-in | C R | — | | | | | |
| Externally mounted: Terminal block for lead | | T F | ● | | | | | |
| Externally mounted: Door flange | | D F | ● | | | | | |
| CE marking | | | Yes | | | | | |
| Colour of cover | | | Grey Blue | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | | |
| Suitability for isolation | | | Yes | | | | | |
| Reverse connection | | | Yes | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

㉔ : One is supplied with every five breakers. Please specify if more are required.


㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) S1250-NN


## Front-connected




## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.





Panel cutout dimensions shown give an allowance of 1.5mm aroundthe handle escutcheon.

## Plug-in (Standard)




## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

# Switch-disconnectors

# S1600-NN



## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 1600 | | | | | |
| Type | | | **S1600-NN** | | | | | |
| Number of poles | | | 3 | 4 | | | | |
| **■ Ratings** | | | | | | | | |
| Rated current, A | | | 1600 | | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | | | |
| Rated operational voltage V | | AC | 690 | | | | | |
| | | DC | 250 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | 45 | | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | 20 (0.3sec.) | | | | | |
| **■ Performance** | | | | | | | | |
| Utilization category | | AC | AC-23A | | | | | |
| JIS C 8201-3 IEC 60947-3 | | DC | DC-22A | | | | | |
| Upstream breaker (OCPD) ㉙ | | | **S1600-NE** | | | | | |
| Weight (◉ marked standard type) kg | | | 24.9 | 32.9 | | | | |
| **■ Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | | | | |
| | With extension bars | | ○ | | | | | |
| Rear-connected (RC) | Flat bar studs | | ◉ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | | |
| | Standard (PMC) | | — | | | | | |
| For distribution boards (PMD) | | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | | |
| Draw-out type (DR) | | | ○ | | | | | |
| TemPlug70 (PG) | | | — | | | | | |
| DIN rail mount | | | — | | | | | |
| **■ Accessories (optional)** | | Symbol | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | | | | |
| Externally mounted: External operating handle | Breaker-mounted | H B | ● | | | | | |
| | Door-mounted (variable depth) | H P | ● | | | | | |
| Externally mounted: Toggle extension | | H A | ● ㉔ | | | | | |
| Externally mounted: Mechanical interlock ⑨ | Slide type | M S | ● | | | | | |
| | Rear-connected type | M B | ● | | | | | |
| | Link type | M L | — | | | | | |
| | Wire type | M W | ● | | | | | |
| Externally mounted: Toggle holder | | H H | ● | | | | | |
| Externally mounted: Toggle lock | | H L | | | | | | |
| Externally mounted: Terminal cover | For front-connected | C F | — | | | | | |
| | For rear-connected and plug-in | C R | — | | | | | |
| Externally mounted: Terminal block for lead | | T F | ● | | | | | |
| Externally mounted: Door flange | | D F | ● | | | | | |
| CE marking | | | Yes | | | | | |
| Colour of cover | | | Grey Blue | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | | |
| Suitability for isolation | | | Yes | | | | | |
| Reverse connection | | | Yes | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


▲ : Semi-standard. ● : "yes" or "available". — : "no" or "not available"

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

㉔ : One is supplied with every five breakers. Please specify if more are required.


㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

## Combinations of Internally Mounted Accessories (Optional)





# Outline dimensions (mm) S1600-NN

## Front-connected





## Rear-connected








Panel cutout dimensions shown give an allowance of 1.5mm aroundthe handle escutcheon.

## Draw-out




## Flush-mounted







# Non-automatic trip breakers

## XS2000NN

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 2000 | | | | |
| Type | | | **XS2000NN** | | | | |
| Number of poles | | | 3 | 4 | | | |
| ■ Ratings | | | | | | | |
| Rated current, A | | | 2000 | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | | |
| Rated operational voltage V | | AC | 690 | | | | |
| | | DC | 250 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | 90 | | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | 35 (0.3sec.) | | | | |
| ■ Performance | | | | | | | |
| Max switching current A | | AC | 12000 | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | DC | 5000 | | | | |
| IEC60947-2 | | | | | | | |
| Ann.L CBI-Y | | | | | | | |
| Endurance | Number of operating cycles with current | | 500 | | | | |
| | Number of operating cycles without current | | 2500 | | | | |
| Upstream breaker (OCPD) ㉙ | | | **XS2000NE** | | | | |
| Weight (◉ marked standard type) kg | | | 51.8 | 64.8 | | | |
| ■ Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | | | |
| | With extension bars | | ○ | | | | |
| Rear-connected (RC) | Flat bar studs | | ◉ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | |
| | Standard (PMC) | | — | | | | |
| For distribution boards (PMD) | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | |
| Draw-out type (DR) | | | ○ | | | | |
| TemPlug70 (PG) | | | — | | | | |
| DIN rail mount | | | — | | | | |
| ■ Accessories (optional) | | Symbol | | | | | |
| Externally mounted: Toggle extension | | H A | ● ② | | | | |
| Externally mounted: Mechanical interlock ⑨ | Rear-connected type | M B | ● | | | | |
| | Link type | M L | — | | | | |
| | Wire type | M W | — | | | | |
| Externally mounted: Terminal cover | For front-connected | C F | — | | | | |
| | For rear-connected and plug-in | C R | — | | | | |
| Externally mounted: Terminal block for lead | | T F | ● | | | | |
| Externally mounted: Door flange | | D F | ● | | | | |
| CE marking | | | Non | | | | |
| Colour of cover | | | Grey Blue | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | |
| Suitability for isolation | | | Yes | | | | |
| Reverse connection | | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available"


② : Supplied as standard.

⑨ : Mechanical interlocks cannot be applied to draw-out type (DR).

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊻ : Fixed depth, not adjustable.


## Combinations of Internally Mounted Accessories (Optional)





Note: With AC UVT, the UVT controller is externally mounted. See page 6-25.

# Outline dimensions (mm) XS2000NN


## Front-connected




## Rear-connected





Panel cutout B (front view)





Panel cutout dimensions shown give an allowance of 2mm aroundthe handle escutcheon.

## Draw-out




Contact TERASAKI if manual connection is required.

## Flush-mounted







# Non-automatic trip breakers

## XS2500NN, XS3200NN

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 2500 | | 3200 | | | |
| Type | | | XS2500NN | | XS3200NN | | | |
| Number of poles | | | 3 | 4 | 3 | | | |
| ■ Ratings | | | | | | | | |
| Rated current, A | | | 2500 | | 3200 | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | 690 | | | |
| Rated operational voltage V | | AC | 690 | | 690 | | | |
| | | DC | 250 | | 250 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | | |
| Rated short circuit making capacity〔$I_{cm}$〕 kA peak | | | 90 | | 90 | | | |
| Rated short time withstand current〔$I_{cw}$〕 kA | | | 35 (0.3sec.) | | 38 (0.5sec.) | | | |
| ■ Performance | | | | | | | | |
| Max switching current A | | AC | 15000 | | 15000 | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | DC | 6250 | | 6250 | | | |
| IEC60947-2 | | | | | | | | |
| Ann.L CBI-Y | | | | | | | | |
| Endurance | Number of operating cycles with current | | 500 | | 500 | | | |
| | Number of operating cycles without current | | 2500 | | 1500 | | | |
| Upstream breaker (OCPD) ㉙ | | | XS2500NE | | XS3200NE | | | |
| Weight (◉ marked standard type) kg | | | 60 | 75.7 | 60 | | | |
| ■ Connections and Mountings | | | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | — | | | |
| | With extension bars | | — | | — | | | |
| Rear-connected (RC) | Flat bar studs | | ◉ | | ◉ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | | |
| | Standard (PMC) | | — | | — | | | |
| For distribution boards (PMD) | | | — | | — | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | | |
| Draw-out type (DR) | | | — | | — | | | |
| TemPlug70 (PG) | | | — | | — | | | |
| DIN rail mount | | | — | | — | | | |
| ■ Accessories (optional) | | Symbol | | | | | | |
| Externally mounted: Toggle extension | | H A | ● ② | | ● ② | | | |
| Mechanical interlock | Rear-connected type | M B | ● | | ● | | | |
| | Link type | M L | — | | — | | | |
| | Wire type | M W | — | | — | | | |
| Terminal cover | For front-connected | C F | — | | — | | | |
| | For rear-connected and plug-in | C R | — | | — | | | |
| Terminal block for lead | | T F | ● | | ● | | | |
| Door flange | | D F | ● | | ● | | | |
| CE marking | | | Non | | Non | | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | | |
| Suitability for isolation | | | Yes | | Yes | | | |
| Reverse connection | | | Yes | | Yes | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


● : "yes" or "available". — : "no" or "not available"

② : Supplied as standard.

㉙ : Please use upstream breaker for overcurrent protection. Rated conditional short-circuit current [Icc] will be the same as Rated short-circuit breaking capacity of upstream breaker.

㊻ : Fixed depth, not adjustable.


## Combinations of Internally Mounted Accessories (Optional)





Note: With AC UVT, the UVT controller is externally mounted. See page 6-25.

## Outline dimensions (mm) XS250ONN, XS320ONN


### Rear-connected




Panel cutout B (front view)





Drilling plan (front view)





Panel cutout dimensions shown give an allowance of 2mm aroundthe handle escutcheon.


### Flush-mounted




Panel cutout (front view)




Drilling plan (front view)




Remark: XS3200NN is only available with 3 poles.



# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## PE50-NFZ, PS50-NFZ, PE125-NFZ

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 50 | 50 | 100 | 125 |
| Type | | | PE50-NFZ | PS50-NFZ | PE125-NFZ | |
| Number of poles ⑭⑮ | | | 3 | 3 | 3 | 3 |
| ■Ratings | | | | | | |
| Rated current, A | | | 15 | 15 | 60 | 125 |
| Calibrated at 40°C | | | 20 | 20 | 75 | |
| | | | 30 | 30 | 100 | |
| | | | 40 | 40 | | |
| | | | 50 | 50 | | |
| Rated operational voltage V | | | 100-440 common | 100-440 common | 100-440 common | 100-440 common |
| Applicable range V | | | 80 – 484 | 80 – 484 | 80 – 484 | 80 – 484 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | 6 | 6 | 6 |
| ■Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 2.5 | 7.5 | 10 | 10 |
| $I_{cu}$(sym) | | 415V | 2.5 | 7.5 | 10 | 10 |
| | | 240V | 7.5 | 15 | 30 | 30 |
| ■Earth leakage alarm specifications | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | Electronic | Electronic |
| Rated sensitivity current mA | | | 30/100/500 selectable | 30/100/500 selectable | 30/100/500 selectable | 30/100/500 selectable |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | 1c | 1c |
| Alarm reset function (manual reset) ㊴ | | | Push button | Push button | Push button | Push button |
| Weight (◉marked standard type) kg | | | 0.8 | 0.8 | 0.9 | 0.9 |
| ■Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ ㊺ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — |
| | Standard (PMC) | | — | — | — | — |
| For distribution boards (PMD) | | | — | — | — | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | | | — | — | — | — |
| TemPlug70 (PG) | | | — | — | — | — |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ |
| ■Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | — | — | — | — |
| External operating handle: Breaker-mounted | | H B | ● | ● | ● | ● |
| External operating handle: Door-mounted (variable depth) | | H P | ● | ● | ● | ● |
| Toggle extension | | H A | — | — | — | — |
| Mechanical interlock: Slide type | | M S | ● | ● | ● | ● |
| Mechanical interlock: Rear-connected type | | M B | — | — | — | — |
| Mechanical interlock: Link type | | M L | — | — | — | — |
| Mechanical interlock: Wire type | | M W | — | — | — | — |
| Toggle holder | | H H | ● | ● | ● | ● |
| Toggle lock | | H L | ● | ● | ● | ● |
| Terminal cover: For front-connected | | C F | ● | ● | ● | ● |
| Terminal cover: For rear-connected and plug-in | | C R | ● | ● | ● | ● |
| Terminal block for lead | | T F | ● | ● | ● | ● |
| Door flange | | D F | — | — | — | — |
| CE marking | | | Non | Non | Non | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Earth leakage indication | | | LED (Red) | LED (Red) | LED (Red) | LED (Red) |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes |
| Reverse connection | | | Non | Non | Non | Non |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑪ : Please order the DIN rail adapter separately. See page 6-152.

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.


⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.

㉚ : See page 6-22 for the contact rating.


㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts.


## Time/Current characteristic curves




## Ambient Compensating Curves





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm)

**PE50-NFZ, PS50-NFZ, PE125-NFZ**

## Front-connected




## Rear-connected (For leakage alarm lead wires, see the front-connected type)





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

Detail of connecting part


| Rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 3-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Panel cutout A (front view)



Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| Rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 3-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Please check the rear connected type for a detailed outline drawing of the terminals.


Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

## Earth leakage trip characteristic




Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAS125-SF

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | 125 | |
| Type | | | | ZAS125-SF | | | |
| Number of poles ⑭⑮ | | | | 3 | | 3 | |
| ■ Ratings | | | | | | | |
| Rated current, A | | | | 15 | 50 | 125 | |
| Calibrated at 40°C | | | | 20 | 60 | | |
| | | | | 30 | 75 | | |
| | | | | 40 | 100 | | |
| Rated operational voltage V | | | | 100-440 common | | 100-440 common | |
| Applicable range V | | | | 80 – 484 | | 80 – 484 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | |
| ■ Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.2 | | AC | 440V | 25 | | 25 | |
| $I_{cu}$(sym) | | | 415V | 30 | | 30 | |
| | | | 240V | 50 | | 50 | |
| ■ Earth leakage alarm specifications | | | | | | | |
| Earth leakage detection (Current operation type) | | | | Electronic | | Electronic | |
| Rated sensitivity current mA | | | | 100/200/500 selectable | | 100/200/500 selectable | |
| Max. operating time sec | | | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | |
| Earth leakage alarm output contact configuration ㉚ | | | | 1c | | 1c | |
| Alarm reset function (manual reset) ㊴ | | | | Push button ⑧ | | Push button ⑧ | |
| Weight (◉ marked standard type) kg | | | | 0.95 | | 0.95 | |
| ■ Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ ④ | | ◉ | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | |
| | Standard (PMC) | | | — | | — | |
| For distribution boards (PMD) | | | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | |
| Draw-out type (DR) | | | | — | | — | |
| TemPlug70 (PG) | | | | ○ | | ○ | |
| DIN rail mount | | | | ○ ⑪ | | ○ ⑪ | |
| ■ Accessories (optional) | | | Symbol | | | | |
| Externally mounted: Motor operator | | | M C | — | | — | |
| External operating handle: Breaker-mounted | | | H B | ● | | ● | |
| External operating handle: Door-mounted (variable depth) | | | H P | ● | | ● | |
| Toggle extension | | | H A | — | | — | |
| Mechanical interlock: Slide type | | | M S | ● | | ● | |
| Mechanical interlock: Rear-connected type | | | M B | — | | — | |
| Mechanical interlock: Link type | | | M L | — | | — | |
| Mechanical interlock: Wire type | | | M W | — | | — | |
| Toggle holder | | | H H | ● | | ● | |
| Toggle lock | | | H L | ● | | ● | |
| Terminal cover: For front-connected | | | C F | ● | | ● | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | ● | |
| Terminal block for lead | | | T F | ● | | ● | |
| Door flange | | | D F | — | | — | |
| CE marking | | | | Non | | Non | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | |
| Earth leakage indication | | | | LED (Red) | | LED (Red) | |
| Colour of cover | | | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | |
| Reverse connection | | | | Yes ⑫ | | Yes ⑫ | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


④ : 50A or less is the M5 wire clamping terminal. ⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating. ㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊸ : For the extension bars, please place the order separately in parts. ⑫ : There are some limitations. See page 5-23 for details.

## Time/Current characteristic curves


15-50A





60-125A




## Ambient Compensating Curves





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZAS125-SF

## Front-connected




## Rear-connected (For leakage alarm lead wires, see the front-connected type)





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.


| Rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Panel cutout A (front view)



Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| Rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |


Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

## Earth leakage trip characteristic




Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAS50-GF, ZAS100-GF

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 50 | | 100 | | |
| Type | | | | ZAS50-GF | | ZAS100-GF | | |
| Number of poles ⑭⑮ | | | | 3 | 4 | 3 | 4 | |
| ■ Ratings | | | | | | | | |
| Rated current, A | | | | 15 | 50 | 15 | 50 | |
| Calibrated at 40°C | | | | 20 | | 20 | 60 | |
| | | | | 30 | | 30 | 75 | |
| | | | | 40 | | 40 | 100 | |
| Rated operational voltage V | | | | 100-440 common | | 100-440 common | | |
| Applicable range V | | | | 80 – 484 | | 80 – 484 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | |
| ■ Rated breaking capacity, kA | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | | AC | 440V | 50 | | 50 | | |
| $I_{cu}$(sym) | | | 415V | 65 | | 65 | | |
| | | | 240V | 85 | | 85 | | |
| ■ Earth leakage alarm specifications | | | | | | | | |
| Earth leakage detection (Current operation type) | | | | Electronic | | Electronic | | |
| | Rated sensitivity current mA | | | 100/200/500 selectable | | 100/200/500 selectable | | |
| | Max. operating time sec | | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | | |
| Earth leakage alarm output contact configuration ㉚ | | | | 1c | | 1c | | |
| Alarm reset function (manual reset) ㊴ | | | | Push button ⑧ | | Push button ⑧ | | |
| Weight (◉ marked standard type) kg | | | | 1.3 | 1.7 | 1.3 | 1.7 | |
| ■ Connections and Mountings | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ | | ◉ | | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | | |
| | Standard (PMC) | | | — | | — | | |
| For distribution boards (PMD) | | | | — | | — | | |
| lush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | |
| Draw-out type (DR) | | | | — | | — | | |
| TemPlug70 (PG) | | | | ○ | — | ○ | — | |
| DIN rail mount | | | | ○ ⑪ | | ○ ⑪ | | |
| ■ Accessories (optional) | | | Symbol | | | | | |
| Externally mounted: Motor operator | | | M C | ● | | ● | | |
| External operating handle: Breaker-mounted | | | H B | ● | | ● | | |
| External operating handle: Door-mounted (variable depth) | | | H P | ● | | ● | | |
| Toggle extension | | | H A | — | | — | | |
| Mechanical interlock: Slide type | | | M S | ● | | ● | | |
| Mechanical interlock: Rear-connected type | | | M B | — | | — | | |
| Mechanical interlock: Link type | | | M L | — | | — | | |
| Mechanical interlock: Wire type | | | M W | — | | — | | |
| Toggle holder | | | H H | ● | | ● | | |
| Toggle lock | | | H L | ● | | ● | | |
| Terminal cover: For front-connected | | | C F | ● | | ● | | |
| Terminal cover: For rear-connected and plug-in | | | C R | ● | | ● | | |
| Terminal block for lead | | | T F | ● | | ● | | |
| Door flange | | | D F | — | | — | | |
| CE marking | | | | Non | | Non | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | Thermal-magnetic | | |
| Earth leakage indication | | | | LED (Red) | | LED (Red) | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | Yes | | |
| Reverse connection | | | | Yes | | Yes | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating. ㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊸ : For the extension bars, please place the order separately in parts.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Time/Current characteristic curves




## Ambient Compensating Curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZAS50-GF, ZAS100-GF

## Front-connected





## Rear-connected (For leakage alarm lead wires, see the front-connected type)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAS125-GF

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 125 | | | | | |
| Type | | | ZAS125-GF | | | | | |
| Number of poles ⑭⑮ | | | 3 | 4 | | | | |
| ■ Ratings | | | | | | | | |
| Rated current, A<br>Calibrated at 40°C | | | 125 | | | | | |
| Rated operational voltage V | | | 100-440 common | | | | | |
| Applicable range V | | | 80 – 484 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$(sym) | AC | 440V | 50 | | | | | |
| | | 415V | 65 | | | | | |
| | | 240V | 85 | | | | | |
| ■ Earth leakage alarm specifications | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | | | | | |
| Rated sensitivity current mA | | | 100/200/500 selectable | | | | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | | | | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | | | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | | | | | |
| Weight (◉ marked standard type) kg | | | 1.3 | 1.7 | | | | |
| ■ Connections and Mountings | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | | | |
| | With extension bars | | ○ ㊸ | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | | |
| | Standard (PMC) | | — | | | | | |
| For distribution boards (PMD) | | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | | |
| Draw-out type (DR) | | | — | | | | | |
| TemPlug70 (PG) | | | ○ | — | | | | |
| DIN rail mount | | | ○ ⑪ | | | | | |
| ■ Accessories (optional) | | Symbol | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | | | | |
| External operating handle: Breaker-mounted | | H B | ● | | | | | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | | | | | |
| Toggle extension | | H A | — | | | | | |
| Mechanical interlock: Slide type | | M S | ● | | | | | |
| Mechanical interlock: Rear-connected type | | M B | — | | | | | |
| Mechanical interlock: Link type | | M L | — | | | | | |
| Mechanical interlock: Wire type | | M W | — | | | | | |
| Toggle holder | | H H | ● | | | | | |
| Toggle lock | | H L | ● | | | | | |
| Terminal cover: For front-connected | | C F | ● | | | | | |
| Terminal cover: For rear-connected and plug-in | | C R | ● | | | | | |
| Terminal block for lead | | T F | ● | | | | | |
| Door flange | | D F | — | | | | | |
| CE marking | | | Non | | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | | | | |
| Earth leakage indication | | | LED (Red) | | | | | |
| Colour of cover | | | Grey Blue | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | | |
| Suitability for isolation | | | Yes | | | | | |
| Reverse connection | | | Yes | | | | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available".


⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating. ㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊸ : For the extension bars, please place the order separately in parts.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Time/Current characteristic curves




## Ambient Compensating Curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZAS125-GF

## Front-connected





## Rear-connected (For leakage alarm lead wires, see the front-connected type)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAE250-SF, ZAS250-SF

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 225 | 250 | 225 | 250 | |
| Type | | | ZAE250-SF | | ZAS250-SF | | |
| Number of poles ⑭⑮ | | | 3 | 3 | 3 | 3 | |
| ■Ratings | | | | | | | |
| Rated current, A | | | 125 200 | 250 | 125 200 | 250 | |
| Calibrated at 40°C | | | 150 225 | | 150 225 | | |
| | | | 175 | | 175 | | |
| Rated operational voltage V | | | 100-440 common | 100-440 common | 100-440 common | 100-440 common | |
| Applicable range V | | | 80 – 484 | 80 – 484 | 80 – 484 | 80 – 484 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | 8 | 8 | |
| ■Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 15 | 15 | 30 | 30 | |
| $I_{cu}$(sym) | | 415V | 25 | 25 | 40 | 40 | |
| | | 240V | 35 | 35 | 85 | 85 | |
| ■Earth leakage alarm specifications | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | Electronic | Electronic | |
| Rated sensitivity current mA | | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | 1c | 1c | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | Push button ⑧ | Push button ⑧ | Push button ⑧ | |
| Weight (◉ marked standard type) kg | | | 1.7 | 1.7 | 1.7 | 1.7 | |
| ■Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | ◉ | ◉ | |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — | |
| | Standard (PMC) | | — | — | — | — | |
| For distribution boards (PMD) | | | — | — | — | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ | |
| Draw-out type (DR) | | | — | — | — | — | |
| TemPlug70 (PG) | | | ○ | ○ | ○ | ○ | |
| DIN rail mount | | | — | — | — | — | |
| ■Accessories (optional) | | Symbol | | | | | |
| Externally mounted: Motor operator | | M C | ● | ● | ● | ● | |
| External operating handle: Breaker-mounted | | H B | ● | ● | ● | ● | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | ● | ● | ● | |
| Toggle extension | | H A | — | — | — | — | |
| Mechanical interlock: Slide type | | M S | ● | ● | ● | ● | |
| Mechanical interlock: Rear-connected type | | M B | — | — | — | — | |
| Mechanical interlock: Link type | | M L | — | — | — | — | |
| Mechanical interlock: Wire type | | M W | — | — | — | — | |
| Toggle holder | | H H | ● | ● | ● | ● | |
| Toggle lock | | H L | ● | ● | ● | ● | |
| Terminal cover: For front-connected | | C F | ● | ● | ● | ● | |
| Terminal cover: For rear-connected and plug-in | | C R | ● | ● | ● | ● | |
| Terminal block for lead | | T F | ● | ● | ● | ● | |
| Door flange | | D F | — | — | — | — | |
| CE marking | | | Non | Non | Non | Non | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | |
| Earth leakage indication | | | LED (Red) | LED (Red) | LED (Red) | LED (Red) | |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | |
| Reverse connection | | | Yes | Yes | Yes | Yes | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating. ㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊸ : For the extension bars, please place the order separately in parts.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Time/Current characteristic curves




## Ambient Compensating Curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZAE250-SF, ZAS250-SF

## Front-connected





*For the extension bars, straight bars or spread bars can be supplied.

## Rear-connected (For leakage alarm lead wires, see the front-connected type)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)




## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAS225-GF

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 225 | | | | | |
| Type | | | ZAS225-GF | | | | | |
| Number of poles ⑭⑮ | | | 3 | 4 | | | | |
| ■ Ratings | | | | | | | | |
| Rated current, A | | | 125 | 200 | | | | |
| Calibrated at 40°C | | | 150 | 225 | | | | |
| | | | 175 | | | | | |
| Rated operational voltage V | | | 100-440 common | | | | | |
| Applicable range V | | | 80 – 484 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 50 | | | | | |
| $I_{cu}$(sym) | | 415V | 65 | | | | | |
| | | 240V | 85 | | | | | |
| ■ Earth leakage alarm specifications | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | | | | | |
| Rated sensitivity current mA | | | 100/200/500 selectable | | | | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | | | | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | | | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | | | | | |
| Weight (◉ marked standard type) kg | | | 1.7 | 2.1 | | | | |
| ■ Connections and Mountings | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | | | |
| | With extension bars | | ○ ㊸ | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | | |
| | Standard (PMC) | | — | | | | | |
| For distribution boards (PMD) | | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | | |
| Draw-out type (DR) | | | — | | | | | |
| TemPlug70 (PG) | | | ○ | — | | | | |
| DIN rail mount | | | — | | | | | |
| ■ Accessories (optional) | | Symbol | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | | | | |
| External operating handle: Breaker-mounted | | H B | ● | | | | | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | | | | | |
| Toggle extension | | H A | — | | | | | |
| Mechanical interlock: Slide type | | M S | ● | | | | | |
| Mechanical interlock: Rear-connected type | | M B | — | | | | | |
| Mechanical interlock: Link type | | M L | — | | | | | |
| Mechanical interlock: Wire type | | M W | — | | | | | |
| Toggle holder | | H H | ● | | | | | |
| Toggle lock | | H L | ● | | | | | |
| Terminal cover: For front-connected | | C F | ● | | | | | |
| Terminal cover: For rear-connected and plug-in | | C R | ● | | | | | |
| Terminal block for lead | | T F | ● | | | | | |
| Door flange | | D F | — | | | | | |
| CE marking | | | Non | | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | | | | |
| Earth leakage indication | | | LED (Red) | | | | | |
| Colour of cover | | | Grey Blue | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | | |
| Suitability for isolation | | | Yes | | | | | |
| Reverse connection | | | Yes | | | | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating. ㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊸ : For the extension bars, please place the order separately in parts.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Time/Current characteristic curves




## Ambient Compensating Curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZAS225-GF

## Front-connected





*Spread extension bars for 3 poles. Staraight extension bars for 4 poles.

## Rear-connected (For leakage alarm lead wires, see the front-connected type)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAS250-GF

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 250 | | | | | |
| Type | | | ZAS250-GF | | | | | |
| Number of poles ⑭⑮ | | | 3 | 4 | | | | |
| ■ Ratings | | | | | | | | |
| Rated current, A<br>Calibrated at 40°C | | | 250 | | | | | |
| Rated operational voltage V | | | 100-440 common | | | | | |
| Applicable range V | | | 80 – 484 | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | | |
| ■ Rated breaking capacity, kA | | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$(sym) | AC | 440V | 50 | | | | | |
| | | 415V | 65 | | | | | |
| | | 240V | 85 | | | | | |
| ■ Earth leakage alarm specifications | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | | | | | |
| Rated sensitivity current mA | | | 100/200/500 selectable | | | | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | | | | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | | | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | | | | | |
| Weight (◉ marked standard type) kg | | | 1.7 | 2.1 | | | | |
| ■ Connections and Mountings | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | | | |
| | With extension bars | | ○ ㊸ | | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | | |
| | Standard (PMC) | | — | | | | | |
| For distribution boards (PMD) | | | — | | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | | |
| Draw-out type (DR) | | | — | | | | | |
| TemPlug70 (PG) | | | ○ | — | | | | |
| DIN rail mount | | | — | | | | | |
| ■ Accessories (optional) | | Symbol | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | | | | |
| External operating handle: Breaker-mounted | | H B | ● | | | | | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | | | | | |
| Toggle extension | | H A | — | | | | | |
| Mechanical interlock: Slide type | | M S | ● | | | | | |
| Mechanical interlock: Rear-connected type | | M B | — | | | | | |
| Mechanical interlock: Link type | | M L | — | | | | | |
| Mechanical interlock: Wire type | | M W | — | | | | | |
| Toggle holder | | H H | ● | | | | | |
| Toggle lock | | H L | ● | | | | | |
| Terminal cover: For front-connected | | C F | ● | | | | | |
| Terminal cover: For rear-connected and plug-in | | C R | ● | | | | | |
| Terminal block for lead | | T F | ● | | | | | |
| Door flange | | D F | — | | | | | |
| CE marking | | | Non | | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | | | | |
| Earth leakage indication | | | LED (Red) | | | | | |
| Colour of cover | | | Grey Blue | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | | |
| Suitability for isolation | | | Yes | | | | | |
| Reverse connection | | | Yes | | | | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating. ㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state. ㊸ : For the extension bars, please place the order separately in parts.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Time/Current characteristic curves




## Ambient Compensating Curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZAS250-GF

## Front-connected





*Spread extension bars for 3 poles. Staraight extension bars for 4 poles.

## Rear-connected (For leakage alarm lead wires, see the front-connected type)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAE400-NF, ZAS400-NF, ZAS400-GF

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | | 400 | | 400 | |
| Type | | | ZAE400-NF | | ZAS400-NF | | ZAS400-GF | |
| Number of poles ⑭⑮ | | | 3 | | 3 | 4 | 3 | 4 |
| ■Ratings | | | | | | | | |
| Rated current, A | | | 250 | 400 | 250 | 400 | 250 | 400 |
| Calibrated at 40°C | | | 300 | | 300 | | 300 | |
| | | | 350 | | 350 | | 350 | |
| Rated operational voltage V | | | 100-440 common | | 100-440 common | | 100-440 common | |
| Applicable range V | | | 80 – 484 | | 80 – 484 | | 80 – 484 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | |
| ■Rated breaking capacity, kA | | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 22 | | 45 | | 65 | |
| $I_{cu}$(sym) | | 415V | 25 | | 50 | | 70 | |
| | | 240V | 35 | | 85 | | 100 | |
| ■Earth leakage alarm specifications | | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | | Electronic | | Electronic | |
| Rated sensitivity current mA | | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | | 1c | | 1c | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | | Push button ⑧ | | Push button ⑧ | |
| Weight (◉ marked standard type) kg | | | 5.2 | | 5.2 | 6.6 | 5.2 | 6.6 |
| ■Connections and Mountings | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | | ◉ | |
| | With extension bars | | ○ | | ○ | | ○ | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | — | |
| | Standard (PMC) | | — | | — | | — | |
| For distribution boards (PMD) | | | — | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | — | | — | | — | |
| TemPlug70 (PG) | | | ○ | | ○ | — | ○ | — |
| DIN rail mount | | | — | | — | | — | |
| ■Accessories (optional) | | Symbol | | | | | | |
| Externally mounted: Motor operator | | M C | ● | | ● | | ● | |
| External operating handle: Breaker-mounted | | H B | ● | | ● | | ● | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | | ● | | ● | |
| Toggle extension | | H A | ● | | ● | | ● | |
| Mechanical interlock | Slide type | M S | ● | | ● | | ● | |
| | Rear-connected type | M B | — | | — | | — | |
| | Link type | M L | — | | — | | — | |
| | Wire type | M W | — | | — | | — | |
| Toggle holder | | H H | ● | | ● | | ● | |
| Toggle lock | | H L | | | | | | |
| Terminal cover | For front-connected | C F | ● | | ● | | ● | |
| | For rear-connected and plug-in | C R | ● | | ● | | ● | |
| Terminal block for lead | | T F | ● | | ● | | ● | |
| Door flange | | D F | — | | — | | — | |
| CE marking | | | Non | | Non | | Non | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | |
| Earth leakage indication | | | LED (Red) | | LED (Red) | | LED (Red) | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | Yes | | Yes | | Yes | |
| Reverse connection | | | Yes | | Yes | | Yes | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.


○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating.


㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

## Time/Current characteristic curves ZAS400-NF, ZAS400-GF




## Ambient Compensating Curves




## Magnetic trip pick-up current

| Rated current | Magnetic trip pick-up current (adjustable range) (A) | | | | | | |
|---|---|---|---|---|---|---|---|
| (A) | $I_n$ × 12 | 11 | 10 | 9 | 8 | 7 | 6 |
| 250 | 3000 | 2750 | 2500 | 2250 | 2000 | 1750 | 1500 |
| 300 | 3600 | 3300 | 3000 | 2700 | 2400 | 2100 | 1800 |
| 350 | 4200 | 3850 | 3500 | 3150 | 2800 | 2450 | 2100 |
| 400 | 4800 | 4400 | 4000 | 3600 | 3200 | 2800 | 2400 |


Notes (1) : Setting tolerance: ±20%.

(2) : **ZAE400-NF** type is a single point fixed setting of 10 times the rated current. Setting tolerance: ±10%.

(3) : The Time/Current characteristic curve is for adjustable instantaneous trip.

Remark (1) : If the model is adjustable and unless otherwise stated when ordering, the scale is factory set to ×12.

## Earth leakage trip characteristic




Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX | AL | SH | MG | AX AL SH | MG AX SH | MG AX AL SH | TL |
|---|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | Shunt trip | Megger measurement switch | | | | Test lead |
| 3 4 | | | | | | | | |

Toggle — Left pole / Right pole


Note: Shunt trip is mounted at the factory.

# Outline dimensions (mm) ZAE400-NF, ZAS400-NF, ZAS400-GF

## Front-connected





## Rear-connected (For leakage alarm lead wires, see the front-connected type)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit




## Time/Current characteristic curves ZAE400-NF





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAS630-CF, ZAS630-NF

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 600 | 630 | 600 | 630 |
| Type | | | ZAS630-CF | | ZAS630-NF | |
| Number of poles ⑭⑮ | | | 3 | 3 | 3 | 3 |
| ■ Ratings | | | | | | |
| Rated current, A | | | 500 | 630 | 500 | 630 |
| Calibrated at 40°C | | | 600 | | 600 | |
| Rated operational voltage V | | | 100-440 common | 100-440 common | 100-440 common | 100-440 common |
| Applicable range V | | | 80 – 484 | 80 – 484 | 80 – 484 | 80 – 484 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | 8 | 8 |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 30 | 30 | 45 | 45 |
| $I_{cu}$(sym) | | 415V | 36 | 36 | 50 | 50 |
| | | 240V | 50 | 50 | 85 | 85 |
| ■ Earth leakage alarm specifications | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | Electronic | Electronic |
| Rated sensitivity current mA | | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | 1c | 1c |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | Push button ⑧ | Push button ⑧ | Push button ⑧ |
| Weight (◉ marked standard type) kg | | | 10.0 | 10.0 | 10.0 | 10.0 |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | — | — | — | — |
| | With extension bars | | ◉ | ◉ | ◉ | ◉ |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — |
| | Standard (PMC) | | — | — | — | — |
| For distribution boards (PMD) | | | — | — | — | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | | | — | — | — | — |
| TemPlug70 (PG) | | | ○ | ○ | ○ | ○ |
| DIN rail mount | | | — | — | — | — |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | ● | ● | ● | ● |
| External operating handle: Breaker-mounted | | H B | ● | ● | ● | ● |
| External operating handle: Door-mounted (variable depth) | | H P | ● | ● | ● | ● |
| Toggle extension | | H A | ● | ● | ● | ● |
| Mechanical interlock: Slide type | | M S | ● | ● | ● | ● |
| Mechanical interlock: Rear-connected type | | M B | — | — | — | — |
| Mechanical interlock: Link type | | M L | — | — | — | — |
| Mechanical interlock: Wire type | | M W | — | — | — | — |
| Toggle holder | | H H | ● | ● | ● | ● |
| Toggle lock | | H L | ● | ● | ● | ● |
| Terminal cover: For front-connected | | C F | ● | ● | ● | ● |
| Terminal cover: For rear-connected and plug-in | | C R | ● | ● | ● | ● |
| Terminal block for lead | | T F | ● | ● | ● | ● |
| Door flange | | D F | — | — | — | — |
| CE marking | | | Non | Non | Non | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) |
| Earth leakage indication | | | LED (Red) | LED (Red) | LED (Red) | LED (Red) |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes |
| Reverse connection | | | Yes | Yes | Yes | Yes |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.


○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating.


㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

## Time/Current characteristic curves




## Ambient Compensating Curves





## Magnetic trip pick-up current

| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) $I_n \times$ 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|
| 500 | 5000 | 4500 | 4000 | 3500 | 3000 | 2500 |
| 600 | 6000 | 5400 | 4800 | 4200 | 3600 | 3000 |
| 630 | 6300 | 5670 | 5040 | 4410 | 3780 | 3150 |

**Note (1) : Setting tolerance: ±20%.**

**Remark (1) : Unless otherwise stated when ordering, the selector dial is factory set to position "10".**

## Earth leakage trip characteristic




Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX | AL | SH | MG | AX AL SH | MG AX SH | MG AX AL SH | TL |
|---|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | Shunt trip | Megger measurement switch | | | | Test lead |
| 3 | | | | | | | | |


Toggle — Left pole / Right pole

Note: Shunt trip is mounted at the factory.


# Outline dimensions (mm) ZAS630-CF, ZAS630-NF

## Front-connected






Drilling plan (front view)





## Rear-connected




(Bottom view)





Drilling plan (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted








Drilling plan (front view)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Circuit Breaker with earth leakage alarm

## ZAS800-CF, ZAS800-NF

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 800 | 800 | | |
| Type | | | ZAS800-CF | ZAS800-NF | | |
| Number of poles ⑭⑮ | | | 3 | 3 | | |
| ■ Ratings | | | | | | |
| Rated current, A | | | 700 | 700 | | |
| Calibrated at 40°C | | | 800 | 800 | | |
| Rated operational voltage V | | | 100-440 common | 100-440 common | | |
| Applicable range V | | | 80 – 484 | 80 – 484 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 30 | 45 | | |
| $I_{cu}$(sym) | | 415V | 36 | 50 | | |
| | | 240V | 50 | 85 | | |
| ■ Earth leakage alarm specifications | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | | |
| Rated sensitivity current mA | | | 100/200/500 selectable | 100/200/500 selectable | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | Push button ⑧ | | |
| Weight (◉ marked standard type) kg | | | 11.0 | 11.0 | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | — | — | | |
| | With extension bars | | ◉ | ◉ | | |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | | |
| | Standard (PMC) | | — | — | | |
| For distribution boards (PMD) | | | — | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | | |
| Draw-out type (DR) | | | — | — | | |
| TemPlug70 (PG) | | | — | — | | |
| DIN rail mount | | | — | — | | |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | ● | ● | | |
| External operating handle: Breaker-mounted | | H B | ● | ● | | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | ● | | |
| Toggle extension | | H A | ● | ● | | |
| Mechanical interlock | Slide type | M S | ● | ● | | |
| | Rear-connected type | M B | — | — | | |
| | Link type | M L | — | — | | |
| | Wire type | M W | — | — | | |
| Toggle holder | | H H | ● | ● | | |
| Toggle lock | | H L | ● | ● | | |
| Terminal cover | For front-connected | C F | ● | ● | | |
| | For rear-connected and plug-in | C R | ● | ● | | |
| Terminal block for lead | | T F | ● | ● | | |
| Door flange | | D F | — | — | | |
| CE marking | | | Non | Non | | |
| Overcurrent trip mechanism | | | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | | |
| Earth leakage indication | | | LED (Red) | LED (Red) | | |
| Colour of cover | | | Grey Blue | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | | |
| Suitability for isolation | | | Yes | Yes | | |
| Reverse connection | | | Yes | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


● : "yes" or "available". — : "no" or "not available".

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉚ : See page 6-22 for the contact rating.


㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

## Time/Current characteristic curves




## Ambient Compensating Curves





## Magnetic trip pick-up current

| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) $I_n \times$ 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|
| 700 | 7000 | 6300 | 5600 | 4900 | 4200 | 3500 |
| 800 | 8000 | 7200 | 6400 | 5600 | 4800 | 4000 |

**Note (1) : Setting tolerance: ±20%.**

**Remark (1) : Unless otherwise stated when ordering, the selector dial is factory set to position "10".**

## Earth leakage trip characteristic




Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX | AL | SH | MG | AX AL SH | MG AX SH | MG AX AL SH | TL |
|---|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | Shunt trip | Megger measurement switch | | | | Test lead |
| 3 | | | | | | | | |


Toggle — Left pole / Right pole

Note: Shunt trip is mounted at the factory.


# Outline dimensions (mm) ZAS800-CF, ZAS800-NF

## Front-connected






Drilling plan (front view)





## Rear-connected




(Bottom view)





Drilling plan (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted








Drilling plan (front view)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions

## Circuit Breaker with earth leakage alarm for distribution boards and control boards

## TB50KSL

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 50 | | | |
| Type | | | TB50KSL | | | |
| Number of poles | | | 2 | | | |
| ■ Ratings | | | | | | |
| Rated current, A | | | 15 50 | | | |
| Calibrated at 40°C | | | 20 | | | |
| | | | 30 | | | |
| | | | 40 | | | |
| Rated operational voltage V | | | 100-240 common | | | |
| Applicable range V | | | 80 – 264 | | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 415V | — | | | |
| $I_{cu}$(sym) | | 200V | 5 (240V) | | | |
| | | 100/200V | — | | | |
| | | 100V | 5 | | | |
| ■ Earth leakage alarm specifications | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | | | |
| Instantaneous tripping type | Rated sensitivity current mA | | 30/100 selectable | | | |
| | Max. operating time sec | | 0.1 | | | |
| Earth leakage alarm output contact configuration | | | — ㊱ | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button | | | |
| Weight (◉ marked standard type) kg | | | 0.3 | | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | | | |
| Rear-connected (RC) | | | — | | | |
| Flush-mounted (FP) | | | — | | | |
| DIN rail mount | | | ○ ㊷ | | | |
| Clip-in chassis mount | | | ◉ | | | |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Toggle holder | | H H | ● | | | |
| Externally mounted: Toggle lock | | H L | — | | | |
| Externally mounted: Terminal cover For front-connected | | C F | ● | | | |
| Externally mounted: Terminal block for lead | | T F | ● | | | |
| CE marking | | | Non | | | |
| Overcurrent trip mechanism | | | Hydraulic-magnetic type | | | |
| Earth leakage indication | | | LED (Red) | | | |
| Colour of cover | | | Grey | | | |
| Trip button (Colour) | | | Yes (Red) | | | |
| Reverse connection | | | Non | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


㊱ : The earth leakage alarm of TB50KSL type is LED indication only.

㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.


㊺ : A wire clamping terminal is provided.

㊷ : Please order the DIN rail mounting bracket separately. (Order type: 50EE-RAIL, 1 set per unit)


## Time/Current characteristic curves




## Ambient Compensating Curves




## Earth leakage trip characteristic




## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | MG<br>Megger measurement switch ■ | AX<br>AL | MG<br>AL |
|---|---|---|---|---|---|
| 2 | | | | | |


Toggle — Left pole / Right pole


Note: If the Megger test switch is mounted, the auxiliary switch cannot be mounted.


℄ : Handle Centre Line

## Outline dimensions (mm) TB50KSL













Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Drilling plan




Clip-in Chassis, part number TDB-50SG (optional)
(12-pieces snap-off chassis)





NOTE: 1.Clip-in chassis is notched between every two pieces to adjust number of pieces to number of breaker poles. (Bend once or twice to snap off.)

2.Screw clip-in chassis down at 4 or 5 pole intervals.

## Control circuit





# 7 Characteristics and Outline Dimensions

## Circuit Breaker with earth leakage alarm for distribution boards and control boards

## TB50KSZ, TB100KSZ

## Ratings and Specifications

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | 50 | 100 | |
| Type | | TB50KSZ | TB100KSZ | |
| Number of poles ⑭⑮ | | 3 | 3 | |
| ■ Ratings | | | | |
| Rated current, A | | 15 50 | 60 | |
| Calibrated at 40°C | | 20 | 75 | |
| | | 30 | 100 | |
| | | 40 | | |
| Rated operational voltage V | | 200-415 common | 200-415 common | |
| Applicable range V | | 160–484 | 160–484 | |
| ■ Rated breaking capacity, kA | | | | |
| JIS C 8201-2-1 Ann.2 | AC 415V | 2.5 | 2.5 | |
| $I_{cu}$(sym) | 200V | 5 | 5 | |
| | 100/200V | 5 | 5 | |
| | 100V | — | — | |
| ■ Earth leakage alarm specifications | | | | |
| Earth leakage detection (Current operation type) | | Electronic | Electronic | |
| Rated sensitivity current mA | | 30/100/500 selectable | 30/100/500 selectable | |
| Max. operating time sec | | 0.1 | 0.1 | |
| Earth leakage alarm output contact configuration ㉚ | | 1c | 1c | |
| Alarm reset function (manual reset) ㊴ | | Push button ㉞ | Push button ㉞ | |
| Weight (◉ marked standard type) kg | | 0.5 | 0.6 | |
| ■ Connections and Mountings | | | | |
| Front-connected (FC) Terminal screws | | ◉ ㊺ | ◉ | |
| Rear-connected (RC) | | — | — | |
| Flush-mounted (FP) | | — | — | |
| DIN rail mount | | ○ ㊷ | ○ ㊷ | |
| Clip-in chassis mount | | ◉ | ◉ | |
| ■ Accessories (optional) | Symbol | | | |
| Externally mounted: Toggle holder | H H | ● | ● | |
| Toggle lock | H L | — | — | |
| Terminal cover For front-connected | C F | ● | ● | |
| Terminal block for lead | T F | ● | ● | |
| CE marking | | Non | Non | |
| Overcurrent trip mechanism | | Hydraulic-magnetic type | Hydraulic-magnetic type | |
| Earth leakage indication | | LED (Red) | LED (Red) | |
| Colour of cover | | Grey | Grey | |
| Trip button (Colour) | | Yes (Red) | Yes (Red) | |
| Reverse connection | | Non | Non | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.

⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.

㉚ : See page 6-22 for the contact rating.


㉞ : Optional lead wire draw-in for remote reset available on request. Please specify "with MRA" when ordering. The external switch should be a self-resetting a-contact (NO) switch (for 24V DC 10mA microload circuit), and do not apply voltage.

㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.


㊺ : A wire clamping terminal is provided.

㊷ : Please order the DIN rail mounting bracket separately. (Order type: 50EE-RAIL, 1 set per unit)


## Time/Current characteristic curves





## Ambient Compensating Curves




## Earth leakage trip characteristic





## Combinations of Internally Mounted Accessories (Optional)





Note: AL SH can be mounted simultaneously as an option.
If the Megger test switch is mounted, the auxiliary switch cannot be mounted.

## Outline dimensions (mm) TB50KSZ, TB100KSZ





## Drilling plan




NOTE: 1.Clip-in chassis is notched between every two pieces to adjust number of pieces to number of breaker poles. (Bend once or twice to snap off.)

2.Screw clip-in chassis down at 4 or 5 pole intervals.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm

## NAE125-SF, NAS125-SF

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | 100 | | 125 | 100 | | 125 |
| Type | | NAE125-SF | | | NAS125-SF | | |
| Number of poles / Elements | | 3P3E ⑩ | | 3P3E ⑩ | 3P3E ⑩ | | 3P3E ⑩ |
| Phase and wires | | 1ø3W | | 1ø3W | 1ø3W | | 1ø3W |
| **■ Ratings** | | | | | | | |
| Rated current, A | | 15 | 50 | 125 | 15 | 50 | 125 |
| Calibrated at 40° C | | 20 | 60 | | 20 | 60 | |
| | | 30 | 75 | | 30 | 75 | |
| | | 40 | 100 | | 40 | 100 | |
| Rated operational voltage AC V | | 100/200 | | 100/200 | 100/200 | | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | 8 | | 8 | 8 | | 8 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | 135 | | 135 | 135 | | 135 |
| | Rated non-operating overvoltage AC V | 120 | | 120 | 120 | | 120 |
| | Rated overvoltage operating time (sec) | 1 or less | | 1 or less | 1 or less | | 1 or less |
| **■ Rated breaking capacity, kA** | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) AC 100/200V | | 35 | | 35 | 50 | | 50 |
| Weight (◉ marked standard type) kg | | 1.15 | | 1.15 | 1.15 | | 1.15 |
| **■ Earth leakage alarm specifications** | | | | | | | |
| Earth leakage detection (Current operation type) | | Electronic | | Electronic | Electronic | | Electronic |
| Rated sensitivity current mA | | 30/100/500 selectable | | 30/100/500 selectable | 30/100/500 selectable | | 30/100/500 selectable |
| | | 100/200/500 selectable | | 100/200/500 selectable | 100/200/500 selectable | | 100/200/500 selectable |
| Max. operating time sec | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable |
| Earth leakage alarm output contact configuration ㉚ | | 1c | | 1c | 1c | | 1c |
| Alarm reset function (manual reset) ㊴ | | Push button ⑧ | | Push button ⑧ | Push button ⑧ | | Push button ⑧ |
| Earth leakage indication | | LED (Red) | | LED (Red) | LED (Red) | | LED (Red) |
| **■ Connections and Mountings** | | | | | | | |
| Front-connected (FC) | Terminal screws | ◉ ④ | | ◉ | ◉ ④ | | ◉ |
| | With extension bars | ○ ㊸ | | ○ ㊸ | ○ ㊸ | | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | △ | | △ | △ | | △ |
| **■ Accessories (optional)** | | **Symbol** | | | | | |
| Externally mounted: Motor operator | | M C | | — | — | | — |
| External operating handle: Breaker-mounted | | H B | | ● | ● | | ● |
| External operating handle: Door-mounted (variable depth) | | H P | | ● | ● | | ● |
| Toggle extension | | H A | | — | — | | — |
| Mechanical interlock: Slide type | | M S | | — | — | | — |
| Mechanical interlock: Link type | | M L | | — | — | | — |
| Mechanical interlock: Wire type | | M W | | — | — | | — |
| Toggle holder | | H H | | ● | ● | | ● |
| Toggle lock | | H L | | ● | ● | | ● |
| Terminal cover: For front-connected | | C F | | ● | ● | | ● |
| Terminal cover: For rear-connected | | C R | | ● | ● | | ● |
| Terminal block for lead | | T F | | ● | ● | | ● |
| Door flange | | D F | | — | — | | — |
| CE marking | | | | Non | Non | | Non |
| Overcurrent trip mechanism | | | | Thermal-magnetic | Thermal-magnetic | | Thermal-magnetic |
| Colour of cover | | | | Grey Blue | Grey Blue | | Grey Blue |
| Trip button (Colour) | | | | Yes (Red) | Yes (Red) | | Yes (Red) |
| Suitability for isolation | | | | Yes | Yes | | Yes |
| Reverse power flow circuit | | | | Yes ㉕ | Yes ㉕ | | Yes ㉕ |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

④ : 50A or less is the M5 wire clamping terminal.

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details.

⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.

㉚ : See page 6-22 for the contact rating.


㊴ : Distribution board branch conductors and busbar conductor supports are available. (Optional)An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

㊸ : For the extension bars, please place the order separately in parts.


㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

## Time/Current characteristic curves


**15-50A**





**60-125A**




## Ambient Compensating Curves





## Combinations of Internally Mounted Accessories (Optional)




## Outline dimensions (mm) NAE125-SF, NAS125-SF

### Front-connected





Preparation of conductor





Note 1) Side unit terminal screws M3.5
2) Tightening torque of M3.5 terminal screws: 0.9 to 1.2Nm
3) Connectable wire: 2.0mm² (max.)
4) Overvoltage detection terminal block connection length: 30m (max.)

Drilling plan (front view)





Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.





### Earth leakage trip characteristic




Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

### Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm

## NAE250-SF, NAS250-SF

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | 225 | | 250 | 225 | | 250 |
| Type | | NAE250-SF | | | NAS250-SF | | |
| Number of poles / Elements | | 3P3E ⑩ | | 3P3E ⑩ | 3P3E ⑩ | | 3P3E ⑩ |
| Phase and wires | | 1ø3W | | 1ø3W | 1ø3W | | 1ø3W |
| **■ Ratings** | | | | | | | |
| Rated current, A | | 125 | 225 | 250 | 125 | 225 | 250 |
| Calibrated at 40° C | | 150 | | | 150 | | |
| | | 175 | | | 175 | | |
| | | 200 | | | 200 | | |
| Rated operational voltage AC V | | 100/200 | | 100/200 | 100/200 | | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | 8 | | 8 | 8 | | 8 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | 135 | | 135 | 135 | | 135 |
| | Rated non-operating overvoltage AC V | 120 | | 120 | 120 | | 120 |
| | Rated overvoltage operating time (sec) | 1 or less | | 1 or less | 1 or less | | 1 or less |
| **■ Rated breaking capacity, kA** | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) AC 100/200V | | 35 | | 35 | 85 | | 85 |
| Weight (◉ marked standard type) kg | | 1.8 | | 1.8 | 1.8 | | 1.8 |
| **■ Earth leakage alarm specifications** | | | | | | | |
| Earth leakage detection (Current operation type) | | Electronic | | Electronic | Electronic | | Electronic |
| Rated sensitivity current mA | | 30/100/500 selectable | | 30/100/500 selectable | 30/100/500 selectable | | 30/100/500 selectable |
| | | 100/200/500 selectable | | 100/200/500 selectable | 100/200/500 selectable | | 100/200/500 selectable |
| Max. operating time sec | | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | | 0.1/0.45/1.0 selectable |
| Earth leakage alarm output contact configuration ㉚ | | 1c | | 1c | 1c | | 1c |
| Alarm reset function (manual reset) ㊴ | | Push button ⑧ | | Push button ⑧ | Push button ⑧ | | Push button ⑧ |
| Earth leakage indication | | LED (Red) | | LED (Red) | LED (Red) | | LED (Red) |
| **■ Connections and Mountings** | | | | | | | |
| Front-connected (FC) | Terminal screws | ◉ | | ◉ | ◉ | | ◉ |
| | With extension bars | ○ ㊸ | | ○ ㊸ | ○ ㊸ | | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | △ | | △ | △ | | △ |
| **■ Accessories (optional)** | | Symbol | | | | | |
| Externally mounted: Motor operator | | M C | ● | ● | ● | ● | ● |
| External operating handle: Breaker-mounted | | H B | ● | ● | ● | ● | ● |
| External operating handle: Door-mounted (variable depth) | | H P | ● | ● | ● | ● | ● |
| Toggle extension | | H A | — | — | — | — | — |
| Mechanical interlock: Slide type | | M S | — | — | — | — | — |
| Mechanical interlock: Link type | | M L | — | — | — | — | — |
| Mechanical interlock: Wire type | | M W | — | — | — | — | — |
| Toggle holder | | H H | ● | ● | ● | ● | ● |
| Toggle lock | | H L | ● | ● | ● | ● | ● |
| Terminal cover | For front-connected | C F | ● | ● | ● | ● | ● |
| | For rear-connected | C R | ● | ● | ● | ● | ● |
| Terminal block for lead | | T F | ● | ● | ● | ● | ● |
| Door flange | | D F | — | — | — | — | — |
| CE marking | | | Non | Non | Non | Non | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | Yes |
| Reverse power flow circuit | | | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details.

⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.


㉚ : See page 6-22 for the contact rating.

㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.


㊸ : For the extension bars, please place the order separately in parts.

㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.


## Time/Current characteristic curves




## Ambient Compensating Curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)





# Outline dimensions (mm) NAE250-SF, NAS250-SF

## Front-connected





Preparation of conductor








Note 1) Side unit terminal screws M3.5
2) Tightening torque of M3.5 terminal screws: 0.9 to 1.2Nm
3) Connectable wire: 2.0mm² (max.)
4) Overvoltage detection terminal block connection length: 30m (max.)

Drilling plan (front view)





Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm

## NAE400-NF, NAS400-NF

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | 400 | | |
| Type | | | **NAE400-NF** | **NAS400-NF** | | |
| Number of poles / Elements | | | 3P2E ⑱ | 3P2E ⑱ | | |
| Phase and wires | | | 1ø3W | 1ø3W | | |
| **■ Ratings** | | | | | | |
| Rated current, A | | | 250 | 250 | | |
| Calibrated at 40° C | | | 300 | 300 | | |
| | | | 350 | 350 | | |
| | | | 400 | 400 | | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | | |
| | Rated non-operating overvoltage AC V | | 120 | 120 | | |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | | |
| **■ Rated breaking capacity, kA** | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 35 | 85 | | |
| Weight (◉ marked standard type) kg | | | 4.9 | 4.9 | | |
| **■ Earth leakage alarm specifications** | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | Electronic | | |
| Rated sensitivity current mA | | | 30/100/500 selectable | 30/100/500 selectable | | |
| | | | 100/200/500 selectable | 100/200/500 selectable | | |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable | 0.1/0.45/1.0 selectable | | |
| Earth leakage alarm output contact configuration ㉚ | | | 1c | 1c | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | Push button ⑧ | | |
| Earth leakage indication | | | LED (Red) | LED (Red) | | |
| **■ Connections and Mountings** | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | | |
| | With extension bars | | ○ | ○ | | |
| Rear-connected (RC) | Flat bar studs | | △ | △ | | |
| **■ Accessories (optional)** | | Symbol | | | | |
| Externally mounted | Motor operator | M C | ● | ● | | |
| | External operating handle — Breaker-mounted | H B | ● | ● | | |
| | External operating handle — Door-mounted (variable depth) | H P | ● | ● | | |
| | Toggle extension | H A | ● | ● | | |
| | Mechanical interlock — Slide type | M S | — | — | | |
| | Mechanical interlock — Link type | M L | — | — | | |
| | Mechanical interlock — Wire type | M W | — | — | | |
| | Toggle holder | H H | ● | ● | | |
| | Toggle lock | H L | | | | |
| | Terminal cover — For front-connected | C F | ● | ● | | |
| | Terminal cover — For rear-connected | C R | ● | ● | | |
| | Terminal block for lead | T F | ● | ● | | |
| | Door flange | D F | — | — | | |
| CE marking | | | Non | Non | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic (adjustable) | | |
| Colour of cover | | | Grey Blue | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | | |
| Suitability for isolation | | | Yes | Yes | | |
| Reverse power flow circuit | | | Yes ㉕ | Yes ㉕ | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details.


⑱ : Do not apply to circuits where overcurrent flows in the neutral wire.

㉚ : See page 6-22 for the contact rating.


㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

## Time/Current characteristic curves NAS400-NF




## Ambient Compensating Curves




## Magnetic trip pick-up current

| Rated current (A) | $I_n$ × | Magnetic trip pick-up current (adjustable range) (A) 12 | 11 | 10 | 9 | 8 | 7 | 6 |
|---|---|---|---|---|---|---|---|---|
| 250 | | 3000 | 2750 | 2500 | 2250 | 2000 | 1750 | 1500 |
| 300 | | 3600 | 3300 | 3000 | 2700 | 2400 | 2100 | 1800 |
| 350 | | 4200 | 3850 | 3500 | 3150 | 2800 | 2450 | 2100 |
| 400 | | 4800 | 4400 | 4000 | 3600 | 3200 | 2800 | 2400 |


Notes (1) : Setting tolerance: ±20%.

(2) : **NAE400-NF** type is a single point fixed setting of 10 times the rated current. Setting tolerance: ±10%.

(3) : The Time/Current characteristic curve is for adjustable instantaneous trip.


Remark (1) : If the model is adjustable and unless otherwise stated when ordering, the scale is factory set to ×12.

## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) NAE400-NF, NAS400-NF

## Front-connected





Note 1) Side unit terminal screws M3.5
2) Tightening torque of M3.5 terminal screws: 0.9 to 1.2Nm
3) Connectable wire: 2.0mm² (max.)
4) Overvoltage detection terminal block connection length: 30m (max.)

Drilling plan (front view)





Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Single phase 3-wire circuit breakers with neutral phase open protection characteristics


The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Control circuit




## Time/Current characteristic curves NAE400-NF





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection

## PE50-NFN, PE125-NFN

## Ratings and Specifications

| | | | | | |
|---|---|---|---|---|---|
| Frame size (A) | | | 50 | 100 | 125 |
| Type | | | PE50-NFN | PE125-NFN | |
| Number of poles / Elements | | | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ |
| Phase and wires | | | 1ø3W | 1ø3W | 1ø3W |
| ■Ratings | | | | | |
| Rated current, A | | | 15 | 60 | 125 |
| Calibrated at 40° C | | | 20 | 75 | |
| | | | 30 | 100 | |
| | | | 40 | | |
| | | | 50 | | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | 6 | 6 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | 135 |
| | Rated non-operating overvoltage AC V | | 120 | 120 | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | 1 or less |
| ■Rated breaking capacity, kA | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 10 | 25 | 25 |
| Weight (◉ marked standard type) kg | | | 0.8 | 0.8 | 0.8 |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | △ | △ | △ |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ |
| ■Accessories (optional) | | Symbol | | | |
| Externally mounted | Motor operator | M C | — | — | — |
| | External operating handle: Breaker-mounted | H B | ● | ● | ● |
| | External operating handle: Door-mounted (variable depth) | H P | ● | ● | ● |
| | Toggle extension | H A | — | — | — |
| | Mechanical interlock: Slide type | M S | ● | ● | ● |
| | Mechanical interlock: Link type | M L | — | — | — |
| | Mechanical interlock: Wire type | M W | — | — | — |
| | Toggle holder | H H | ● | ● | ● |
| | Toggle lock | H L | ● | ● | ● |
| | Terminal cover: For front-connected | C F | ● | ● | ● |
| | Terminal cover: For rear-connected | C R | ● | ● | ● |
| | Terminal block for lead | T F | ● | ● | ● |
| | Door flange | D F | — | — | — |
| CE marking | | | Non | Non | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Overvoltage operation indication function | | | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes |
| Reverse power flow circuit | | | Non | Non | Non |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.
⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
㊺ : A wire clamping terminal is provided.
㊸ : For the extension bars, please place the order separately in parts.


**Remarks:**

(1): This circuit breaker is designed for single-phase 3-wire 100/200V circuits only.
(2): Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.
(3): Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.
(4): Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.
(5): Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.
(6): The test button checks the overvoltage operation.


## Time/Current characteristic curves




## Ambient Compensating Curves





## Combinations of Internally Mounted Accessories (Optional)




## Outline dimensions (mm) PE50-NFN, PE125-NFN

### Front-connected





### Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




### Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection

## NS125-SF

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | 125 | | |
| Type | | | NS125-SF | | | |
| Number of poles / Elements | | | 3P3E ⑩ | 3P3E ⑩ | | |
| Phase and wires | | | 1ø3W | 1ø3W | | |
| ■Ratings | | | | | | |
| Rated current, A | | | 15 50 | 125 | | |
| Calibrated at 40° C | | | 20 60 | | | |
| | | | 30 75 | | | |
| | | | 40 100 | | | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | | |
| | Rated non-operating overvoltage AC V | | 120 | 120 | | |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | | |
| ■Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 50 | 50 | | |
| Weight (◉ marked standard type) kg | | | 0.95 | 0.95 | | |
| ■Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ④ | ◉ | | |
| | With extension bars | | ○ ⑬ | ○ ⑬ | | |
| Rear-connected (RC) | Flat bar studs | | △ | △ | | |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | | |
| ■Accessories (optional) | | Symbol | | | | |
| Externally mounted | Motor operator | M C | — | — | | |
| | External operating handle: Breaker-mounted | H B | ● | ● | | |
| | External operating handle: Door-mounted (variable depth) | H P | ● | ● | | |
| | Toggle extension | H A | — | — | | |
| | Mechanical interlock: Slide type | M S | ● | ● | | |
| | Mechanical interlock: Link type | M L | — | — | | |
| | Mechanical interlock: Wire type | MW | — | — | | |
| | Toggle holder | H H | ● | ● | | |
| | Toggle lock | H L | ● | ● | | |
| | Terminal cover: For front-connected | C F | ● | ● | | |
| | Terminal cover: For rear-connected | C R | ● | ● | | |
| | Terminal block for lead | T F | ● | ● | | |
| | Door flange | D F | — | — | | |
| CE marking | | | Non | Non | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | | |
| Overvoltage operation indication function | | | Mechanical button | Mechanical button | | |
| Colour of cover | | | Grey Blue | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | | |
| Suitability for isolation | | | Yes | Yes | | |
| Reverse power flow circuit | | | Yes ⑭ | Yes ⑭ | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.
④ : 50A or less is the M5 wire clamping terminal.
⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑬ : For the extension bars, please place the order separately in parts.
⑭ : Since the overvoltage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

**Remarks:**


(1): This circuit breaker is designed for single-phase 3-wire 100/200V circuits only.
(2): Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.
(3): Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.
(4): Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.
(5): Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.
(6): The test button checks the overvoltage operation.

## Time/Current characteristic curves


**15-50A**





**60-125A**




## Ambient Compensating Curves





## Combinations of Internally Mounted Accessories (Optional)




## Outline dimensions (mm) NS125-SF

### Front-connected





### Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




### Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection

## NE250-SF, NS250-SF

## Ratings and Specifications

| Frame size (A) | | | 225 | 250 | 225 | 250 |
|---|---|---|---|---|---|---|
| Type | | | NE250-SF | | NS250-SF | |
| Number of poles / Elements | | | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ | 3P3E ⑩ |
| Phase and wires | | | 1ø3W | 1ø3W | 1ø3W | 1ø3W |
| ■Ratings | | | | | | |
| Rated current, A | | | 125 225 | 250 | 125 225 | 250 |
| Calibrated at 40° C | | | 150 | | 150 | |
| | | | 175 | | 175 | |
| | | | 200 | | 200 | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | 100/200 | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | 8 | 8 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | 135 | 135 |
| | Rated non-operating overvoltage AC V | | 120 | 120 | 120 | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | 1 or less | 1 or less |
| ■Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 35 | 35 | 85 | 85 |
| Weight (◉ marked standard type) kg | | | 1.6 | 1.6 | 1.6 | 1.6 |
| ■Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | △ | △ | △ | △ |
| DIN rail mount | | | — | — | — | — |
| ■Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | ● | ● | ● | ● |
| External operating handle: Breaker-mounted | | H B | ● | ● | ● | ● |
| External operating handle: Door-mounted (variable depth) | | H P | ● | ● | ● | ● |
| Toggle extension | | H A | — | — | — | — |
| Mechanical interlock: Slide type | | M S | ● | ● | ● | ● |
| Mechanical interlock: Link type | | M L | — | — | — | — |
| Mechanical interlock: Wire type | | M W | — | — | — | — |
| Toggle holder | | H H | ● | ● | ● | ● |
| Toggle lock | | H L | ● | ● | ● | ● |
| Terminal cover: For front-connected | | C F | ● | ● | ● | ● |
| Terminal cover: For rear-connected | | C R | ● | ● | ● | ● |
| Terminal block for lead | | T F | ● | ● | ● | ● |
| Door flange | | D F | — | — | — | — |
| CE marking | | | Non | Non | Non | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Overvoltage operation indication function | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes |
| Reverse power flow circuit | | | Yes ㉔ | Yes ㉔ | Yes ㉔ | Yes ㉔ |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.

㊸ : For the extension bars, please place the order separately in parts.

㉔ : Since the overvoltage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

**Remarks:**

(1): This circuit breaker is designed for single-phase 3-wire 100/200V circuits only.

(2): Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.


(3): Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.

(4): Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.


(5): Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.

(6): The test button checks the overvoltage operation.

## Time/Current characteristic curves





## Ambient Compensating Curves





## Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.






## Combinations of Internally Mounted Accessories (Optional)




## Outline dimensions (mm) NE250-SF, NS250-SF

### Front-connected








*For the extension bars, straight bars or spread bars can be supplied.




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection

## NE400-NF, NS400-NF

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | 400 | | | |
| Type | | | NE400-NF | NS400-NF | | | |
| Number of poles / Elements | | | 3P2E ⑱ | 3P2E ⑱ | | | |
| Phase and wires | | | 1ø3W | 1ø3W | | | |
| ■Ratings | | | | | | | |
| Rated current, A | | | 250 | 250 | | | |
| Calibrated at 40° C | | | 300 | 300 | | | |
| | | | 350 | 350 | | | |
| | | | 400 | 400 | | | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | | | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | | | |
| | Rated non-operating overvoltage AC V | | 120 | 120 | | | |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | | | |
| ■Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 35 | 85 | | | |
| Weight (◉ marked standard type) kg | | | 4.8 | 4.8 | | | |
| ■Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | | | |
| | With extension bars | | ○ | ○ | | | |
| Rear-connected (RC) | Flat bar studs | | △ | △ | | | |
| DIN rail mount | | | — | — | | | |
| ■Accessories (optional) | | Symbol | | | | | |
| Externally mounted: Motor operator | | M C | ● | ● | | | |
| External operating handle: Breaker-mounted | | H B | ● | ● | | | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | ● | | | |
| Toggle extension | | H A | ● | ● | | | |
| Mechanical interlock: Slide type | | M S | ● | ● | | | |
| Mechanical interlock: Link type | | M L | — | — | | | |
| Mechanical interlock: Wire type | | M W | — | — | | | |
| Toggle holder | | H H | ● | ● | | | |
| Toggle lock | | H L | | | | | |
| Terminal cover: For front-connected | | C F | ● | ● | | | |
| Terminal cover: For rear-connected | | C R | ● | ● | | | |
| Terminal block for lead | | T F | ● | ● | | | |
| Door flange | | D F | — | — | | | |
| CE marking | | | Non | Non | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | | | |
| Overvoltage operation indication function | | | Mechanical button | Mechanical button | | | |
| Colour of cover | | | Grey Blue | Grey Blue | | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | | | |
| Suitability for isolation | | | Yes | Yes | | | |
| Reverse power flow circuit | | | Yes ⑭ | Yes ⑭ | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑱ : Do not apply to circuits where overcurrent flows in the neutral wire.

⑭ : Since the overvoltage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

**Remarks:**

(1): This circuit breaker is designed for single-phase 3-wire 100/200V circuits only.

(2): Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.


(3): Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.

(4): Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.


(5): Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.

(6): The test button checks the overvoltage operation.

## Time/Current characteristic curves NS400-NF




## Ambient Compensating Curves




## Magnetic trip pick-up current

| Rated current (A) | $I_n$× | Magnetic trip pick-up current (adjustable range) (A) 12 | 11 | 10 | 9 | 8 | 7 | 6 |
|---|---|---|---|---|---|---|---|---|
| 250 | | 3000 | 2750 | 2500 | 2250 | 2000 | 1750 | 1500 |
| 300 | | 3600 | 3300 | 3000 | 2700 | 2400 | 2100 | 1800 |
| 350 | | 4200 | 3850 | 3500 | 3150 | 2800 | 2450 | 2100 |
| 400 | | 4800 | 4400 | 4000 | 3600 | 3200 | 2800 | 2400 |


Notes (1) : Setting tolerance: ±20%.

(2) : **NE400-NF** type is a single point fixed setting of 10 times the rated current. Setting tolerance: ±10%.

(3) : The Time/Current characteristic curve is for adjustable instantaneous trip.


Remark (1) : If the model is adjustable and unless otherwise stated when ordering, the scale is factory set to ×12.

## Combinations of Internally Mounted Accessories (Optional)





## Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Outline dimensions (mm) NE400-NF, NS400-NF

### Front-connected





Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Control circuit




## Time/Current characteristic curves NE400-NF





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection

## NS630-NF

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 600 | 630 | | |
| Type | | | NS630-NF | | | |
| Number of poles / Elements | | | 3P2E ⑱ | 3P2E ⑱ | | |
| Phase and wires | | | 1ø3W | 1ø3W | | |
| ■Ratings | | | | | | |
| Rated current, A | | | 500 | 630 | | |
| Calibrated at 40° C | | | 600 | | | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | | |
| | Rated non-operating overvoltage AC V | | 120 | 120 | | |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | | |
| ■Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 85 | 85 | | |
| Weight (◉ marked standard type) kg | | | 10.0 | 10.0 | | |
| ■Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | — | — | | |
| | With extension bars | | ◉ | ◉ | | |
| Rear-connected (RC) | Flat bar studs | | △ | △ | | |
| DIN rail mount | | | — | — | | |
| ■Accessories (optional) | | Symbol | | | | |
| Externally mounted | Motor operator | M C | ● | ● | | |
| | External operating handle: Breaker-mounted | H B | ● | ● | | |
| | External operating handle: Door-mounted (variable depth) | H P | ● | ● | | |
| | Toggle extension | H A | ● | ● | | |
| | Mechanical interlock: Slide type | M S | ● | ● | | |
| | Mechanical interlock: Link type | M L | — | — | | |
| | Mechanical interlock: Wire type | M W | — | — | | |
| | Toggle holder | H H | ● | ● | | |
| | Toggle lock | H L | | | | |
| | Terminal cover: For front-connected | C F | ● | ● | | |
| | Terminal cover: For rear-connected | C R | ● | ● | | |
| | Terminal block for lead | T F | ● | ● | | |
| | Door flange | D F | — | — | | |
| CE marking | | | Non | Non | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | | |
| Overvoltage operation indication function | | | Mechanical button | Mechanical button | | |
| Colour of cover | | | Grey Blue | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | | |
| Suitability for isolation | | | Yes | Yes | | |
| Reverse power flow circuit | | | Yes ⑭ | Yes ⑭ | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑱ : Do not apply to circuits where overcurrent flows in the neutral wire.

⑭ : Since the overvoltage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

**Remarks:**

(1): This circuit breaker is designed for single-phase 3-wire 100/200V circuits only.

(2): Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.


(3): Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.

(4): Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.


(5): Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.

(6): The test button checks the overvoltage operation.

## Time/Current characteristic curves




## Ambient Compensating Curves





## Magnetic trip pick-up current

| Rated current (A) | $I_n$ × | Magnetic trip pick-up current (adjustable range) (A) 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|---|
| 500 | | 5000 | 4500 | 4000 | 3500 | 3000 | 2500 |
| 600 | | 6000 | 5400 | 4800 | 4200 | 3600 | 3000 |
| 630 | | 6300 | 5670 | 5040 | 4410 | 3780 | 3150 |

**Note (1) : Setting tolerance: ±20%.**


**Remark (1) : Unless otherwise stated when ordering, the selector dial is factory set to position "10".**

## Combinations of Internally Mounted Accessories (Optional)





## Single phase 3-wire circuit breakers with neutral phase open protection characteristics


The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Outline dimensions (mm) NS630-NF

### Front-connected





Drilling plan (front view)





Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire circuit breakers with neutral phase open protection

## NS800-NF

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 800 | | | |
| Type | | | NS800-NF | | | |
| Number of poles / Elements | | | 3P2E ⑱ | | | |
| Phase and wires | | | 1ø3W | | | |
| ■ Ratings | | | | | | |
| Rated current, A | | | 700 | | | |
| Calibrated at 40° C | | | 800 | | | |
| Rated operational voltage AC V | | | 100/200 | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | | | |
| | Rated non-operating overvoltage AC V | | 120 | | | |
| | Rated overvoltage operating time (sec) | | 1 or less | | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 85 | | | |
| Weight (◉ marked standard type) kg | | | 11.0 | | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | — | | | |
| | With extension bars | | ◉ | | | |
| Rear-connected (RC) | Flat bar studs | | △ | | | |
| DIN rail mount | | | — | | | |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | ● | | | |
| External operating handle | Breaker-mounted | H B | ● | | | |
| | Door-mounted (variable depth) | H P | ● | | | |
| Toggle extension | | H A | ● | | | |
| Mechanical interlock | Slide type | M S | ● | | | |
| | Link type | M L | — | | | |
| | Wire type | M W | — | | | |
| Toggle holder | | H H | ● | | | |
| Toggle lock | | H L | | | | |
| Terminal cover | For front-connected | C F | ● | | | |
| | For rear-connected | C R | ● | | | |
| Terminal block for lead | | T F | ● | | | |
| Door flange | | D F | — | | | |
| CE marking | | | Non | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | | |
| Overvoltage operation indication function | | | Mechanical button | | | |
| Colour of cover | | | Grey Blue | | | |
| Trip button (Colour) | | | Yes (Red) | | | |
| Suitability for isolation | | | Yes | | | |
| Reverse power flow circuit | | | Yes ⑭ | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

⑱ : Do not apply to circuits where overcurrent flows in the neutral wire.

⑭ : Since the overvoltage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

**Remarks:**

(1): This circuit breaker is designed for single-phase 3-wire 100/200V circuits only.

(2): Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.


(3): Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.

(4): Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.


(5): Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.

(6): The test button checks the overvoltage operation.

## Time/Current characteristic curves




## Ambient Compensating Curves





## Magnetic trip pick-up current

| Rated current (A) | $I_n$ × | Magnetic trip pick-up current (adjustable range) (A) 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|---|
| 700 | | 7000 | 6300 | 5600 | 4900 | 4200 | 3500 |
| 800 | | 8000 | 7200 | 6400 | 5600 | 4800 | 4000 |

**Note (1) : Setting tolerance: ±20%.**


**Remark (1) : Unless otherwise stated when ordering, the selector dial is factory set to position "10".**

## Combinations of Internally Mounted Accessories (Optional)





## Single phase 3-wire circuit breakers with neutral phase open protection characteristics


The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Outline dimensions (mm) NS800-NF

### Front-connected





Drilling plan (front view)





Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Control circuit





# 7 Characteristics and Outline Dimensions

## Circuit Breaker for distribution boards

## TB-5S

### Ratings and Specifications

| Category | | | Compatibility circuit breaker | | |
|---|---|---|---|---|---|
| Frame size (A) | | | 50 | | |
| Type | | | TB-5S | | |
| Number of poles | | | 1 | 2 | 3 |
| ■ Ratings | | | | | |
| Rated current, A | | | 10 | 30 | |
| Calibrated at 40°C | | | 15 | 40 | |
| 45°C | | | 20 | 50 | |
| Rated operational voltage V | AC | | 240 | 415 | 415 |
| | DC | | 125 | 125 | — |
| ■ Rated breaking capacity, kA | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 415 V | — | 2.5 | 2.5 |
| $I_{cu}$ (sym) | | 240 V | 2.5 | 5 | — |
| | | 200 V | 2.5 | 5 | 5 |
| | | 100 / 200 V | — | — | — |
| | | 100 V | 5 | — | — |
| | DC | 110 V | 1 | 5 | — |
| NK | AC | 250 V | — | 5 ㊹ | — |
| (sym) | | 125 V | — | 42 | — |
| | DC | 125 V | — | 5 | — |
| Weight kg | | | 0.16 | 0.34 | 0.5 |
| ■ Connections | | | | | |
| Front-connected type on both line side and load side | | | ● ㊺ | | |
| Line side plug-in type, load side front-connected type | | | — | | |
| Plug-in type on both line side and load side | | | — | | |
| ■ Mountings (optional) | | | | | |
| Clip-in chassis | | | ● | | |
| Mounting base for single-row installation | | | — | | |
| Mounting base for branched-into-dual-rows | | | — | | |
| ■ Accessories (optional) | | Symbol | | | |
| Externally mounted: Toggle holder | | HH | ● | | |
| Externally mounted: Toggle lock | | HL | ● | — | |
| Externally mounted: Toggle cap | | HC | ● | — | |
| CE marking | | | Non | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | |
| Colour of cover | | | Black | | |
| Reverse connection | | | Yes | | |


**Notes:**

● : "yes" or "available". — : "no" or "not available".


㊹ : 2.5kA for 10A.

㊺ : A wire clamping terminal is provided.


### Time/Current characteristic curves





### Ambient Compensating Curves




## Outline dimensions (mm) TB-5S








Preparation of conductor





(t=4mm max.)

## Clip and Clip-in chassis Outline dimensions (mm)




NOTE: Clips A are supplied with breakers, 2 pieces/pole. For multi-pole installation, clip-to-clip distance is 25mm.

Clip-in Chassis, part number TDB-50SG
(12-pieces snap-off chassis)




NOTE: 1.Clip-in chassis is notched between every two pieces to adjust number of pieces to number of breaker poles. (Bend once or twice to snap off.)

2.Screw clip-in chassis down at 4 or 5 pole intervals.




# 7 Characteristics and Outline Dimensions

## Circuit Breaker for distribution boards

## TB-5P

### Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Category | | | Line side Plug-in | | | | |
| Frame size (A) | | | 50 | | | | |
| Type | | | **TB-5P** | | | | |
| Number of poles | | | 2 | | | | |
| **■ Ratings** | | | | | | | |
| Rated current, A | | | 10 | 30 | | | |
| Calibrated at 40°C | | | 15 | 40 | | | |
| 45°C | | | 20 | 50 | | | |
| Rated operational voltage V | AC | | 415 | | | | |
| | DC | | 125 | | | | |
| **■ Rated breaking capacity, kA** | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 415 V | 2.5 | | | | |
| $I_{cu}$ (sym) | | 240 V | 5 | | | | |
| | | 200 V | 5 | | | | |
| | | 100 / 200 V | — | | | | |
| | | 100 V | — | | | | |
| | DC | 110 V | 5 | | | | |
| NK | AC | 250 V | 5 ㊹ | | | | |
| (sym) | | 125 V | 42 | | | | |
| | DC | 125 V | 5 | | | | |
| Weight kg | | | 0.28 | | | | |
| **■ Connections** | | | | | | | |
| Front-connected type on both line side and load side | | | — | | | | |
| Line side plug-in type, load side front-connected type | | | ● | | | | |
| Plug-in type on both line side and load side | | | — | | | | |
| **■ Mountings (optional)** | | | | | | | |
| Clip-in chassis | | | — | | | | |
| Mounting base for single-row installation | | | ● ㊼ | | | | |
| Mounting base for branched-into-dual-rows | | | ● ㊼ | | | | |
| **■ Accessories (optional)** | | | **Symbol** | | | | |
| Externally mounted: Toggle holder | | | HH | ● | | | |
| Toggle lock | | | HL | — | | | |
| Toggle cap | | | HC | — | | | |
| CE marking | | | | Non | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | |
| Colour of cover | | | | Black | | | |
| Reverse connection | | | | Yes | | | |


**Notes:**

● : "yes" or "available". — : "no" or "not available".


㊹ : 2.5kA for 10A.

㊼ : Specify the branch bars when ordering.

### Time/Current characteristic curves






### Ambient Compensating Curves




## Outline dimensions (mm) TB-5P

2P









Preparation of conductor





### Single mounting base –TDB-50PC

Example 1









Example 2





### Double mounting base –TDA-50PC Type




Drilling plan (front view)




Note: See page 7-170 for branch conductors.




# 7 Characteristics and Outline Dimensions

## Circuit Breaker for distribution boards

## TB-5D

### Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Category | | | Plug-in | | | | |
| Frame size (A) | | | 50 | | | | |
| Type | | | TB-5D | | | | |
| Number of poles | | | 2 | | | | |
| ■ Ratings | | | | | | | |
| Rated current, A | | | 10 30 | | | | |
| Calibrated at 40°C | | | 15 40 | | | | |
| 45°C | | | 20 50 | | | | |
| Rated operational voltage V | AC | | 250 | | | | |
| | DC | | 125 | | | | |
| ■ Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 415 V | — | | | | |
| $I_{cu}$ (sym) | | 240 V | — | | | | |
| | | 200 V | — | | | | |
| | | 100 / 200 V | — | | | | |
| | | 100 V | — | | | | |
| | DC | 110 V | — | | | | |
| NK | AC | 250 V | 5 ㊹ | | | | |
| (sym) | | 125 V | 42 | | | | |
| | DC | 125 V | 5 | | | | |
| Weight kg | | | 0.28 | | | | |
| ■ Connections | | | | | | | |
| Front-connected type on both line side and load side | | | — | | | | |
| Line side plug-in type, load side front-connected type | | | — | | | | |
| Plug-in type on both line side and load side | | | ● | | | | |
| ■ Mountings (optional) | | | | | | | |
| Clip-in chassis | | | — | | | | |
| Mounting base for single-row installation | | | ● ㊼ | | | | |
| Mounting base for branched-into-dual-rows | | | ● ㊼ | | | | |
| ■ Accessories (optional) | | | Symbol | | | | |
| Externally mounted: Toggle holder | | | HH | ● | | | |
| Toggle lock | | | HL | — | | | |
| Toggle cap | | | HC | — | | | |
| CE marking | | | | Non | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | |
| Colour of cover | | | | Black | | | |
| Reverse connection | | | | Yes | | | |


**Notes:**

● : "yes" or "available". — : "no" or "not available".


㊹ : 2.5kA for 10A.

㊼ : Specify the branch bars when ordering.


### Time/Current characteristic curves





### Ambient Compensating Curves




## Outline dimensions (mm) TB-5D





### Single mounting base–TDB-50DC




### Double mounting base –TDA-50DC Type




Note: See page 7-170 for branch conductors.



# 7 Characteristics and Outline Dimensions

## Circuit Breaker for distribution boards

## TB-51C, TB-52C

## Ratings and Specifications

| Category | | | TB mini size | |
|---|---|---|---|---|
| Frame size (A) | | | 50 | 50 |
| Type | | | **TB-51C** | **TB-52C** |
| Number of poles | | | 2 ㊸ | 2 |
| **■ Ratings** | | | | |
| Rated current, A | | | 15 | 15 |
| Calibrated at 40°C | | | 20 | 20 |
| 45°C | | | 30 | 30 |
| Rated operational voltage V | AC | | 100 | 240 |
| | DC | | — | — |
| **■ Rated breaking capacity, kA** | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 415 V | — | — |
| $I_{cu}$ (sym) | | 240 V | — | 2.5 |
| | | 200 V | — | 2.5 |
| | | 100 / 200 V | — | 5 |
| | | 100 V | 5 | — |
| | DC | 110 V | — | — |
| NK | AC | 250 V | — | — |
| (sym) | | 125 V | — | — |
| | DC | 125 V | — | — |
| Weight kg | | | 0.15 | 0.16 |
| **■ Connections** | | | | |
| Front-connected type on both line side and load side | | | ● ㊽ | ● ㊽ |
| Line side plug-in type, load side front-connected type | | | — | — |
| Plug-in type on both line side and load side | | | — | — |
| **■ Mountings (optional)** | | | | |
| Clip-in chassis | | | ● | ● |
| Mounting base for single-row installation | | | — | — |
| Mounting base for branched-into-dual-rows | | | — | — |
| **■ Accessories (optional)** | | **Symbol** | | |
| Externally mounted Toggle holder | | HH | ● | ● |
| Toggle lock | | HL | — | — |
| Toggle cap | | HC | ● | ● |
| CE marking | | | Non | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic |
| Colour of cover | | | Black | Black |
| Reverse connection | | | Yes | Yes |


**Notes:**

● : "yes" or "available". — : "no" or "not available".


㊸ : This is 2-pole 1-element.

㊽ : Distribution board branch conductors and busbar conductor supports are available. (Optional)

## Time/Current characteristic curves





## Ambient Compensating Curves




## Support for distribution board branch conductors and busbar conductors


Prepare branch conductors (optional) and busbar mounting screws.





| Type | Qty used / 1 row | | |
|---|---|---|---|
| | Single-phase 100V | Single-phase 200V | Single-phase 100V / 200V |
| TBJ-1V | 2 | — | 1 |
| TBJ-2N | 1 | — | — |
| TBJ-2V | — | 2 | 1 |
| TBJ-1N | — | — | 1 |

Note: For connection, see the conductor layout diagram on page 7-169.

Busbar conductor support type BJ-3S




## Outline dimensions (mm) TB-51C, TB-52C




## Clip-in chassis mounting dimensions

Clip-in Chassis, part number TDB-50SG (optional)
(12-pieces snap-off chassis)





NOTE: 1.Clip-in chassis is notched between every two pieces to adjust number of pieces to number of breaker poles. (Bend once or twice to snap off.)

2.Screw clip-in chassis down at 4 or 5 pole intervals.


## Conductor layout diagram

Single-phase 100V





(Note) Tightening torque of branch conductor connecting screws: 2 to 2.9Nm

Single-phase 200V




(Note) Tightening torque of branch conductor connecting screws: 2 to 2.9Nm

Single-phase 100/200V





(Note) Tightening torque of branch conductor connecting screws: 2 to 2.9Nm

## Applicable breakers — TB-5D, TB-5P


### ◉Mounting bases, branching bars and other accessories

**Mounting bases for double-row installation (for four circuits)**

#### ◉TDA-50PC
TB-5P type plug-in line side.
The line side can be connected to the busbar with a branch body with a blade.





#### ◉TDA-50DC
TB-5D type plug-in for both line side and load side.
The line side can be connected to the busbar with a branch body with a blade.





**Mounting bases for single-row installation (for two circuits)**


#### ◉TDB-50PC
TB-5P type plug-in line side.
The line side can be connected to the busbar with a branch body with a blade.





#### ◉TDB-50DC
TB-5D type plug-in for both line side and load side.
The line side can be connected to the busbar with a branch body with a blade.





#### ◉Pressure plate DC
It is used to fix the breaker to a 2-row plug-in base.






#### ◉Pressure plate SC
It is used to fix the breaker to a 1-row plug-in base.







#### ◉Braided line terminal BH-SC
Single-row plug-in base terminal for connection of separate circuit breakers to different power supplies.




### ◉Branching bars


| Application | Two branches from outer busbar | Two branches from inner busbar |
|---|---|---|
| Type | 2RT-LC | 2S-LC |
| Arrangement |   |   |


| Application | One branch from inner busbar | One branch from outer busbar | One branch from outer busbar in opposite direction |
|---|---|---|---|
| Type | IS-LC | IRT-LC | IT-LC |
| Arrangement |   |   |   |

## Applicable breakers — PS50-PF, PS125-NF/PF/NN/NE/PE

### ◉Plug-in mounting base


● Outline dimensions for double-row (TPPM12D3)









### ◉Branching bars


*Not supplied





● Outline dimensions for single-row (TPPM12S3)








| Components / Parts to be purchased | | | | Mounting / connecting screws | | | Remarks |
|---|---|---|---|---|---|---|---|
| | Name | Type | Qty | Size | Qty | Remarks | |
| For double | Plug-in base | TPPM12D3 | 2 | M4×30 | 4 | For breaker mounting | For 3-pole breaker |
| | Branching bar (thickness) | 2RT-LDB (t=2) | 2 | M5×12 | 2 | For busbar connection | 15 – 50A |
| | | | | M4×10 | 4 | For Mounting base installation | |
| | | 22S-LDB (t=2) | 1 | M5×12 | 1 | For busbar connection | |
| | | | | M4×10 | 2 | For Mounting base installation | |
| | | 2RT-LD10B (t=3) | 2 | M5×12 | 2 | For busbar connection | 60 – 125A |
| | | | | M4×10 | 4 | For Mounting base installation | |
| | | 22S-LD10B (t=3) | 1 | M5×12 | 1 | For busbar connection | |
| | | | | M4×10 | 2 | For Mounting base installation | |
| | Connecting plate | Connecting plate 3 | 1 | M4×25 | 4 | | |
| | Insulator for arc | Arc guard 3 | 1 | | | | |
| | Branching bar barrier | Busbar barrier D | 2 | | | | |
| For single | Plug-in base | TPPM12S3 | 1 | M4×30 | 4 | For breaker mounting | For 3-pole breaker |
| | Branching bar (thickness) | 1R-LDB (t=2) | 1 | M5×12 | 3 | For busbar connection | 15 – 50A |
| | | 1S-LDB (t=2) | 1 | M4×8 | 3 | For Mounting base installation | |
| | | 1T-LDB (t=2) | 1 | | | | |
| | | 1R-LD10B (t=3) | 1 | M5×12 | 3 | For busbar connection | 60 – 125A |
| | | 1S-LD10B (t=3) | 1 | M4×8 | 3 | For Mounting base installation | |
| | | 1T-LD10B (t=3) | 1 | | | | |


Notes:

1. The number required to form either single or double plug-in base.
2. Branch bars for 10 – 50A and 60 – 125A differ in thickness only. The conductor for 10 – 50A (2mm thick) can be used for applications where the breaker rated current is 50A or less.

### ◉Connecting plate 【Order code : CP3E】



### ◉Insulator for arc 【Order code : ARC3E】



### ◉Branching bar barrier 【Order code : BARRD】



# 7 Characteristics and Outline Dimensions


## Circuit Breaker for distribution boards


## Plug-in base for Distribution boards / Branching bars

**Applicable breakers S50-SF, S125-SF/SN, PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN**

### ◉Plug-in mounting base


● Outline dimensions for double-row(T2PM12LD2, T2PM12LD3)









### ◉Branching bars

＊Not supplied




● Outline dimensions for single-row(T2PM12LS2, T2PM12LS3)








| Components / Parts to be purchased | | | | Mounting / connecting screws | | | Remarks |
|---|---|---|---|---|---|---|---|
| | Name | Type | Qty | Size | Qty | Remarks | |
| For double | Plug-in base | T2PM12LD2 | 2 | M4×30 | 2 | For breaker mounting | For 2-pole breaker |
| | | T2PM12LD3 | 2 | M4×30 | 4 | For breaker mounting | For 3-pole breaker |
| | Branching bar (thickness) | 2RT-LDB (t=2) | 2 | M5×12 | 2 | For busbar connection | 15 – 50A |
| | | | | M4×8 | 4 | For Mounting base installation | |
| | | 22S-LDB (t=2) | 1 | M5×12 | 1 | For busbar connection | |
| | | | | M4×8 | 2 | For Mounting base installation | |
| | | 2RT-LD10B (t=3) | 2 | M5×12 | 2 | For busbar connection | 60 – 125A |
| | | | | M4×8 | 4 | For Mounting base installation | |
| | | 22S-LD10B (t=3) | 1 | M5×12 | 1 | For busbar connection | |
| | | | | M4×8 | 2 | For Mounting base installation | |
| | Connecting plate | Connecting plate 2 (for 2-pole breaker) | 1 | M4×35 | 4 | | |
| | | Connecting plate 3PD (for 3-pole breaker) | 1 | M4×35 | 4 | | |
| | Insulator for arc | Arc guard 2P (for 2-pole breaker) | 1 | | | | |
| | | Arc guard 3P (for 3-pole breaker) | 1 | | | | |
| | Branching bar barrier | Busbar barrier D | 2 | | | | |
| For single | Plug-in base | T2PM12LS2 | 1 | M4×30 | 2 | For breaker mounting | For 2-pole breaker |
| | | T2PM12LS3 | 1 | M4×30 | 4 | For breaker mounting | For 3-pole breaker |
| | Branching bar (thickness) | 1R-LDB (t=2) | 1 | M5×12 | 3 | For busbar connection | 15 – 50A |
| | | 1S-LDB (t=2) | 1 | M4×8 | 3 | For Mounting base installation | |
| | | 1T-LDB (t=2) | 1 | | | | |
| | | 1R-LD10B (t=3) | 1 | M5×12 | 3 | For busbar connection | 60 – 125A |
| | | 1S-LD10B (t=3) | 1 | M4×8 | 3 | For Mounting base installation | |
| | | 1T-LD10B (t=3) | 1 | | | | |


### ◉Connecting plate

【Order code : CP2E (for 2-pole breaker)
CP3D (for 3-pole breaker)】



### ◉Insulator for arc

【Order code : ARC2D (for 2-pole breaker)
ARC3D (for 3-pole breaker)】



### ◉Branching bar barrier

【Order code : BARRD】




Notes:

1. The number required to form either single or double plug-in base.
2. Branch bars for 10 – 50A and 60 – 125A differ in thickness only. The conductor for 10 – 50A (2mm thick) can be used for applications where the breaker rated current is 50A or less.


## Applicable breakers S100-GF, S125-GF

### ◉Plug-in mounting base

#### ● Outline dimensions for double-row (XDA2D)





#### ● Outline dimensions for single-row (XDA2S)




### ◉Branching bars

*Not supplied





| Components / Parts to be purchased | | | | Mounting / connecting screw | | | | | | Remarks |
|---|---|---|---|---|---|---|---|---|---|---|
| | | | | Standard | | | With load end terminal | | | |
| | Name | Type | Qty | Size | Qty | Remarks | Size | Qty | Remarks | |
| For double | Plug-in base | XDA2D | 2 | M5×25 | 4 | For breaker mounting | M5×25 | 4 | For breaker mounting | For 3-pole breaker |
| | Branching bar | 2RT-LE(t=2) | 2 | M5×12 | 2 | For busbar connection | M4×8 | 4 | For fixing to plug-in base | 15 – 50A |
| | | 22S-LE (t=2) | 1 | M5×12 | 1 | For busbar connection | M4×8 | 2 | For fixing to plug-in base | 15 – 50A |
| | | 2RT-LE10 (t=3) | 2 | M5×12 | 2 | For busbar connection | M4×8 | 4 | For fixing to plug-in base | 60 – 125A |
| | | 22S-LE10 (t=3) | 1 | M5×12 | 1 | For busbar connection | M4×8 | 2 | For fixing to plug-in base | 60 – 125A |
| | Connecting plate | Connecting plate 3 | 1 | M4×35 | 4 | | M4×35 | 4 | | |
| | Insurator for arc | Arc guard 3 | 1 | | | | | | | |
| | Branching bar barrier | Busbar barrier E | 2 | | | | | | | |
| For single | Plug-in base | XDA2S | 1 | M4×30 | 4 | For breaker mounting | | | For breaker mounting | For 3-pole breaker |
| | Branching bar | 1R-LE (t=2) | 1 | M5×12 | 3 | For busbar connection | M4×8 | 3 | For fixing to plug-in base | 15 – 50A |
| | | 1S-LE (t=2) | 1 | M5×12 | 3 | For busbar connection | M4×8 | 3 | For fixing to plug-in base | 15 – 50A |
| | | 1T-LE (t=2) | 1 | M5×12 | 3 | For busbar connection | M4×8 | 3 | For fixing to plug-in base | 15 – 50A |
| | | 1R-LE10 (t=3) | 1 | M5×12 | 3 | For busbar connection | M4×8 | 3 | For fixing to plug-in base | 60 – 125A |
| | | 1S-LE10 (t=3) | 1 | M5×12 | 3 | For busbar connection | M4×8 | 3 | For fixing to plug-in base | 60 – 125A |
| | | 1T-LE10 (t=3) | 1 | M5×12 | 3 | For busbar connection | M4×8 | 3 | For fixing to plug-in base | 60 – 125A |


Notes:

1. The number required to form either single or double plug-in base
2. Please specify the type of plug-in base.
3. Branch bars for 10 – 50A and 60 – 125A differ in thickness only. The conductor for 10 – 50A (2mm thick) can be used for applications where the breaker rated current is 50A or less.

### ◉Connecting plate 【Order code : CP3E】



### ◉Insulator for arc 【Order code : ARC3E】



### ◉Branching bar barrier 【Order code : BARRE】







# Earth Leakage Circuit Breakers

# PZE30-NF, PZE50-NF, PZS30-NF, PZS50-NF

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 30 | 50 | 30 | 50 |
| Type | | | PZE30-NF | PZE50-NF | PZS30-NF | PZS50-NF |
| Number of poles | | | 3 | 3 | 3 | 3 |
| Phase and wires | 1ø2W | ⑭ | ● | ● | ● | ● |
| | 3ø3W, 1ø3W | ⑮ | ● | ● | ● | ● |
| | 3ø4W | | — | — | — | — |
| **■ Ratings** | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | 6 | 6 | 6 |
| Rated current, A | | | 5 15 30 | 15 30 50 | 5 15 30 | 15 30 50 |
| Calibrated at 40°C | | | 10 20 | 20 40 | 10 20 | 20 40 |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | 100-440 common | 100-440 common | 100-440 common |
| | Operable voltage fluctuation range V | | 80-484 | 80-484 | 80-484 | 80-484 |
| | Time delay tripping type | | — | — | — | — |
| | Operable voltage fluctuation range V | | — | — | — | — |
| Rated sensitivity current mA | Instantaneous tripping type | | 15 | 15 ㉝ | 15 | 15 ㉝ |
| | | | 30 | 30 | 30 | 30 |
| | | | — | 100/200/500 selectable ㊶ | 100/200/500 selectable ㊶ | 100/200/500 selectable ㊶ |
| | Max. operating time sec | | 0.1 | 0.1 | 0.1 | 0.1 |
| | Time delay tripping type | | — | — | — | — |
| | Max. operating time sec | | — | — | — | — |
| | Non-operating time sec | | — | — | — | — |
| **■ Rated breaking capacity, kA** | | | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 1.5 | 2.5 | 2.5 | 7.5 |
| $I_{cu}$(sym) | | 415V | 1.5 | 2.5 | 2.5 | 7.5 |
| | | 240V | 2.5 | 7.5 | 7.5 | 15 |
| | | 100V | 2.5 | 7.5 | 7.5 | 15 |
| Weight (◉ marked standard type) kg | | | 0.8 | 0.8 | 0.8 | 0.8 |
| **■ Connections and Mountings** | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ | ◉ ㊺ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — |
| | Standard (PMC) | | — | — | — | — |
| For distribution boards (PMD) | | | — | — | — | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | | | — | — | — | — |
| TemPlug70 (PG) | | | — | — | — | — |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ |
| **■ Accessories (optional)** | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | — | — | — | — |
| External operating handle | Breaker-mounted | H B | ● | ● | ● | ● |
| | Door-mounted (variable depth) | H P | ● | ● | ● | ● |
| Toggle extension | | H A | — | — | — | — |
| Mechanical interlock | Slide type | M S | ● | ● | ● | ● |
| | Link type | M L | — | — | — | — |
| | Wire type | M W | — | — | — | — |
| Toggle holder | | H H | ● | ● | ● | ● |
| Toggle lock | | H L | ● | ● | ● | ● |
| Terminal cover | For front-connected | C F | ● | ● | ● | ● |
| | For rear-connected and plug-in | C R | ● | ● | ● | ● |
| Terminal block for lead | | T F | ● | ● | ● | ● |
| Door flange | | D F | — | — | — | — |
| CE marking | | | Non | Non | Non | Non |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | Electronic | Electronic |
| Overcurrent trip mechanism | | | Thermal-magnetic ⑦ | Thermal-magnetic | Thermal-magnetic ⑦ | Thermal-magnetic |
| Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes |
| Reverse connection | | | Non | Non | Non | Non |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.


● : "yes" or "available". — : "no" or "not available". ⑦ : Hydraulic-magnetic type for below 10A rating.

⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㉝ : Applicable to 15A to 30A. ㊶ : Not applicable to 20A or less.

㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts.


**Remark:** The rated sensitivity current is set to 100mA before delivery.

## Time/Current characteristic curves





## Ambient compensating curves


(5, 10A)




(15—50A)





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) PZE30-NF, PZE50-NF, PZS30-NF, PZS50-NF


## Front-connected





Preparation of conductor





With extension bars (optional)





Drilling plan (front view)





## Rear-connected





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

Drilling plan (front view)





Detail of connecting part





| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 3-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |


Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 3-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |


Please check the rear side for a detailed outline drawing of the terminals.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.


Drilling plan (front view)




## Earth leakage trip characteristic




## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Earth Leakage Circuit Breakers

## ZS50-SF

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 50 | | | | |
| Type | | | ZS50-SF | | | | |
| Number of poles | | | 3 | | | | |
| Phase and wires | 1ø2W | ⑭ | ● | | | | |
| | 3ø3W, 1ø3W | ⑮ | ● | | | | |
| | 3ø4W | | — | | | | |
| **■ Ratings** | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | |
| Rated current, A | | | 15 30 50 | | | | |
| Calibrated at 40°C | | | 20 40 | | | | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | | | | |
| | Operable voltage fluctuation range V | | 80–484 | | | | |
| | Time delay tripping type | | 100-440 common | | | | |
| | Operable voltage fluctuation range V | | 80–484 | | | | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | | | | |
| | | | 100/200/500 selectable | | | | |
| | | | — | | | | |
| | Max. operating time sec | | 0.1 | | | | |
| | Time delay tripping type | | 100/200/500 selectable | | | | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | | | | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | | | | |
| **■ Rated breaking capacity, kA** | | | | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 25 | | | | |
| $I_{cu}$(sym) | | 415V | 30 | | | | |
| | | 240V | 50 | | | | |
| | | 100V | 50 | | | | |
| Weight (◉ marked standard type) kg | | | 0.95 | | | | |
| **■ Connections and Mountings** | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | | | | |
| | With extension bars | | ○ ㊸ | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | |
| | Standard (PMC) | | — | | | | |
| For distribution boards (PMD) | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | |
| Draw-out type (DR) | | | — | | | | |
| TemPlug70 (PG) | | | ○ | | | | |
| DIN rail mount | | | ○ ⑪ | | | | |
| **■ Accessories (optional)** | | | Symbol | | | | |
| Externally mounted: Motor operator | | | M C | — | | | |
| External operating handle | Breaker-mounted | | H B | ● | | | |
| | Door-mounted (variable depth) | | H P | ● | | | |
| Toggle extension | | | H A | — | | | |
| Mechanical interlock | Slide type | | M S | ● | | | |
| | Link type | | M L | — | | | |
| | Wire type | | M W | — | | | |
| Toggle holder | | | H H | ● | | | |
| Toggle lock | | | H L | ● | | | |
| Terminal cover | For front-connected | | C F | ● | | | |
| | For rear-connected and plug-in | | C R | ● | | | |
| Terminal block for lead | | | T F | ● | | | |
| Door flange | | | D F | — | | | |
| CE marking | | | | Non | | | |
| Earth leakage trip mechanism (Current operation type) | | | | Electronic | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | |
| Earth leakage indication | | | | Mechanical button | | | |
| Colour of cover | | | | Grey Blue | | | |
| Trip button (Colour) | | | | Yes (Red) | | | |
| Suitability for isolation | | | | Yes | | | |
| Reverse connection | | | | Yes ⑫ | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". ⑪ : Please order the DIN rail adapter separately. See page 6-152.

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts.

⑫ : There are some limitations. See page 5-23 for details.


**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX | AL | MG | AX | MG | MG | TL |
|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | Megger measurement switch ■ | AL | AX | AL | Test lead |
| 3 | | | | | | | |

Toggle — Left pole / Right pole


## Time/Current characteristic curves




## Ambient compensating curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.

# Outline dimensions (mm) ZS50-SF

## Front-connected




## Rear-connected





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

| rated current (A) | A | B | C | D | E |
|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 |

Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

| rated current (A) | A | B | C | D | E |
|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 |

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Earth Leakage Circuit Breakers

## PZE60-NF, PZS60-NF, PZE125-NF


## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 60 | 60 | 100 | 125 |
| Type | | | PZE60-NF | PZS60-NF | PZE125-NF | |
| Number of poles | | | 3 | 3 | 3 | 3 |
| Phase and wires | 1ø2W | ⑭ | ● | ● | ● | ● |
| | 3ø3W, 1ø3W | ⑮ | ● | ● | ● | ● |
| | 3ø4W | | — | — | — | — |
| ■ Ratings | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | 6 | 6 | 6 |
| Rated current, A Calibrated at 40°C | | | 60 | 60 | 60<br>75<br>100 | 125 |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | 100-440 common | 100-440 common | 100-440 common |
| | Operable voltage fluctuation range V | | 80-484 | 80-484 | 80-484 | 80-484 |
| | Time delay tripping type | | — | — | — | — |
| | Operable voltage fluctuation range V | | — | — | — | — |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | 30 | 30 | 30 |
| | | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable |
| | | | — | — | — | — |
| | Max. operating time sec | | 0.1 | 0.1 | 0.1 | 0.1 |
| | Time delay tripping type | | — | — | — | — |
| | Max. operating time sec | | — | — | — | — |
| | Non-operating time sec | | — | — | — | — |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | AC | 440V | 2.5 | 10 | 10 | 10 |
| | | 415V | 2.5 | 10 | 10 | 10 |
| | | 240V | 7.5 | 30 | 30 | 30 |
| | | 100V | 7.5 | 30 | 30 | 30 |
| Weight (◉ marked standard type) kg | | | 0.9 | 0.9 | 0.9 | 0.9 |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | ◉ | ◉ |
| | With extension bars | | ○ ⑬ | ○ ⑬ | ○ ⑬ | ○ ⑬ |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — |
| | Standard (PMC) | | — | — | — | — |
| For distribution boards (PMD) | | | — | — | — | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | | | — | — | — | — |
| TemPlug70 (PG) | | | — | — | — | — |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ | ○ ⑪ |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | — | — | — | — |
| External operating handle | Breaker-mounted | H B | ● | ● | ● | ● |
| | Door-mounted (variable depth) | H P | ● | ● | ● | ● |
| Toggle extension | | H A | — | — | — | — |
| Mechanical interlock | Slide type | M S | ● | ● | ● | ● |
| | Link type | M L | — | — | — | — |
| | Wire type | M W | — | — | — | — |
| Toggle holder | | H H | ● | ● | ● | ● |
| Toggle lock | | H L | ● | ● | ● | ● |
| Terminal cover | For front-connected | C F | ● | ● | ● | ● |
| | For rear-connected and plug-in | C R | ● | ● | ● | ● |
| Terminal block for lead | | T F | ● | ● | ● | ● |
| Door flange | | D F | — | — | — | — |
| CE marking | | | Non | Non | Non | Non |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | Electronic | Electronic |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes |
| Reverse connection | | | Non | Non | Non | Non |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". ⑪ : Please order the DIN rail adapter separately. See page 6-152.
⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ⑬ : For the extension bars, please place the order separately in parts.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) PZE60-NF, PZS60-NF, PZE125-NF


## Front-connected





Preparation of conductor





With extension bars (optional)





Drilling plan (front view)





## Rear-connected




① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.


Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.





Detail of connecting part

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Drilling plan (front view)






Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |


Please check the rear side for a detailed outline drawing of the terminals.

Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.


Drilling plan (front view)




## Earth leakage trip characteristic




## Control circuit



# Earth Leakage Circuit Breakers

# ZS125-SF



## Ratings and Specifications


| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | 125 | | |
| Type | | | ZS125-SF | | | |
| Number of poles | | | 3 | 3 | | |
| Phase and wires | 1ø2W | ⑭ | ● | ● | | |
| | 3ø3W, 1ø3W | ⑮ | ● | ● | | |
| | 3ø4W | | — | — | | |
| ■ Ratings | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | | |
| Rated current, A Calibrated at 40°C | | | 15 40 75<br>20 50 100<br>30 60 | 125 | | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | 100-440 common | | |
| | Operable voltage fluctuation range V | | 80–484 | 80–484 | | |
| | Time delay tripping type | | 100-440 common | 100-440 common | | |
| | Operable voltage fluctuation range V | | 80–484 | 80–484 | | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | 30 | | |
| | | | 100/200/500 selectable | 100/200/500 selectable | | |
| | | | — | — | | |
| | | Max. operating time sec | 0.1 | 0.1 | | |
| | Time delay tripping type | | 100/200/500 selectable | 100/200/500 selectable | | |
| | | Max. operating time sec | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | | |
| | | Non-operating time sec | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 25 | 25 | | |
| $I_{cu}$(sym) | | 415V | 30 | 30 | | |
| | | 240V | 50 | 50 | | |
| | | 100V | 50 | 50 | | |
| Weight (◉ marked standard type) kg | | | 0.95 | 0.95 | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ④ | ◉ | | |
| | With extension bars | | ○ ⑬ | ○ ⑬ | | |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | — | — | | |
| | | Standard (PMC) | — | — | | |
| | For distribution boards (PMD) | | — | — | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | | |
| Draw-out type (DR) | | | — | — | | |
| TemPlug70 (PG) | | | ○ | ○ | | |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | | |
| ■ Accessories (optional) | | | | Symbol | | |
| Externally mounted: Motor operator | | | — | M C | | |
| External operating handle | Breaker-mounted | | ● | H B | | |
| | Door-mounted (variable depth) | | ● | H P | | |
| Toggle extension | | | — | H A | | |
| Mechanical interlock | Slide type | | ● | M S | | |
| | Link type | | — | M L | | |
| | Wire type | | — | M W | | |
| Toggle holder | | | ● | H H | | |
| Toggle lock | | | ● | H L | | |
| Terminal cover | For front-connected | | ● | C F | | |
| | For rear-connected and plug-in | | ● | C R | | |
| Terminal block for lead | | | ● | T F | | |
| Door flange | | | — | D F | | |
| CE marking | | | Non | Non | | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | | |
| Earth leakage indication | | | Mechanical button | Mechanical button | | |
| Colour of cover | | | Grey Blue | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | | |
| Suitability for isolation | | | Yes | Yes | | |
| Reverse connection | | | Yes ⑫ | Yes ⑫ | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". ④ : 50A or less is the M5 wire clamping terminal. ⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ⑬ : For the extension bars, please place the order separately in parts.
⑫ : There are some limitations. See page 5-23 for details.

## Time/Current characteristic curves


**15-50A**





**60-125A**




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZS125-SF

## Front-connected




## Rear-connected


Detail of connecting part




① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.


Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

Drilling plan (front view)





| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted





① : Studs are horizontal direction as standard. They will be factory installed in the horizontal direction unless otherwise specified. Vertical position is a special specification. Please specify this when ordering.

| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 15-50 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-125 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |


Note) If you will arrange the studs vertically, please insulate them carefully with insulating tubes, insulating tape, or similar because the insulation distance between the studs is insufficient.

## Earth leakage trip characteristic




Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.

## Control circuit







# Earth Leakage Circuit Breakers

# ZS100-GF

## Ratings and Specifications

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | | 100 | |
| Type | | | ZS100-GF | |
| Number of poles | | | 3 | 4 |
| Phase and wires | 1ø2W | ⑭ | ● | — |
| | 3ø3W, 1ø3W | ⑮ | ● | — |
| | 3ø4W | | — | ● |
| **■ Ratings** | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | |
| Rated current, A | | | 15 40 75 | |
| Calibrated at 40°C | | | 20 50 100 | |
| | | | 30 60 | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | |
| | Time delay tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | |
| | | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | |
| **■ Rated breaking capacity, kA** | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 50 | |
| $I_{cu}$(sym) | | 415V | 65 | |
| | | 240V | 85 | |
| | | 100V | 85 | |
| Weight (◉ marked standard type) kg | | | 1.3 | 1.7 |
| **■ Connections and Mountings** | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | |
| | With extension bars | | ○ ⑬ | |
| Rear-connected (RC) | Flat bar studs | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | |
| | Standard (PMC) | | — | |
| For distribution boards (PMD) | | | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | |
| Draw-out type (DR) | | | — | |
| TemPlug70 (PG) | | | ○ | — |
| DIN rail mount | | | ○ ⑪ | |
| **■ Accessories (optional)** | | Symbol | | |
| Externally mounted: Motor operator | | M C | ● | |
| External operating handle | Breaker-mounted | H B | ● | |
| | Door-mounted (variable depth) | H P | ● | |
| Toggle extension | | H A | — | |
| Mechanical interlock | Slide type | M S | ● | |
| | Link type | M L | — | |
| | Wire type | M W | — | |
| Toggle holder | | H H | ● | |
| Toggle lock | | H L | ● | |
| Terminal cover | For front-connected | C F | ● | |
| | For rear-connected and plug-in | C R | ● | |
| Terminal block for lead | | T F | ● | |
| Door flange | | D F | — | |
| CE marking | | | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic | |
| Earth leakage indication | | | Mechanical button | |
| Colour of cover | | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | |
| Suitability for isolation | | | Yes | |
| Reverse connection | | | Yes ⑫ | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.


○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ⑬ : For the extension bars, please place the order separately in parts.


⑫ : There are some limitations. See page 5-23 for details.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Combinations of Internally Mounted Accessories (Optional)





## Time/Current characteristic curves




## Ambient compensating curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.

# Outline dimensions (mm) ZS100-GF

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit



# Earth Leakage Circuit Breakers

# ZS125-GF



## Ratings and Specifications

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | | 125 | |
| Type | | | ZS125-GF | |
| Number of poles | | | 3 | 4 |
| Phase and wires | 1ø2W | ⑭ | ● | — |
| | 3ø3W, 1ø3W | ⑮ | ● | — |
| | 3ø4W | | — | ● |
| **■ Ratings** | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | |
| Rated current, A Calibrated at 40°C | | | 125 | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | |
| | Time delay tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | |
| | | | 100/200/500 selectable | |
| | | Max. operating time sec | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | |
| | | Max. operating time sec | 0.45/1.0/2.0 selectable | |
| | | Non-operating time sec | 0.1/0.5/1.2 or more | |
| **■ Rated breaking capacity, kA** | | | | |
| JIS C 8201-2-2 Ann.2 | | AC 440V | 50 | |
| $I_{cu}$(sym) | | 415V | 65 | |
| | | 240V | 85 | |
| | | 100V | 85 | |
| Weight (◉ marked standard type) kg | | | 1.3 | 1.7 |
| **■ Connections and Mountings** | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | |
| | With extension bars | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | |
| | Standard (PMC) | | — | |
| For distribution boards (PMD) | | | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | |
| Draw-out type (DR) | | | — | |
| TemPlug70 (PG) | | | ○ | — |
| DIN rail mount | | | ○ ⑪ | |
| **■ Accessories (optional)** | | Symbol | | |
| Externally mounted: Motor operator | | M C | ● | |
| External operating handle: Breaker-mounted | | H B | ● | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | |
| Toggle extension | | H A | — | |
| Mechanical interlock: Slide type | | M S | ● | |
| Mechanical interlock: Link type | | M L | — | |
| Mechanical interlock: Wire type | | M W | — | |
| Toggle holder | | H H | ● | |
| Toggle lock | | H L | ● | |
| Terminal cover: For front-connected | | C F | ● | |
| Terminal cover: For rear-connected and plug-in | | C R | ● | |
| Terminal block for lead | | T F | ● | |
| Door flange | | D F | — | |
| CE marking | | | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic | |
| Earth leakage indication | | | Mechanical button | |
| Colour of cover | | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | |
| Suitability for isolation | | | Yes | |
| Reverse connection | | | Yes ⑫ | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑪ : Please order the DIN rail adapter separately. See page 6-152. ⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole. ⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole. ㊸ : For the extension bars, please place the order separately in parts.

⑫ : There are some limitations. See page 5-23 for details.


**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX | AL | MG | AX | MG | MG | MG | TL |
|---|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | Megger measurement switch | AL | AX | AL | AX AL | Test lead |
| 3 4 | | | | | | | | |

Toggle — Left pole / Right pole


## Time/Current characteristic curves





## Ambient compensating curves




## Earth leakage trip characteristic






Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.

# Outline dimensions (mm) ZS125-GF

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Earth Leakage Circuit Breakers

## ZE250-SF, ZS250-SF

## Ratings and Specifications

| Frame size (A) | | | 225 | 250 | 225 | 250 |
|---|---|---|---|---|---|---|
| Type | | | ZE250-SF | | ZS250-SF | |
| Number of poles | | | 3 | 3 | 3 | 3 |
| Phase and wires | 1ø2W | ⑭ | ● | ● | ● | ● |
| | 3ø3W, 1ø3W | ⑮ | ● | ● | ● | ● |
| | 3ø4W | | — | — | — | — |
| **■ Ratings** | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | 8 | 8 |
| Rated current, A | | | 125 175 225 | 250 | 125 175 225 | 250 |
| Calibrated at 40°C | | | 150 200 | | 150 200 | |
| | | | 100-440 common | 100-440 common | 100-440 common | 100-440 common |
| Rated operational voltage AC V | Instantaneous tripping type | | 80–484 | 80–484 | 80–484 | 80–484 |
| | Operable voltage fluctuation range V | | 100-440 common | 100-440 common | 100-440 common | 100-440 common |
| | Time delay tripping type | | 80–484 | 80–484 | 80–484 | 80–484 |
| | Operable voltage fluctuation range V | | 30 | 30 | 30 | 30 |
| Rated sensitivity current mA | Instantaneous tripping type | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable |
| | | | — | — | — | — |
| | Max. operating time sec | | 0.1 | 0.1 | 0.1 | 0.1 |
| | Time delay tripping type | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more |
| **■ Rated breaking capacity, kA** | | | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 15 | 15 | 30 | 30 |
| $I_{cu}$(sym) | | 415V | 25 | 25 | 40 | 40 |
| | | 240V | 35 | 35 | 85 | 85 |
| | | 100V | 35 | 35 | 85 | 85 |
| Weight (◉ marked standard type) kg | | | 1.7 | 1.7 | 1.7 | 1.7 |
| **■ Connections and Mountings** | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | ○ | ○ |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | — | — |
| | Standard (PMC) | | — | — | — | — |
| For distribution boards (PMD) | | | — | — | — | — |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | ○ | ○ |
| Draw-out type (DR) | | | — | — | — | — |
| TemPlug70 (PG) | | | ○ | ○ | ○ | ○ |
| DIN rail mount | | | — | — | — | — |
| **■ Accessories (optional)** | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | ● | ● | ● | ● |
| External operating handle | Breaker-mounted | H B | ● | ● | ● | ● |
| | Door-mounted (variable depth) | H P | ● | ● | ● | ● |
| Toggle extension | | H A | — | — | — | — |
| Mechanical interlock | Slide type | M S | ● | ● | ● | ● |
| | Link type | M L | — | — | — | — |
| | Wire type | M W | — | — | — | — |
| Toggle holder | | H H | ● | ● | ● | ● |
| Toggle lock | | H L | ● | ● | ● | ● |
| Terminal cover | For front-connected | C F | ● | ● | ● | ● |
| | For rear-connected and plug-in | C R | ● | ● | ● | ● |
| Terminal block for lead | | T F | ● | ● | ● | ● |
| Door flange | | D F | — | — | — | — |
| CE marking | | | Non | Non | Non | Non |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | Electronic | Electronic |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes | Yes |
| Reverse connection | | | Yes | Yes | Yes | Yes |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.

⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.


㊸ : For the extension bars, please place the order separately in parts.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Time/Current characteristic curves




## Ambient compensating curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZE250-SF, ZS250-SF

## Front-connected





*For the extension bars, straight bars or spread bars can be supplied.

## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted




## Control circuit



# Earth Leakage Circuit Breakers

# ZS225-GF



## Ratings and Specifications

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | | 225 | |
| Type | | | ZS225-GF | |
| Number of poles | | | 3 | 4 |
| Phase and wires | 1ø2W | ⑭ | ● | — |
| | 3ø3W, 1ø3W | ⑮ | ● | — |
| | 3ø4W | | — | ● |
| **■ Ratings** | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | |
| Rated current, A | | | 125 200 | |
| Calibrated at 40°C | | | 150 225 | |
| | | | 175 | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | |
| | Time delay tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | |
| | | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | |
| **■ Rated breaking capacity, kA** | | | | |
| JIS C 8201-2-2 Ann.2 | | AC 440V | 50 | |
| $I_{cu}$(sym) | | 415V | 65 | |
| | | 240V | 85 | |
| | | 100V | 85 | |
| Weight (◉ marked standard type) kg | | | 1.7 | 2.1 |
| **■ Connections and Mountings** | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | |
| | With extension bars | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | |
| | Standard (PMC) | | — | |
| For distribution boards (PMD) | | | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | |
| Draw-out type (DR) | | | — | |
| TemPlug70 (PG) | | | ○ | — |
| DIN rail mount | | | — | |
| **■ Accessories (optional)** | | Symbol | | |
| Externally mounted: Motor operator | | M C | ● | |
| External operating handle: Breaker-mounted | | H B | ● | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | |
| Toggle extension | | H A | — | |
| Mechanical interlock: Slide type | | M S | ● | |
| Mechanical interlock: Link type | | M L | — | |
| Mechanical interlock: Wire type | | M W | — | |
| Toggle holder | | H H | ● | |
| Toggle lock | | H L | ● | |
| Terminal cover: For front-connected | | C F | ● | |
| Terminal cover: For rear-connected and plug-in | | C R | ● | |
| Terminal block for lead | | T F | ● | |
| Door flange | | D F | — | |
| CE marking | | | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic | |
| Earth leakage indication | | | Mechanical button | |
| Colour of cover | | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | |
| Suitability for isolation | | | Yes | |
| Reverse connection | | | Yes ⑫ | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.


⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.

㊸ : For the extension bars, please place the order separately in parts.


⑫ : There are some limitations. See page 5-23 for details.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Time/Current characteristic curves




## Ambient compensating curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZS225-GF

## Front-connected





*Spread extension bars for 3 poles. Staraight extension bars for 4 poles.

## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit



# Earth Leakage Circuit Breakers

# ZS250-GF



## Ratings and Specifications

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | | 250 | |
| Type | | | ZS250-GF | |
| Number of poles | | | 3 | 4 |
| Phase and wires | 1ø2W | ⑭ | ● | — |
| | 3ø3W, 1ø3W | ⑮ | ● | — |
| | 3ø4W | | — | ● |
| **■ Ratings** | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | |
| Rated current, A Calibrated at 40°C | | | 250 | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | |
| | Time delay tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | |
| | | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | |
| **■ Rated breaking capacity, kA** | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | AC | 440V | 50 | |
| | | 415V | 65 | |
| | | 240V | 85 | |
| | | 100V | 85 | |
| Weight (◉ marked standard type) kg | | | 1.7 | 2.1 |
| **■ Connections and Mountings** | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | |
| | With extension bars | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | |
| | Standard (PMC) | | — | |
| For distribution boards (PMD) | | | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | |
| Draw-out type (DR) | | | — | |
| TemPlug70 (PG) | | | ○ | — |
| DIN rail mount | | | — | |
| **■ Accessories (optional)** | | Symbol | | |
| Externally mounted: Motor operator | | M C | ● | |
| External operating handle: Breaker-mounted | | H B | ● | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | |
| Toggle extension | | H A | — | |
| Mechanical interlock: Slide type | | M S | ● | |
| Mechanical interlock: Link type | | M L | — | |
| Mechanical interlock: Wire type | | M W | — | |
| Toggle holder | | H H | ● | |
| Toggle lock | | H L | ● | |
| Terminal cover: For front-connected | | C F | ● | |
| Terminal cover: For rear-connected and plug-in | | C R | ● | |
| Terminal block for lead | | T F | ● | |
| Door flange | | D F | — | |
| CE marking | | | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic | |
| Earth leakage indication | | | Mechanical button | |
| Colour of cover | | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | |
| Suitability for isolation | | | Yes | |
| Reverse connection | | | Yes ⑫ | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.


⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.

㊸ : For the extension bars, please place the order separately in parts.


⑫ : There are some limitations. See page 5-23 for details.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Time/Current characteristic curves





## Ambient compensating curves





## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZS250-GF

## Front-connected





*Spread extension bars for 3 poles. Staraight extension bars for 4 poles.

## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Earth Leakage Circuit Breakers

## ZE400-NF, ZS400-NF, ZS400-GF

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | | 400 | | 400 | |
| Type | | | ZE400-NF | | ZS400-NF | | ZS400-GF | |
| Number of poles | | | 3 | | 3 | 4 | 3 | 4 |
| Phase and wires | 1ø2W | ⑭ | ● | | ● | — | ● | — |
| | 3ø3W, 1ø3W | ⑮ | ● | | ● | — | ● | — |
| | 3ø4W | | — | | — | ● | — | ● |
| **■ Ratings** | | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | 8 | |
| Rated current, A | | | 250 | 350 | 250 | 350 | 250 | 350 |
| Calibrated at 40°C | | | 300 | 400 | 300 | 400 | 300 | 400 |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | | 100-440 common | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | | 80–484 | | 80–484 | |
| | Time delay tripping type | | 100-440 common | | 100-440 common | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | | 80–484 | | 80–484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | | 30 | | 30 | |
| | | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | |
| | | | — | | — | | — | |
| | Max. operating time sec | | 0.1 | | 0.1 | | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | | 100/200/500 selectable | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | | 0.45/1.0/2.0 selectable | | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | | 0.1/0.5/1.2 or more | | 0.1/0.5/1.2 or more | |
| **■ Rated breaking capacity, kA** | | | | | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 22 | | 45 | | 65 | |
| $I_{cu}$(sym) | | 415V | 25 | | 50 | | 70 | |
| | | 240V | 35 | | 85 | | 100 | |
| | | 100V | 35 | | 85 | | 100 | |
| Weight (◉ marked standard type) kg | | | 5.2 | | 5.2 | 6.6 | 5.2 | 6.6 |
| **■ Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | ◉ | | ◉ | |
| | With extension bars | | ○ | | ○ | | ○ | |
| Rear-connected (RC) | Flat bar studs | | ○ | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | — | | — | |
| | Standard (PMC) | | — | | — | | — | |
| For distribution boards (PMD) | | | — | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | — | | — | | — | |
| TemPlug70 (PG) | | | ○ | | ○ | — | ○ | — |
| DIN rail mount | | | — | | — | | — | |
| **■ Accessories (optional)** | | Symbol | | | | | | |
| Externally mounted: Motor operator | | MC | ● | | ● | | ● | |
| External operating handle | Breaker-mounted | HB | ● | | ● | | ● | |
| | Door-mounted (variable depth) | HP | ● | | ● | | ● | |
| Toggle extension | | HA | ● | | ● | | ● | |
| Mechanical interlock | Slide type | MS | ● | | ● | | ● | |
| | Link type | ML | — | | — | | — | |
| | Wire type | MW | — | | — | | — | |
| Toggle holder | | HH | | | | | | |
| Toggle lock | | HL | ● | | ● | | ● | |
| Terminal cover | For front-connected | CF | ● | | ● | | ● | |
| | For rear-connected and plug-in | CR | ● | | ● | | ● | |
| Terminal block for lead | | TF | ● | | ● | | ● | |
| Door flange | | DF | — | | — | | — | |
| CE marking | | | Non | | Non | | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | | Electronic | | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | |
| Earth leakage indication | | | Mechanical button | | Mechanical button | | Mechanical button | |
| Colour of cover | | | Grey Blue | | Grey Blue | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | Yes | | Yes | | Yes | |
| Reverse connection | | | Yes ⑫ | | Yes ⑫ | | Yes ⑫ | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.

⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.


⑫ : There are some limitations. See page 5-23 for details.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Combinations of Internally Mounted Accessories (Optional)




## Time/Current characteristic curves ZS400-NF, ZS400-GF




## Ambient compensating curves




## Magnetic trip pick-up current

| Rated current (A) | $I_n$× | Magnetic trip pick-up current (adjustable range) (A) 12 | 11 | 10 | 9 | 8 | 7 | 6 |
|---|---|---|---|---|---|---|---|---|
| 250 | | 3000 | 2750 | 2500 | 2250 | 2000 | 1750 | 1500 |
| 300 | | 3600 | 3300 | 3000 | 2700 | 2400 | 2100 | 1800 |
| 350 | | 4200 | 3850 | 3500 | 3150 | 2800 | 2450 | 2100 |
| 400 | | 4800 | 4400 | 4000 | 3600 | 3200 | 2800 | 2400 |

**Notes:**


(1) : Setting tolerance: ±20%.

(2) : ZE400-NF type is a single point fixed setting of 10 times the rated current. Setting tolerance: ±10%.

(3) : The Time/Current characteristic curve is for adjustable instantaneous trip.

Remark (1) : If the model is adjustable and unless otherwise stated when ordering, the scale is factory set to ×12.


## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.

# Outline dimensions (mm) ZE400-NF, ZS400-NF, ZS400-GF

## Front-connected





## Rear-connected




Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted





Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit




## Time/Current characteristic curves ZE400-NF





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Earth Leakage Circuit Breakers

## ZS630-CF, ZS630-NF

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 600 | 630 | 600 | 630 | |
| Type | | | | ZS630-CF | | ZS630-NF | | |
| Number of poles | | | | 3 | | 3 | | |
| Phase and wires | 1ø2W | | ⑭ | ● | | ● | | |
| | 3ø3W, 1ø3W | | ⑮ | ● | | ● | | |
| | 3ø4W | | | — | | — | | |
| **■ Ratings** | | | | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | | 8 | | 8 | | |
| Rated current, A | | | | 500 | 630 | 500 | 630 | |
| Calibrated at 40°C | | | | 600 | | 600 | | |
| Rated operational voltage AC V | Instantaneous tripping type | | | 100-440 common | | 100-440 common | | |
| | Operable voltage fluctuation range V | | | 80–484 | | 80–484 | | |
| | Time delay tripping type | | | 100-440 common | | 100-440 common | | |
| | Operable voltage fluctuation range V | | | 80–484 | | 80–484 | | |
| Rated sensitivity current mA | Instantaneous tripping type | | | 30 | | 30 | | |
| | | | | 100/200/500 selectable | | 100/200/500 selectable | | |
| | | | | — | | — | | |
| | Max. operating time sec | | | 0.1 | | 0.1 | | |
| | Time delay tripping type | | | 100/200/500 selectable | | 100/200/500 selectable | | |
| | Max. operating time sec | | | 0.45/1.0/2.0 selectable | | 0.45/1.0/2.0 selectable | | |
| | Non-operating time sec | | | 0.1/0.5/1.2 or more | | 0.1/0.5/1.2 or more | | |
| **■ Rated breaking capacity, kA** | | | | | | | | |
| JIS C 8201-2-2 Ann.2 | | AC | 440V | 30 | | 45 | | |
| $I_{cu}$(sym) | | | 415V | 36 | | 50 | | |
| | | | 240V | 50 | | 85 | | |
| | | | 100V | 50 | | 85 | | |
| Weight (◉ marked standard type) kg | | | | 10.0 | | 10.0 | | |
| **■ Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | — | | — | | |
| | With extension bars | | | ◉ | | ◉ | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | |
| Plug-in (PM) | For switchboards | High-performance (PMB) | | — | | — | | |
| | | Standard (PMC) | | — | | — | | |
| | For distribution boards (PMD) | | | — | | — | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | |
| Draw-out type (DR) | | | | — | | — | | |
| TemPlug70 (PG) | | | | ○ | | ○ | | |
| DIN rail mount | | | | — | | — | | |
| **■ Accessories (optional)** | | | | | | | | Symbol |
| Externally mounted | Motor operator | | | ● | | ● | | M C |
| | External operating handle | Breaker-mounted | | ● | | ● | | H B |
| | | Door-mounted (variable depth) | | ● | | ● | | H P |
| | Toggle extension | | | ● | | ● | | H A |
| | Mechanical interlock | Slide type | | ● | | ● | | M S |
| | | Link type | | — | | — | | M L |
| | | Wire type | | — | | — | | M W |
| | Toggle holder | | | ● | | ● | | H H |
| | Toggle lock | | | ● | | ● | | H L |
| | Terminal cover | For front-connected | | ● | | ● | | C F |
| | | For rear-connected and plug-in | | ● | | ● | | C R |
| | Terminal block for lead | | | ● | | ● | | T F |
| | Door flange | | | — | | — | | D F |
| CE marking | | | | Non | | Non | | |
| Earth leakage trip mechanism (Current operation type) | | | | Electronic | | Electronic | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic (adjustable) | | Thermal-magnetic (adjustable) | | |
| Earth leakage indication | | | | Mechanical button | | Mechanical button | | |
| Colour of cover | | | | Grey Blue | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | Yes | | |
| Reverse connection | | | | Yes ⑫ | | Yes ⑫ | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.

⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.


⑫ : There are some limitations. See page 5-23 for details.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Combinations of Internally Mounted Accessories (Optional)




## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) | $I_n$× | Magnetic trip pick-up current (adjustable range) (A) 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|---|
| 500 | | 5000 | 4500 | 4000 | 3500 | 3000 | 2500 |
| 600 | | 6000 | 5400 | 4800 | 4200 | 3600 | 3000 |
| 630 | | 6300 | 5670 | 5040 | 4410 | 3780 | 3150 |

Note (1) : Setting tolerance: ±20%.

Remark (1) : Unless otherwise stated when ordering, the selector dial is factory set to position "10".


## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.


# Outline dimensions (mm) ZS630-CF, ZS630-NF

## Front-connected






Drilling plan (front view)





## Rear-connected




(Bottom view)





Drilling plan (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted








Drilling plan (front view)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

# Earth Leakage Circuit Breakers

# ZS800-CF, ZS800-NF

## Ratings and Specifications

| | | | | | |
|---|---|---|---|---|---|
| Frame size (A) | | | 800 | 800 | |
| Type | | | ZS800-CF | ZS800-NF | |
| Number of poles | | | 3 | 3 | |
| Phase and wires | 1ø2W | ⑭ | ● | ● | |
| | 3ø3W, 1ø3W | ⑮ | ● | ● | |
| | 3ø4W | | — | — | |
| ■Ratings | | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | |
| Rated current, A | | | 700 | 700 | |
| Calibrated at 40°C | | | 800 | 800 | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | 80–484 | |
| | Time delay tripping type | | 100-440 common | 100-440 common | |
| | Operable voltage fluctuation range V | | 80–484 | 80–484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | 30 | |
| | | | 100/200/500 selectable | 100/200/500 selectable | |
| | | | — | — | |
| | Max. operating time sec | | 0.1 | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | 100/200/500 selectable | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | 0.1/0.5/1.2 or more | |
| ■Rated breaking capacity, kA | | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 30 | 45 | |
| $I_{cu}$(sym) | | 415V | 36 | 50 | |
| | | 240V | 50 | 85 | |
| | | 100V | 50 | 85 | |
| Weight (◉ marked standard type) kg | | | 11.0 | 11.0 | |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) | Terminal screws | | — | — | |
| | With extension bars | | ◉ | ◉ | |
| Rear-connected (RC) | Flat bar studs | | ○ | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | — | |
| | Standard (PMC) | | — | — | |
| For distribution boards (PMD) | | | — | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | ○ | |
| Draw-out type (DR) | | | — | — | |
| TemPlug70 (PG) | | | — | — | |
| DIN rail mount | | | — | — | |
| ■Accessories (optional) | | Symbol | | | |
| Externally mounted: Motor operator | | M C | ● | ● | |
| External operating handle | Breaker-mounted | H B | ● | ● | |
| | Door-mounted (variable depth) | H P | ● | ● | |
| Toggle extension | | H A | ● | ● | |
| Mechanical interlock | Slide type | M S | ● | ● | |
| | Link type | M L | — | — | |
| | Wire type | M W | — | — | |
| Toggle holder | | H H | ● | ● | |
| Toggle lock | | H L | | | |
| Terminal cover | For front-connected | C F | ● | ● | |
| | For rear-connected and plug-in | C R | ● | ● | |
| Terminal block for lead | | T F | ● | ● | |
| Door flange | | D F | — | — | |
| CE marking | | | Non | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic (adjustable) | Thermal-magnetic (adjustable) | |
| Earth leakage indication | | | Mechanical button | Mechanical button | |
| Colour of cover | | | Grey Blue | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | |
| Suitability for isolation | | | Yes | Yes | |
| Reverse connection | | | Yes ⑫ | Yes ⑫ | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.

⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.


⑫ : There are some limitations. See page 5-23 for details.

**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.


## Combinations of Internally Mounted Accessories (Optional)




## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) $I_n$× | Magnetic trip pick-up current (adjustable range) (A) 10 | 9 | 8 | 7 | 6 | 5 |
|---|---|---|---|---|---|---|
| 700 | 7000 | 6300 | 5600 | 4900 | 4200 | 3500 |
| 800 | 8000 | 7200 | 6400 | 5600 | 4800 | 4000 |

Note (1) : Setting tolerance: ±20%.

Remark (1) : Unless otherwise stated when ordering, the selector dial is factory set to position "10".


## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec, 1.25-2.0sec for 2.0sec.


# Outline dimensions (mm) ZS800-CF, ZS800-NF

## Front-connected






Drilling plan (front view)





## Rear-connected




(Bottom view)





Drilling plan (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted








Drilling plan (front view)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Control circuit





# 7 Characteristics and Outline Dimensions

TemBreak2

## Earth Leakage Circuit Breakers for motor protection

## ZE30-NM, ZE50-NM, ZS30-NM, ZS50-CM

## Ratings and Specifications

| Frame size (A) | | | | 30 | | 30 | | 50 | | 50 | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| Type | | | | ZE30-NM | | ZS30-NM | | ZE50-NM | | ZS50-CM | |
| Number of poles | | | | 3 | | 3 | | 3 | | 3 | |
| ■ Ratings | | | | (A) | (kW) 200V | (A) | (kW) 200V | (A) | (kW) 200V | (A) | (kW) 200V |
| Rated capacity of motor and rated current of circuit breaker Calibrated at 40°C | | | | 1.4 | 0.2 | 0.7 | — | 45 | 11 | 0.7 | — |
| | | | | 2.6 | 0.4 | 1.4 | 0.2 | | | 1.4 | 0.2 |
| | | | | 4 | 0.75 | 2 | — | | | 2 | — |
| | | | | 5 | 1 | 2.6 | 0.4 | | | 2.6 | 0.4 |
| | | | | 8 | 1.5 | 4 | 0.75 | | | 4 | 0.75 |
| | | | | 10 | 2.2 | 5 | 1 | | | 5 | 1 |
| | | | | 16 | 3.7 | 8 | 1.5 | | | 8 | 1.5 |
| | | | | 24 | 5.5 | 10 | 2.2 | | | 10 | 2.2 |
| | | | | 32 | 7.5 | 12 | — | | | 12 | — |
| | | | | | | 16 | 3.7 | | | 16 | 3.7 |
| | | | | | | 24 | 5.5 | | | 24 | 5.5 |
| | | | | | | 32 | 7.5 | | | 32 | 7.5 |
| | | | | | | | | | | 40 | — |
| | | | | | | | | | | 45 | 11 |
| Remarks: Select according to the full load current of the motor. | | | | | | | | | | | |
| Rated impulse withstand voltage [$U_{imp}$] kV | | | | 6 | | 6 | | 6 | | 6 | |
| Rated operational voltage AC V | Instantaneous tripping type | | | 100-440 common | | 100-440 common | | 100-440 common | | 100-440 common | |
| | Operable voltage fluctuation range V | | | 80–484 | | 80–484 | | 80–484 | | 80–484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | | 30 | | 30 | | 30 | | 30 | |
| | | | | 100 | | 100/200/500 selectable | | 100/200 selectable | | 100/200/500 selectable | |
| | Max. operating time sec | | | 0.1 | | 0.1 | | 0.1 | | 0.1 | |
| ■ Rated breaking capacity, kA | | | | | | | | | | | |
| JIS C 8201-2-2 Ann.2 | | AC | 440V | 1.5 | | 2.5 | | 2.5 | | 7.5 | |
| $I_{cu}$(sym) | | | 415V | 1.5 | | 2.5 | | 2.5 | | 7.5 | |
| | | | 240V | 2.5 ㊾ | | 5 ㊾ | | 5 ㊾ | | 10 ㊾ | |
| | | | 100V | 5 | | 5 | | 5 | | 10 | |
| Weight (◉ marked standard type) kg | | | | 0.5 | | 0.5 | | 0.5 | | 0.5 | |
| ■ Connections and Mountings | | | | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ ㊺ | | ◉ ㊺ | | ◉ ㊺ | | ◉ ㊺ | |
| | With extension bars | | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | ○ | | ○ | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | — | | — | | — | |
| | Standard (PMC) | | | — | | — | | — | | — | |
| For distribution boards (PMD) | | | | — | | — | | — | | — | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | ○ | | ○ | | ○ | |
| Draw-out type (DR) | | | | — | | — | | — | | — | |
| TemPlug70 (PG) | | | | — | | — | | — | | — | |
| DIN rail mount | | | | ◉ | | ◉ | | ◉ | | ◉ | |
| ■ Accessories (optional) | | | Symbol | | | | | | | | |
| Externally mounted: Motor operator | | | M C | — | | — | | — | | — | |
| External operating handle | Breaker-mounted | | H B | △ | | △ | | △ | | △ | |
| | Door-mounted (variable depth) | | H P | △ | | △ | | △ | | △ | |
| Toggle extension | | | H A | — | | — | | — | | — | |
| Mechanical interlock | Slide type | | M S | ● | | ● | | ● | | ● | |
| | Rear-connected type | | M B | — | | — | | — | | — | |
| | Link type | | M L | — | | — | | — | | — | |
| | Wire type | | M W | — | | — | | — | | — | |
| Toggle holder | | | H H | — | | — | | — | | — | |
| Toggle lock | | | H L | ● | | ● | | ● | | ● | |
| Terminal cover | For front-connected | | C F | ● | | ● | | ● | | ● | |
| | For rear-connected and plug-in | | C R | ● ② | | ● ② | | ● ② | | ● ② | |
| Terminal block for lead | | | T F | ● | | ● | | ● | | ● | |
| Door flange | | | D F | — | | — | | — | | — | |
| CE marking | | | | Non | | Non | | Non | | Non | |
| Earth leakage trip mechanism (Current operation type) | | | | Electronic | | Electronic | | Electronic | | Electronic | |
| Overcurrent trip mechanism | | | | Hydraulic-magnetic type | | Hydraulic-magnetic type | | Hydraulic-magnetic type | | Hydraulic-magnetic type | |
| Earth leakage indication | | | | Mechanical button | | Mechanical button | | Mechanical button | | Mechanical button | |
| Colour of cover | | | | Light Grey | | Light Grey | | Light Grey | | Light Grey | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | Yes (Red) | | Yes (Red) | |
| Suitability for isolation | | | | Yes | | Yes | | Yes | | Yes | |
| Reverse connection | | | | Non | | Non | | Non | | Non | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.


② : Supplied as standard. ㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts. ㊾ : This is the value for 230V AC.

**Remark:** The rated sensitivity current is set to 100mA before delivery.


## Time/Current characteristic curves




## Ambient compensating curves




## Earth leakage trip characteristic




## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX | AL | SH | UV | MG | TL | AX AL SH | AX AL UV | MG AX AL UV | TL AX AL |
|---|---|---|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | Shunt trip | Under voltage trip | Megger measurement switch | Test lead | | | | |
| 3 | | | | | | | | | | |


Toggle — Left pole / Right pole

Note: For auxiliary switches or alarm switches, left-hand mounting has priority.
Shunt trip and undervoltage trip are mounted on the side of the circuit breaker.In the case of flush-mounted type (FP), it cannot be installed.


## Outline dimensions (mm) ZE30-NM, ZE50-NM, ZS30-NM, ZS50-CM

### Front-connected






Drilling plan (front view)




Panel cutout A (front view)






Detail of connecting part





Preparation of conductor


### Rear-connected





(Bottom view)






Drilling plan (front view)


Note: The mounting direction of the studs cannot be changed. Please specify the mounting direction when ordering.
The line side and load side will be factory installed in the horizontal direction unless otherwise specified.

### Flush-mounted








Drilling plan (front view)

Note: The mounting direction of the studs cannot be changed. Please specify the mounting direction when ordering.
The line side and load side will be factory installed in the horizontal direction unless otherwise specified.

## Control circuit






## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | | | |
| Type | | | ZE100-NM | | | |
| Number of poles | | | 3 | | | |
| ■ Ratings | | | | | | |
| Rated capacity of motor and rated current of circuit breaker Calibrated at 40°C | (A) | (kW) 200V | 415V | | | |
| | 60 | 15 | 30 | | | |
| | 75 | 18.5 | 37 | | | |
| | 90 | 22 | 45 | | | |
| Remarks: Select according to the full load current of the motor. | | | | | | |
| Rated impulse withstand voltage 〔$U_{imp}$〕 kV | | | 6 | | | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | | | |
| | Operable voltage fluctuation range V | | 80–484 | | | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | | | |
| | | | 100/200/500 selectable | | | |
| | Max. operating time sec | | 0.1 | | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | AC | 440V | 10 | | | |
| | | 415V | 10 | | | |
| | | 240V | 25 ㊾ | | | |
| | | 100V | 25 | | | |
| Weight (◉ marked standard type) kg | | | 0.5 | | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | |
| | With extension bars | | ○ ㊸ | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | |
| | Standard (PMC) | | — | | | |
| For distribution boards (PMD) | | | — | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | |
| Draw-out type (DR) | | | — | | | |
| TemPlug70 (PG) | | | — | | | |
| DIN rail mount | | | ◉ | | | |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | — | | | |
| External operating handle | Breaker-mounted | H B | △ | | | |
| | Door-mounted (variable depth) | H P | △ | | | |
| Toggle extension | | H A | — | | | |
| Mechanical interlock | Slide type | M S | ● | | | |
| | Rear-connected type | M B | — | | | |
| | Link type | M L | — | | | |
| | Wire type | M W | — | | | |
| Toggle holder | | H H | — | | | |
| Toggle lock | | H L | ● | | | |
| Terminal cover | For front-connected | C F | ● | | | |
| | For rear-connected and plug-in | C R | ● ② | | | |
| Terminal block for lead | | T F | ● | | | |
| Door flange | | D F | — | | | |
| CE marking | | | Non | | | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | | | |
| Overcurrent trip mechanism | | | Hydraulic-magnetic type | | | |
| Earth leakage indication | | | Mechanical button | | | |
| Colour of cover | | | Light Grey | | | |
| Trip button (Colour) | | | Yes (Red) | | | |
| Suitability for isolation | | | Yes | | | |
| Reverse connection | | | Non | | | |


**Notes:**
◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.
② : Supplied as standard. ㊺ : A wire clamping terminal is provided. ㊸ : For the extension bars, please place the order separately in parts. ㊾ : This is the value for 230V AC.

**Remark:** The rated sensitivity current is set to 100mA before delivery.


## Time/Current characteristic curves





## Ambient compensating curves




## Earth leakage trip characteristic





## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.
Shunt trip and undervoltage trip are mounted on the side of the circuit breaker.In the case of flush-mounted type (FP), it cannot be installed.


# Outline dimensions (mm) ZE100-NM

## Front-connected






Drilling plan (front view)




Panel cutout A (front view)






Detail of connecting part





Preparation of conductor


## Rear-connected





(Bottom view)






Drilling plan (front view)


Note: The mounting direction of the studs cannot be changed. Please specify the mounting direction when ordering. The line side and load side will be factory installed in the horizontal direction unless otherwise specified.

## Flush-mounted








Drilling plan (front view)

Note: The mounting direction of the studs cannot be changed. Please specify the mounting direction when ordering. The line side and load side will be factory installed in the horizontal direction unless otherwise specified.

## Control circuit







# Earth Leakage Circuit Breakers for motor protection

# ZS100-SM

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | | 100 | | |
| Type | | | | ZS100-SM | | |
| Number of poles | | | | 3 | | |
| ■ Ratings | | | | | | |
| Rated capacity of motor and rated current of circuit breaker Calibrated at 40°C | | | (A) | (kW) 200V | 415V | |
| | | | 16 | 3.7 | 7.5 | |
| | | | 24 | 5.5 | 11 | |
| | | | 32 | 7.5 | 15 | |
| | | | 40 | — | 18.5 | |
| | | | 45 | 11 | 22 | |
| | | | 60 | 15 | 30 | |
| | | | 75 | 18.5 | 37 | |
| | | | 90 | 22 | 45 | |
| | | | 100 | — | 55 | |
| Remarks: Select according to the full load current of the motor. | | | | | | |
| Rated impulse withstand voltage ($U_{imp}$) kV | | | | 8 | | |
| Rated operational voltage AC V | Instantaneous tripping type | | | 100-440 common | | |
| | | Operable voltage fluctuation range V | | 80—484 | | |
| Rated sensitivity current mA | Instantaneous tripping type | | | 30 | | |
| | | | | 100/200/500 selectable | | |
| | Max. operating time sec | | | 0.1 | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | AC | 440V | | 25 | | |
| | | 415V | | 30 | | |
| | | 240V | | 50 | | |
| | | 100V | | 50 | | |
| Weight (◉ marked standard type) kg | | | | 0.95 | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ ④ | | |
| | With extension bars | | | ○ ㊸ | | |
| Rear-connected (RC) | Flat bar studs | | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | | — | | |
| | Standard (PMC) | | | — | | |
| For distribution boards (PMD) | | | | — | | |
| Flush-mounted (FP) | With flat bar studs | | | ○ | | |
| Draw-out type (DR) | | | | — | | |
| TemPlug70 (PG) | | | | ○ | | |
| DIN rail mount | | | | ○ ⑪ | | |
| ■ Accessories (optional) | | | Symbol | | | |
| Externally mounted: Motor operator | | | M C | — | | |
| External operating handle | Breaker-mounted | | H B | ● | | |
| | Door-mounted (variable depth) | | H P | ● | | |
| Toggle extension | | | H A | — | | |
| Mechanical interlock | Slide type | | M S | ● | | |
| | Rear-connected type | | M B | — | | |
| | Link type | | M L | — | | |
| | Wire type | | M W | — | | |
| Toggle holder | | | H H | ● | | |
| Toggle lock | | | H L | ● | | |
| Terminal cover | For front-connected | | C F | ● | | |
| | For rear-connected and plug-in | | C R | ● | | |
| Terminal block for lead | | | T F | ● | | |
| Door flange | | | D F | — | | |
| CE marking | | | | Non | | |
| Earth leakage trip mechanism (Current operation type) | | | | Electronic | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | |
| Earth leakage indication | | | | Mechanical button | | |
| Colour of cover | | | | Grey Blue | | |
| Trip button (Colour) | | | | Yes (Red) | | |
| Suitability for isolation | | | | Yes | | |
| Reverse connection | | | | Yes ⑫ | | |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". ④ : 50A or less is the M5 wire clamping terminal.
⑪ : Please order the DIN rail adapter separately. See page 6-152. ㊸ : For the extension bars, please place the order separately in parts. ⑫ : There are some limitations. See page 5-23 for details.


**Remark:** The rated sensitivity current is set to 100mA before delivery.

## Time/Current characteristic curves


**16-45A**




**60-100A**




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)

| Poles | AX | AL | MG | AX | MG | MG | TL |
|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | Megger measurement switch ■ | AL | AX | AL | Test lead |
| 3 | | | | | | | |


Toggle — Left pole / Right pole

# Outline dimensions (mm) ZS100-SM

## Front-connected





## Rear-connected





| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 16-45 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-100 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted





| rated current (A) | A | B | C | D | E | F |
|---|---|---|---|---|---|---|
| 16-45 | 10.5 | 6.5 | 4 | 13 | 16 | 4 |
| 60-100 | 12.5 | 8.5 | 4 | 13 | 16 | 5 |

## Earth leakage trip characteristic




## Control circuit







# Earth Leakage Circuit Breakers for motor protection

# ZS250-SM

## Ratings and Specifications

| | | | | | | |
|---|---|---|---|---|---|---|
| Frame size (A) | | | 225 | | | |
| Type | | | ZS250-SM | | | |
| Number of poles | | | 3 | | | |
| ■ Ratings | | | | | | |
| Rated capacity of motor and rated current of circuit breaker Calibrated at 40°C | | | (A) / (kW) 200V / 415V: 125 / 30 / —; 150 / 37 / 75; 175 / 45 / 90; 225 / 55 / 110 | | | |
| Remarks: Select according to the full load current of the motor. | | | | | | |
| Rated impulse withstand voltage [$U_{imp}$] kV | | | 8 | | | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | | | |
| | | Operable voltage fluctuation range V | 80—484 | | | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | | | |
| | | | 100/200/500 selectable | | | |
| | Max. operating time sec | | 0.1 | | | |
| ■ Rated breaking capacity, kA | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$(sym) | AC | 440V | 30 | | | |
| | | 415V | 40 | | | |
| | | 240V | 85 | | | |
| | | 100V | 85 | | | |
| Weight (◉ marked standard type) kg | | | 1.7 | | | |
| ■ Connections and Mountings | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | |
| | With extension bars | | ○ ㊸ | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | |
| | Standard (PMC) | | — | | | |
| For distribution boards (PMD) | | | — | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | |
| Draw-out type (DR) | | | — | | | |
| TemPlug70 (PG) | | | ○ | | | |
| DIN rail mount | | | — | | | |
| ■ Accessories (optional) | | Symbol | | | | |
| Externally mounted: Motor operator | | M C | ● | | | |
| External operating handle | Breaker-mounted | H B | ● | | | |
| | Door-mounted (variable depth) | H P | ● | | | |
| Toggle extension | | H A | — | | | |
| Mechanical interlock | Slide type | M S | ● | | | |
| | Rear-connected type | M B | — | | | |
| | Link type | M L | — | | | |
| | Wire type | M W | — | | | |
| Toggle holder | | H H | ● | | | |
| Toggle lock | | H L | ● | | | |
| Terminal cover | For front-connected | C F | ● | | | |
| | For rear-connected and plug-in | C R | ● | | | |
| Terminal block for lead | | T F | ● | | | |
| Door flange | | D F | — | | | |
| CE marking | | | Non | | | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | | |
| Earth leakage indication | | | Mechanical button | | | |
| Colour of cover | | | Grey Blue | | | |
| Trip button (Colour) | | | Yes (Red) | | | |
| Suitability for isolation | | | Yes | | | |
| Reverse connection | | | Yes | | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available".


㊸ : For the extension bars, please place the order separately in parts.

**Remark:** The rated sensitivity current is set to 100mA before delivery.


## Time/Current characteristic curves





## Ambient compensating curves




## Earth leakage trip characteristic





## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) ZS250-SM


## Front-connected





Preparation of conductor




With extension bars (optional)*





Drilling plan (front view)





*For the extension bars,
straight bars or spread bars can be supplied.


## Rear-connected




(Bottom view)





Drilling plan (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted





Drilling plan (front view)




## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire earth leakage circuit breakers with neutral phase open protection

## PZE50-NFN, PZE125-NFN

## Ratings and Specifications

| | | | | | |
|---|---|---|---|---|---|
| Frame size (A) | | | 50 | 100 | 125 |
| Type | | | PZE50-NFN | PZE125-NFN | |
| Number of poles / Elements | | | 3P3E ㊵ | 3P3E ㊵ | 3P3E ㊵ |
| Phase and wires | | | 1ø3W | 1ø3W | 1ø3W |
| ■Ratings | | | | | |
| Rated current, A | | | 15 40 | 60 | 125 |
| Calibrated at 40°C | | | 20 50 | 75 | |
| | | | 30 | 100 | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 6 | 6 | 6 |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | 30 | 30 |
| | | | | 100/200/500 selectable | 100/200/500 selectable |
| | | Max. operating time sec | 0.1 | 0.1 | 0.1 |
| | Time delay tripping type | | — | — | — |
| | | Max. operating time sec | — | — | — |
| | | Non-operating time sec | — | — | — |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | 135 |
| | Rated non-operating overvoltage AC V | | 120 | 120 | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | 1 or less |
| ■Rated breaking capacity, kA | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 10 | 25 | 25 |
| Weight (◉ marked standard type) kg | | | 0.8 | 0.9 | 0.9 |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊺ | ◉ | ◉ |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ |
| Rear-connected (RC) | Flat bar studs | | △ | △ | △ |
| DIN rail mount | | | ○ ⑪ | ○ ⑪ | ○ ⑪ |
| ■Accessories (optional) | | Symbol | | | |
| Externally mounted | Motor operator | M C | — | — | — |
| | External operating handle: Breaker-mounted | H B | ● | ● | ● |
| | External operating handle: Door-mounted (variable depth) | H P | ● | ● | ● |
| | Toggle extension | H A | — | — | — |
| | Mechanical interlock: Slide type | M S | ● | ● | ● |
| | Mechanical interlock: Link type | M L | — | — | — |
| | Mechanical interlock: Wire type | MW | — | — | — |
| | Toggle holder | H H | ● | ● | ● |
| | Toggle lock | H L | ● | ● | ● |
| | Terminal cover: For front-connected | C F | ● | ● | ● |
| | Terminal cover: For rear-connected | C R | ● | ● | ● |
| | Terminal block for lead | T F | ● | ● | ● |
| | Door flange | D F | — | — | — |
| CE marking | | | Non | Non | Non |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | Electronic |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic |
| Overvoltage / Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes | Yes |
| Reverse power flow circuit | | | Non | Non | Non |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.
⑪ : Please order the DIN rail adapter separately. See page 6-152.
㊵ : They can also be applied to circuits where overcurrent flows in the neutral wire. Can be used as a main circuit breaker for photovoltaic power generation systems. See page 3-27 for details.
㊺ : A wire clamping terminal is provided.
㊸ : For the extension bars, please place the order separately in parts.


**Remarks:**

(1) : The rated sensitivity current is set to 100mA before delivery.
(2) : This circuit breaker is designed for single-phase 3-wire 100/200 V circuits only.
(3) : Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.
(4) : Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker.
If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.
(5) : Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit.
The circuit breaker will not work unless this connection is made.
(6) : Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.
(7) : The test button checks the overvoltage operation.


## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)




## Outline dimensions (mm) PZE50-NFN, PZE125-NFN

### Front-connected





Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Earth leakage trip characteristic





### Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire earth leakage circuit breakers with neutral phase open protection

## ZNS125-SF

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | | 125 | | |
| Type | | | ZNS125-SF | | | | |
| Number of poles / Elements | | | 3P3E ㊵ | | 3P3E ㊵ | | |
| Phase and wires | | | 1ø3W | | 1ø3W | | |
| ■Ratings | | | | | | | |
| Rated current, A | | | 15 | 50 | 125 | | |
| Calibrated at 40°C | | | 20 | 60 | | | |
| | | | 30 | 75 | | | |
| | | | 40 | 100 | | | |
| Rated operational voltage AC V | | | 100/200 | | 100/200 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | 8 | | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | | 30 | | |
| | | | 100/200/500 selectable | | 100/200/500 selectable | | |
| | | Max. operating time sec | 0.1 | | 0.1 | | |
| | Time delay tripping type | | 100/200/500 selectable | | 100/200/500 selectable | | |
| | | Max. operating time sec | 0.45 | | 0.45 | | |
| | | Non-operating time sec | 0.1 | | 0.1 | | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | | 135 | | |
| | Rated non-operating overvoltage AC V | | 120 | | 120 | | |
| | Rated overvoltage operating time (sec) | | 1 or less | | 1 or less | | |
| ■Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$ (sym) AC 100/200V | | | 50 | | 50 | | |
| Weight (◉ marked standard type) kg | | | 0.95 | | 0.95 | | |
| ■Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ④ | | ◉ | | |
| | With extension bars | | ○ ⑤③ | | ○ ⑤③ | | |
| Rear-connected (RC) | Flat bar studs | | △ | | △ | | |
| DIN rail mount | | | ○ ⑪ | | ○ ⑪ | | |
| ■Accessories (optional) | | Symbol | | | | | |
| Externally mounted | Motor operator | M C | — | | — | | |
| | External operating handle — Breaker-mounted | H B | ● | | ● | | |
| | External operating handle — Door-mounted (variable depth) | H P | ● | | ● | | |
| | Toggle extension | H A | — | | — | | |
| | Mechanical interlock — Slide type | M S | ● | | ● | | |
| | Mechanical interlock — Link type | M L | — | | — | | |
| | Mechanical interlock — Wire type | MW | — | | — | | |
| | Toggle holder | H H | ● | | ● | | |
| | Toggle lock | H L | ● | | ● | | |
| | Terminal cover — For front-connected | C F | ● | | ● | | |
| | Terminal cover — For rear-connected | C R | ● | | ● | | |
| | Terminal block for lead | T F | ● | | ● | | |
| | Door flange | D F | — | | — | | |
| CE marking | | | Non | | Non | | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | | Electronic | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | Thermal-magnetic | | |
| Overvoltage / Earth leakage indication | | | Mechanical button | | Mechanical button | | |
| Colour of cover | | | Grey Blue | | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | | Yes (Red) | | |
| Suitability for isolation | | | Yes | | Yes | | |
| Reverse power flow circuit | | | Yes ⑮ | | Yes ⑮ | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified. ○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

④ : 50A or less is the M5 wire clamping terminal.

⑪ : Please order the DIN rail adapter separately. See page 6-152.

㊵ : They can also be applied to circuits where overcurrent flows in the neutral wire. Can be used as a main circuit breaker for photovoltaic power generation systems. See page 3-27 for details.

⑤③ : For the extension bars, please place the order separately in parts.

⑮ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

**Remarks:**

(1) : The rated sensitivity current is set to 100mA before delivery.

(2) : This circuit breaker is designed for single-phase 3-wire 100/200 V circuits only.

(3) : Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.


(4) : Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.

(5) : Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.

(6) : Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.


(7) : The test button checks the overvoltage operation.

## Combinations of Internally Mounted Accessories (Optional)





## Time/Current characteristic curves


15-50A




60-125A





## Ambient compensating curves



## Outline dimensions (mm) ZNS125-SF


### Front-connected





Preparation of conductor





With extension bars (optional)




Drilling plan (front view)





Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec.

### Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire earth leakage circuit breakers with neutral phase open protection

## ZNE250-SF, ZNS250-SF

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 225 | 250 | 225 | 250 | |
| Type | | | ZNE250-SF | | ZNS250-SF | | |
| Number of poles / Elements | | | 3P3E ㊵ | 3P3E ㊵ | 3P3E ㊵ | 3P3E ㊵ | |
| Phase and wires | | | 1ø3W | 1ø3W | 1ø3W | 1ø3W | |
| ■ Ratings | | | | | | | |
| Rated current, A | | | 125 225 | 250 | 125 225 | 250 | |
| Calibrated at 40°C | | | 150 | | 150 | | |
| | | | 175 | | 175 | | |
| | | | 200 | | 200 | | |
| Rated operational voltage AC V | | | 100/200 | 100/200 | 100/200 | 100/200 | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 | 8 | 8 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | 30 | 30 | 30 | |
| | | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | |
| | | Max. operating time sec | 0.1 | 0.1 | 0.1 | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | 100/200/500 selectable | |
| | | Max. operating time sec | 0.45 | 0.45 | 0.45 | 0.45 | |
| | | Non-operating time sec | 0.1 | 0.1 | 0.1 | 0.1 | |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 | 135 | 135 | |
| | Rated non-operating overvoltage AC V | | 120 | 120 | 120 | 120 | |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less | 1 or less | 1 or less | |
| ■ Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$ (sym) AC 100/200V | | | 35 | 35 | 85 | 85 | |
| Weight (◉ marked standard type) kg | | | 1.7 | 1.7 | 1.7 | 1.7 | |
| ■ Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ | ◉ | ◉ | |
| | With extension bars | | ○ ㊸ | ○ ㊸ | ○ ㊸ | ○ ㊸ | |
| Rear-connected (RC) | Flat bar studs | | △ | △ | △ | △ | |
| DIN rail mount | | | — | — | — | — | |
| ■ Accessories (optional) | | | | | | | Symbol |
| Externally mounted | Motor operator | | ● | ● | ● | ● | M C |
| | External operating handle | Breaker-mounted | ● | ● | ● | ● | H B |
| | | Door-mounted (variable depth) | ● | ● | ● | ● | H P |
| | Toggle extension | | — | — | — | — | H A |
| | Mechanical interlock | Slide type | ● | ● | ● | ● | M S |
| | | Link type | — | — | — | — | M L |
| | | Wire type | — | — | — | — | MW |
| | Toggle holder | | ● | ● | ● | ● | H H |
| | Toggle lock | | ● | ● | ● | ● | H L |
| | Terminal cover | For front-connected | ● | ● | ● | ● | C F |
| | | For rear-connected | ● | ● | ● | ● | C R |
| | Terminal block for lead | | ● | ● | ● | ● | T F |
| | Door flange | | — | — | — | — | D F |
| CE marking | | | Non | Non | Non | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic | Electronic | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | Thermal-magnetic | |
| Overvoltage / Earth leakage indication | | | Mechanical button | Mechanical button | Mechanical button | Mechanical button | |
| Colour of cover | | | Grey Blue | Grey Blue | Grey Blue | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) | Yes (Red) | Yes (Red) | |
| Suitability for isolation | | | Yes | Yes | Yes | Yes | |
| Reverse power flow circuit | | | Yes ㉕ | Yes ㉕ | Yes ㉕ | Yes ㉕ | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available". △ : Custom-built product. Please contact us for details.

㊵ : They can also be applied to circuits where overcurrent flows in the neutral wire. Can be used as a main circuit breaker for photovoltaic power generation systems. See page 3-27 for details.

㊸ : For the extension bars, please place the order separately in parts.

㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

**Remarks:**

(1) : The rated sensitivity current is set to 100mA before delivery.

(2) : This circuit breaker is designed for single-phase 3-wire 100/200 V circuits only.

(3) : Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.


(4) : Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.

(5) : Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.


(6) : Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.

(7) : The test button checks the overvoltage operation.


## Combinations of Internally Mounted Accessories (Optional)





## Time/Current characteristic curves




## Ambient compensating curves





## Earth leakage trip characteristic




Time delay tripping type will operate on 0.15-0.45sec for 0.45sec.


## Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Outline dimensions (mm) ZNE250-SF, ZNS250-SF

### Front-connected





*For the extension bars, straight bars or spread bars can be supplied.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Control circuit





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Single phase 3-wire earth leakage circuit breakers with neutral phase open protection

## ZNE400-NF, ZNS400-NF

## Ratings and Specifications

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | | 400 | 400 |
| Type | | | ZNE400-NF | ZNS400-NF |
| Number of poles / Elements | | | 3P2E ⑱ | 3P2E ⑱ |
| Phase and wires | | | 1ø3W | 1ø3W |
| ■Ratings | | | | |
| Rated current, A | | | 250 | 250 |
| Calibrated at 40°C | | | 300 | 300 |
| | | | 350 | 350 |
| | | | 400 | 400 |
| Rated operational voltage AC V | | | 100/200 | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | 8 |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | 30 |
| | | | 100/200/500 selectable | 100/200/500 selectable |
| | | Max. operating time sec | 0.1 | 0.1 |
| | Time delay tripping type | | 100/200/500 selectable | 100/200/500 selectable |
| | | Max. operating time sec | 0.45 | 0.45 |
| | | Non-operating time sec | 0.1 | 0.1 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 | 135 |
| | Rated non-operating overvoltage AC V | | 120 | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less | 1 or less |
| ■Rated breaking capacity, kA | | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$ (sym) AC 100/200V | | | 35 | 85 |
| Weight (◉ marked standard type) kg | | | 5.2 | 5.2 |
| ■Connections and Mountings | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | ◉ |
| | With extension bars | | ○ | ○ |
| Rear-connected (RC) | Flat bar studs | | △ | △ |
| DIN rail mount | | | — | — |
| ■Accessories (optional) | | Symbol | | |
| Externally mounted: Motor operator | | M C | ● | ● |
| External operating handle: Breaker-mounted | | H B | ● | ● |
| External operating handle: Door-mounted (variable depth) | | H P | ● | ● |
| Toggle extension | | H A | ● | ● |
| Mechanical interlock: Slide type | | M S | ● | ● |
| Mechanical interlock: Link type | | M L | — | — |
| Mechanical interlock: Wire type | | MW | — | — |
| Toggle holder | | H H | ● | ● |
| Toggle lock | | H L | | |
| Terminal cover: For front-connected | | C F | ● | ● |
| Terminal cover: For rear-connected | | C R | ● | ● |
| Terminal block for lead | | T F | ● | ● |
| Door flange | | D F | — | — |
| CE marking | | | Non | Non |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | Electronic |
| Overcurrent trip mechanism | | | Thermal-magnetic | Thermal-magnetic(adjustable) |
| Overvoltage / Earth leakage indication | | | Mechanical button | Mechanical button |
| Colour of cover | | | Grey Blue | Grey Blue |
| Trip button (Colour) | | | Yes (Red) | Yes (Red) |
| Suitability for isolation | | | Yes | Yes |
| Reverse power flow circuit | | | Yes ⑮ | Yes ⑮ |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering.
● : "yes" or "available". — : "no" or "not available".
△ : Custom-built product. Please contact us for details.
⑱ : Do not apply to circuits where overcurrent flows in the neutral wire.
⑮ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.


**Remarks:**

(1) : The rated sensitivity current is set to 100mA before delivery.
(2) : This circuit breaker is designed for single-phase 3-wire 100/200 V circuits only.
(3) : Connect the neutral wire to the central pole and the voltage lines (200V) to the left and right poles.
(4) : Be sure to connect the overvoltage detection lead wire to the OFF side of the circuit breaker. If you connect it to the ON side, voltage will be applied to the OFF side even when the circuit breaker is turned OFF.
(5) : Connect the overvoltage detection lead wire to the neutral wire on the load side (OFF side) of the circuit. The circuit breaker will not work unless this connection is made.
(6) : Connect the overvoltage detection lead wire to the end of the load side (OFF side) of the circuit.
(7) : The test button checks the overvoltage operation.

## Time/Current characteristic curves ZNS400-NF




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) | $I_n$× | Magnetic trip pick-up current (adjustable range) (A) 12 | 11 | 10 | 9 | 8 | 7 | 6 |
|---|---|---|---|---|---|---|---|---|
| 250 | | 3000 | 2750 | 2500 | 2250 | 2000 | 1750 | 1500 |
| 300 | | 3600 | 3300 | 3000 | 2700 | 2400 | 2100 | 1800 |
| 350 | | 4200 | 3850 | 3500 | 3150 | 2800 | 2450 | 2100 |
| 400 | | 4800 | 4400 | 4000 | 3600 | 3200 | 2800 | 2400 |


**Notes (1) : Setting tolerance: ±20%.**
**(2) : ZNE400-NF type is a single point fixed setting of 10 times the rated current. Setting tolerance: ±10%.**
**(3) : The Time/Current characteristic curve is for adjustable instantaneous trip.**
**Remark (1) : If the model is adjustable and unless otherwise stated when ordering, the scale is factory set to ×12.**

## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec.

## Combinations of Internally Mounted Accessories (Optional)





## Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Outline dimensions (mm) ZNE400-NF, ZNS400-NF

### Front-connected





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Control circuit




## Time/Current characteristic curves ZNE400-NF





# 7 Characteristics and Outline Dimensions

## Earth Leakage Circuit Breaker for distribution boards and control boards

## TZ30EC, TZ50EE

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | | 30 | | 50 | | |
| Type | | | | TZ30EC | | TZ50EE | | |
| Number of poles | | | | 2 | 3 | 2 | 3 | |
| Phase and wires | 1ø2W | | ⑭ | ● | ● | ● | ● | |
| | 3ø3W, 1ø3W | | ⑮ | ●(1ø3W) | ● | ●(1ø3W) | ● | |
| **■ Ratings** | | | | | | | | |
| Rated current, A | | | | 5 30 | | 5 30 | | |
| Calibrated at 40°C | | | | 10 | | 10 40 | | |
| | | | | 15 | | 15 50 | | |
| | | | | 20 | | 20 | | |
| Rated operational voltage | AC V | | | 100-240 common | | 100-240 common | | |
| | Operable voltage fluctuation range V | | | 80—264 | | 80—264 | | |
| Rated sensitivity current mA | Instantaneous tripping type | | | 15, 30 | | 15, 30, 100 | | |
| | Max. operating time sec | | | 0.1 | | 0.1 | | |
| **■ Rated breaking capacity, kA** | | | | | | | | |
| JIS C 8201-2-2 Ann.2 | | AC | 240V | 2.5 | | 5 | | |
| $I_{cu}$ (sym) | | | 200V | 2.5 | | 5 | | |
| | | | 100/200V | 2.5 | | 5 | | |
| | | | 100V | 2.5 | | 5 | | |
| Weight (◉ marked standard type) kg | | | | 0.4 | 0.5 | 0.4 | 0.5 | |
| **■ Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | | ◉ ㊺ | | ◉ ㊺ | | |
| DIN rail mount | | | | ○ ㊿ | | ○ ㊿ | | |
| Clip-in chassis mount | | | | ◉ | | ◉ | | |
| **■ Accessories (optional)** | | | **Symbol** | | | | | |
| Externally mounted: Toggle holder | | | H H | ● | | ● | | |
| Toggle lock | | | H L | — | | — | | |
| Toggle cap | | | H C | — | | — | | |
| Terminal cover For front-connected | | | C F | ● | | ● | | |
| Terminal block for lead | | | T F | ● | | ● | | |
| CE marking | | | | Non | | Non | | |
| Earth leakage trip mechanism (Current operation type) | | | | Electronic | | Electronic | | |
| Overcurrent trip mechanism | | | | Hydraulic-magnetic type | | Hydraulic-magnetic type | | |
| Earth leakage indication | | | | Mechanical button | | Mechanical button | | |
| Colour of cover | | | | Grey | | Grey | | |
| Trip button (Colour) | | | | Yes (Red) | | Yes (Red) | | |
| Reverse connection | | | | Yes | | Yes | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available".


⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.

⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.


㊺ : A wire clamping terminal is provided.

㊿ : Please order the DIN rail mounting bracket separately. (Order type: 50EE-RAIL, 1 set per unit)


## Time/Current characteristic curves





## Ambient compensating curves




## Earth leakage trip characteristic





## Combinations of Internally Mounted Accessories (Optional)





Note: If the Megger test switch is mounted, the auxiliary switch cannot be mounted.

## Outline dimensions (mm) TZ30EC, TZ50EE




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Drilling plan




NOTE: 1.Clip-in chassis is notched between every two pieces to adjust number of pieces to number of breaker poles. (Bend once or twice to snap off.)

2.Screw clip-in chassis down at 4 or 5 pole intervals.

## Control circuit






# 7 Characteristics and Outline Dimensions

## Earth Leakage Circuit Breaker for distribution boards and control boards

## TZ100EC

## Ratings and Specifications

| | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 100 | | | | | |
| Type | | | TZ100EC | | | | | |
| Number of poles | | | 3 | | | | | |
| Phase and wires | 1ø2W | ⑭ | ● | | | | | |
| | 3ø3W, 1ø3W | ⑮ | ● | | | | | |
| **■ Ratings** | | | | | | | | |
| Rated current, A | | | 60 | | | | | |
| Calibrated at 40°C | | | 75 | | | | | |
| | | | 100 | | | | | |
| Rated operational voltage | AC V | | 100-240 | | | | | |
| | | | common | | | | | |
| | Operable voltage fluctuation range V | | 80—264 | | | | | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30、100 | | | | | |
| | Max. operating time sec | | 0.1 | | | | | |
| **■ Rated breaking capacity, kA** | | | | | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 240V | 5 | | | | | |
| $I_{cu}$ (sym) | | 200V | 5 | | | | | |
| | | 100/200V | 5 | | | | | |
| | | 100V | 5 | | | | | |
| Weight (◉ marked standard type) kg | | | 0.5 | | | | | |
| **■ Connections and Mountings** | | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | | | |
| DIN rail mount | | | ○ ⑫ | | | | | |
| Clip-in chassis mount | | | ◉ | | | | | |
| **■ Accessories (optional)** | | Symbol | | | | | | |
| Externally mounted: Toggle holder | | H H | ● | | | | | |
| Toggle lock | | H L | — | | | | | |
| Toggle cap | | H C | — | | | | | |
| Terminal cover For front-connected | | C F | ● | | | | | |
| Terminal block for lead | | T F | ● | | | | | |
| CE marking | | | Non | | | | | |
| Earth leakage trip mechanism | | | Electronic | | | | | |
| Overcurrent trip mechanism (Current operation type) | | | Hydraulic-magnetic type | | | | | |
| Earth leakage indication | | | Mechanical button | | | | | |
| Colour of cover | | | Grey | | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | | |
| Reverse connection | | | Yes | | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering.


● : "yes" or "available". — : "no" or "not available".

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.


⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.

⑫ : Please order the DIN rail mounting bracket separately. (Order type: 50EE-RAIL, 1 set per unit)


## Time/Current characteristic curves





## Ambient compensating curves




## Earth leakage trip characteristic





## Combinations of Internally Mounted Accessories (Optional)





Note: If the Megger test switch is mounted, the auxiliary switch cannot be mounted.


## Outline dimensions (mm) TZ100EC




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Drilling plan





NOTE: 1.Clip-in chassis is notched between every two pieces to adjust number of pieces to number of breaker poles. (Bend once or twice to snap off.)

2.Screw clip-in chassis down at 4 or 5 pole intervals.

## Control circuit





# 7 Characteristics and Outline Dimensions

## Earth Leakage Circuit Breaker for distribution boards and control boards

## TZ-51C, TZ-52C

## Ratings and Specifications

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | | 50 | 50 |
| Type | | | TZ-51C | TZ-52C |
| Number of poles | | | 2 ㊸㊹ | 2 |
| Phase and wires | 1ø2W | ⑭ | ● | ● |
| | 3ø3W, 1ø3W | ⑮ | — | ●(1ø3W) |
| ■Ratings | | | | |
| Rated current, A | | | 15 | 15 |
| Calibrated at 40°C | | | 20 | 20 |
| | | | 30 | 30 |
| Rated operational voltage | AC V | | 100 | 100-200 common |
| | Operable voltage fluctuation range V | | 80—121 | 80—242 |
| Rated sensitivity current mA | Instantaneous tripping type | | 15, 30 | 15, 30 |
| | Max. operating time sec | | 0.1 | 0.1 |
| ■Rated breaking capacity, kA | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 240V | — | — |
| $I_{cu}$ (sym) | | 200V | — | 2.5 |
| | | 100/200V | — | 5 |
| | | 100V | 5 | — |
| Weight (◉ marked standard type) kg | | | 0.15 | 0.16 |
| ■Connections and Mountings | | | | |
| Front-connected (FC) | Terminal screws | | ◉ ㊽ | ◉ ㊽ |
| DIN rail mount | | | — | — |
| Clip-in chassis mount | | | ◉ | ◉ |
| ■Accessories (optional) | | Symbol | | |
| Externally mounted: Toggle holder | | H H | ● | ● |
| Toggle lock | | H L | — | — |
| Toggle cap | | H C | ● | ● |
| Terminal cover For front-connected | | C F | — | — |
| Terminal block for lead | | T F | — | — |
| CE marking | | | Non | Non |
| Earth leakage trip mechanism | | | Electronic | Electronic |
| Overcurrent trip mechanism (Current operation type) | | | Thermal-magnetic | Thermal-magnetic |
| Earth leakage indication | | | Mechanical button | Mechanical button |
| Colour of cover | | | Black | Black |
| Trip button (Colour) | | | Non | Non |
| Reverse connection | | | Non | Non |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.


○ : Optional standard. Specify when ordering.

● : "yes" or "available". — : "no" or "not available".


㊸ : This is 2-pole 1-element. ㊽ : Distribution board branch conductors and busbar conductor supports are available. (Optional) ㊹ : **TZ-51C** does not support harmonics or surges. Please use **TZ-52C** if necessary.

**Remark: TZ-51C** and **TZ-52C** types are compatible with **TB-51C** and **TB-52C**.


## Time/Current characteristic curves




## Ambient compensating curves





## Earth leakage trip characteristic





## Support for distribution board branch conductors and busbar conductors

Prepare branch conductors (optional) and busbar mounting screws.





| Type | Qty used / 1 row | | |
|---|---|---|---|
| | Single-phase 100V | Single-phase 200V | Single-phase 100V / 200V |
| TBJ-1V | 2 | — | 1 |
| TBJ-2N | 1 | — | — |
| TBJ-2V | — | 2 | 1 |
| TBJ-1N | — | — | 1 |

Busbar conductor support type BJ-3S





Note: For connection, see the conductor layout diagram on page 7-225.

## Outline dimensions (mm) TZ-51C, TZ-52C




## Clip-in chassis mounting dimensions


Clip-in Chassis, part number TDB-50SG (optional)
(12-pieces snap-off chassis)




NOTE: 1.Clip-in chassis is notched between every two pieces to adjust number of pieces to number of breaker poles. (Bend once or twice to snap off.)

2.Screw clip-in chassis down at 4 or 5 pole intervals.

## Conductor layout diagram




(Note) Tightening torque of branch conductor connecting screws: 2 to 2.9 Nm

(Note) Tightening torque of branch conductor connecting screws: 2 to 2.9 Nm


(Note) Tightening torque of branch conductor connecting screws: 2 to 2.9 Nm

# Special Breakers


# High-Performance Electronic Smart Circuit Breaker (TPOU type OCR)

## Outline dimensions (mm) — PS125-NE/PE

### Front-connected





Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


## Outline dimensions (mm) — PS250-NE/PE

### Front-connected




*For the extension bars, straight bars or spread bars can be supplied.


Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Outline dimensions (mm) PS400-NE/GE, PH400-CE

### Front-connected





Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Outline dimensions (mm) PS630-NE/GE, PH630-CE

### Front-connected





Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Outline dimensions (mm) — H400-NE, L400-NE


### Front-connected




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Outline dimensions (mm) — S630-NE


### Front-connected




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Outline dimensions (mm) — H630-NE, L630-NE

### Front-connected






Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


Note: All high-performance electronic circuit breakers are supplied with an OCR controller. The panel cutout differs from the standard type electronic circuit breaker. For other than front-connected connections, see the standard type outline dimension drawing.

## Outline dimensions (mm) S800-NE

### Front-connected













Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Outline dimensions (mm) H800-NE, L800-NE

### Front-connected













Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Outline dimensions (mm) S1000-CE

### Front-connected




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

Note: All high-performance electronic circuit breakers are supplied with an OCR controller. The panel cutout differs from the standard type electronic circuit breaker. For other than front-connected connections, see the standard type outline dimension drawing.

# Special Breakers

# 690V AC Circuit Breaker



## Ratings and Specifications

| Type | L125-PF | | | | |
|---|---|---|---|---|---|
| Number of poles | 3 | | | | |
| ■Ratings | | | | | |
| Rated current, A | 15 | 60 | | | |
| Calibrated at 45°C | 20 | 75 | | | |
| | 30 | 100 | | | |
| | 40 | 125 | | | |
| | 50 | | | | |
| Rated insulation voltage〔$U_i$〕 V | 690 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | 8 | | | | |
| ■Rated breaking capacity, kA | | | | | |
| IEC 60947-2 $I_{cu}/I_{cs}$(sym) AC 690V | 70/33 | | | | |
| ■Rated short time withstand current 〔$I_{cw}$〕 kA | — | | | | |
| Weight (◉ marked standard type) kg | 2.4 | | | | |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) Terminal screws | ◉ | | | | |
| With extension bars | ○ | | | | |
| Rear-connected (RC) Flat bar studs | ○ | | | | |
| Plug-in (PM) For switchboards High-performance (PMB) | ○ ㊿1 | | | | |
| Standard (PMC) | — | | | | |
| For distribution boards (PMD) | — | | | | |
| Flush-mounted (FP) With flat bar studs | — | | | | |
| Draw-out type (DR) | — | | | | |
| TemPlug70 (PG) | — | | | | |
| DIN rail mount | — | | | | |
| Clip-in chassis mount | — | | | | |
| ■Accessories (optional) Symbol | | | | | |
| Externally mounted: Motor operator M C | ● | | | | |
| External operating handle: Breaker-mounted H B | ● | | | | |
| Door-mounted (variable depth) H P | ● | | | | |
| Toggle extension H A | — | | | | |
| Mechanical interlock: Slide type M S | ● | | | | |
| Toggle holder H H | ● | | | | |
| Toggle lock H L | ● | | | | |
| Terminal cover: For front-connected C F | ● | | | | |
| For rear-connected and plug-in C R | ● ㊿6 | | | | |
| Terminal block for lead T F | ● | | | | |
| Door flange D F | ● | | | | |
| CE marking | Yes | | | | |
| Overcurrent trip mechanism | Thermal-magnetic | | | | |
| Colour of cover | Grey Blue | | | | |
| Trip button (Colour) | Yes (Red) | | | | |
| Suitability for isolation | Yes | | | | |
| Reverse connection | Non | | | | |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


㊿1 : A safety lock function is provided.

㊿6 : Terminal covers are provided as standard on the line side and load side.

## Time/Current characteristic curves




## Ambient compensating curves





## Combinations of Internally Mounted Accessories (Optional)

| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3 | | | | | | | | | | | |

Toggle — Left pole / Right pole


# Outline dimensions (mm) L125-PF

## Front-connected





* Be sure to mount the standard equipment insulating cap.

## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Plug-in (High-performance)





# 7 Characteristics and Outline Dimensions TemBreak PRO

## Special Breakers

## 690V AC Circuit Breaker

## Ratings and Specifications

| Type | | | L400-PE | | |
|---|---|---|---|---|---|
| Number of poles | | | 3 | | |
| ■Ratings | | | | | |
| Rated current, A | | | (Adjustable) | (Adjustable) | |
| Calibrated at 45°C | | | 125 | 175 | |
| | | | 150 | 200 | |
| | | | 175 | 225 | |
| | | | 200 | 250 | |
| | | | 225 | 300 | |
| | | | | 350 | |
| | | | | 400 | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | |
| ■Rated breaking capacity, kA | | | | | |
| IEC 60947-2 $I_{cu}/I_{cs}$(sym) | | AC 690V | 70/50 | | |
| ■Rated short time withstand current 〔$I_{cw}$〕 kA | | | 5(0.3sec) | | |
| Weight (◉ marked standard type) kg | | | 8.9 | | |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) | Terminal screws | | — | | |
| | With extension bars | | — | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | ○ ㊶ | | |
| | Standard (PMC) | | ◉ | | |
| For distribution boards (PMD) | | | — | | |
| Flush-mounted (FP) | With flat bar studs | | — | | |
| Draw-out type (DR) | | | — | | |
| TemPlug70 (PG) | | | — | | |
| DIN rail mount | | | — | | |
| Clip-in chassis mount | | | — | | |
| ■Accessories (optional) | | Symbol | | | |
| Externally mounted: Motor operator | | M C | ● | | |
| External operating handle: Breaker-mounted | | H B | ● | | |
| External operating handle: Door-mounted (variable depth) | | H P | ● | | |
| Toggle extension | | H A | — | | |
| Mechanical interlock | Slide type | M S | ● | | |
| Toggle holder | | H H | ● | | |
| Toggle lock | | H L | | | |
| Terminal cover | For front-connected | C F | — | | |
| | For rear-connected and plug-in | C R | ● ㊻ | | |
| Terminal block for lead | | T F | ● | | |
| Door flange | | D F | ● | | |
| CE marking | | | Yes | | |
| Overcurrent trip mechanism | | | Electronic ⑯ | | |
| Colour of cover | | | Grey Blue | | |
| Trip button (Colour) | | | Yes (Red) | | |
| Suitability for isolation | | | Yes | | |
| Reverse connection | | | Non | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.


○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑯ : Optional preferential alarm or ground fault trip function available on request.

㊶ : A safety lock function is provided.

㊻ : Terminal covers are provided as standard on the line side and load side.

## Time/Current characteristic curves




## Overcurrent tripping characteristics

| Characteristics No. | | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | | CT rated current : ($I_{CT}$) = 250A<br>125, 150, 175, 200, 225 | | | | | | |
| | | CT rated current : ($I_{CT}$) = 400A<br>175, 200, 225, 250, 300, 350, 400 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) | ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | | ($I_r$)×1400% Max. ($I_{CT}$)×1300%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | | |
| Pick-up current (A) : ($I_p$) | | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | | |
| Pick-up current (A) : ($I_g$) | | ($I_{CT}$)×20% Setting tolerance ±15% ① | | | | | | |
| Time settings (s) : ($t_g$) | | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| Neutral protection | | | | | | | | |
| Pick-up current (A) : ($I_N$) | | ($I_r$)×100% or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Note ① : When ($I_{CT}$)=250A, ground fault trip cannot be used.

Note ② : When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$) × 50% is set.

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.


## Combinations of Internally Mounted Accessories (Optional)

| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3 | | | | | | | | | | | |

Toggle — Left pole / Right pole


# Outline dimensions (mm) L400-PE

## Rear-connected






∗ Be sure to mount the standard equipment insulating cap.
Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Plug-in (Standard)




## Plug-in (High-performance)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

# Special Breakers

# 690V AC Circuit Breaker



## Ratings and Specifications

| Type | L800-PE | | | | |
|---|---|---|---|---|---|
| Number of poles | 3 | | | | |
| ■Ratings | | | | | |
| Rated current, A | (Adjustable) | | | | |
| Calibrated at 45°C | 350 600<br>400 700<br>450 800<br>500 | | | | |
| Rated insulation voltage〔$U_i$〕 V | 690 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | 8 | | | | |
| ■Rated breaking capacity, kA | | | | | |
| IEC 60947-2 $I_{cu}/I_{cs}$(sym) AC 690V | 70/50 | | | | |
| ■Rated short time withstand current 〔$I_{cw}$〕 kA | 10(0.3sec) | | | | |
| Weight (◉ marked standard type) kg | 15.6 | | | | |
| ■Connections and Mountings | | | | | |
| Front-connected (FC) Terminal screws | — | | | | |
| With extension bars | — | | | | |
| Rear-connected (RC) Flat bar studs | ○ | | | | |
| Plug-in (PM) For switchboards High-performance (PMB) | ○ ㊶ | | | | |
| Standard (PMC) | ◉ | | | | |
| For distribution boards (PMD) | — | | | | |
| Flush-mounted (FP) With flat bar studs | — | | | | |
| Draw-out type (DR) | — | | | | |
| TemPlug70 (PG) | — | | | | |
| DIN rail mount | — | | | | |
| Clip-in chassis mount | — | | | | |
| ■Accessories (optional) Symbol | | | | | |
| Externally mounted: Motor operator M C | ● | | | | |
| External operating handle: Breaker-mounted H B | ● | | | | |
| Door-mounted (variable depth) H P | ● | | | | |
| Toggle extension H A | ● | | | | |
| Mechanical interlock: Slide type M S | ● | | | | |
| Toggle holder H H | ● | | | | |
| Toggle lock H L | | | | | |
| Terminal cover: For front-connected C F | — | | | | |
| For rear-connected and plug-in C R | ● ㊻ | | | | |
| Terminal block for lead T F | ● | | | | |
| Door flange D F | ● | | | | |
| CE marking | Yes | | | | |
| Overcurrent trip mechanism | Electronic ⑯ | | | | |
| Colour of cover | Grey Blue | | | | |
| Trip button (Colour) | Yes (Red) | | | | |
| Suitability for isolation | Yes | | | | |
| Reverse connection | Non | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.


○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑯ : Optional preferential alarm or ground fault trip function available on request.

㊶ : A safety lock function is provided.

㊻ : Terminal covers are provided as standard on the line side and load side.

## Time/Current characteristic curves




## Overcurrent tripping characteristics

| Characteristics No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|---|---|---|---|---|---|---|
| Rated current settings (A) : ($I_r$) | CT rated current : ($I_{CT}$) = 800A<br>350, 400, 450, 500, 600, 700, 800 | | | | | | |
| Long time-delay time settings (s) : ($t_r$) | 11 | 21 | 21 | 5 | 10 | 19 | 29 |
| | at ($I_r$)×200% | | | at ($I_r$)×600% | | | |
| | Setting tolerance ±20% | | | | | | |
| Short time-delay pick-up current (A) : ($I_{sd}$) ($I_r$)× | 2.5 | 2.5 | 5 | 10 | 10 | 10 | 10 |
| | Setting tolerance ±15% | | | | | | |
| Short time-delay time settings (s) : ($t_{sd}$) | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 | 0.2 |
| | Total clearing time +50ms, resettable time –20ms | | | | | | |
| Instantaneous trip pick-up current (A) : ($I_i$) | ($I_r$)×1400% Max. ($I_{CT}$)×1200%<br>Setting tolerance ±20% | | | | | | |
| Option: Preferential trip alarm | | | | | | | |
| Pick-up current (A) : ($I_p$) | ($I_r$)×80% Setting tolerance ±10% | | | | | | |
| Time settings (s) : ($t_p$) | Definite time-delay characteristic, 40sec. Setting tolerance ±10% | | | | | | |
| Ground falut trip | | | | | | | |
| Pick-up current (A) : ($I_g$) | ($I_{CT}$)×20% Setting tolerance ±15% | | | | | | |
| Time settings (s) : ($t_g$) | Definite time-delay characteristic, 0.2sec.<br>Total tripping time +50ms, resettable time –20ms. | | | | | | |
| Neutral protection | | | | | | | |
| Pick-up current (A) : ($I_N$) | ($I_r$)×100% or 50% selectable ② | | | | | | |
| Time settings (s) : ($t_N$) | ($t_N$)=($t_r$) Same as Long time-delay time settings | | | | | | |

Remark: Characteristic No.4 will be applied as standard setting unless otherwise specified.

Note ② : When ($I_r$) < ($I_{CT}$), the pick-up current tolerance becomes large when ($I_N$)=($I_r$) × 50% is set.


## Combinations of Internally Mounted Accessories (Optional)

| Poles | AX<br>Auxiliary switch | AL<br>Alarm switch | SH<br>Shunt trip | UV<br>Under voltage trip | AX<br>AL | AX<br>SH | AX<br>UV | AL<br>SH | AL<br>UV | AX<br>AL<br>SH | AX<br>AL<br>UV |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 3 | | | | | | | | | | | |

Toggle — Left pole / Right pole


# Outline dimensions (mm) L800-PE

## Rear-connected






Note: Studs are factory installed in horizontal direction both on the line and load sides.

## Plug-in (Standard)




## Plug-in (High-performance)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Ratings and Specifications


| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | | | | |
| Type | | | E400-SF | | | | |
| Number of poles | | | 3 | | | | |
| ■ Ratings | | | | | | | |
| Rated current, A | | | 250 | | | | |
| Calibrated at 40° C | | | 300 | | | | |
| | | | 350 | | | | |
| | | | 400 | | | | |
| Rated insulation voltage〔$U_i$〕 V | | | 690 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | |
| Rated short time withstand current 〔$I_{cw}$〕 kA | | | — | | | | |
| Utilization Category | | | A | | | | |
| ■ Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.1 Ann.2 | | AC 690V | — | | | | |
| IEC 60947-2 | | 500V | 15/15 | | | | |
| $I_{cu}/I_{cs}$(sym) | | 440V | 25/22 | | | | |
| | | 415V | 36/25 | | | | |
| | | 380V | 36/25 | | | | |
| | | 240V | 50/35 | | | | |
| | ① | DC 250V | 25/19 | | | | |
| | | 125V | 40/30 | | | | |
| NK | | AC 690V | — | | | | |
| $I_{cu}/I_{cs}$(sym) | | 450V | — | | | | |
| | | 240V | — | | | | |
| | ① | DC 250V | — | | | | |
| Weight (◉ marked standard type) kg | | | 4.1 | | | | |
| ■ Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | | |
| | With extension bars | | ○ | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | |
| | Standard (PMC) | | — | | | | |
| For distribution boards (PMD) | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | |
| Draw-out type (DR) | | | — | | | | |
| TemPlug70 (PG) | | | — | | | | |
| DIN rail mount | | | — | | | | |
| ■ Accessories (optional) | | | Symbol | | | | |
| Externally mounted: Motor operator | | | M C | — | | | |
| External operating handle: Breaker-mounted | | | H B | ● | | | |
| Door-mounted (variable depth) | | | H P | — | | | |
| Toggle extension | | | H A | ● | | | |
| Mechanical interlock: Slide type | | | M S | ● | | | |
| Rear-connected type | | | M B | — | | | |
| Link type | | | M L | — | | | |
| Wire type | | | M W | — | | | |
| Toggle holder | | | H H | ● | | | |
| Toggle lock | | | H L | | | | |
| Terminal cover: For front-connected | | | C F | ● | | | |
| For rear-connected and plug-in | | | C R | ● | | | |
| Terminal block for lead | | | T F | ● | | | |
| Door flange | | | D F | ● | | | |
| CE marking | | | | Yes | | | |
| Overcurrent trip mechanism | | | | Thermal-magnetic | | | |
| Colour of cover | | | | Grey Blue | | | |
| Trip button (Colour) | | | | Yes (Red) | | | |
| Suitability for isolation | | | | Yes | | | |
| Reverse connection | | | | Yes | | | |

**Notes:**
◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".
① : DC is a special specification. When ordering, please specify DC.

## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) $I_n\times$ 10 |
|---|---|
| 250 | 2500 |
| 300 | 3000 |
| 350 | 3500 |
| 400 | 4000 |

Note (1) : Setting tolerance: ±20%.


## Combinations of Internally Mounted Accessories (Optional)





Note: For auxiliary switches or alarm switches, left-hand mounting has priority.

# Outline dimensions (mm) E400-SF

## Front-connected





## Rear-connected




Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted




Note: Studs are factory installed in horizontal direction both on the line and load sides.

Notes ① : 134mm can also be used. However, the toggle extension cannot be used.
② : 144mm can also be used. However, the toggle extension cannot be used.
③ : 43mm can also be used. However, the toggle extension cannot be used.

# Special Breakers

# Circuit Breaker with earth leakage alarm

## Ratings and Specifications

| | | | | | | | |
|---|---|---|---|---|---|---|---|
| Frame size (A) | | | 400 | | | | |
| Type | | | ZAE400-SF | | | | |
| Number of poles | | | 3 | | | | |
| ■ Ratings | | | | | | | |
| Rated current, A | | | 250 | | | | |
| Calibrated at 40°C | | | 300 | | | | |
| | | | 350 | | | | |
| | | | 400 | | | | |
| Rated insulation voltage AC V | | | 100-440 common | | | | |
| Operable voltage fluctuation range V | | | 80—484 | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | | | | |
| ■ Rated breaking capacity, kA | | | | | | | |
| JIS C 8201-2-1 Ann.2 | AC | 440V | 25 | | | | |
| $I_{cu}$(sym) | | 415V | 36 | | | | |
| | | 240V | 50 | | | | |
| ■ Earth leakage alarm specifications | | | | | | | |
| Earth leakage detection (Current operation type) | | | Electronic | | | | |
| Rated sensitivity current mA | | Instantaneous tripping type | — | | | | |
| | | Time delay type | 100/200/500 selectable | | | | |
| Max. operating time sec | | Instantaneous tripping type | — | | | | |
| | | Time delay type | 0.1/0.45/1.0 selectable | | | | |
| Earth leakage alarm output contact configuration | | | 1c | | | | |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ | | | | |
| Weight (◉ marked standard type) kg | | | 4.7 | | | | |
| ■ Connections and Mountings | | | | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | | | | |
| | With extension bars | | ○ | | | | |
| Rear-connected (RC) | Flat bar studs | | ○ | | | | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | | | | |
| | Standard (PMC) | | — | | | | |
| For distribution boards (PMD) | | | — | | | | |
| Flush-mounted (FP) | With flat bar studs | | ○ | | | | |
| Draw-out type (DR) | | | — | | | | |
| TemPlug70 (PG) | | | — | | | | |
| DIN rail mount | | | — | | | | |
| ■ Accessories (optional) | | Symbol | | | | | |
| Externally mounted: Motor operator | | M C | — | | | | |
| External operating handle: Breaker-mounted | | H B | ● | | | | |
| Door-mounted (variable depth) | | H P | — | | | | |
| Toggle extension | | H A | ● | | | | |
| Mechanical interlock: Slide type | | M S | ● | | | | |
| Rear-connected type | | M B | — | | | | |
| Link type | | M L | — | | | | |
| Wire type | | M W | — | | | | |
| Toggle holder | | H H | ● | | | | |
| Toggle lock | | H L | | | | | |
| Terminal cover: For front-connected | | C F | ● | | | | |
| For rear-connected and plug-in | | C R | ● | | | | |
| Terminal block for lead | | T F | ● | | | | |
| Door flange | | D F | — | | | | |
| CE marking | | | Non | | | | |
| Overcurrent trip mechanism | | | Thermal-magnetic | | | | |
| Earth leakage indication | | | Red LED | | | | |
| Colour of cover | | | Grey Blue | | | | |
| Trip button (Colour) | | | Yes (Red) | | | | |
| Suitability for isolation | | | Yes | | | | |
| Reverse connection | | | Yes | | | | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.
○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".
⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details.
⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.
⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.
㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.


**Remark:** The rated sensitivity current is set to 100mA and the time delay tripping type's operating time is set to 0.45 seconds before delivery.

## Combinations of Internally Mounted Accessories (Optional)


| Poles | AX | AL | MG | AX | MG | MG | MG | TL |
|---|---|---|---|---|---|---|---|---|
| | Auxiliary switch | Alarm switch | Megger measurement switch | AL | AX | AL | AX<br>AL | Test lead |
| 3 | | | | | | | | |

Toggle — Left pole / Right pole

## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) | $I_n$ × | Magnetic trip pick-up current (adjustable range) (A) |
|---|---|---|
| 250 | 10 | 2500 |
| 300 | | 3000 |
| 350 | | 3500 |
| 400 | | 4000 |

Note (1) : Setting tolerance: ±20%.


## Earth leakage trip characteristic






Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.


# Outline dimensions (mm) ZAE400-SF


## Front-connected





















## Rear-connected













Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted (For leakage alarm lead wires, see the front-connected type)








Note: Studs are factory installed in horizontal direction both on the line and load sides.

Notes ① : 134mm can also be used. However, the toggle extension cannot be used.
② : 144mm can also be used. However, the toggle extension cannot be used.
③ : 43mm can also be used. However, the toggle extension cannot be used.

## Control circuit



# Special Breakers

## Single phase 3-wire circuit breakers with neutral phase open protection and earth leakage alarm

## Ratings and Specifications

| | | | |
|---|---|---|---|
| Frame size (A) | | | 400 |
| Type | | | NAE400-SF |
| Number of poles / Elements | | | 3P3E ⑩ |
| Phase and wires | | | 1ø3W |
| ■ Ratings | | | |
| Rated current, A | | | 250 |
| Calibrated at 40°C | | | 300 |
| | | | 350 |
| | | | 400 |
| Rated operational voltage AC V | | | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 |
| | Rated non-operating overvoltage AC V | | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less |
| ■ Rated breaking capacity, kA | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) AC 100/200V | | | 50 |
| Weight (◉ marked standard type) kg | | | 4.9 |
| ■ Earth leakage alarm specifications | | | |
| Earth leakage detection (Current operation type) | | | Electronic |
| Rated sensitivity current mA | | | 30/100/500 selectable |
| | | | 100/200/500 selectable |
| Max. operating time sec | | | 0.1/0.45/1.0 selectable |
| Earth leakage alarm output contact configuration | | | 1c |
| Alarm reset function (manual reset) ㊴ | | | Push button ⑧ |
| Earth leakage indication | | | Red LED |
| ■ Connections and Mountings | | | |
| Front-connected (FC) | Terminal screws | | ◉ |
| | With extension bars | | ○ |
| ■ Accessories (optional) | | Symbol | |
| Externally mounted: Motor operator | | M C | ● |
| Externally mounted: External operating handle | Breaker-mounted | H B | ● |
| | Door-mounted (variable depth) | H P | ● |
| Externally mounted: Toggle extension | | H A | ● |
| Externally mounted: Mechanical interlock | Slide type | M S | — |
| | Link type | M L | — |
| | Wire type | M W | — |
| Externally mounted: Toggle holder | | H H | ● |
| Externally mounted: Toggle lock | | H L | |
| Externally mounted: Terminal cover | For front-connected | C F | ● |
| Externally mounted: Terminal block for lead | | T F | ● |
| Externally mounted: Door flange | | D F | — |
| CE marking | | | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic |
| Colour of cover | | | Grey Blue |
| Trip button (Colour) | | | Yes (Red) |
| Suitability for isolation | | | Yes |
| Reverse power flow circuit | | | Yes ㉕ |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑧ : Optional remote reset or automatic reset available on request. Please apply this when the reset button cannot be pressed due to the installation of external accessories, etc. See page 6-27 for details.

⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.


㊴ : An earth leakage alarm maintains the operating state until pressing the reset button or turning the main circuit power OFF. If the electric leakage continues, it will be reset while you hold down the reset button, but when you release the reset button, it will return to the operating state.

㉕ : Since the overvoltage and earth leakage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) | $I_n \times$ 10 Magnetic trip pick-up current (adjustable range) (A) |
|---|---|
| 250 | 2500 |
| 300 | 3000 |
| 350 | 3500 |
| 400 | 4000 |


Note (1) : Setting tolerance: ±20%.

## Earth leakage trip characteristic





Time delay tripping type will operate on 0.15-0.45sec for 0.45sec, 0.6-1.0sec for 1.0sec.

## Combinations of Internally Mounted Accessories (Optional)




# Outline dimensions (mm) NAE400-SF

## Front-connected





Remarks 1) Side unit terminal screws M3.5
2) Tightening torque of M3.5 terminal screws: 0.9 to 1.2Nm
3) Connectable wire: 2.0mm² (max.)
4) Overvoltage detection terminal block connection length: 30m (max.)
Note ① : 134mm can also be used. However, the toggle extension cannot be used.

Drilling plan (front view)





Panel cutout A (front view)




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

### Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Control circuit



# Special Breakers

## Single phase 3-wire circuit breakers with neutral phase open protection

## Ratings and Specifications

| | | | |
|---|---|---|---|
| Frame size (A) | | | 400 |
| Type | | | NE400-SF |
| Number of poles / Elements | | | 3P3E ⑩ |
| Phase and wires | | | 1ø3W |
| ■ Ratings | | | |
| Rated current, A | | | 250 |
| Calibrated at 40°C | | | 300 |
| | | | 350 |
| | | | 400 |
| Rated operational voltage AC V | | | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 |
| | Rated non-operating overvoltage AC V | | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less |
| ■ Rated breaking capacity, kA | | | |
| JIS C 8201-2-1 Ann.2 $I_{cu}$ (sym) AC 100/200V | | | 50 |
| Weight (◉ marked standard type) kg | | | 4.2 |
| ■ Connections and Mountings | | | |
| Front-connected (FC) | Terminal screws | | ◉ |
| | With extension bars | | ○ |
| DIN rail mount | | | — |
| ■ Accessories (optional) | | Symbol | |
| Externally mounted: Motor operator | | M C | — |
| Externally mounted: External operating handle | Breaker-mounted | H B | ● |
| Externally mounted: External operating handle | Door-mounted (variable depth) | H P | — |
| Externally mounted: Toggle extension | | H A | ● |
| Externally mounted: Mechanical interlock | Slide type | M S | ● |
| Externally mounted: Mechanical interlock | Link type | M L | — |
| Externally mounted: Mechanical interlock | Wire type | M W | — |
| Externally mounted: Toggle holder | | H H | ● |
| Externally mounted: Toggle lock | | H L | |
| Externally mounted: Terminal cover | For front-connected | C F | ● |
| Externally mounted: Terminal block for lead | | T F | ● |
| Externally mounted: Door flange | | D F | — |
| CE marking | | | Non |
| Overcurrent trip mechanism | | | Thermal-magnetic |
| Overvoltage operation indication function | | | Mechanical button |
| Colour of cover | | | Grey Blue |
| Trip button (Colour) | | | Yes (Red) |
| Suitability for isolation | | | Yes |
| Reverse power flow circuit | | | Yes ⑭ |

**Notes:**


◉ : Standard. This configuration used unless otherwise specified.

○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".


⑩ : They can also be applied to circuits where overcurrent flows in the neutral wire.

⑭ : Since the overvoltage detection circuit has a continuous rating specification, there is no need to turn off the power of the detection circuit using a megger test switch, etc.

## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current

| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) $I_n \times$ 10 |
|---|---|
| 250 | 2500 |
| 300 | 3000 |
| 350 | 3500 |
| 400 | 4000 |


Note (1) : Setting tolerance: ±20%.

## Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.





## Combinations of Internally Mounted Accessories (Optional)



℄ : Handle Centre Line

## Outline dimensions (mm) NE400-SF


### Front-connected




Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

Note ① : 134mm can also be used. However, the toggle extension cannot be used.

## Control circuit



# Special Breakers

# Earth Leakage Circuit Breakers

## Ratings and Specifications

| | | | | |
|---|---|---|---|---|
| Frame size (A) | | | 400 | |
| Type | | | ZE400-SF | |
| Number of poles | | | 3 | |
| Phase and wires | 1ø2W | ⑭ | ● | |
| | 3ø3W, 1ø3W | ⑮ | ● | |
| | 3ø4W | | — | |
| **■ Ratings** | | | | |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 | |
| Rated current, A Calibrated at 40°C | | | 250 400 300 350 | |
| Rated operational voltage AC V | Instantaneous tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80—484 | |
| | Time delay tripping type | | 100-440 common | |
| | Operable voltage fluctuation range V | | 80—484 | |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 | |
| | | | 100/200/500 selectable | |
| | | | — | |
| | Max. operating time sec | | 0.1 | |
| | Time delay tripping type | | 100/200/500 selectable | |
| | Max. operating time sec | | 0.45/1.0/2.0 selectable | |
| | Non-operating time sec | | 0.1/0.5/1.2 or more | |
| **■ Rated breaking capacity, kA** | | | | |
| JIS C 8201-2-2 Ann.2 | AC | 440V | 25 | |
| $I_{cu}$(sym) | | 415V | 36 | |
| | | 240V | 50 | |
| | | 100V | 50 | |
| Weight (◉ marked standard type) kg | | | 4.7 | |
| **■ Connections and Mountings** | | | | |
| Front-connected (FC) | Terminal screws | | ◉ | |
| | With extension bars | | ○ | |
| Rear-connected (RC) | Flat bar studs | | ○ | |
| Plug-in (PM) For switchboards | High-performance (PMB) | | — | |
| | Standard (PMC) | | — | |
| For distribution boards (PMD) | | | — | |
| Flush-mounted (FP) | With flat bar studs | | ○ | |
| Draw-out type (DR) | | | — | |
| TemPlug70 (PG) | | | — | |
| DIN rail mount | | | — | |
| **■ Accessories (optional)** | | Symbol | | |
| Externally mounted: Motor operator | | M C | — | |
| External operating handle | Breaker-mounted | H B | ● | |
| | Door-mounted (variable depth) | H P | — | |
| Toggle extension | | H A | ● | |
| Mechanical interlock | Slide type | M S | ● | |
| | Link type | M L | — | |
| | Wire type | M W | — | |
| Toggle holder | | H H | ● | |
| Toggle lock | | H L | | |
| Terminal cover | For front-connected | C F | ● | |
| | For rear-connected and plug-in | C R | ● | |
| Terminal block for lead | | T F | ● | |
| Door flange | | D F | — | |
| CE marking | | | Non | |
| Earth leakage trip mechanism (Current operation type) | | | Electronic | |
| Overcurrent trip mechanism | | | Thermal-magnetic | |
| Earth leakage indication | | | Mechanical button | |
| Colour of cover | | | Grey Blue | |
| Trip button (Colour) | | | Yes (Red) | |
| Suitability for isolation | | | Yes | |
| Reverse connection | | | Yes | |

**Notes:**

◉ : Standard. This configuration used unless otherwise specified.


○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

⑭ : When applying 3-pole type to a 1ø2W circuit, use both ends and do not use the central pole.


⑮ : When applying 3-pole type to a 1ø3W circuit, apply voltage to both ends and connect the neutral wire to the central pole.

**Remark:** The rated sensitivity current is set to 100mA before delivery.

## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current


| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) $I_n\times$ 10 |
|---|---|
| 250 | 2500 |
| 300 | 3000 |
| 350 | 3500 |
| 400 | 4000 |

Note (1) : Setting tolerance: ±20%.

## Earth leakage trip characteristic






## Combinations of Internally Mounted Accessories (Optional)





# Outline dimensions (mm) ZE400-SF


## Front-connected




















## Rear-connected










Note: Studs are factory installed in horizontal direction both on the line and load sides.






Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.

## Flush-mounted








Note: Studs are factory installed in horizontal direction both on the line and load sides.

Notes ① : 134mm can also be used. However, the toggle extension cannot be used.
② : 144mm can also be used. However, the toggle extension cannot be used.
③ : 43mm can also be used. However, the toggle extension cannot be used.

## Control circuit



# Special Breakers

## Single phase 3-wire earth leakage circuit breakers with neutral phase open protection

## Ratings and Specifications

| | | | |
|---|---|---|---|
| Frame size (A) | | | 400 |
| Type | | | ZNE400-SF |
| Number of poles / Elements | | | 3P3E ㊵ |
| Phase and wires | | | 1ø3W |
| ■ Ratings | | | |
| Rated current, A | | | 250 |
| Calibrated at 40°C | | | 300 |
| | | | 350 |
| | | | 400 |
| Rated operational voltage AC V | | | 100/200 |
| Rated impulse withstand voltage〔$U_{imp}$〕 kV | | | 8 |
| Rated sensitivity current mA | Instantaneous tripping type | | 30 |
| | | | 100/200/500 selectable |
| | | Max. operating time sec | 0.1 |
| | Time delay tripping type | | 100/200/500 selectable |
| | | Max. operating time sec | 0.45/1.0/2.0 selectable |
| | | Non-operating time sec | 0.1/0.5/1.2 or more |
| Single 3-phase neutral wire open phase protection characteristics | Rated operating overvoltage AC V | | 135 |
| | Rated non-operating overvoltage AC V | | 120 |
| | Rated overvoltage operating time (sec) | | 1 or less |
| ■ Rated breaking capacity, kA | | | |
| JIS C 8201-2-2 Ann.2 $I_{cu}$ (sym) | | AC 100/200V | 50 |
| Weight (◉ marked standard type) kg | | | 4.7 |
| ■ Connections and Mountings | | | |
| Front-connected (FC) | Terminal screws | | ◉ |
| | With extension bars | | ○ |
| DIN rail mount | | | — |
| ■ Accessories (optional) | | Symbol | |
| Externally mounted: Motor operator | | M C | — |
| Externally mounted: External operating handle | Breaker-mounted | H B | ● |
| | Door-mounted (variable depth) | H P | — |
| Externally mounted: Toggle extension | | H A | ● |
| Externally mounted: Mechanical interlock | Slide type | M S | ● |
| | Link type | M L | — |
| | Wire type | M W | — |
| Externally mounted: Toggle holder | | H H | ● |
| Externally mounted: Toggle lock | | H L | |
| Externally mounted: Terminal cover | For front-connected | C F | ● |
| Externally mounted: Terminal block for lead | | T F | ● |
| Externally mounted: Door flange | | D F | — |
| CE marking | | | Non |
| Earth leakage trip mechanism (Current operation type) | | | Electronic |
| Overcurrent trip mechanism | | | Thermal-magnetic |
| Overvoltage / Earth leakage indication | | | Mechanical button |
| Colour of cover | | | Grey Blue |
| Trip button (Colour) | | | Yes (Red) |
| Suitability for isolation | | | Yes |
| Reverse power flow circuit | | | Yes |


**Notes:**

◉ : Standard. This configuration used unless otherwise specified.


○ : Optional standard. Specify when ordering. ● : "yes" or "available". — : "no" or "not available".

㊵ : They can also be applied to circuits where overcurrent flows in the neutral wire. Can be used as a main circuit breaker for photovoltaic power generation systems.

## Time/Current characteristic curves




## Ambient compensating curves





## Magnetic trip pick-up current


| Rated current (A) | Magnetic trip pick-up current (adjustable range) (A) $I_n\times$ 10 |
|---|---|
| 250 | 2500 |
| 300 | 3000 |
| 350 | 3500 |
| 400 | 4000 |

Note (1) : Setting tolerance: ±20%.

## Earth leakage trip characteristic





## Combinations of Internally Mounted Accessories (Optional)




℄ : Handle Centre Line

## Outline dimensions (mm) ZNE400-SF

### Front-connected




Panel cutout A (front view)





Panel cutout dimensions shown give an allowance of 1.0mm around the handle escutcheon.


Note ① : 134mm can also be used. However, the toggle extension cannot be used.

### Single phase 3-wire circuit breakers with neutral phase open protection characteristics

The operating voltage of the single phase 3-wire circuit breakers with neutral phase open protection is set at more than 120V and less than 135V. If there is an abnormal voltage above 135V due to neutral wire open phase, the circuit breaker will reliably trip within 1 second.




## Control circuit




## Type 2 heat resistance breakers


℄ : Handle Centre Line

### Outline dimensions (mm) (Front-connected)


FC-52ET Type FC-53ET Type





FC-50HET Type





FC-100ET Type




FC-225ET Type




FC-400ET Type




Note: Please contact us for characteristics and other details.


# Earth Leakage Relays

## TZS series


## Outline dimensions (mm)

• Earth Leakage Relays **(TZD-HD, TZD-MD)**


Front-connected




Drilling plan





Flush-mounted




## Circuit diagram


• Earth Leakage Relays





* TZS-HD type is not equipped with a selector switch.


Note: The output contacts remain operational until the RESET button is pressed.
If the control power supply fails, the contacts automatically reset.
Tightening torque of M3 terminal screws: 0.45 to 0.73 Nm

## Time / Current characteristic curves




• Earth leakage monitor








| ZCT | Type | Earth leakage monitor type | d ø | A | B | C | D | E | F | G | H |
|---|---|---|---|---|---|---|---|---|---|---|---|
| **TZS-15** | I | **TZS-HD, TZS-MD** | 15 | — | 55 | 60 | 32 | 28 | — | 25 | 46 |
| **TZS-24** | I | **TZS-HD, TZS-MD** | 24 | — | 67 | 72 | 40 | 32 | — | 34 | 58 |
| **TZS-40** | II | **TZS-HD, TZS-MD** | 40 | 30 | 71 | 113 | 51 | 62 | 57 | 110 | 130 |
| **TZS-68** | II | **TZS-HD, TZS-MD** | 68 | 42 | 85 | 141 | 65 | 76 | 70 | 134 | 150 |
| **TZS-100** | II | **TZS-HD, TZS-MD** | 100 | 45 | 105 | 181 | 85 | 96 | 90 | 150 | 170 |


# Circuit Breaker with motor operators

## Outline dimensions (mm) (T2MC12) S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF, ZS100-GF, ZS125-GF

### Front-connected





### Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


### Plug-in (Standard)




Panel hinge position (hatching area) (bottom view)




### Plug-in (High-performance)




Notes ① : Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.
② : When the motor operator is mounted, the test button, reset button, sensitivity selector switch, and operating time selector switch cannot be operated.


# Outline dimensions (mm) (TPMC16S) PS50-PF, PS125-NF/PF/NE/PE/NM/NN

## Front-connected





## Rear-connected


| Rated current[A] | C |
|---|---|
| 15 ～ 50 | 4 |
| 60 ～ 125 | 5 |




(Bottom view)





Drilling plan (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout (front view)





Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


## Plug-in (Standard)





Preparation of conductor





Detail of connecting part





Mounting base (rear view)





Drilling plan (front view)





Panel hinge position (hatching area) (bottom view)





## Plug-in (High-performance)





Preparation of conductor





Detail of connecting part




Mounting base (rear view)




Drilling plan (front view)





Note ① : Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.

# Circuit Breaker with motor operators


## Outline dimensions (mm) (T2MC25) — ZAS225-GF, ZAS250-GF, ZS225-GF, ZS250-GF

### Front-connected





*Spread extension bars for 3 poles. Staraight extension bars for 4 poles.

### Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


Panel hinge position (hatching area) (bottom view)




Note: When the motor operator is mounted, the test button, reset button, sensitivity selector switch, and operating time selector switch cannot be operated.


## Outline dimensions (mm) (T2MC25L) E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF, ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF

### Front-connected





＊For the extension bars, straight bars or spread bars can be supplied.

### Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout (front view)





Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.

### Plug-in (Standard)





Panel hinge position (hatching area) (bottom view)





Notes ① : Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.
② : When the motor operator is mounted, the test button, reset button, sensitivity selector switch, and operating time selector switch cannot be operated.

## Outline dimensions (mm) (TPMC25S) PS250-PF/NE/PE/NN

### Front-connected





### Rear-connected




Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout (front view)





Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.

### Plug-in (Standard)


Preparation of conductor




Panel hinge position (hatching area) (bottom view)





### Plug-in (High-performance)





Note ① : Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.

# Outline dimensions (mm) (T2MC25) H100-NF, L100-NF, H125-NF, L125-NF, H225-NF/NE, L225-NF, H250-NF, L250-NF


## Front-connected




## Rear-connected





## Panel cutout (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


## Plug-in (Standard)




## Panel hinge position (hatching area) (bottom view)



## Plug-in(High-performance)





Note: Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.


# Circuit Breaker with motor operators

## Outline dimensions (mm) (T2MC40) E400-NF, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF, ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF

### Front-connected





### Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


Panel hinge position (hatching area) (bottom view)





Notes ① : Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.
② : When the motor operator is mounted, the test button, reset button, sensitivity selector switch, and operating time selector switch cannot be operated.

# Outline dimensions (mm) (TPMC63S) PS400-CF/NF/GF/NE/GE/NN, PH400-CF/CE


## Front-connected




## Rear-connected





Panel cutout (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


## Plug-in (Standard)




Panel hinge position (hatching area) (bottom view)



## Plug-in (High-performance)





Note: Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.


# Circuit Breaker with motor operators

## Outline dimensions (mm) (TPMC63S) — PS630-CF/NF/GF/NE/GE/NN, PH630-CF/CE


### Front-connected




### Rear-connected





### Panel cutout (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


### Plug-in (Standard)




### Panel hinge position (hatching area) (bottom view)




### Plug-in (High-performance)





Note: Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.

# Outline dimensions (mm) (T2MC40) H400-NE, L400-NE

## Front-connected





## Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


## Plug-in (Standard)




Panel hinge position (hatching area) (bottom view)




## Plug-in (High-performance)



# Circuit Breaker with motor operators


## Outline dimensions (mm) (T2MC80) S630-CF/NF/NE/GN, ZAS630-CF/NF, NS630-NF, ZS630-CF/NF, S800-CF/NF/NE/RF/RE/PF/PE/NN, ZAS800-CF/NF, NS800-NF, ZS800-CF/NF

### Front-connected





| Type of breaker | t1 | t2 | L1 | L2 |
|---|---|---|---|---|
| S630-CF, S630-NF, S630-GN | 8 | 8 | 32 | 34 |
| S630-NE, NS630-NF, ZAS630-CF, ZAS630-NF, ZS630-CF, ZS630-NF | 8 | 8 | 32 | 36 |
| S800-CF, S800-NF, S800-RF, S800-PF, S800-NN | 10 | 10 | 32 | 35 |
| S800-NE, S800-RE, S800-PE, ZAS800-CF, ZAS800-NF, ZS800-CF, ZS800-NF | 10 | 10 | 32 | 36 |

### Rear-connected





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout (front view)




Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


### Plug-in (Standard)




Panel hinge position (hatching area) (bottom view)




### Plug-in(High-performance)





Notes ① : Some connection methods and number of poles are not compatible depending on the model. See the outline drawing for each model for compatibility.
② : When the motor operator is mounted, the test button, reset button, sensitivity selector switch, and operating time selector switch cannot be operated.


# Outline dimensions (mm) (T2MC80) S1000-CE/NN

## Front-connected




Drilling plan (front view)





| Type of breaker | t1 | t2 | L1 | L2 |
|---|---|---|---|---|
| S1000-CE<br>S1000-NN | 14 | 14 | 32 | 37 |


## Rear-connected

(Bottom view)

Drilling plan (front view)





Panel cutout (front view)





Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.


Panel hinge position (hatching area) (bottom view)




## Outline dimensions (mm) (T2MC80) H630-NE, L630-NE

### Front-connected








Drilling plan (front view)





### Rear-connected

(Bottom view) Drilling plan (front view)




Panel cutout (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.

### Plug-in (Standard)


Detail of connecting part




Mounting base (rear view) Drilling plan (front view)





Panel hinge position (hatching area) (bottom view)





### Plug-in (High-performance)


Detail of connecting part





Preparation of conductor





Mounting base (rear view)





Drilling plan (front view)







# Outline dimensions (mm) (T2MC80) H800-NE, L800-NE

## Front-connected





Drilling plan (front view)




## Rear-connected


(Bottom view)

Drilling plan (front view)




Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout (front view)





Panel cutout dimensions shown give an allowance of 1.5mm around motor operator.

## Plug-in (Standard)


Detail of connecting part

Mounting base (rear view)

Drilling plan (front view)




Panel hinge position (hatching area) (bottom view)




## Plug-in (High-performance)

Detail of connecting part


Mounting base (rear view)

Drilling plan (front view)




## Outline dimensions (mm) (T2MCX6) S1250-NE/GE/NN

### Front-connected





### Rear-connected




Note: Studs are factory installed in horizontal direction both on the line and load sides.


Panel cutout dimensions shown give an allowance of 1.0mm around motor operator.


### Plug-in (Standard)




## Outline dimensions (mm) (XMD9) TL-1000NE, TL-1200NE

### Front-connected








Drilling plan (front view)





### Rear-connected


(Bottom view)




Drilling plan (front view)





Panel cutout (front view)





Note: Studs are factory installed in horizontal direction both on the line and load sides.

Panel cutout dimensions shown give
an allowance of 1.0mm around motor operator.


### Plug-in (Standard)




Mounting base
(XDM8 Type)





Drilling plan (front view)




## Outline dimensions (mm) (T2MCX6) S1600-NE/NN

### Front-connected





### Rear-connected




Panel cutout dimensions shown give an allowance of 1.0mm around motor operator.

### Draw-out




* Contact TERASAKI if manual connection is required.
The external dimensions are different.

# 8 Handling and maintenance


1 Transportation and storage ····· 8-2
2 Environmental operating conditions ····· 8-2
3 Installation and connection ····· 8-2
4 Maintenance and inspection ····· 8-4

# 8 Handling and maintenance

1 Transportation and storage 2 Environmental operating conditions 3 Installation and connection


## 1 Transportation and storage

### ■ Storage Precautions

- **Avoid corrosive gases:**
  Do not leave the breakers in an atmosphere of hydrogen sulfide or ammonia gas.
- **Avoid humidity:**
  Do not leave the breakers in high humidity for a long period. Keep it free from condensation.
- **Avoid direct sunlight:**
  Do not expose the breakers to direct sunlight for a long period.
- **Avoid dust:**
  Keep the breakers in the ON position and covered against dust during storage.
- **Storage temperature:** –25 to +60°C


### ■ Transportation Precautions

- **Handle and transport with care:**



Do not drop the breakers during transportation.
Carefully pack the breakers before transportation.
Take due measures against moisture and gas absorption of the breakers during long transportation.

- **Hold by the breaker body:**



Be sure to hold the breaker by its body during handling and transportation.
Holding the breaker by a lead wire, terminal cover, stud or flush plate may result in the breaker being dropped, damaged and/or failed.

## 2 Environmental operating conditions

Use the breakers in the following environmental conditions:


| | |
|---|---|
| Ambient temperature | Within the range of –10°C to 40°C. When using in high temperature conditions exceeding 40°C, reduce the current used. However, the average value over 24 hours should not exceed 35°C. 50°C……Approx. 90% 60°C……Approx. 70% |
| Humidity | 85% or less, no condensation |
| Vibration/Shock | No unusual vibration and mechanical shock |
| Altitude | 2,000 m max |
| Atmosphere | No excessive water vapor, smoke, oil vapor, dust, salt or corrosive substances.<br>No sudden change in temperature. Non-condensing |

Note) When using the device in an environment other than as described above, please use a circuit breaker for special environments (see page 4-29)

## 3 Installation and connection


### ■ Installation Precautions

- **Avoid direct sunlight:**




Install the breakers in an area that is not exposed to direct sunlight.
Otherwise, the breakers may malfunction due to a temperature rise.

- **Avoid vibration and shock:**




If installing the breakers in an area that is exposed to vibration or shock, use cushions to relieve vibration or shock applied to the breakers.

- **Avoid dust and chippings:**




Take measures so that the breakers are not directly exposed to rainwater, oil, dust or chippings. Pay special attention to electrically conducive particles such as iron chippings that can enter the breakers. House the breakers in enclosures during use.

- **Do not block the arc gas exhaust ports:**




Do not block the arc gas exhaust ports. Doing so may deteriorate the breaking capacity. Ensure due insulation distance (arc space) between current carrying parts and grounded metal members in the vicinity of the exhaust ports. See page 5-18 for instructions regarding insulation distance.

- **Do not remove the back cover:**



Do not remove the base back cover or thread locking compound.


- **Pay attention to the mounting angle:**




When using a hydraulic-magnetic type overcurrent trip mechanism, the overcurrent tripping performance will vary depending on the mounting position, so pay attention to the mounting angle. It is recommended to use hydraulic-magnetic type overcurrent trip mechanisms in a vertical orientation. See page 5-21 for correction of rated current depending on mounting angle.


## ■ Connection Precautions

**• Tighten to a proper torque:**




Undertightening terminal screws may result in overheat or malfunction and overtightening in damage to the mold. Tighten the screws to the specified torques. See pages 5-14 to 5-17 for proper tightening torques. Use screwdrivers suited to the size and type of screws.

**• Never lubricate threads:**





Do not lubricate screw threads. Doing so will decrease the frictional resistance, resulting in looseness and overheat.

**• Insulate exposed live parts:**





Electrically and positively insulate bare live parts of front-connected breakers using interpole barriers, terminal covers, insulation tube and/or insulation tape.

**• Do not deform studs:**



Tighten the conductor connections of rear-connected or plug-in breakers so that the studs do not suffer deformation due to excessive force.


**• Normal connection of power supply and load is preferable:**




It is preferable in principle that the breaker is in normal connection. If reverse connection is necessary, refer to page 5-23.


**• Connecting Earth Leakage Circuit Breakers and Circuit Breakers with Earth Leakage Alarm**

• Connecting to single-phase 3-wire circuits





When applying 3-pole type to a single-phase 3-wire circuit, apply voltage to both ends and connect the neutral wire to the central pole.

• Connecting to single-phase 2-wire circuits





When applying 3-pole type to a single-phase 2-wire circuit, use both ends and do not use the central pole.

• Parallel connection




If you connect an earth leakage circuit breaker in parallel, an unbalanced current will flow, a malfunction will occur, and the tripping coil may burn out. Therefore, never connect in parallel. (Moulded case circuit breakers and earth leakage circuit breakers/circuit breakers with earth leakage alarm must also never be connected in parallel.)

**• Firmly secure pole conductors in parallel with each other:**




Install connecting conductors so that they are in parallel with each other. Firmly secure or tie the conductors by insulating support in case they are acted upon by an electromagnetic force, the strength of which depends on the magnitude of fault current. See the table to the right.

**Electromagnetic force acted per meter of conductor**

| Conventional rated current kA (Power factor) | Electromagnetic force (three-phase short-circuit) N | |
|---|---|---|
| | Conductor clearance: 10 cm | Conductor clearance: 20 cm |
| 10 (0.4) | 490 | 245 |
| 18 (0.3) | 1880 | 940 |
| 25 (0.2) | 4430 | 2215 |
| 35 (0.2) | 8690 | 4345 |
| 42 (0.2) | 12520 | 6260 |
| 50 (0.2) | 17740 | 8870 |
| 65 (0.2) | 29980 | 14990 |
| 85 (0.2) | 51270 | 25635 |
| 100 (0.2) | 70960 | 35480 |
| 125 (0.2) | 110870 | 55435 |

# 1. Initial inspection

After installing the breakers, inspect them according to the table shown below before energizing them for the first time. Make sure that the breakers are not energized before starting the inspection.

| Check item | Criterion |
|---|---|
| 1. Packing material debris, iron chippings, electrical wire debris or other electrically conductive foreign matter | Must have been completely removed. |
| 2. Cracks of or damage to the cover and base | Must not have occurred. |
| 3. Terminal screws and conductor clamping screws | Must have been tightened to the torques specified on pages 5-14 to 5-17. |
| 4. Insulation resistance<br>See the following precautions regarding earth leakage circuit breakers/circuit breakers with earth leakage alarm. | Must be 5 megohms or higher when measured with a 500V insulation resistance tester. |
| 5. Rated voltage and circuit voltage | Must be identical or within the permitted range. |
| 6. Apply the circuit voltage and press the test button to check the trip operation. (Earth leakage circuit breakers) | Check that earth leakage trip occurs. |

## Caution

**Do not apply a voltage to the wrong place or apply voltage that exceeds the standard. Doing so may cause failure.**

### ■ Test voltage for withstand voltage test

Perform the dielectric withstand test according to the table shown below. Make sure that the test voltage does not exceed the upper limits specified in the table.

(Units in voltage)

| Main circuit | | Auxiliary or control circuit (Note 1) | |
|---|---|---|---|
| Rated insulation voltage (Note 3) | Test voltage (ac rms) | Rated insulation voltage of operating circuit | Test voltage (ac rms) |
| Ui≤300 | 2000 | Uis≤60 | 1000 (Note 2) |
| 300<Ui≤690 | 2500 | 60<Uis≤690 | 2Uis+1000 (1500 min) |

**Notes:** 1. Between terminal group and ground only
2. Isolate 24V DC motors from the control circuit. Dielectric withstand voltage: 500V AC or 1000V AC
3. If the rated insulation voltage is not described in this catalogue, use the maximum rated voltage.

### ■ Products with no electronic circuit connected to the main circuit left and right poles

(Moulded case circuit breakers)

| Measurement points \ Test | | Insulation resistance measurement (Note 1) | | Withstand voltage test | |
|---|---|---|---|---|---|
| Toggle condition | | ON | OFF | ON | OFF |
| Between main circuit live part and ground | | ○ | ○ | ○ | ○ |
| Between different poles | Line side | ○ | ○ | ○ | ○ |
| | Load side | ○ | ○ | ○ | ○ |
| Between power supply and load terminals | | — | ○ | — | ○ |
| Between operation circuit live part and ground | | ○ | ○ | ○ | ○ |


(Note 1) Use a 500 V insulation resistance tester.

### ■ Products with an electronic circuit connected to the main circuit left and right poles

(Earth leakage circuit breakers/circuit breakers with earth leakage alarm/Single phase 3-wire circuit breakers with neutral phase open protection/Single phase 3-wire earth leakage circuit breakers with neutral phase open protection)

| Measurement points \ Test | | Insulation resistance measurement (Note 1) | | Withstand voltage test(Note 3) | |
|---|---|---|---|---|---|
| Toggle condition | | ON | OFF | ON | OFF |
| Between main circuit live part and ground | | ○ | ○ | ○(note 5) | ○(note 5) |
| Between left - centre (RS), centre - right (ST) poles | Line side | ○(note 4) | ○ | ○(note 4) | ○ |
| | Load side | ○(note 4) | ○(note 4) | ○(note 4) | ○(note 4) |
| Between left - right (RT) poles | Line side | × | ○ | × | ○ |
| | Load side | × | ×(note 2) | × | × |
| Between power supply and load terminals | | — | ○ | — | ○ |
| Between operation circuit live part and ground | | ○ | ○ | ○ | ○ |

(Note 1) Use a 500 V insulation resistance tester.
Do not measure between the left and right poles. They will not be damaged even if you make the wrong measurement, but they will be damaged if 1000 V is applied. The resistance value is almost zero ( Ω ).
(Note 2) You can perform the measurement if a Megger test switch MG (page 6-15) is mounted.
(Note 3) If you mistakenly apply the test voltage to the × mark in the table, replace with a new one.
(Note 4) For single phase 3-wire circuit breaker with neutral phase open protection and single phase 3-wire earth leakage circuit breaker with neutral phase open protection, remove the overvoltage detection lead from the neutral wire. Failure to do so may cause failure.
(Note 5) When performing a withstand voltage test between each pole of the main circuit live part and ground with the load wiring connected to the circuit breaker, perform the test between the main circuit live parts collectively and ground. Excessive voltage is applied between the poles via the capacitance to ground of the wiring and the impedance connected to ground (surge capacitor, arrester, noise filter, etc.), and there is a risk of failure.



## 2. Periodic Inspection

Periodic inspection is needed to maintain the optimum performance of the breakers and prevent malfunctions. Perform the first inspection one month after the system is put into commission and subsequently, at periodic intervals depending on the operating conditions.

### ■ Guidelines for inspection intervals

| Operating conditions | | Installation location | Examples | Guidelines for inspection intervals |
|---|---|---|---|---|
| Typical | 1 | Where the ambient air is always clean and dry. | Dustproof and air-conditioned electrical installation rooms | Every 2 or 3 years before 10 years since installation<br>Every year after 10 years since installation<br>Every 6 months after 15 years since installation |
| | 2 | Indoors where dust is low and corrosive gases are not present. | Switchboards or enclosures in electrical installation rooms not dustproof nor air-conditioned | Every year before 10 years since installation<br>Every 6 months after 10 years since installation<br>Every month after 15 years since installation |
| Harsh | 1 | Where sulfur dioxide, hydrogen sulfide, chloride and/or high-humidity gases are present and dust is low. | Geothermal power plants, sewage treatment plants, steel making plants, paper making plants or pulp making plants | Every 6 months before 5 years since installation<br>Every month after 5 years since installation |
| | 2 | Where dust and/or corrosive gases are severe, making it impossible for people to stay in for a long time. | Chemical plants, quarries or mines. | Every month |

### ■ Check items

Make sure that the breakers are not energized before starting the inspection.

| Check item | Criterion | Remedy |
|---|---|---|
| 1. Terminal screws | Must not be loosened. | If loosened, retighten to the torque specified on pages 5-14 to 5-17. |
| 2. Terminals and their vicinities | Must be free of dust and oil. | If not, clean with a cleaner.<br>Wipe with a clean cloth. |
| 3. Cracks of or damage to the cover and base | Must not have occurred. | If cracks or damage is found, replace. |
| 4. Operating mechanism | Must work smoothly. | If not, replace or contact us. |
| 5. Tripping mechanism | Must trip smoothly and ability reset operation after tripping opration. | If not, replace or contact us. |
| 6. Discoloration or overheat signs of terminals and/or base | Must not be present by visual inspection. | If present, replace.<br>(Discoloration of silver coating to a certain degree proves no problem). |
| 7. Insulation resistance | Must be 5 megohms or higher when measured with a 500V insulation resistance tester. | If not, replace. |
| 8. Press the test button about once a month with voltage applied to check the trip operation. (Earth leakage circuit breakers) | Operates properly and can reclose. | If there is an operational defect, replace with a new item.(Note: If there is an operational defect, do not press and hold the test button for 5 seconds or more.) |

## 3. Inspection and treatment after fault current breaking

If the circuit breaker operates to prevent a fault current, determine whether it can be reused or must be replaced with a new unit depending on the size of the fault current.

1. If the arc gas outlet is clean and no other abnormalities are found, it can be reused.
2. If you find black soot stains on the arc gas outlet, it is acceptable to determine that it can be reused if the insulation resistance is 5 MΩ or higher. However, pay attention to whether there is any abnormal temperature rise at the terminals, etc. while the power is on, or any other abnormalities.
   If the insulation resistance is 5 MΩ or less, perform a withstand voltage test. If it meets the specified dielectric strength, reduce the load as much as possible, only use for a short time while making sure that there is no abnormal temperature rise at the terminals, etc., and replace it with a new unit as soon as possible.
   • Measure the insulation resistance and withstand voltage test according to page 8-4.
   • In the case of an earth leakage circuit breaker, also check the trip operation with the test button.
3. If the toggle and arc gas outlet are significantly dirty with soot, and metal molten particles can be seen, replace it with a new unit.

# 4. Troubleshooting guide

Take an appropriate action according to the following table when a trouble occurs:

## ■ Troubles in breakers

| Category | Symptom | Possible cause | Remedy/Action |
|---|---|---|---|
| Overheat | ○Overheat of terminals<br>○Burnout of terminal insulation | ○Looseness of terminal screws or conductor clamping screws | ○Retighten. |
| | | ○Increase in contact resistance of contactors | ○Replace. |
| | | ○Contact failure between stud conductor and terminal (due to looseness of screws or foreign matter) | |
| | ○Overheat (exceeding 70°C) of breaker molded case | ○Increase in contact resistance of contactors | ○Replace. |
| | | ○Looseness of interior parts | |
| | | ○Increase in current density due to disconnection of braided wire | |
| | | ○High-frequency distortion of load current | ○Improve distortion factor. |
| Continuity failure | ○Abnormal voltage on load side | ○Excessive wear of contactors | ○Replace. |
| | | ○Foreign matter between contactors | |
| | | ○Damage to current carrying parts (due to excessively frequent switching or corrosive gases) | |
| Inoperativeness | ○Closing not allowed | ○Breaker is kept in tripped state, i.e., is not reset. | ○Reset. |
| | ○Resetting not allowed | ○UVT is not excited. | ○Energize. |
| | | ○Bimetal is not enough cooled after tripping due to overcurrent. | ○Cool down before resetting. |
| | | ○Bimetal is deformed e.g. by corrosion. | ○Replace. |
| | | ○Admissible number of operation cycles is exceeded and service life has expired. (SHT or UVT was frequently used for tripping). | |
| | | ○Mechanical failure | |
| Nuisance tripping | ○Tripping occurring while rated current is still not reached | ○Ambient temperature too high (exceeding 40°C) | ○Reduce ambient temperature e.g. through ventilation. |
| | | ○Overheat due to looseness of terminal screws | ○Retighten. |
| | | ○Overheat of interior parts | ○Replace. |
| | | ○Vibration and/or shock | ○Use cushions or the like to dampen vibration and shock. |
| | | ○Incompatible frequency (for thermal-magnetic breakers with CT) | ○Replace to match frequency. |
| | | ○High-frequency distortion of load current | ○Reduce load current or change rated current. |
| | | ○Conductor size smaller than specified | ○Use larger size conductors or change rated current. |
| | | ○Inductive noise enters due to a large current busbar nearby (for earth leakage circuit breaker) | ○Isolate noise source. |
| | | ○Electromagnetic-induced noise (for earth leakage circuit breakers · electronic circuit breakers) | ○Isolate noise source. (Electric field strength 10 V/m or less) |
| | | ○Excessive surge (for earth leakage circuit breakers · electronic circuit breakers) | ○Isolate surge source. |
| | ○Tripping due to starting current | ○Inrush starting current | ○Change instantaneous trip pickup current or replace with breaker having larger rated current. |
| | | ○Switching operation of star-delta starter | |
| | | ○Start of inching (resulting in instantaneous tripping) | |
| | | ○Instantly trips and operates due to capacitor charging current, incandescent lamp overcurrent, fluorescent lamp starting current, etc. | |
| | | ○Starting current too high (resulting in long-delayed tripping) | ○Replace with breaker having larger rated current. |
| | | ○Starting time too long (resulting in long-delayed tripping) | |
| | | ○Short-circuit in motor | ○Repair or replace motor. |
| | | ○Erroneous connection of control circuit for SHT or UVT | ○Check connection. |
| No response to overcurrent | ○No tripping at trip pickup current | ○Failure in coordination with an upstream current-limiting fuse or breaker | ○Review coordination. |
| | | ○Ambient temperature too low | ○Check compensation current. |
| | | ○Incompatible frequency | ○Match frequency. |

## ■ Troubles in accessories

| Category | Symptom | Possible cause | Remedy/Action |
|---|---|---|---|
| Failure of accessories | ○Failure of motor operator | ○Wiring mistakes in control circuit<br>○ Continuous on/off operations due to wiring mistakes in control circuit | ○Check and correct wiring. |
| | | ○Voltage drop due to insufficient capacity of power supply cable | ○Use larger size cable. |
| | | ○Insufficient power supply capacity of control circuit | ○Increase power supply capacity. |
| | | ○Closing/opening/resetting not allowed due to improper stroke adjustment of operation mechanism | ○Return to Terasaki for stroke readjustment. |
| | ○Failure of SHT | ○Supply-voltage drop due to insufficient current carrying capacity of control circuit | ○Increase current carrying capacity. |
| | | ○Supply-voltage drop due to insufficient power supply capacity. | ○Increase power supply capacity. |
| | | ○Coil burnout due to continuous excitations, improper coil ratings, failure or fusion of anti-burnout contacts, etc. | ○Return to Terasaki or replace. |
| | ○Failure of UVT | ○Not tripped even if no voltage due to remanence<br>○Not tripped even if no voltage due to improper stroke adjustment | ○Repair or replace. |
| | ○Failure of auxiliary and/or alarm switches | ○Fusion or burnout of microswitch contacts due to their improper ratings | ○Return to Terasaki or replace. Load to microswitch contacts will be relieved e.g through auxiliary relays. |
| | | ○Improper adjustment of microswitches | ○Return to Terasaki for repair. |

# 5. Operational performance capability

The operation durability of circuit breakers depends on their frame size. The larger the frame size is, the lower the operation durability is.
IEC 60947-2 specifies the operation durability of circuit breakers as shown in the table below. It must be kept in mind that circuit breakers are a protection tool and unlike electromagnetic relays, are not intended for frequent switching operation.

Number of operating cycles

| 1 | 2 | 3 | 4 | 5 |
|---|---|---|---|---|
| Rated current, A (Note 1) | Number of operating cycles per hour (Note 2) | Number of operating cycles | | |
| | | Without current | With current (Note 3) | Total |
| $I_n \leq 100$ | 120 | 8500 | 1500 | 10000 |
| $100 < I_n \leq 315$ | 120 | 7000 | 1000 | 8000 |
| $315 < I_n \leq 630$ | 60 | 4000 | 1000 | 5000 |
| $630 < I_n \leq 2500$ | 20 | 2500 | 500 | 3000 |
| $2500 < I_n$ | 10 | 1500 | 500 | 2000 |

**Notes:** 1. This means the maximum rated current for a given frame size.
2. Column 2 gives the minimum operating rate. This rate may be increased with the consent of the manufacturer; in this case the rate used shall be stated in the test report.
3. During each operating cycle, the circuit-breaker shall remain closed for a sufficient time to ensure that the full current is established, but not exceeding 2 s.

## ■ Recommendation for updates

With moulded case circuit breakers and earth leakage circuit breakers, ageing can occur due to the usage environment and conditions of the coil, electronic components and insulation in addition to the service life of the contacts and parts that depend on the number of switching operations.
Regarding the use of products, they should not only be updated based on the above operation durability performance, but should be updated after around 15 years as described in the standard operating conditions in the “Recommended Maintenance and Inspection of High and Low Voltage Electrical Equipment” published by JEMA Japan Electrical Manufacturers’ Association.

# 9 Appendix


1 Trip button, earth leakage indicator, test button, selector switch mounting position ····· 9-2
2 Handle operation and dimensions ····· 9-5
3 Maintenance and Inspection Checker ····· 9-6
4 Internal Resistance and Power Consumption ····· 9-7
5 Calculation and Reference Graphs of the Short Circuit Current ····· 9-10
6 Order Form ····· 9-19

# 9 Appendix

## 1 Trip button, earth leakage indicator, test button, selector switch mounting position

ASL : Arrangement Standard Line ℄ : Handle Centre Line ⊬ : Handle Frame Centre Line





Fig. 1





Fig. 2





Fig. 3





Fig. 4





Fig. 5





Fig. 6





Fig. 7





Fig. 8





Fig. 9





Fig.10





Fig. 11





Fig. 12

ASL : Arrangement Standard Line ℄ : Handle Centre Line ℍ : Handle Frame Centre Line





Fig. 13





Fig. 14





Fig. 15





Fig. 16





Fig. 17





Fig. 16





Fig. 19





Fig. 20





Fig. 21





Fig. 22





Fig. 23





Fig. 24

# 9 Appendix

## 1 Trip button, earth leakage indicator, test button,selector switch mounting position

### Mounting dimensions mm

| Series | Breaker | Ref. figure | Number of poles | Trip button A | B | C | D | E |
|---|---|---|---|---|---|---|---|---|
| MCCB | E30-NM, S30-NM, E50-NM, S50-NM, E100-NM | 1 | 3 | 32.7 | 13.5 | 4 | — | — |
| | PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF, PE60-NF, PS60-NF, PE125-NF/NN, | 18 | 2/3 | 7.5 | 18.8 | — | 6.9 | 3.4 |
| | S50-SF, S125-SF/SN | 11 | 2/3/4 | 7.6 | 18.8 | — | 6.9 | 3.4 |
| | PS50-PF, PS125-NF/PF/NN, PS125-NE/PE | 12 | 2/3/4 | 7 | 17.9 | — | 7.9 | 3.4 |
| | S100-GF, S125-GF | 2 | 2/3/4 | 13.8 | 20.4 | — | 3.3 | 4.3 |
| | H100-NF, H125-NF, H225-NF/NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF | 2 | 3/4 | 17.2 | 20.4 | — | 3.3 | 4.3 |
| | E250-SF, S250-SF, S250-SM/SN | 11 | 3/4 | 9.5 | 18.6 | — | 3 | 4.8 |
| | PS250-PF/NN, PS250-NE/PE | 12 | 3/4 | 7 | 17.9 | — | 7.9 | 3.4 |
| | PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE | 11 | 3/4 | 22.3 | 38.7 | — | 6.3 | 8.6 |
| | E400-NF, H400-NE, L400-NE | 3 ① | 3/4 | 21.6 | 37.2 | — | 5.3 | 6.6 |
| | S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, S1000-CE/NN | 3 ② | 3/4 | 21.8 | 33 | — | 5.3 | 6.6 |
| | H630-NE, L630-NE, H800-NE, L800-NE | 3 ② | 3/4 | 21.8 | 33 | — | 5.3 | 6.6 |

| Series | Breaker | Ref. figure | Number of poles | Trip button A | B | A2 | B2 | C | D | E |
|---|---|---|---|---|---|---|---|---|---|---|
| MCCB | S1250-NE/GE/NN | 9 ③ | 3/4 | 30 | 37.5 | 31 | 70.5 | 6 | 6 | 8 |
| | S1600-NE/NN | 9 ③ | 3/4 | 30 | 37.5 | 31 | 70.5 | 6 | 6 | 8 |

| Series | Breaker | Ref. figure | Number of poles | Trip button A | B | C |
|---|---|---|---|---|---|---|
| MCCB | TL-1000NE, TL-1200NE | 10 | 3/4 | 0 | 72.5 | 6 |
| | XS2000NE/NN, XS2500NE/NN, XS3200NE/NN | 10 | 3/4 | +39 | 126 | 6 |

| Series | Breaker | Ref. figure | Number of poles | Trip button A | B | C | D | E | Earth leakage / overvoltage indicator F | G | H | Test button I | J | K | Sensitivity selector switch L | M | N | O | Operating time selector switch Q | S | Reset button U | V |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| ELCB | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM | 6 | 3 | 32.7 | 13.5 | 4 | — | — | 25.7 | 6.7 | 5.5 | 24.2 | 21.2 | 5 | — | 13.5 | 7.8 | 3.6 | — | — | — | — |
| | PZE30-NF, PZE50-NF, PZE60-NF, PZE125-NF, PZS30-NF, PZS50-NF, PZS60-NF | 19 | 3 | 7.5 | 18.8 | — | 6.9 | 3.4 | 23.3 | 0.4 | 5 | 23.3 | 9.1 | 4.8 | — | 14.4 | 7 | 2 | — | — | — | — |
| | ZS50-SF, ZS125-SF, ZS100-SM | 15 | 3 | 7.6 | 18.8 | — | 6.9 | 3.4 | 15.3 | 6.5 | 3.3 | — | 1.5 | 5 | 21.5 | 10.5 | 8 | 3 | 16.5 | 3 | — | — |
| | ZS100-GF, ZS125-GF | 7 | 3/4 | 13.8 | 20.4 | — | 3.3 | 4.3 | 26.2 | 5.8 | 5.5 | — | 1.9 | 5 | 26.7 | 9 | 8 | 3 | 14 | 3 | — | — |
| | ZS225-GF, ZS250-GF | 7 | 3/4 | 17.2 | 20.4 | — | 3.3 | 4.3 | 31.1 | 5.8 | 5.5 | — | 1.9 | 5 | 31.6 | 9 | 8 | 3 | 14 | 3 | — | — |
| | ZE250-SF, ZS250-SF/SM | 15 | 3 | 9.5 | 18.6 | — | 3.0 | 4.8 | 31.1 | 5.8 | 5.5 | — | 1.9 | 5 | 31.6 | 9 | 8 | 3 | 14 | 3 | — | — |
| | ZE400-NF, ZS400-NF/GF | 8 ① | 3/4 | 21.6 | 37.2 | — | 5.3 | 6.6 | 41 | 10 | 7 | — | 5 | 7 | — | 22 | 8 | 3 | 27 | 3 | — | — |
| | ZS630-CF, ZS630-NF, ZS800-CF, ZS800-NF | 8 ② | 3/4 | 21.8 | 33 | — | 5.3 | 6.6 | 64.2 | 8.5 | 7 | — | 6.5 | 7 | — | 20.5 | 8 | 3 | 25.5 | 3 | — | — |
| Circuit Breaker with Earth Leakage Alarm | PE50-NFZ, PS50-NFZ, PE125-NFZ | 20 | 3 | 7.5 | 18.8 | — | 6.9 | 3.4 | 27.9 | 11.4 | 5.2 | 19.1 | 2.4 | 5.4 | 21.9 | 14 | 7 | 2 | 7 | 2 | 27.1 | 5.4 |
| | ZAS50-GF, ZAS100-GF, ZAS125-GF | 4 | 3/4 | 13.8 | 20.4 | — | 3.3 | 4.3 | 26.2 | 12.3 | 3 | — | 1.9 | 5 | 26.7 | 9 | 8 | 3 | 14 | 3 | 5.8 | 5 |
| | ZAS225-GF, ZAS250-GF | 4 | 3/4 | 17.2 | 20.4 | — | 3.3 | 4.3 | 31.1 | 12.3 | 3 | — | 1.9 | 5 | 31.6 | 9 | 8 | 3 | 14 | 3 | 5.8 | 5 |
| | ZAS125-SF | 13 | 3 | 7.6 | 18.8 | — | 6.9 | 3.4 | 21.5 | 13.5 | 3 | — | 1.5 | 5 | 21.5 | 10.5 | 8 | 3 | 16.5 | 3 | 6.5 | 5 |
| | ZAE250-SF, ZAS250-SF | 13 | 3 | 9.5 | 18.6 | — | 3.0 | 4.8 | 31.1 | 12.3 | 3 | — | 1.9 | 5 | 31.6 | 9 | 8 | 3 | 14 | 3 | 5.8 | 5 |
| | ZAE400-NF, ZAS400-NF/GF | 5 ① | 3/4 | 21.6 | 37.2 | — | 5.3 | 6.6 | 41 | 20 | 3 | — | 5 | 7 | — | 22 | 8 | 3 | 27 | 3 | 10 | 7 |
| | ZAS630-CF/NF, ZAS800-CF/NF | 5 ② | 3/4 | 21.8 | 33 | — | 5.3 | 6.6 | 64.2 | 22 | 3 | — | 6.5 | 7 | — | 20.5 | 8 | 3 | 25.5 | 3 | 8.5 | 7 |
| Single phase 3-wire circuit breaker with neutral phase open protection | PE50-NFN, PE125-NFN | 21 | 3 | 7.5 | 18.8 | — | 6.9 | 3.4 | 23.3 | 0.4 | 5 | 23.3 | 9.1 | 4.8 | — | — | — | — | — | — | — | — |
| | NS125-SF | 14 | 3 | 7.6 | 18.8 | — | 6.9 | 3.4 | 15.3 | 6.5 | 3.3 | — | 1.5 | 5 | 21.5 | — | — | — | — | — | — | — |
| | NE250-SF, NS250-SF | 14 | 3 | 9.5 | 18.6 | — | 3.0 | 4.8 | 31.1 | 5.8 | 5.5 | — | 1.9 | 5 | 31.6 | — | — | — | — | — | — | — |
| | NE400-NF, NS400-NF | 17 | 3 | 21.6 | 37.2 | — | 5.3 | 6.6 | 41 | 10 | 7 | — | 5 | 7 | — | — | — | — | — | — | — | — |
| | NS630-NF, NS800-NF | 17 | 3 | 21.8 | 33 | — | 5.3 | 6.6 | 64.2 | 8.5 | 7 | — | 6.5 | 7 | — | — | — | — | — | — | — | — |
| Single phase 3-wire earth leakage circuit breaker with neutral phase open protection | PZE50-NFN, PZE125-NFN | 22 | 3 | 7.5 | 18.8 | — | 6.9 | 3.4 | 23.3 | 0.4 | 5 | 23.3 | 9.1 | 4.8 | — | 14.4 | 7 | 2 | — | — | — | — |
| | ZNS125-SF | 16 | 3 | 7.6 | 18.8 | — | 6.9 | 3.4 | 15.3 | 6.5 | 3.3 | — | 1.5 | 5 | 21.5 | 10.5 | 8 | 3 | — | — | — | — |
| | ZNE250-SF, ZNS250-SF | 16 | 3 | 9.5 | 18.6 | — | 3.0 | 4.8 | 31.1 | 5.8 | 5.5 | — | 1.9 | 5 | 31.6 | 9 | 8 | 3 | — | — | — | — |
| | ZNE400-NF, ZNS400-NF | 8 ① | 3 | 21.6 | 37.2 | — | 5.3 | 6.6 | 41 | 10 | 7 | — | 5 | 7 | — | 22 | 8 | 3 | — | — | — | — |

| Series | Breaker | Ref. figure | Number of poles | Trip button A | B | C | D | E | Overvoltage indicator button F | G | H | Overvoltage test button I | J | K | Earth leakage indicator LED L | M | N | Earth leakage alarm test button O | P | Sensitivity current selector switch Q | R | Operating time selector switch S | T | U | Earth leakage alarm reset button V | W |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| Single phase 3-wire circuit breaker with neutral phase open protection and earth leakage alarm | NAE125-SF, NAS125-SF | 23 | 3 | 7.6 | 18.8 | — | 6.9 | 3.4 | 15.3 | 6.5 | 3.3 | 21.5 | 1.5 | 5 | 49 | 13.5 | 3.2 | 1.5 | 5 | 10.5 | 3 | 16.5 | 3 | 8 | 6.5 | 5 |
| | NAE250-SF, NAS250-SF | 23 | 3 | 9.5 | 18.6 | — | 3 | 4.8 | 31.1 | 5.8 | 5.5 | 31.6 | 1.9 | 5 | 64 | 15.5 | 3.2 | 0.5 | 5 | 8.5 | 3 | 14.5 | 3 | 8 | 8.5 | 5 |
| | NAE400-NF, NAS400-NF | 24 | 3 | 21.6 | 37.2 | — | 5.3 | 6.6 | 41 | 10 | 7 | 41 | 5 | 7 | 85.5 | 32.5 | 3.2 | 17.5 | 5 | 8.5 | 3 | 2.5 | 3 | 8 | 25.5 | 5 |

Notes ① : Apply ℄ Handle Centre Line.
② : Apply ASL Arrangement Standard Line.
③ : 2 trip buttons are equipped.

## 2 Handle operation and dimensions

# Moulded Case Circuit Breakers • Earth Leakage Circuit Breakers





Fig.1






Fig.2





| Frame size(A) | MCCB | ELCB | Number of poles | Ref. figure | Operetion angle ON α° | OFF β° | Trip γ° | Reset δ° | Dimensions (mm) A | B | C | D | E | F | G | Operating force N OFF ↓ ON | ON ↓ OFF | Trip ↓ Reset | Radius of rotation (mm) |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 30, 50, 60, 100, 125 | **E30-NM, S30-NM, E50-NM, S50-NM, E100-NM** | **ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM** | 2 | 1 | 22 | 15 | 4 | 17.5 | 57 | 84 | 9.5 | 5 | 5 | 12 | 19 | 15.6 | 20.1 | 33.1 | 26.9 |
| | | | 3 | | | | | | | | | | | | | 21.9 | 26.0 | 59.5 | 26.9 |
| | **PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN** | **PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN** | 2/3 ② | 1 | 13.4 | 11.6 | 2.5 | 14 | 36.8 | 90 | 0 | 7 | 5.4 | 13 | 16.6 | 15 | 23 | 38 | 53.2 |
| | | | 2/3 ③ | | | | | | | | | | | | | 25 | 35 | 52 | 53.2 |
| | **S50-SF, S125-SF/SN, NAE125-SF, NAS125-SF, ZAS125-SF, NS125-SF** | **ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF** | 2/3/4 | 1 | 12.7 | 10.4 | 2 | 13.2 | 40.6 | 95 | –2 | 7.4 | 7.8 | 13 | 22.8 | 44.1 | 37.2 | 78.4 | 54.5 |
| | **PS50-PF, PS125-NF/PF/NN, PS125-NE/PE** | | 2/3/4 | 1 | 14.5 | 9.3 | 4.3 | 12.2 | 39.4 | 95 | –1.1 | 7.4 | 6.8 | 13 | 23.2 | 40 | 30 | 60 | 56 |
| | **S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF** | **ZS100-GF, ZS125-GF** | 2/3/4 | 1 | 19.2 | 16.5 | 4.1 | 19 | 26 | 92 | 0 | 6.8 | 9.3 | 13 | 20.4 | 22.0 | 28.0 | 68.0 | 66.0 |
| | **H100-NF, H125-NF, L100-NF, L125-NF** | | 3/4 | 1 | 19.2 | 16.5 | 4.1 | 19 | 61 | 127 | 0 | 6.8 | 9.3 | 13 | 20.4 | 25.0 | 36.0 | 76.0 | 66.0 |
| 225, 250 | **H225-NF/NE, H250-NF, L225-NF, L250-NF** | | 3/4 | 1 | 19.2 | 16.5 | 4.1 | 19 | 61 | 127 | 0 | 6.8 | 9.3 | 13 | 20.4 | 25.0 | 36.0 | 76.0 | 66.0 |
| | **E250-SF, S250-SF, S250-SM/SN, ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF** | **ZE250-SF, ZS250-SF/SM, ZNE250-SF, ZNS250-SF** | 3/4 | 1 | 11.8 | 13.2 | 3.8 | 16.2 | 40.5 | 95 | 0 | 7.4 | 7.2 | 13 | 21.1 | 53.0 | 57.0 | 91.0 | 54.4 |
| | **PS250-PF/NN, PS250-NE/PE** | | 3/4 | 1 | 14.5 | 9.3 | 4.3 | 12.2 | 39.4 | 95 | –1.1 | 7.4 | 6.8 | 13 | 23.2 | 55 | 40 | 95 | 56 |
| | **ZAS225-GF, ZAS250-GF** | **ZS225-GF, ZS250-GF** | 3/4 | 1 | 19.2 | 16.5 | 4.1 | 19 | 26 | 92 | 0 | 6.8 | 9.3 | 13 | 20.4 | 25.0 | 36.0 | 76.0 | 66.0 |
| 400 | **E400-NF, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF** | **ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF** | 3/4 | 2 | 19.8 | 19.3 | –3.5 | 22.5 | 53.6 | 145 | 2.8 | 14 | 9 | 34 | 39.5 | 110 | 115 | 125 | 91.4 |
| | **PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE** | | 3/4 | 2 | 18.3 | 12.6 | 2 | 14.7 | 56.3 | 151 | –4 | 16.4 | 12 | 34 | 35.5 | 150 | 130 | 175 | 94.7 |
| | **H400-NE, L400-NE** | | 3/4 | 2 | 19.8 | 19.3 | –3.5 | 22.5 | 90.6 | 182 | 2.8 | 14 | 9 | 34 | 39.5 | 110 | 115 | 125 | 91.4 |
| 600, 630, 800, 1000 | **PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE** | | 3/4 | 2 | 18.3 | 12.6 | 2 | 14.7 | 56.3 | 151 | –4 | 16.4 | 12 | 34 | 35.5 | 150 | 130 | 175 | 94.7 |
| | **S630-CF/NF/NE/GN, S800-CF/NF/RF/PF/NN, ZAS630-CF/NF, ZAS800-CF/NF, NS630-NF, NS800-NF, S800-NE/RE/PE, S1000-CE/NN** | **ZS630-CF/NF, ZS800-CF/NF** | 3/4 | 2 | 20 | 18 | 2 | 22 | 53.7 | 145 | 5 | 13 | 11 | 40 | 39.5 | 140 | 140 | 170 | 91.3 |
| | **H630-NE, L630-NE, H800-NE, L800-NE,** | | 3/4 | 2 | 20 | 18 | 2 | 22 | 90.7 | 182 | 5 | 13 | 11 | 40 | 39.5 | 140 | 140 | 170 | 91.3 |
| | **TL-1000NE, TL-1200NE** | | 3/4 | 1 | 22 | 4 | 12 | 9 | 93.5 | 191 | –2.8 | 11 | 12.5 | 40 | 30 | 157 | 294 | 343 | 98.3 |
| 1250 | **S1250-NE/GE/NN** | | 3/4 | 1 | 22 | 4 | 12 | 9 | 73.5 | 171 | –2.8 | 11 | 12.5 | 40 | 30 | 157 | 294 | 343 | 98.3 |
| 1600 | **S1600-NE/NN** | | 3/4 | 1 | 22 | 4 | 12 | 9 | 93.5 | 191 | –2.8 | 11 | 12.5 | 40 | 30 | 157 | 294 | 343 | 98.3 |
| 2000, 2500, 3200 | **XS2000NE, XS2000NN, XS2500NE, XS2500NN, XS3200NE, XS3200NN** | | 3/4 | 1 | 18.3 | 10 | 7.7 | 15.3 | 100 | 245 | +2 | 20.5 | 24 | 60 | 56.5 | 382 | 322 | 559 | 146 |

Unit : Operating force : N
(1 N ≒ $\frac{1}{9.8}$ kgf)

Notes ① : Apply ℄ Handle Centre Line depending on the model. See the outline drawing in Chapter 7.
② : In the case of 10A or less.
③ : In the case of 15A or more.

# 3 Maintenance and Inspection Checker

## TNS-3 OCR Checker





The TNS-3 type OCR checker can be used to easily check the trip function of XOU type OCR and XOS type OCR electronic circuit breakers and AGR12BL type OCR AR-E type air circuit breakers in the field. The types of check are the set current value and tripping time of each of Long Time Delay (LTD), Short Time Delay (STD), Instantaneous (INST), and Ground Fault Trip (GFT). Please use the checker according to the application.

### Ratings and Specifications

| Type | TNS-3 |
|---|---|
| Power Source | 100～240V AC Single Phase 50/60Hz |
| Power Consumption | 30VA |
| Application<br>(Please use with no power flowing through the circuit breaker) | ●LTD function check (Set current and trip time values)<br>●STD function check (Set trip time value)<br>●INST function check (Set trip time value)<br>●GFT function check (Set trip time value) |
| Measurement of set current values | ●Display 4-digit digital display<br>●Range XOS(OCR) 0～750mA<br>XOU(OCR) 0～1500mA |
| Measurement of tripping time values | ●Display 3-digit digital display<br>●Range 0.01～999.9s |
| Outline Dimensions | 241mm(W)×157mm(H)×109mm(D) |
| Weight | 2.3kg |
| Accessories | ●Power cord (with power conversion plug type C) 3m, 1pc |
| Optional ① | Order codes<br>TNS-3 CABLE1 XOS type OCR MIP cable 2m, 1pc<br>TNS-3 CABLE2 XOU type OCR (for 400 to 1600AF) MIP cable 2m, 1pc<br>TNS-3 CABLE3 XOU type OCR (for 225AF) MIP cable 2m, 1pc<br>TNS-3 CABLE4 AGR-12 BL type OCR (for AR-E type ACB) MIP cable 2m, 1pc |

Note ① : MIP cables are not provided as standard. Please specify the cables you require separately.

## TTP00 OCR Checker




The TTP00 type OCR checker can be used to easily check the trip function of TPOT type OCR, TPOP type OCR, and TPOU type OCR electronic circuit breakers in the field.

### Ratings and Specifications

| Type | TTP00 |
|---|---|
| Power Source | Single-phase 100 to 240V AC, 50/60Hz or<br>AA alkaline batteries 1.5V × 4 or<br>nickel-metal hydride rechargeable batteries 1.2V × 4 |
| Power Consumption | 3VA |
| Application<br>(Please use with no power flowing through the circuit breaker) | ●LTD function check (Set current and tripping time values)<br>●STD function check (Set current and tripping time values)<br>●INST function check (Set current value)<br>●Preferential trip alarm function check (Set current and tripping time values)<br>●GF function check (Set current and tripping time values)<br>●N-phase protection function check (Set current and tripping time values) |
| Measurement of set current values | ●Display 4-digit digital display<br>●Range 1A～9,999A |
| Measurement of tripping time values | ●Display Digital display (0.01s unit for 9.99s or less, 0.1s unit for 10.0s or more)<br>●Range 0.01～999.9sec |
| Outline Dimensions | 80mm(W)×165mm(H)×35mm(D) |
| Weight | 0.4kg (including accessories) |
| Accessories | MIP cable 2m × 1pc<br>AC adapter (with power cord 1.9m) × 1unit<br>AC adapter plug<br>Type A (for domestic use) × 1pc<br>Type C (for Europe) × 1pc |
| Optional cable ① | [Order codes]<br>TTPMCA MIP cable for TPOT, TPOP and TPOU OCR 2m × 1pc<br>TTPCCA MIP cable for calibration |

Note ① : The MIP cable that is included as standard with TTP00 is used for TemPower PRO air circuit breakers, when using TTP00 for electronic circuit breaker, be sure to order the TTPMCA type MIP cable.

# 4 Internal Resistance and Power Consumption

## ■ Moulded Case Circuit Breakers

| Frame size(A) | Breaker | Rated current (A) | Internal resistance (DCmΩ) ① ・Value per pole FC | Plug-in | DC Power consumption (W) ② ・Value per pole FC | Plug-in |
|---|---|---|---|---|---|---|
| 30 | **PE30-NF, PS30-NF** | 3 | 135 | 136 | 1.22 | 1.22 |
| | | 5 | 51.5 | 51.9 | 1.29 | 1.30 |
| | | 10 | 13.0 | 13.3 | 1.30 | 1.33 |
| | | 15 | 7.1 | 7.3 | 1.60 | 1.64 |
| | | 20 | 6.8 | 6.9 | 2.72 | 2.76 |
| | | 30 | 2.7 | 3.2 | 2.43 | 2.88 |
| | **E30-NM, S30-NM** | 1.4 | 490 | — | 2.9 | — |
| | | 2.6 | 143 | — | 2.9 | — |
| | | 4 | 60 | — | 2.9 | — |
| | | 8 | 17.5 | — | 3.4 | — |
| | | 10 | 11.4 | — | 3.4 | — |
| | | 16 | 5.6 | — | 4.3 | — |
| | | 24 | 2.9 | — | 5.1 | — |
| | | 32 | 2.1 | — | 6.5 | — |
| | **S30-NM** | 0.7 | 1940 | — | 2.8 | — |
| | | 2 | 241 | — | 2.9 | — |
| | | 5 | 39.3 | — | 2.9 | — |
| | | 12 | 9.6 | — | 4.2 | — |
| 50 | **PE50-NF, PS50-NF** | 15 | 7.1 | 7.3 | 1.60 | 1.64 |
| | | 20 | 6.8 | 6.9 | 2.72 | 2.76 |
| | | 30 | 2.7 | 3.2 | 2.43 | 2.88 |
| | | 40 | 2.4 | 2.5 | 3.84 | 4.00 |
| | | 50 | 1.6 | 1.8 | 4.00 | 4.50 |
| | **PE50-NFZ, PS50-NFZ** | 15 | 7.1 | 7.3 | 1.60 | 1.64 |
| | | 20 | 6.8 | 6.9 | 2.72 | 2.76 |
| | | 30 | 2.7 | 3.2 | 2.43 | 2.88 |
| | | 40 | 2.4 | 2.5 | 3.84 | 4.00 |
| | | 50 | 1.6 | 1.8 | 4.00 | 4.50 |
| | **PE50-NFN** | 15 | 7.1 | 7.3 | 1.60 | 1.64 |
| | | 20 | 6.8 | 6.9 | 2.72 | 2.76 |
| | | 30 | 2.7 | 3.2 | 2.43 | 2.88 |
| | | 40 | 2.4 | 2.5 | 3.84 | 4.00 |
| | | 50 | 1.6 | 1.8 | 4.00 | 4.50 |
| | **S50-SF** | 15 | 8.63 | 8.75 | 1.94 | 1.97 |
| | | 20 | 8.63 | 8.75 | 3.45 | 3.5 |
| | | 30 | 3.18 | 3.3 | 2.86 | 2.97 |
| | | 40 | 2.72 | 2.84 | 4.35 | 4.54 |
| | | 50 | 2.69 | 2.81 | 6.73 | 7.03 |
| | **ZAS50-GF** | 15 | 15.7 | — | 3.53 | — |
| | | 20 | 15.7 | — | 6.28 | — |
| | | 30 | 9.0 | — | 8.10 | — |
| | | 40 | 2.1 | — | 3.36 | — |
| | | 50 | 2.1 | — | 5.25 | — |
| | **S50-NM** | 10 | 10.9 | — | 3.3 | — |
| | | 12 | 9.1 | — | 3.3 | — |
| | | 16 | 5.1 | — | 2.5 | — |
| | **E50-NM, S50-NM** | 24 | 2.9 | — | 5.1 | — |
| | | 32 | 2.1 | — | 6.5 | — |
| | | 40 | 1.7 | — | 8.1 | — |
| | | 45 | 1.6 | — | 9.9 | — |
| | **PS50-PF** | 15 | 13.31 | 13.45 | 2.99 | 3.03 |
| | | 20 | 12.23 | 12.37 | 4.89 | 4.95 |
| | | 30 | 8.78 | 8.92 | 7.90 | 8.03 |
| | | 40 | 5.51 | 5.65 | 8.82 | 9.04 |
| | | 50 | 5.22 | 5.36 | 13.05 | 13.40 |
| | **TB-5S** | 10 | 6.56 | — | 0.656 | — |
| | | 15 | 5.05 | — | 1.14 | — |
| | | 20 | 4.16 | — | 1.66 | — |
| | | 30 | 2.44 | — | 2.2 | — |
| | | 40 | 1.73 | — | 2.77 | — |
| | | 50 | 1.5 | — | 3.75 | — |
| | **TB-5P Line side Plug-in Load side Front-connected** | 10 | 6.76 | | 0.676 | |
| | | 15 | 5.25 | | 1.18 | |
| | | 20 | 4.36 | | 1.74 | |
| | | 30 | 2.64 | | 2.38 | |
| | | 40 | 1.93 | | 3.09 | |
| | | 50 | 1.70 | | 4.25 | |
| | **TB-5D** | 10 | — | 6.96 | — | 0.696 |
| | | 15 | — | 5.45 | — | 1.23 |
| | | 20 | — | 4.56 | — | 1.82 |
| | | 30 | — | 2.84 | — | 2.56 |
| | | 40 | — | 2.13 | — | 3.41 |
| | | 50 | — | 1.90 | — | 4.75 |
| | **TB-51C (2P1E)** | 15 | 5.77 ③ | — | 1.3 ③ | — |
| | | 15 | 1.55 ④ | — | 0.35 ④ | — |
| | | 20 | 5.5 ③ | — | 2.2 ③ | — |
| | | 20 | 1.55 ④ | — | 0.62 ④ | — |
| | | 30 | 4.04 ③ | — | 3.64 ③ | — |
| | | 30 | 1.55 ④ | — | 1.4 ④ | — |
| | **TB-52C (2P2E)** | 15 | 5.77 | — | 1.3 | — |
| | | 20 | 5.5 | — | 2.2 | — |
| | | 30 | 4.04 | — | 3.64 | — |
| 60 | **PE60-NF, PS60-NF** | 60 | 1.2 | 1.3 | 4.32 | 4.68 |
| 100 | **S100-GF** | 15 | 15 | 15.3 | 3.38 | 3.44 |
| | | 20 | 15 | 15.3 | 6.0 | 6.12 |
| | | 30 | 8.0 | 8.27 | 7.2 | 7.44 |
| | | 40 | 1.8 | 2.07 | 2.88 | 3.31 |
| | | 50 | 1.8 | 2.07 | 4.5 | 5.18 |
| | | 60 | 1.3 | 1.57 | 4.68 | 5.65 |
| | | 75 | 0.80 | 1.07 | 4.5 | 6.02 |
| | | 100 | 0.80 | 1.07 | 8.0 | 10.7 |

| Frame size(A) | Breaker | Rated current (A) | Internal resistance (DCmΩ) ① ・Value per pole FC | Plug-in | DC Power consumption (W) ② ・Value per pole FC | Plug-in |
|---|---|---|---|---|---|---|
| 100 | **H100-NF, L100-NF** | 15 | 23.5 | 23.6 | 5.29 | 5.31 |
| | | 20 | 23.5 | 23.6 | 9.4 | 9.44 |
| | | 30 | 11.9 | 12 | 10.7 | 10.8 |
| | | 40 | 1.99 | 2.13 | 3.18 | 3.41 |
| | | 50 | 1.99 | 2.13 | 4.98 | 5.33 |
| | | 60 | 1.62 | 1.76 | 5.83 | 6.34 |
| | | 75 | 0.97 | 1.11 | 9.7 | 6.24 |
| | | 100 | 0.97 | 1.11 | 9.7 | 11.1 |
| | **E100-NM** | 60 | 0.80 | — | 8.7 | — |
| | | 75 | 0.70 | — | 11.5 | — |
| | | 90 | 0.70 | — | 17 | — |
| | **ZAS100-GF** | 15 | 15.7 | — | 3.53 | — |
| | | 20 | 15.7 | — | 6.28 | — |
| | | 30 | 9.0 | — | 8.1 | — |
| | | 40 | 2.1 | — | 3.36 | — |
| | | 50 | 2.1 | — | 5.25 | — |
| | | 60 | 1.6 | — | 5.76 | — |
| | | 75 | 1.1 | — | 6.19 | — |
| | | 100 | 1.1 | — | 11 | — |
| 125 | **PE125-NF** | 60 | 1.2 | 1.3 | 4.32 | 4.68 |
| | | 75 | 1.0 | 1.1 | 5.63 | 6.19 |
| | | 100 | 0.83 | 1.1 | 8.30 | 11.0 |
| | | 125 | 0.62 | 0.85 | 9.69 | 13.3 |
| | **PE125-NFZ** | 60 | 1.2 | — | 4.32 | — |
| | | 75 | 1.0 | — | 5.63 | — |
| | | 100 | 0.83 | — | 8.30 | — |
| | | 125 | 0.62 | — | 9.69 | — |
| | **PE125-NFN** | 60 | 1.2 | — | 4.32 | — |
| | | 75 | 1.0 | — | 5.63 | — |
| | | 100 | 0.83 | — | 8.30 | — |
| | | 125 | 0.62 | — | 9.69 | — |
| | **S125-SF, S125-SN** | 15 | 8.63 | 8.75 | 1.94 | 1.97 |
| | | 20 | 8.63 | 8.75 | 3.45 | 3.5 |
| | | 30 | 3.18 | 3.3 | 2.86 | 2.97 |
| | | 40 | 2.72 | 2.84 | 4.35 | 4.54 |
| | | 50 | 2.69 | 2.81 | 6.73 | 7.03 |
| | | 60 | 2.14 | 2.26 | 7.7 | 8.14 |
| | | 75 | 1.42 | 1.54 | 7.99 | 8.66 |
| | | 100 | 0.93 | 1.05 | 9.3 | 10.5 |
| | | 125 | 0.84 | 0.96 | 13.13 | 15 |
| | **NAE125-SF, NAS125-SF** | 15 | 5.47 | — | 1.23 | — |
| | | 20 | 3.87 | — | 1.55 | — |
| | | 30 | 2.70 | — | 2.43 | — |
| | | 40 | 2.35 | — | 3.76 | — |
| | | 50 | 1.87 | — | 4.67 | — |
| | | 60 | 1.28 | — | 4.60 | — |
| | | 75 | 1.22 | — | 6.86 | — |
| | | 100 | 0.65 | — | 6.46 | — |
| | | 125 | 0.65 | — | 10.09 | — |
| | **PS125-NF, PS125-PF** | 15 | 13.31 | 13.45 | 2.99 | 3.03 |
| | | 20 | 12.23 | 12.37 | 4.89 | 4.95 |
| | | 30 | 8.78 | 8.92 | 7.90 | 8.03 |
| | | 40 | 5.51 | 5.65 | 8.82 | 9.04 |
| | | 50 | 5.22 | 5.36 | 13.05 | 13.40 |
| | | 60 | 1.61 | 1.75 | 5.80 | 6.30 |
| | | 75 | 1.58 | 1.72 | 8.89 | 9.68 |
| | | 100 | 1.12 | 1.26 | 11.20 | 12.60 |
| | | 125 | 1.20 | 1.34 | 18.75 | 20.94 |
| | **PS125-NE, PS125-PE** | 40 | 1.0 | 1.14 | 1.6 | 1.8 |
| | | 50 | 1.0 | 1.14 | 2.5 | 2.9 |
| | | 60 | 1.0 | 1.14 | 3.6 | 4.1 |
| | | 75 | 1.0 | 1.14 | 5.6 | 6.4 |
| | | 100 | 1.0 | 1.14 | 10.0 | 11.4 |
| | | 125 | 1.0 | 1.14 | 15.6 | 17.8 |
| | **S125-GF** | 125 | 0.8 | 1.07 | 12.5 | 16.7 |
| | **H125-NF, L125-NF** | 125 | 0.97 | 1.11 | 15.2 | 17.3 |
| | **ZAS125-SF** | 15 | 5.47 | — | 1.23 | — |
| | | 20 | 3.87 | — | 1.55 | — |
| | | 30 | 2.7 | — | 2.43 | — |
| | | 40 | 2.35 | — | 3.76 | — |
| | | 50 | 1.87 | — | 4.67 | — |
| | | 60 | 1.28 | — | 4.6 | — |
| | | 75 | 1.22 | — | 6.86 | — |
| | | 100 | 0.65 | — | 6.46 | — |
| | | 125 | 0.65 | — | 10.09 | — |
| | **NS125-SF** | 15 | 5.67 | — | 1.28 | — |
| | | 20 | 3.84 | — | 1.54 | — |
| | | 30 | 2.63 | — | 2.37 | — |
| | | 40 | 2.47 | — | 3.95 | — |
| | | 50 | 1.93 | — | 4.83 | — |
| | | 60 | 1.93 | — | 6.95 | — |
| | | 75 | 1.3 | — | 7.34 | — |
| | | 100 | 0.78 | — | 7.84 | — |
| | | 125 | 0.41 | — | 6.44 | — |
| | **ZAS125-GF** | 125 | 0.60 | — | 9.4 | — |

Notes ① : The resistance value is a reference value. It cannot be used for acceptance inspections, etc.
② : The power consumption value is calculated based on the DC internal resistance.
③ : The value of poles with a trip element.
④ : The value of poles without a trip element.
⑤ : Please contact us.

# 4 Internal Resistance and Power Consumption

## ■ Moulded Case Circuit Breakers

| Frame size(A) | Breaker | Rated current (A) | Internal resistance (DCmΩ) ① ・Value per pole | | DC Power consumption (W) ② ・Value per pole | |
|---|---|---|---|---|---|---|
| | | | FC | Plug-in | FC | Plug-in |
| 225 | **H225-NE** | 125 | 0.39 | — | 6.09 | — |
| | | 150 | 0.39 | — | 8.78 | — |
| | | 175 | 0.39 | — | 11.9 | — |
| | | 200 | 0.39 | — | 15.6 | — |
| | | 225 | 0.39 | — | 19.7 | — |
| | **H225-NF, L225-NF** | 125 | 0.57 | 0.71 | 8.91 | 11.09 |
| | | 150 | 0.57 | 0.71 | 12.83 | 15.98 |
| | | 175 | 0.36 | 0.50 | 11.03 | 15.31 |
| | | 200 | 0.36 | 0.50 | 14.4 | 20 |
| | | 225 | 0.36 | 0.50 | 18.23 | 25.31 |
| | **ZAS225-GF** | 125 | 0.44 | — | 6.88 | — |
| | | 150 | 0.44 | — | 9.9 | — |
| | | 175 | 0.37 | — | 11.33 | — |
| | | 200 | 0.37 | — | 14.8 | — |
| | | 225 | 0.37 | — | 18.73 | — |
| 225, 250 | **E250-SF, S250-SF** | 125 | 0.45 | 0.59 | 7.03 | 9.22 |
| | | 150 | 0.45 | 0.59 | 10.13 | 13.28 |
| | | 175 | 0.35 | 0.49 | 10.72 | 15.01 |
| | | 200 | 0.35 | 0.49 | 14 | 19.6 |
| | | 225 | 0.26 | 0.40 | 13.16 | 20.25 |
| | | 250 | 0.26 | 0.40 | 16.25 | 25 |
| | **S250-SM** | 125 | 0.45 | 0.59 | 7.03 | 9.22 |
| | | 150 | 0.45 | 0.59 | 10.13 | 13.28 |
| | | 175 | 0.35 | 0.49 | 10.72 | 15.01 |
| | | 225 | 0.26 | 0.40 | 13.16 | 20.25 |
| | **NAE250-SF, NAS250-SF** | 125 | 0.50 | — | 7.81 | — |
| | | 150 | 0.50 | — | 11.25 | — |
| | | 175 | 0.36 | — | 11.03 | — |
| | | 200 | 0.36 | — | 14.40 | — |
| | | 225 | 0.31 | — | 15.69 | — |
| | | 250 | 0.31 | — | 19.38 | — |
| | **PS250-PF** | 125 | 0.90 | 1.17 | 14.06 | 18.28 |
| | | 150 | 0.57 | 0.84 | 12.83 | 18.90 |
| | | 175 | 0.46 | 0.73 | 14.09 | 22.36 |
| | | 200 | 0.45 | 0.72 | 18.00 | 28.80 |
| | | 225 | 0.38 | 0.65 | 19.24 | 32.91 |
| | | 250 | 0.41 | 0.68 | 25.63 | 42.50 |
| | **PS250-NE, PS250-PE** | 125 | 0.6 | 0.87 | 9.4 | 13.6 |
| | | 150 | 0.6 | 0.87 | 13.5 | 19.6 |
| | | 175 | 0.6 | 0.87 | 18.4 | 26.6 |
| | | 200 | 0.6 | 0.87 | 24.0 | 34.8 |
| | | 225 | 0.6 | 0.87 | 30.4 | 44.0 |
| | | 250 | 0.6 | 0.87 | 37.5 | 54.4 |
| | **H250-NF, L250-NF** | 250 | 0.36 | 0.50 | 22.5 | 31.3 |
| | **ZAE250-SF, ZAS250-SF** | 125 | 0.50 | — | 7.81 | — |
| | | 150 | 0.50 | — | 11.25 | — |
| | | 175 | 0.36 | — | 11.03 | — |
| | | 200 | 0.36 | — | 14.4 | — |
| | | 225 | 0.31 | — | 15.69 | — |
| | | 250 | 0.31 | — | 19.38 | — |
| | **ZAS250-GF** | 250 | 0.29 | — | 18.1 | — |
| | **NE250-SF, NS250-SF** | 125 | 0.45 | — | 7.03 | — |
| | | 150 | 0.45 | — | 10.13 | — |
| | | 175 | 0.35 | — | 10.72 | — |
| | | 200 | 0.35 | — | 14 | — |
| | | 225 | 0.26 | — | 13.16 | — |
| | | 250 | 0.26 | — | 16.25 | — |
| 400 | **E400-NF** | 250 | 0.24 | — | 15 | — |
| | | 300 | 0.14 | — | 12.6 | — |
| | | 350 | 0.14 | — | 17.15 | — |
| | | 400 | 0.14 | — | 22.4 | — |
| | **NAE400-NF, NAS400-NF** | 250 | 0.26 | — | 16.3 | — |
| | | 300 | 0.26 | — | 23.4 | — |
| | | 350 | 0.20 | — | 24.5 | — |
| | | 400 | 0.20 | — | 32 | — |
| | **PS400-CF, PS400-NF, PS400-GF, PH400-CF** | 225 | 0.33 | 0.39 | 16.8 | 19.8 |
| | | 250 | 0.33 | 0.39 | 20.7 | 24.4 |
| | | 300 | 0.25 | 0.30 | 22.3 | 27.2 |
| | | 350 | 0.24 | 0.33 | 29.2 | 40.4 |
| | | 400 | 0.24 | 0.33 | 38.1 | 52.7 |
| | **PS400-NE, PS400-GE, PH400-CE** | 125 | 0.16 | 0.30 | 2.5 | 4.7 |
| | | 150 | 0.16 | 0.30 | 3.7 | 6.8 |
| | | 175 | 0.16 | 0.30 | 5.0 | 9.2 |
| | | 200 | 0.16 | 0.30 | 6.5 | 12.0 |
| | | 225 | 0.16 | 0.30 | 8.2 | 15.2 |
| | | 250 | 0.16 | 0.30 | 10.2 | 18.8 |
| | | 300 | 0.16 | 0.25 | 14.6 | 22.7 |
| | | 350 | 0.16 | 0.25 | 19.9 | 30.9 |
| | | 400 | 0.16 | 0.25 | 26.0 | 40.3 |
| | **H400-NE, L400-NE** | 250 | 0.19 | 0.23 | 11.9 | 14.4 |
| | | 300 | 0.19 | 0.23 | 17.1 | 20.7 |
| | | 350 | 0.19 | 0.23 | 23.2 | 28.2 |
| | | 400 | 0.19 | 0.23 | 30.4 | 36.8 |
| | **ZAE400-NF, ZAS400-NF, ZAS400-GF, NE400-NF, NS400-NF** | 250 | 0.26 | — | 15.3 | — |
| | | 300 | 0.26 | — | 23.4 | — |
| | | 350 | 0.20 | — | 24.5 | — |
| | | 400 | 0.20 | — | 32 | — |
| 600, 630 | **S630-CF, S630-NF** | 500 | 0.11 | 0.12 | 27.5 | 30.0 |
| | | 600 | 0.11 | 0.12 | 39.6 | 43.2 |
| | | 630 | 0.11 | 0.12 | 43.7 | 47.6 |
| | **S630-NE** | 250 | 0.08 | 0.09 | 5.0 | 5.63 |
| | | 300 | 0.08 | 0.09 | 7.2 | 8.1 |
| | | 350 | 0.08 | 0.09 | 9.8 | 11 |
| | | 400 | 0.08 | 0.09 | 12.8 | 14.4 |
| | | 500 | 0.08 | 0.09 | 20 | 22.5 |
| | | 600 | 0.08 | 0.09 | 28.8 | 32.4 |
| | | 630 | 0.08 | 0.09 | 31.8 | 35.7 |

| Frame size(A) | Breaker | Rated current (A) | Internal resistance (DCmΩ) ① ・Value per pole | | DC Power consumption (W) ② ・Value per pole | |
|---|---|---|---|---|---|---|
| | | | FC | Plug-in | FC | Plug-in |
| 600, 630 | **PS630-CF, PS630-NF, PS630-GF, PH630-CF** | 500 | 0.14 | 0.17 | 34.4 | 43.7 |
| | | 600 | 0.14 | 0.17 | 49.5 | 62.9 |
| | **PS630-NE, PS630-GE, PH630-CE** | 250 | 0.09 | 0.20 | 5.8 | 12.3 |
| | | 300 | 0.09 | 0.20 | 8.4 | 17.7 |
| | | 350 | 0.09 | 0.20 | 11.4 | 24.1 |
| | | 400 | 0.09 | 0.20 | 14.8 | 31.4 |
| | | 500 | 0.09 | 0.20 | 23.2 | 49.1 |
| | | 600 | 0.09 | 0.20 | 33.4 | 70.7 |
| | | 630 | 0.09 | 0.20 | 36.8 | 78.0 |
| | **H630-NE, L630-NE** | 250 | 0.10 | 0.12 | 6.3 | 7.5 |
| | | 300 | 0.10 | 0.12 | 9.0 | 10.8 |
| | | 350 | 0.10 | 0.12 | 12.3 | 14.7 |
| | | 400 | 0.10 | 0.12 | 16.0 | 19.2 |
| | | 500 | 0.10 | 0.12 | 25.0 | 30.0 |
| | | 600 | 0.10 | 0.12 | 36.0 | 43.2 |
| | | 630 | 0.10 | 0.12 | 39.7 | 47.6 |
| | **NS630-NF** | 500 | 0.12 | — | 30 | — |
| | | 600 | 0.12 | — | 43.2 | — |
| | | 630 | 0.12 | — | 47.6 | — |
| | **ZAS630-CF, ZAS630-NF** | 500 | 0.12 | — | 30 | — |
| | | 600 | 0.12 | — | 43.2 | — |
| | | 630 | 0.12 | — | 47.6 | — |
| 800 | **S800-CF, S800-NF, S800-RF, S800-PF** | 700 | 0.09 | 0.11 | 44.1 | 53.9 |
| | | 800 | 0.09 | 0.11 | 57.6 | 70.4 |
| | **S800-NE, S800-RE, S800-PE** | 350 | 0.08 | 0.10 | 9.8 | 12.3 |
| | | 400 | 0.08 | 0.10 | 12.8 | 16 |
| | | 450 | 0.08 | 0.10 | 16.2 | 20.3 |
| | | 500 | 0.08 | 0.10 | 20 | 25 |
| | | 600 | 0.08 | 0.10 | 28.8 | 36 |
| | | 700 | 0.08 | 0.10 | 39.2 | 49 |
| | | 800 | 0.08 | 0.10 | 51.2 | 64 |
| | **NS800-NF** | 700 | 0.10 | — | 49 | — |
| | | 800 | 0.10 | — | 64 | — |
| | **ZAS800-CF, ZAS800-NF** | 700 | 0.10 | — | 49 | — |
| | | 800 | 0.10 | — | 64 | — |
| | **H800-NE, L800-NE** | 350 | 0.10 | 0.12 | 12.3 | 14.7 |
| | | 400 | 0.10 | 0.12 | 16.0 | 19.2 |
| | | 450 | 0.10 | 0.12 | 20.3 | 24.3 |
| | | 500 | 0.10 | 0.12 | 25.0 | 30.0 |
| | | 600 | 0.10 | 0.12 | 36.0 | 43.2 |
| | | 700 | 0.10 | 0.12 | 49.0 | 58.8 |
| | | 800 | 0.10 | 0.12 | 64.0 | 76.8 |
| 1000 | **S1000-CE** | 400 | 0.062 | — | 9.9 | — |
| | | 500 | 0.062 | — | 15.5 | — |
| | | 600 | 0.062 | — | 22.3 | — |
| | | 700 | 0.062 | — | 30.4 | — |
| | | 800 | 0.062 | — | 39.7 | — |
| | | 900 | 0.062 | — | 50.2 | — |
| | | 1000 | 0.062 | — | 62.0 | — |
| | **TL-1000NE** | 500 | 0.045 | 0.060 | 11.3 | 15.0 |
| | | 600 | 0.045 | 0.060 | 16.2 | 21.6 |
| | | 700 | 0.045 | 0.060 | 22.1 | 29.4 |
| | | 800 | 0.045 | 0.060 | 28.8 | 38.4 |
| | | 900 | 0.045 | 0.060 | 36.5 | 48.6 |
| | | 1000 | 0.045 | 0.060 | 45.0 | 60.0 |
| 1200 | **TL-1200NE** | 600 | 0.045 | 0.060 | 16.2 | 21.6 |
| | | 700 | 0.045 | 0.060 | 22.1 | 29.4 |
| | | 800 | 0.045 | 0.060 | 28.8 | 38.4 |
| | | 1000 | 0.045 | 0.060 | 45.0 | 60.0 |
| | | 1200 | 0.045 | 0.060 | 64.8 | 86.4 |
| 1250 | **S1250-NE, S1250-GE** | 500 | 0.040 | 0.053 | 10 | 13.3 |
| | | 600 | 0.040 | 0.053 | 14.4 | 19.1 |
| | | 700 | 0.040 | 0.053 | 19.6 | 26 |
| | | 800 | 0.040 | 0.053 | 25.6 | 33.9 |
| | | 1000 | 0.040 | 0.053 | 40 | 53 |
| | | 1200 | 0.040 | 0.053 | 57.6 | 76.3 |
| | | 1250 | 0.040 | 0.053 | 62.5 | 82.8 |
| 1600 | **S1600-NE** | 700 | 0.022 | 0.039 ⑥ | 10.8 | 19.1 ⑥ |
| | | 800 | 0.022 | 0.039 ⑥ | 14.1 | 25 ⑥ |
| | | 900 | 0.022 | 0.039 ⑥ | 17.8 | 31.6 ⑥ |
| | | 1000 | 0.022 | 0.039 ⑥ | 22 | 39 ⑥ |
| | | 1200 | 0.022 | 0.039 ⑥ | 31.7 | 56.2 ⑥ |
| | | 1400 | 0.022 | 0.039 ⑥ | 43.1 | 76.4 ⑥ |
| | | 1500 | 0.022 | 0.039 ⑥ | 49.5 | 87.8 ⑥ |
| | | 1600 | 0.022 | 0.039 ⑥ | 56.3 | 99.8 ⑥ |
| 2000 | **XS2000NE** | 1000 | 0.017 | 0.022 ⑥ | 17.0 | 22.0 ⑥ |
| | | 1200 | 0.017 | 0.022 ⑥ | 24.5 | 31.7 ⑥ |
| | | 1400 | 0.017 | 0.022 ⑥ | 33.3 | 43.1 ⑥ |
| | | 1600 | 0.017 | 0.022 ⑥ | 43.5 | 56.3 ⑥ |
| | | 1800 | 0.017 | 0.023 ⑥ | 55.1 | 74.5 ⑥ |
| | | 2000 | 0.017 | 0.023 ⑥ | 68.0 | 92.0 ⑥ |
| 2500 | **XS2500NE** | 1200 | 0.017 ⑦ | — | 24.5 ⑦ | — |
| | | 1400 | 0.017 ⑦ | — | 33.3 ⑦ | — |
| | | 1600 | 0.017 ⑦ | — | 43.5 ⑦ | — |
| | | 2000 | 0.017 ⑦ | — | 68.0 ⑦ | — |
| | | 2500 | 0.017 ⑦ | — | 106.2 ⑦ | — |
| 3200 | **XS3200NE** | 3200 | 0.017 ⑦ | — | 174.1 ⑦ | — |

Notes ① : The resistance value is a reference value. It cannot be used for acceptance inspections, etc.
② : The power consumption value is calculated based on the DC internal resistance.
⑥ : The value of the Draw-out type.
⑦ : The value of the Rear-connected type.

## ■ Earth Leakage Circuit Breakers

| Frame size(A) | ELCB | Rated current (A) | Internal resistance (DCmΩ) ① • Value per pole | | DC Power consumption (W) ② • Value per pole | |
|---|---|---|---|---|---|---|
| | | | FC | Plug-in | FC | Plug-in |
| 30 | **PZE30-NF, PZS30-NF** | 5 | 51.5 | — | 1.29 | — |
| | | 10 | 13.0 | — | 1.30 | — |
| | | 15 | 7.1 | — | 1.60 | — |
| | | 20 | 6.8 | — | 2.72 | — |
| | | 30 | 2.7 | — | 2.43 | — |
| | **ZE30-NM, ZS30-NM** | 1.4 | 490 | — | 1.0 | — |
| | | 2.6 | 146 | — | 1.0 | — |
| | | 4 | 62.5 | — | 1.0 | — |
| | | 5 | 39.5 | — | 1.0 | — |
| | | 8 | 17.7 | — | 1.1 | — |
| | | 10 | 11.6 | — | 1.2 | — |
| | | 16 | 5.8 | — | 1.5 | — |
| | | 24 | 3.1 | — | 1.8 | — |
| | | 32 | 2.3 | — | 2.4 | — |
| | **ZS30-NM** | 0.7 | 1940 | — | 1.0 | — |
| | | 2 | 242 | — | 1.0 | — |
| | | 12 | 9.8 | — | 1.4 | — |
| 50 | **PZE50-NF, PZS50-NF** | 15 | 7.1 | — | 1.60 | — |
| | | 20 | 6.8 | — | 2.72 | — |
| | | 30 | 2.7 | — | 2.43 | — |
| | | 40 | 2.4 | — | 3.84 | — |
| | | 50 | 1.6 | — | 4.00 | — |
| | **PZE50-NFN** | 15 | 7.1 | — | 1.60 | — |
| | | 20 | 6.8 | — | 2.72 | — |
| | | 30 | 2.7 | — | 2.43 | — |
| | | 40 | 2.4 | — | 3.84 | — |
| | | 50 | 1.6 | — | 4.00 | — |
| | **ZS50-SF** | 15 | 5.47 | — | 1.23 | — |
| | | 20 | 3.87 | — | 1.55 | — |
| | | 30 | 2.7 | — | 2.43 | — |
| | | 40 | 2.35 | — | 3.76 | — |
| | | 50 | 1.87 | — | 4.67 | — |
| | **ZE50-NM** | 45 | 1.8 | — | 3.6 | — |
| | **ZS50-CM** | 0.7 | 1940 | — | 1.0 | — |
| | | 1.4 | 490 | — | 1.0 | — |
| | | 2 | 242 | — | 1.0 | — |
| | | 2.6 | 146 | — | 1.0 | — |
| | | 4 | 61 | — | 1.0 | — |
| | | 5 | 39.5 | — | 1.0 | — |
| | | 8 | 17.7 | — | 1.1 | — |
| | | 10 | 11.6 | — | 1.2 | — |
| | | 12 | 9.8 | — | 1.4 | — |
| | | 16 | 5.8 | — | 1.5 | — |
| | | 24 | 3.1 | — | 1.8 | — |
| | | 32 | 2.3 | — | 2.4 | — |
| | | 40 | 1.9 | — | 3.0 | — |
| | | 45 | 1.8 | — | 3.6 | — |
| | **TZ-51C (2P1E)** | 15 | 6.6 ③ | — | 2.49 ③ | — |
| | | 15 | 1.63 ④ | — | 1.37 ④ | — |
| | | 20 | 6.12 ③ | — | 3.45 ③ | — |
| | | 20 | 1.63 ④ | — | 1.65 ④ | — |
| | | 30 | 3.55 ③ | — | 4.2 ③ | — |
| | | 30 | 1.63 ④ | — | 2.47 ④ | — |
| | **TZ-52C (2P2E)** | 15 | 6.6 | — | 2.49 | — |
| | | 20 | 6.12 | — | 3.45 | — |
| | | 30 | 3.61 | — | 4.25 | — |
| 60 | **PZE60-NF, PZS60-NF** | 60 | 1.2 | — | 4.32 | — |
| 100, 125 | **ZS100-GF** | 15 | 15.7 | — | 3.53 | — |
| | | 20 | 15.7 | — | 6.28 | — |
| | | 30 | 9.0 | — | 8.1 | — |
| | | 40 | 2.1 | — | 3.36 | — |
| | | 50 | 2.1 | — | 5.25 | — |
| | | 60 | 1.6 | — | 5.76 | — |
| | | 75 | 1.1 | — | 6.19 | — |
| | | 100 | 1.1 | — | 11 | — |
| | **ZE100-NM** | 60 | 1.0 | — | 3.6 | — |
| | | 75 | 0.90 | — | 5.1 | — |
| | | 90 | 0.90 | — | 7.3 | — |
| | **ZS100-SM** | 16 | 5.47 | — | 1.4 | — |
| | | 24 | 3.87 | — | 2.23 | — |
| | | 32 | 2.7 | — | 2.77 | — |
| | | 40 | 2.35 | — | 3.76 | — |
| | | 45 | 2.11 | — | 4.27 | — |
| | | 60 | 1.28 | — | 4.6 | — |
| | | 75 | 1.22 | — | 6.86 | — |
| | | 90 | 0.78 | — | 6.33 | — |
| | | 100 | 0.65 | — | 6.46 | — |
| | **PZE125-NF** | 60 | 1.2 | — | 4.32 | — |
| | | 75 | 1.0 | — | 5.63 | — |
| | | 100 | 0.83 | — | 8.30 | — |
| | | 125 | 0.62 | — | 9.69 | — |
| | **PZE125-NFN** | 60 | 1.2 | — | 4.32 | — |
| | | 75 | 1.0 | — | 5.63 | — |
| | | 100 | 0.83 | — | 8.30 | — |
| | | 125 | 0.62 | — | 9.69 | — |
| | **ZS125-SF, ZNS125-SF** | 15 | 5.47 | — | 1.23 | — |
| | | 20 | 3.87 | — | 1.55 | — |
| | | 30 | 2.70 | — | 2.43 | — |
| | | 40 | 2.35 | — | 3.76 | — |
| | | 50 | 1.87 | — | 4.67 | — |
| | | 60 | 1.28 | — | 4.6 | — |
| | | 75 | 1.22 | — | 6.86 | — |
| | | 100 | 0.65 | — | 6.46 | — |
| | | 125 | 0.65 | — | 10.09 | — |
| | **ZS125-GF** | 125 | 0.60 | — | 9.4 | — |
| 225 | **ZS225-GF** | 125 | 0.44 | — | 6.88 | — |
| | | 150 | 0.44 | — | 9.9 | — |
| | | 175 | 0.37 | — | 11.33 | — |
| | | 200 | 0.37 | — | 14.8 | — |
| | | 225 | 0.37 | — | 18.73 | — |
| 250 | **ZS250-GF** | 250 | 0.29 | — | 18.1 | — |
| | **ZS250-SM** | 125 | 0.50 | — | 7.81 | — |
| | | 150 | 0.50 | — | 11.25 | — |
| | | 175 | 0.36 | — | 11.03 | — |
| | | 225 | 0.31 | — | 15.69 | — |
| | **ZE250-SF, ZS250-SF, ZNE250-SF, ZNS250-SF** | 125 | 0.50 | — | 7.81 | — |
| | | 150 | 0.50 | — | 11.25 | — |
| | | 175 | 0.36 | — | 11.03 | — |
| | | 200 | 0.36 | — | 14.4 | — |
| | | 225 | 0.31 | — | 15.69 | — |
| | | 250 | 0.31 | — | 19.38 | — |
| 400 | **ZE400-NF, ZS400-NF, ZS400-GF,ZNE400-NF, ZNS400-NF** | 250 | 0.26 | — | 16.3 | — |
| | | 300 | 0.26 | — | 23.4 | — |
| | | 350 | 0.20 | — | 24.5 | — |
| | | 400 | 0.20 | — | 32 | — |
| 600, 630 | **ZS630-CF, ZS630-NF** | 500 | 0.12 | — | 30 | — |
| | | 600 | 0.12 | — | 43.2 | — |
| 800 | **ZS800-CF, ZS800-NF** | 700 | 0.10 | — | 49 | — |
| | | 800 | 0.10 | — | 64 | — |

Notes ① : The resistance value is a reference value. It cannot be used for acceptance inspections, etc.
② : The power consumption value is calculated based on the DC internal resistance.
③ : The value of poles with a trip element.
④ : The value of poles without a trip element.

# 5 Calculation and Reference Graphs of the Short Circuit Current

Refers to the percentage impedance method (1000kVA standard) calculation method and the method of finding the estimated short circuit current (symmetrical r.m.s. value) using a quick view graph.

**Short circuit current on a 3-phase circuit.**

It assumes that a short circuit has occurred at Point F of the electrical distribution system shown in Figure 1. Figure 2 shows an impedance diagram.

Fig.1 Elec. Dis. System






Fig.2 Impedance Diagram





Z s : % impedance of power source
Z t : % impedance of transformer
Zm : % impedance of motor
Zw : % impedance of electric cable
Z b : % impedance of bus duct

## 1. Short Circuit Current Calculation

NOTE: Each impedance is calculated by taking the following value

| | |
|---|---|
| Percent. impedance of power source (Zs) | Short circuit capacity of power source : 1000MVA. Xs/Rs = 25 (Based on NEMA AB - 1) Z s = 0.004 + j 0.0999 (%) (Converted to 1000kVA standard capacity) |
| Percent impedance of transformer (Zt) | (Converted to 1000kVA standard capacity. Average values of transformer manufacturers (Refer to Table 1). |
| Percent impedance of motor (Zm) | The total capacity of a motor group related to the short circuit current is equal to the capacity of the transformer. Impedance=25%. Xm/Rm=6 (Table 1 indicates the converted value to 1000kVA standard capacity) |
| Impedance of electric cable (Zw) Impedance of bus duct (Zb) | Refer to Table 2 and 3. (For electric wires, the values of a single core 6cm Distance at 50Hz are applied to the calculation example and reference graph.) |

[The short circuit current at Point F is calcuated in the following conditions: Example]




Transformer Capacity : 750kVA
Secondary side voltage : 415 V
Frequency : 50Hz
Electric cable : 325㎟,10m

Total impedance of power source

$$Z_A = \frac{(Zs + Zt) \cdot Zm}{Zs + Zt + Zm} \quad \cdots\cdots \text{Table 1}$$

$$= 1.327 + j\,5.266\ (\%)$$

Impedence of electric cable

Multiply the value in Table 2 by the cable length of 10m and convert into the standard capacity of 1000kVA.

$$Zw = \frac{1000 \times 10^3}{415^2}(0.057 + j0.118) \times 10^{-3} \times 10 \times 100$$

$$= 0.331 + j\,0.6852\ (\%)$$

Total impedance

$$Z = Z_A + Zw = 1.658 + j5.9512$$

$$= 6.1778$$

Symmetrical r.m.s. value of 3-phase short circuit current

$$Is = \frac{1000 \times 10^3}{\sqrt{3} \times 415 \times 6.1778} \times 100 \fallingdotseq 22520\,(A)$$

**Table 1. Impedance in 3-phase Circuit** (Converted to 1000kVA standard capacity)

| Trans. Cap (kVA) | % impedance of Trans. Zt (%) | % impedance of motor Zm (%) | Total % impedance of power source ZA (%) |
|---|---|---|---|
| 50 | 33.4 + j 37.8 | 82.2 + j 493.2 | 28.98 + j 36.33 |
| 75 | 21.6 + j 31.47 | 54.8 + j 328.8 | 18.28 + j 29.39 |
| 100 | 16.0 + j 24.8 | 41.1 + j 246.6 | 13.46 + j 23.03 |
| 150 | 10.0 + j 18.07 | 27.4 + j 164.4 | 8.341 + j 16.57 |
| 200 | 7.4 + j 13.8 | 20.55 + j 123.3 | 6.161 + j 12.64 |
| 300 | 4.8 + j 10.9 | 13.7 + j 82.2 | 3.914 + j 9.773 |
| 500 | 2.56 + j 7.62 | 8.22 + j 49.32 | 2.064 + j 6.696 |
| 750 | 1.68 + j 6.16 | 5.48 + j 32.88 | 1.327 + j 5.266 |
| 1000 | 1.22 + j 5.21 | 4.11 + j 24.66 | 0.957 + j 4.372 |
| 1500 | 0.773 + j 3.99 | 2.74 + j 16.44 | 0.607 + j 3.278 |
| 2000 | 0.57 + j 3.035 | 2.055 + j 12.33 | 0.449 + j 2.5 |

Note : $Z_A = \frac{(Zs+Zt)\cdot Zm}{Zs+Zt+Zm}$

## Table 2. JIS wire impedance (Zw)

| Cable size (mm²) | Resistance Rw (mΩ/m) | Reactance Xw (mΩ/m) | | | | | |
|---|---|---|---|---|---|---|---|
| | | 50Hz | | | 60Hz | | |
| | | 2-core – 3-core | Single core, closed | Single core 6cm distance | 2-core – 3-core | Single core, closed | Single core 6cm distance |
| ø1.6mm | 8.92 | 0.103 | 0.143 | 0.287 | 0,123 | 0.172 | 0.344 |
| ø2.0mm | 5.65 | 0.097 | 0.134 | 0.273 | 0.116 | 0.161 | 0.327 |
| ø2.6mm | 3.35 | 0.096 | 0.127 | 0.256 | 0.115 | 0.152 | 0.308 |
| 2 | 9.24 | 0.100 | 0.138 | 0.279 | 0.020 | 0.167 | 0.335 |
| 3.5 | 5.20 | 0.092 | 0.126 | 0.261 | 0.110 | 0.152 | 0.314 |
| 5.5 | 3.33 | 0.092 | 0.120 | 0.247 | 0.110 | 0.145 | 0.297 |
| 8 | 2.31 | 0.092 | 0.116 | 0.236 | 0.110 | 0.140 | 0.283 |
| 14 | 1.30 | 0.088 | 0.111 | 0.218 | 0.106 | 0.134 | 0.261 |
| 22 | 0.824 | 0.086 | 0.105 | 0.204 | 0.104 | 0.127 | 0.245 |
| 30 | 0.623 | 0.083 | 0.101 | 0.195 | 0.100 | 0.122 | 0.234 |
| 38 | 0.487 | 0.083 | 0.098 | 0.187 | 0.100 | 0.118 | 0.225 |
| 50 | 0.378 | 0.081 | 0.095 | 0.178 | 0.097 | 0.115 | 0.214 |
| 60 | 0.303 | 0.079 | 0.092 | 0.172 | 0.095 | 0.111 | 0.206 |
| 80 | 0.230 | 0.078 | 0.087 | 0.173 | 0.094 | 0.107 | 0.196 |
| 100 | 0.180 | 0.076 | 0.086 | 0.155 | 0.092 | 0.104 | 0.186 |
| 125 | 0.144 | 0.076 | 0.087 | 0.148 | 0.091 | 0.106 | 0.178 |
| 150 | 0.118 | 0.075 | 0.084 | 0.142 | 0.090 | 0.101 | 0.170 |
| 200 | 0.092 | 0.073 | 0.084 | 0.134 | 0.089 | 0.101 | 0.161 |
| 250 | 0.072 | 0.073 | 0.082 | 0.126 | 0.087 | 0.099 | 0.151 |
| 325 | 0.057 | 0.072 | 0.080 | 0.118 | 0.086 | 0.097 | 0.142 |
| 400 | 0.045 | — | 0.079 | 0.112 | — | 0.095 | 0.134 |
| 500 | 0.037 | — | 0.078 | 0.105 | — | 0.094 | 0.127 |

(1) The resistance values are based on JISC3307 "660V Polyvinyl Chloride Insulated Wires (IV)" and JISC3342 "600V Polyvinyl Chloride Insulated and Sheathed Cables (VV)".
(2) The reactance value L=0.05 + 0.4605 log10 D/r (mH/km) (D=core centre to centre distance, r=center radius) then $Xw = 2\pi fL \times 10^{-3}$ (mΩ/m) (f=frequency) was calculated.

## Table 3. Impedance of Bus Duct (Zb)


| Rated Current (A) | Resistance (mΩ/m) | Reactance (mΩ/m) | |
|---|---|---|---|
| | | 50Hz | 60Hz |
| 400 | 0.158 | 0.039 | 0.046 |
| 600 | 0.127 | 0.033 | 0.039 |
| 800 | 0.085 | 0.024 | 0.028 |
| 1000 | 0.065 | 0.018 | 0.022 |
| 1200 | 0.053 | 0.014 | 0.017 |
| 1500 | 0.041 | 0.012 | 0.014 |
| 2000 | 0.025 | 0.014 | 0.017 |
| 2500 | 0.020 | 0.013 | 0.016 |
| 3000 | 0.017 | 0.011 | 0.013 |

# 5 Calculation and Reference Graphs of the Short Circuit Current

## 2. Reference graph


For the corresponding transformer capacity and the secondary voltage, read the current value(amperage)at the crossing point of the scale, indicating the distance to the short circuit point and the curve of the electric cable size.

Example 1




From Graph.11A graph 45000A is obtained for 2×200㎟、10m cable


Example 2





From Graph.11A graph for 325 ㎟, 4m cable, 50000A — A.
From the same graph for the busduct of 1500A, 8m cable, 58000A — B.
The lesser value between A and B indicates the short circuit current at Point F.

## Short circuit Current Reference Graphs ( The electric cable impedance for single core, 6cm distance at 50Hz )


**Graph. 3A**





**Graph. 3B**





**Graph. 4A**





**Graph. 4B**





**Graph. 5A**





**Graph. 5B**




**Graph. 6A** 3-phase Transformer Capacity 150kVA Secondary Voltage 200V





**Graph. 6B** 3-phase Transformer Capacity 150kVA Secondary Voltage 415V





**Graph. 7A** 3-phase Transformer Capacity 200kVA Secondary Voltage 200V





**Graph. 7B** 3-phase Transformer Capacity 200kVA Secondary Voltage 415V





**Graph. 8A** 3-phase Transformer Capacity 300kVA Secondary Voltage 200V





**Graph. 8B** 3-phase Transformer Capacity 300kVA Secondary Voltage 415V




**Graph. 9A** 3-phase Transformer Capacity 500kVA Secondary Voltage 200V





**Graph. 9B** 3-phase Transformer Capacity 500kVA Secondary Voltage 415V




## 5 Calculation and Reference Graphs of the Short Circuit Current


**Graph. 10A**





**Graph. 10B**





**Graph. 11A**





**Graph. 11B**





**Graph. 12A**





**Graph. 12B**




**Graph. 13A**




**Graph. 13B**



## Short Circuit Current on a single phase 3-Wire System

It assumes that a short circuit has occurred at Point F of the electrical distribution system shown in Figure 14. Figure 15 shows an impedance diagram.

Fig.14 Elec. Dis. System






Fig.15 Impedance Diagram





Z s： % impedance of power source
Z t： % impedance of transformer
Zw： % impedance of electric cable
Z b： % impedance of bus duct

## 1. Short Circuit Current Calculation

NOTE: Each impedance is calculated by taking the following value.

| | |
|---|---|
| Percent impedance of power source (Zs) | Short circuit capacity of power source:500MVA. X s/R s = 25, Z s = 0.008 + j 0.1998 (%) (Converted to 1000kVA standard capacity) |
| Percent impedance of transformer (Zt) | (Converted to 1000kVA standard capacity. (Refer to Table 4). |
| Impedance of electric cable (Zw) Impedance of bus duct (Zb) | Refer to Table 2 and 3.(For electric wires, the values of a single core 6cm Distance at 50Hz are applied to the calculation example and reference graph.) |

[The short circuit current at point F is calculated in the following conditions: Example]
Transformer Capacity 500kVA, Secondary side voltage 200/100V, Frequency 50Hz
Electric cable 2×200㎟, 10m




| | | |
|---|---|---|
| Total impedance of power source | Z A= Z s+ Z t———Table 4 =2.408 + j 9.5 (%) | Z A= Z s+ Z t———Table 4 =3.608 + j 9.0 (%) |
| Impedence of electric cable | Multiply the value in Table 2 by the cable length of 20m (both ways) and convert into the standard capacity of 1000kVA $Zw = \frac{1000\times10^3}{200^2}\{\frac{1}{2}(0.092 + j0.134)\} \times10^{-3}\times20\times100$ = 2.3 + j3.35 (%) | $Zw = \frac{1000\times10^3}{100^2}\{\frac{1}{2}(0.092 + j0.134)\} \times10^{-3}\times20\times100$ = 9.2 + j13.4 (%) |
| Total impedance | Z = ZA + Zw = 4.708 + j12.85 = 13.685 (%) | Z = ZA + Zw = 12.808 + j22.4 = 25.803 (%) |
| Symmetrical r.m.s. value of the short circuit current | $Is = \frac{1000\times10^3}{200\times13.685} \times100$ ≒36500(A) | $Is = \frac{1000\times10^3}{100\times25.803} \times100$ ≒38750 |

**Table 4. Impedance in a single phase 3-wire circuit** (Converted to 1000kVA standard capacity)

| Trans. Cap (kVA) | % impedance of Trans.Zt (%) | | Total % if impedance of power source ZA (%) | |
|---|---|---|---|---|
| | Between external cables | External cables to neutral cables | Between external cables | External cables to neutral cables |
| 10 | 210 +j106 | 290 +j110 | 210.008+j106.2 | 290.008+j110.2 |
| 20 | 90 +j71.5 | 135 +j65 | 90.008+j71.7 | 135.008+j65.2 |
| 30 | 51.67+j47.33 | 80 +j41.33 | 51.675+j47.5 | 80.008+j41.5 |
| 50 | 28 +j32.6 | 42 +j37.2 | 28.008+j32.8 | 42.008+j37.4 |
| 75 | 19.33+j32 | 32 +j35.73 | 19.341+j32.2 | 32.008+j35.9 |
| 100 | 14.5 +j25.1 | 22 +j28.6 | 14.508+j25.3 | 22.008+j28.8 |
| 150 | 9.0 +j18.67 | 13.33+j16.13 | 9.008+j18.9 | 13.341+j16.3 |
| 200 | 6.75+j16.7 | 10.0 +j14 | 6.758+j16.9 | 10.008+j14.2 |
| 300 | 4.17+j11.6 | 6.0 +j10.6 | 4.175+j11.8 | 6.008+j10.8 |
| 500 | 2.4 +j9.3 | 3.6 +j8.8 | 2.408+j9.5 | 3.608+j9.0 |


Note: ZA = Zs + Zt

# 5 Calculation and Reference Graphs of the Short Circuit Current


## 2. Reference graph

For the corresponding transformer capacity and the secondary voltage,read the current value(amperage)at the crossing point of the scale, indicating the distance to the short circuit point and the curve of the electric cable size.


**Graph. 16A** Single Phase, 3 Wire Transformer Capacity 10kVA Between External Cables: 200V





**Graph. 16B** Single Phase, 3 Wire Transformer Capacity 10kVA External Cable to Newtral Cable: 100V





**Graph. 17A** Single Phase, 3 Wire Transformer Capacity 20kVA Between External Cables: 200V





**Graph. 17B** Single Phase, 3 Wire Transformer Capacity 20kVA External Cable to Newtral Cable: 100V





**Graph. 18A** Single Phase, 3 Wire Transformer Capacity 30kVA Between External Cables: 200V





**Graph. 18B** Single Phase, 3 Wire Transformer Capacity 30kVA External Cable to Newtral Cable: 100V




**Graph. 19A** Single Phase, 3 Wire Transformer Capacity 50kVA Between External Cables: 200V





**Graph. 19B** Single Phase, 3 Wire Transformer Capacity 50kVA External Cable to Newtral Cable: 100V





**Graph. 20A** Single Phase, 3 Wire Transformer Capacity 75kVA Between External Cables: 200V





**Graph. 20B** Single Phase, 3 Wire Transformer Capacity 75kVA External Cable to Newtral Cable: 100V




**Graph. 21A** Single Phase, 3 Wire Transformer Capacity 100kVA Between External Cables: 200V





**Graph. 21B** Single Phase, 3 Wire Transformer Capacity 100kVA External Cable to Newtral Cable: 100V




## 5 Calculation and Reference Graphs of the Short Circuit Current


**Graph. 22A** Single Phase, 3 Wire Transformer Capacity 150kVA Between External Cables: 200V





**Graph. 22B** Single Phase, 3 Wire Transformer Capacity 150kVA External Cable to Newtral Cable: 100V





**Graph. 23A** Single Phase, 3 Wire Transformer Capacity 200kVA Between External Cables: 200V





**Graph. 23B** Single Phase, 3 Wire Transformer Capacity 200kVA External Cable to Newtral Cable: 100V





**Graph. 24A** Single Phase, 3 Wire Transformer Capacity 300kVA Between External Cables: 200V





**Graph. 24B** Single Phase, 3 Wire Transformer Capacity 300kVA External Cable to Newtral Cable: 100V




**Graph. 25A** Single Phase, 3 Wire Transformer Capacity 500kVA Between External Cables: 200V




**Graph. 25B** Single Phase, 3 Wire Transformer Capacity 500kVA External Cable to Newtral Cable: 100V



# 1. Moulded Case Circuit Breakers

**Moulded Case Circuit Breakers**

**Type** — PS250-PF

| |
|---|
| Economical series |
| Standard series |
| High-fault level series |
| Current limiting standard series |
| Current limiting High-fault level series |
| Motor protection series |
| Switch-disconnectors |
| Circuit Breaker with Earth Leakage Alarm |
| Single phase 3-wire circuit breaker with neutral phase open protection and earth leakage alarm |
| Single phase 3-wire circuit breaker with neutral phase open protection |

**Number of poles** — 3

| |
|---|
| 2 P |
| 3 P |
| 4 P |

**Mounting and Connection** — RC-D

| | |
|---|---|
| F C | Front-connected |
| F C （BAR） | Front-connected (When extension bars are attached as an option) ＊1 |
| R C ＊2 | Rear-connected |
| P M C | Plug-in (Standard) (Please order the required number of plug-in bases separately) |
| P M B | Plug-in (High-performance) (Please order the required number of plug-in bases separately) |
| P M D | Plug-in (For distribution mode) (Please order the required number of plug-in bases separately) |
| D R | Draw-out |
| F P ＊2 | Flush-mounted |
| P G | TemPlug70 |

＊1 : Extension bars of 250 A frame or less are supplied separately.
＊2 : Specify the orientation of the flat bar stud on the line/load side.

| | |
|---|---|
| A | Line side-Vertical, Load side-Horizontal |
| B | Line side-Horizontal, Load side-Vertical |
| C | Line side-Vertical, Load side-Vertical |
| D | Line side-Horizontal, Load side-Horizontal |

**Rated current** — 225A

| |
|---|
| For DC specifications, specify the rated voltage.<br>V DC |

**Sensitivity current**

| | |
|---|---|
| 30mA | Please specify whether you require an earth leakage alarm. |
| 100/200/500mA selectable | |

**Accessory** — AX1C

| Accessories(Optional) | | | |
|---|---|---|---|
| | symbol | Type | Specified items / other |
| Internally Mounted | A X | Auxiliary switch | C |
| | A L | Alarm switch | C |
| | S H | Shunt trip | V AC/DC Hz |
| | U V | Under voltage trip | V AC/DC Hz |
| Externally mounted | M C | Motor operators | V AC/DC |
| | H B | External operating handles | Breaker-mounted |
| | H P | | Door-mounted |
| | M S | Mechanical interlock | Slide type(Breaker-mounted) |
| | M B | | Rear-connected type |
| | M L | | Link type |
| | MW | | Wire type |
| | H H | Toggle holder | |
| | H L | Toggle lock | |
| | C F | Terminal cover | For front-connected |
| | C R | | For rear-connected and plug-in |
| | C S | | For front-connected type with cable clamps |
| | B A | Interpole barrier | |
| | T F | Terminal block for lead | |
| | D F | Door flange | |

**Quantity** — 10

# 2.Moulded Case Circuit Breakers TPOT type, TPOP type electronic OCR

**Electronic breakers**

**Type** — PS250-NE

| |
|---|
| Standard series |
| High-fault level series |
| Current limiting standard series |
| Current limiting High-fault level series |

**Number of poles** — 3

| |
|---|
| 3 P |
| 4 P |

**Mounting and Connection** — RC-C

| | |
|---|---|
| F C | Front-connected |
| F C (BAR) | Front-connected (When extension bars are attached as an option) ＊1 |
| R C ＊2 | Rear-connected |
| P M C ＊3 | Plug-in (Standard) (Please order the required number of plug-in bases separately) |
| P M B ＊3 | Plug-in (High-performance) (Please order the required number of plug-in bases separately) |
| P M D ＊4 | Plug-in (For distribution mode) (Please order the required number of plug-in bases separately) |
| D R | Draw-out |
| F P ＊2 | Flush-mounted |
| P G | TemPlug70 |

＊1 : Extension bars of 250A frame or less are supplied separately.
＊2 : Specify the orientation of the flat bar stud on the line/load side.

| | |
|---|---|
| A | Line side-Vertical, Load side-Horizontal |
| B | Line side-Horizontal, Load side-Vertical |
| C | Line side-Vertical, Load side-Vertical |
| D | Line side-Horizontal, Load side-Horizontal |

＊3 : PS630-NE and PS630-GE are not supported.
＊4 : PMD can be specified only for PS125-NE and PS125-PE 3 poles.

**Rated current** — 250A

**Overcurrent trip device OCR type** — TPOT

| OCR type | Protective functions | | | Alarm function |
|---|---|---|---|---|
| | Long time, Short time, Instantaneous | Ground fault | Neutral protection | Preferential trip alarm |
| TPOT (LSI) | ● | — | — | ● |
| TPOP (LSIG) | ● | ● ＊5 | ● ＊6 | ● |

＊5 : 3-pole breakers support 3Φ3W only.
＊6 : Not compatible with 100A or less.

**Accessory** — UV 220V AC

| Accessories(Optional) | | | |
|---|---|---|---|
| | symbol | Type | Specified items/other |
| Internally Mounted | A X | Auxiliary switch | C |
| | A L | Alarm switch | C |
| | S H | Shunt trip | V AC/DC Hz |
| | U V | Under voltage trip | V AC/DC Hz |
| Externally mounted | M C | Motor operators | V AC/DC |
| | H B | External operating handles | Breaker-mounted |
| | H P | | Door-mounted |
| | M S | Mechanical interlock | Slide type(Breaker-mounted) |
| | M B | | Rear-connected type |
| | M L | | Link type |
| | M W | | Wire type |
| | H H | Toggle holder | |
| | H L | Toggle lock | |
| | C F | Terminal cover | For front-connected |
| | C R | | For rear-connected and plug-in |
| | C S | | For front-connected type with cable clamps |
| | B A | Interpole barrier | |
| | T F | Terminal block for lead | |
| | D F | Door flange | |

**Quantity** — 8

# 3.Moulded Case Circuit Breakers　TPOU type electronic OCR (smart circuit breakers)

**Electronic breakers**

**Type**
PS400-NE

| | |
|---|---|
| Standard series | |
| High-fault level series | |
| Current limiting standard series | |
| Current limiting High-fault level series | |

**Number of poles**
3

| | |
|---|---|
| 3 P | |
| 4 P | |

**Mounting and Connection**
RC-C

| | |
|---|---|
| F C | Front-connected |
| F C (BAR) | Front-connected (When extension bars are attached as an option) ＊1 |
| R C ＊2 | Rear-connected |
| P M C ＊3 | Plug-in (Standard) (Please order the required number of plug-in bases separately) |
| P M B ＊3 | Plug-in (High-performance) (Please order the required number of plug-in bases separately) |
| P M D ＊4 | Plug-in (For distribution mode) (Please order the required number of plug-in bases separately) |
| D R | Draw-out |
| F P ＊2 | Flush-mounted |
| P G | TemPlug70 |

＊1 : Extension bars of 250A frame or less are supplied separately.
＊2 : Specify the orientation of the flat bar stud on the line/load side.

| | |
|---|---|
| A | Line side-Vertical, Load side-Horizontal |
| B | Line side-Horizontal, Load side-Vertical |
| C | Line side-Vertical, Load side-Vertical |
| D | Line side-Horizontal, Load side-Horizontal |

＊3 : PS630-NE and PS630-GE are not supported.
＊4 : PMD can be specified only for PS125-NE and PS125-PE 3 poles.

**Rated current**
400A

**Overcurrent trip device OCR type**
TPOU

| | | | |
|---|---|---|---|
| TPOU (SMART) | Protective functions | Long time, Short time, Instantaneous | ● |
| | | Ground fault | ● ＊5 |
| | | Neutral protection | ● ＊6 |
| | | Zone interlock | ● |
| | Alarm function | Preferential trip alarm | ● |
| | Measurement/display function | | ● |
| | Communication function | | ● |

＊5 : 3-pole breakers support 3Φ3W only.
＊6 : Not compatible with 100A or less.

**Accessory**
UV 220V AC

| Accessories(Optional) | | | |
|---|---|---|---|
| | symbol | Type | Specified items/other |
| Internally Mounted | A X | Auxiliary switch | C |
| | A L | Alarm switch | C |
| | S H | Shunt trip | V AC/DC Hz |
| | U V | Under voltage trip | V AC/DC Hz |
| Externally mounted | M C | Motor operators | V AC/DC |
| | H B | External operating handles | Breaker-mounted |
| | H P | | Door-mounted |
| | M S | Mechanical interlock | Slide type(Breaker-mounted) |
| | M B | | Rear-connected type |
| | M L | | Link type |
| | MW | | Wire type |
| | H H | Toggle holder | |
| | H L | Toggle lock | |
| | C F | Terminal cover | For front-connected |
| | C R | | For rear-connected and plug-in |
| | C S | | For front-connected type with cable clamps |
| | B A | Interpole barrier | |
| | T F | Terminal block for lead | |
| | D F | Door flange | |

**Quantity**
8

# 4.Moulded Case Circuit Breakers XOU electronic OCR

**Electronic breakers**

**Type**
H400-NE

| |
|---|
| Standard series |
| High-fault level series |
| Current limiting standard series |
| Current limiting High-fault level series |

**Number of poles**
3

| |
|---|
| 3 P |
| 4 P |

**Mounting and Connection**
FC

| | |
|---|---|
| F C | Front-connected |
| F C (BAR) | Front-connected (When extension bars are attached as an option) |
| R C ＊1 | Rear-connected |
| P M C ＊2 | Plug-in (Standard) (Please order the required number of plug-in bases separately) |
| P M B ＊3 | Plug-in (High-performance) (Please order the required number of plug-in bases separately) |
| D R | Draw-out |
| F P ＊1 | Flush-mounted |
| P G | TemPlug70 |

＊1 : Specify the orientation of the flat bar stud on the line/load side.

| | |
|---|---|
| A | Line side-Vertical, Load side-Horizontal |
| B | Line side-Horizontal, Load side-Vertical |
| C | Line side-Vertical, Load side-Vertical |
| D | Line side-Horizontal, Load side-Horizontal |

＊2 : 4-pole type breakers, S1000-CE and S1600-NE are not supported.
＊3 : Models above 1000AF are supported.

**Rated current**
400A

**Overcurrent trip device protection code**
APG

**OCR controller control power supply**
110V AC

A □ □ □
- N : Neutral protection
- G : Ground falut trip
- P : Preferential trip alarm

See page 6-6 for applications.
Note: When "P" is applied, specify the control power supply.

**Overcurrent trip characteristics**
4

| Characteristics | Type |
|---|---|
| 1 | Generator protection characteristics |
| 2 | General protection characteristics |
| 3 | General protection characteristics |
| 4 | General protection characteristics |
| 5 | Motor protection characteristics |
| 6 | Motor protection characteristics |
| 7 | Motor protection characteristics |

**Accessory**
SH 110V AC

Accessories (Optional)

| | symbol | Type | Specified items / other |
|---|---|---|---|
| Internally Mounted | A X | Auxiliary switch | C |
| | A L | Alarm switch | C |
| | S H | Shunt trip | V AC/DC Hz |
| | U V | Under voltage trip | V AC/DC Hz |
| Externally mounted | M C | Motor operators | V AC/DC |
| | H B | External operating handles | Breaker-mounted |
| | H P | | Door-mounted |
| | M S | Mechanical interlock | Slide type (Breaker-mounted) |
| | M B | | Rear-connected type |
| | M L | | Link type |
| | MW | | Wire type |
| | H H | Toggle holder | |
| | H L | Toggle lock | |
| | C F | Terminal cover | For front-connected |
| | C R | | For rear-connected and plug-in |
| | C S | | For front-connected type with cable clamps |
| | B A | Interpole barrier | |
| | T F | Terminal block for lead | |
| | D F | Door flange | |

**Quantity**
12

# 5.Moulded Case Circuit Breakers　XOW electronic OCR (high-performance type)

**Electronic breakers**

**Type**
S800-NE

| |
|---|
| Standard series |
| High-fault level series |
| Current limiting standard series |
| Current limiting High-fault level series |

**Number of poles**
3

| |
|---|
| 3 P |
| 4 P |

**Mounting and Connection**
RC-C

| | |
|---|---|
| F C | Front-connected |
| F C (BAR) | Front-connected (When extension bars are attached as an option) |
| R C ＊1 | Rear-connected |
| P M C ＊2 | Plug-in (Standard) (Please order the required number of plug-in bases separately) |
| P M B ＊2 | Plug-in (High-performance) (Please order the required number of plug-in bases separately) |
| D R | Draw-out |
| F P ＊1 | Flush-mounted |
| P G | TemPlug70 |

＊1 : Specify the orientation of the flat bar stud on the line/load side.

| | |
|---|---|
| A | Line side-Vertical, Load side-Horizontal |
| B | Line side-Horizontal, Load side-Vertical |
| C | Line side-Vertical, Load side-Vertical |
| D | Line side-Horizontal, Load side-Horizontal |

＊2 : 4-pole type breakers and S1000-CE are not supported.

**Rated current**
800A

**Overcurrent trip device OCR type**
XOW-1L-AP

**OCR controller control power supply**
220V AC

| OCR type | OCR controller control power supply |
|---|---|
| XOW-1L-A | 100-120V AC or 200-240V AC |
| XOW-1L-AGN | |
| XOW-1L-AP | |
| XOW-1L-APGNS | |
| XOW-1L-APC | |
| XOW-1L-APGNSC | |
| XOW-1S-A | |
| XOW-1S-AGN | |
| XOW-1S-AP | |
| XOW-1S-APGNS | |
| XOW-1S-APCWH | |
| XOW-1S-APGNSCWH | |

**LCD display window mounting orientation**
Vertical ON side upper

| LCD display window mounting orientation |
|---|
| Vertical ON side upper (standard) |
| Horizontal ON side right |
| Horizontal ON side left |

**Accessory**
UV 220V AC

| Accessories(Optional) | | | |
|---|---|---|---|
| | symbol | Type | Specified items / other |
| Internally Mounted | A X | Auxiliary switch | C |
| | A L | Alarm switch | C |
| | S H | Shunt trip | V AC/DC Hz |
| | U V | Under voltage trip | V AC/DC Hz |
| Externally mounted | M C | Motor operators | V AC/DC |
| | H B | External operating handles | Breaker-mounted |
| | H P | | Door-mounted |
| | M S | Mechanical interlock | Slide type (Breaker-mounted) |
| | M B | | Rear-connected type |
| | M L | | Link type |
| | M W | | Wire type |
| | H H | Toggle holder | |
| | H L | Toggle lock | |
| | C F | Terminal cover | For front-connected |
| | C R | | For rear-connected and plug-in |
| | C S | | For front-connected type with cable clamps |
| | B A | Interpole barrier | |
| | T F | Terminal block for lead | |
| | D F | Door flange | |

**Quantity**
8

# 6.Moulded Case Circuit Breakers XOS electronic OCR

**Electronic breakers**

**Type** XS2000NE

| |
|---|
| Standard series |
| High-fault level series |
| Current limiting standard series |
| Current limiting High-fault level series |

**Number of poles** 3

| |
|---|
| 3 P |
| 4 P |

**Mounting and Connection** FC

| | |
|---|---|
| F C | Front-connected |
| F C (BAR) | Front-connected (When extension bars are attached as an option) |
| R C ＊1 | Rear-connected |
| P M | Plug-in (Please order the required number of plug-in bases separately) |
| D R | Draw-out |
| F P ＊1 | Flush-mounted |
| P G | TemPlug70 |

＊1 : Specify the orientation of the flat bar stud on the line/load side.

| | |
|---|---|
| A | Line side-Vertical, Load side-Horizontal |
| B | Line side-Horizontal, Load side-Vertical |
| C | Line side-Vertical, Load side-Vertical |
| D | Line side-Horizontal, Load side-Horizontal |

**Rated current** 2000A

**Overcurrent trip device protection code** AP

**OCR controller control power supply** 100V AC

A □ □ □
- I : Trip indicator
- G : Ground falut trip
- P : Preferential trip alarm
- H : High Instantaneous Trip (See page 4-4)
- A : With long time, short time, instantaneous (standard product)

Please specify if necessary. (See page 6-10 for applications) If not required, you do not need to fill it out.

Note: When “I” or “P” is applied, specify the control power supply.


**Accessory** SH 100V AC

Accessories(Optional)

| | symbol | Type | Specified items / other |
|---|---|---|---|
| Internally Mounted | A X | Auxiliary switch | C |
| | A L | Alarm switch | C |
| | S H | Shunt trip | V AC/DC Hz |
| | U V | Under voltage trip | V AC/DC Hz |
| Externally mounted | M B | Mechanical interlock | Rear-connected type |
| | T F | Terminal block for lead | |
| | D F | Door flange | |

**Quantity** 5

# 7.Moulded Case Circuit Breakers TB series for distribution boards



# 8.Earth Leakage Circuit Breakers

**Earth Leakage Circuit Breakers**

**Type**
2S100-GF

| |
|---|
| Economical series |
| Standard series |
| High-fault level series |
| Earth Leakage Circuit Breakers for motor protection |
| Single phase 3-wire earth leakage circuit breaker with neutral phase open protection |

**Number of poles**
3

| |
|---|
| 3 P |
| 4 P |

**Mounting and Connection**
FP-D

| | |
|---|---|
| F C | Front-connected |
| F C (BAR) | Front-connected (When extension bars are attached as an option) |
| R C ＊1 | Rear-connected |
| F P ＊1 | Flush-mounted |
| P G | TemPlug70 |

＊1 : Specify the orientation of the flat bar stud on the line/load side.

| | |
|---|---|
| A | Line side-Vertical, Load side-Horizontal |
| B | Line side-Horizontal, Load side-Vertical |
| C | Line side-Vertical, Load side-Vertical |
| D | Line side-Horizontal, Load side-Horizontal |

**Rated current**
100A

**Sensitivity current**
100/200/500mA

| | |
|---|---|
| 15mA | For electric shock prevention |
| 30mA | |
| 100mA | For electric leakage fire prevention and for electric shock prevention by grounding equipment together |
| 100/200mA selectable | |
| 100/200/500mA selectable | |

**Please enter "time delay type" or "Instantaneous tripping type"**
time delay type

**Accessory**
AL 1C

Accessories(Optional)

| | symbol | Type | Specified items / other |
|---|---|---|---|
| Internally Mounted | A X | Auxiliary switch | C |
| | A L | Alarm switch | C |
| | T L | Test lead | |
| | M G | Megger test switch | |
| Externally mounted | M C | Motor operators | V AC/DC |
| | H B | External operating handles | Breaker-mounted |
| | H P | | Door-mounted |
| | M S | Mechanical interlock | Slide type (Breaker-mounted) |
| | M L | | Link type |
| | M W | | Wire type |
| | H H | Toggle holder | |
| | H L | Toggle lock | |
| | C F | Terminal cover | For front-connected |
| | C R | | For rear-connected and plug-in |
| | C S | | For front-connected type with cable clamps |
| | B A | Interpole barrier | |
| | T F | Terminal block for lead | |
| | D F | Door flange | |

**Quantity**
15

# 9. Earth Leakage Relays TZS series

## (Separate type)

**Type**

TZS-100HD

| | |
|---|---|
| HD | High-sensitivity Instantaneous tripping type |
| MD | Medium sensitivity Instantaneous tripping / time delay tripping type |

**Mounting and Connection**

FC

| | |
|---|---|
| FC | Front-connected |
| FP | Flush-mounted |

**Rated control voltage**

100V-200V

| | |
|---|---|
| 100-200V | Selection type |
| 415-440V | Custom-built. |

**Sensitivity current**

30mA

| | |
|---|---|
| HD | 30mA |
| MD | 100 / 200 / 500 / 1000mA selectable |

Remarks (1) Sensitivity current switching type is set to 100mA before delivery.

**Please enter the time delay time only for the medium sensitivity high speed/time delay type.**

| | |
|---|---|
| MD | 0.1 or less / 0.3 / 0.5 / 1.0 / 2 seconds switching |

Remarks (2) The time delay switching type is set to 0.1 or less before delivery.

**Quantity**

2

Remarks (3) Delivered as a set together with an earth leakage monitor (ZCT).
The type display on the relay body is TZS-HD or TZS-MD.

# 10. Internal accessory order type

The following internal accessories are parts that can be mounted with one touch. They make it possible to quickly respond to emergencies and specification changes. When ordering, please specify the type ordered and quantity.

| Internally mounted accessories | Breaker | | Specification | | Accessory order type ① |
|---|---|---|---|---|---|
| | Moulded Case Circuit Breakers | Earth Leakage Circuit Breakers | | | |
| Auxiliary switch (AX) | E30-NM, S30-NM, E50-NM, S50-NM, E100-NM | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM | Standard | 1C contact. Left side mounting | AX05WL3SW ③ |
| | | | | 1C contact. Right side mounting | AX05WR3SW ③ |
| | | | For microload | 1C contact. Left side mounting | AX05WL3RW ③ |
| | | | | 1C contact. Right side mounting | AX05WR3RW ③ |
| | PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN, S50-SF, S125-SF, S125-SN, NAE125-SF, NAS125-SF, ZAS125-SF, NS125-SF, PS50-PF, PS125-NF/PF/NM/NN, PS125-NE/PE, E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF, PS250-PF/NN, PS250-NE/PE, PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE | PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN, ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF, ZE250-SF, ZS250-SF, ZS250-SM, ZNE250-SF, ZNS250-SF | Standard ② | 1C contact | AX00LML3SW |
| | | | | 2C contact | AX00LML4SW |
| | | | For microload ② | 1C contact | AX00LML3RW |
| | | | | 2C contact | AX00LML4RW |
| | S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF, H100-NF, H125-NF, H225-NF, H225-NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, ZAS225-GF, ZAS250-GF, H400-NE, L400-NE, E400-NF, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF, NS630-NF, NS800-NF, S630-CF/NF/NE/GN, ZAS630-CF/NF, H630-NE, L630-NE, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, H800-NE, L800-NE, ZAS800-CF/NF, S1000-CE/NN, S1250-NE/GE/NN, S1600-NE/NN | ZS100-GF, ZS125-GF, ZS225-GF, ZS250-GF, ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF, ZS630-CF, ZS630-NF, ZS800-CF, ZS800-NF | Standard② | 1C contact | AX00M3SW |
| | | | | 2C contact | AX00M4SW |
| | | | | 3C contact | AX00M5SW |
| | | | | 4C contact | AX00M6SW |
| | | | For microload ② | 1C contact | AX00M3RW |
| | | | | 2C contact | AX00M4RW |
| | | | | 3C contact | AX00M5RW |
| | | | | 4C contact | AX00M6RW |
| Alarm switch (AL) | E30-NM, S30-NM, E50-NM, S50-NM, E100-NM | ZE30-NM, ZS30-NM, ZE50-NM, ZS50-CM, ZE100-NM | Standard | 1C contact. Left side mounting | AL05KL3SW ③ |
| | | | | 1C contact. Right side mounting | AL05KR3SW ③ |
| | | | For microload | 1C contact. Left side mounting | AL05KL3RW ③ |
| | | | | 1C contact. Right side mounting | AL05KR3RW ③ |
| | PE30-NF/NN, PS30-NF, PE50-NF/NN/NFZ/NFN, PS50-NF/NFZ, PE60-NF, PS60-NF, PE125-NF/NN/NFZ/NFN, S50-SF, S125-SF, S125-SN, NAE125-SF, NAS125-SF, ZAS125-SF, NS125-SF, PS50-PF, PS125-NF/PF/NM/NN, PS125-NE/PE, E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF, NAE250-SF, NAS250-SF, NE250-SF, NS250-SF, PS250-PF/NN, PS250-NE/PE, PS400-CF/NF/GF/NN, PS400-NE/GE, PH400-CF, PH400-CE, PS630-CF/NF/GF/NN, PS630-NE/GE, PH630-CF, PH630-CE | PZE30-NF, PZS30-NF, PZE50-NF/NFN, PZS50-NF, PZE60-NF, PZS60-NF, PZE125-NF/NFN, ZS50-SF, ZS125-SF, ZS100-SM, ZNS125-SF, ZE250-SF, ZS250-SF, ZS250-SM, ZNE250-SF, ZNS250-SF | Standard | 1C contact. Left side mounting | AL00LML3SW |
| | | | | 2C contact. Right side mounting | AL00LMR4SW |
| | | | For microload | 1C contact. Left side mounting | AL00LML3RW |
| | | | | 2C contact. Right side mounting | AL00LMR4RW |
| | S100-GF, S125-GF, ZAS50-GF, ZAS100-GF, ZAS125-GF, H100-NF, H125-NF, H225-NF, H225-NE, H250-NF, L100-NF, L125-NF, L225-NF, L250-NF, ZAS225-GF, ZAS250-GF, H400-NE, L400-NE, E400-NF, ZAE400-NF, ZAS400-NF/GF, NAE400-NF, NAS400-NF, NE400-NF, NS400-NF, NS630-NF, NS800-NF, S630-CF/NF/NE/GN, ZAS630-CF/NF, H630-NE, L630-NE, S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, H800-NE, L800-NE, ZAS800-CF/NF, S1000-CE/NN, S1250-NE/GE/NN, S1600-NE/NN | ZS100-GF, ZS125-GF, ZS225-GF, ZS250-GF, ZE400-NF, ZS400-NF/GF, ZNE400-NF, ZNS400-NF, ZS630-CF, ZS630-NF, ZS800-CF, ZS800-NF | Standard | 1C contact | AL00M3SW |
| | | | For microload | 1C contact | AL00M3RW |

Notes ① : All internal accessories are for lead wire draw-out.
② : 2C to 4C contacts do not mean there are 2 to 4 switches, but one switch on the 2nd C, 3rd C, and 4th C with ring marks labeled 2C, 3C, 4C. For auxiliary switches or alarm switches, left-hand mounting has priority.
③ : Circuit breakers with undervoltage trip cannot be retrofitted with an auxiliary switch or alarm switch by the customer.

| Internally mounted accessories | Breaker<br>Moulded Case Circuit Breakers | Specification | | Accessory order type ① |
|---|---|---|---|---|
| Shunt trip (SH) | **E30-NM, S30-NM,<br>E50-NM, S50-NM,<br>E100-NM** | 100–120V AC / 100–110V DC | | SH05A10W |
| | | 200–240V AC | | SH05A20W |
| | | 380–450V AC | | SH05A40W |
| | **PE30-NF/NN, PS30-NF, PE50-NF/NN, PS50-NF,<br>PE60-NF, PS60-NF, PE125-NF/NN,<br>S50-SF, S125-SF, S125-SN,<br>PS50-PF, PS125-NF/PF/NM/NN, PS125-NE/PE,<br>E250-SF, S250-SF, S250-SM/SN, PS250-PF/NN, PS250-NE/PE,<br>PS400-CF/NF/GF/NN, PS400-NE/GE,<br>PH400-CF, PH400-CE,<br>PS630-CF/NF/GF/NN, PS630-NE/GE,<br>PH630-CF, PH630-CE** | 100–120V AC | | SH00LA10W |
| | | 200–240V AC | | SH00LA20W |
| | | 380–450V AC | | SH00LA40W |
| | | 24V DC | | SH00LD02W |
| | | 48V DC | | SH00LD04W |
| | | 100–120V DC | | SH00LD10W |
| | | 200–240V DC | | SH00LD20W |
| | **S100-GF, S125-GF, H100-NF, H125-NF, H225-NF/NE, H250-NF,<br>L100-NF, L125-NF, L225-NF, L250-NF,<br>H400-NE, L400-NE, E400-NF** | 100–120V AC | | SH00A10W |
| | | 200–240V AC | | SH00A20W |
| | | 380–450V AC | | SH00A40W |
| | | 24V DC | | SH00D02W |
| | | 48V DC | | SH00D04W |
| | | 100–120V DC | | SH00D10W |
| | | 200–240V DC | | SH00D20W |
| | **S630-CF/NF/NE/GN, H630-NE, L630-NE,<br>S800-CF/NF/RF/PF/NN, S800-NE/RE/PE, H800-NE, L800-NE,<br>S1000-CE/NN** | 100–120V AC | | SH80A10W |
| | | 200–240V AC | | SH80A20W |
| | | 380–450V AC | | SH80A40W |
| | | 24V DC | | SH80D02W |
| | | 48V DC | | SH80D04W |
| | | 100–120V DC | | SH80D10W |
| | | 200–240V DC | | SH80D20W |
| | **S1250-NE/GE/NN, S1600-NE/NN** | 100–120V AC | | SHX6A10W |
| | | 200–240V AC | | SHX6A20W |
| | | 380–450V AC | | SHX6A40W |
| | | 24V DC | | SHX6D02W |
| | | 48V DC | | SHX6D04W |
| | | 100–120V DC | | SHX6D10W |
| | | 200–240V DC | | SHX6D20W |
| Under voltage trip (UV) | **PE30-NF/NN, PS30-NF,<br>PE50-NF/NN, PS50-NF,<br>PE60-NF, PS60-NF, PE125-NF/NN,<br>S50-SF, S125-SF, S125-SN,<br>PS50-PF, PS125-NF/PF/NM/NN,<br>PS125-NE/PE,<br>E250-SF, S250-SF, S250-SM/SN,<br>PS250-PF/NN,<br>PS250-NE/PE,<br>PS400-CF/NF/GF/NN,<br>PS400-NE/GE, PH400-CF, PH400-CE,<br>PS630-CF/NF/GF/NN, PS630-NE/GE,<br>PH630-CF, PH630-CE** | Instantaneous type | 100–120V AC | UV00LA10NW |
| | | | 200–240V AC | UV00LA20NW |
| | | | 380–450V AC | UV00LA40NW |
| | | | 24V DC | UV00LD02NW |
| | | | 100–120V DC | UV00LD10NW |
| | | | 200–240V DC | UV00LD20NW |
| | **S100-GF, S125-GF, H100-NF, H125-NF,<br>H225-NF/NE, H250-NF,<br>L100-NF, L125-NF, L225-NF, L250-NF,<br>H400-NE, L400-NE, E400-NF** | Instantaneous type | 100–120V AC | UV00A10NW |
| | | | 200–240V AC | UV00A20NW |
| | | | 380–450V AC | UV00A40NW |
| | | | 24V DC | UV00D02NW |
| | | | 100–120V DC | UV00D10NW |
| | | | 200–240V DC | UV00D20NW |
| | **S630-CF/NF/NE/GN,<br>H630-NE, L630-NE,<br>S800-CF/NF/RF/PF/NN,<br>S800-NE/RE/PE,<br>H800-NE, L800-NE, S1000-CE/NN,<br>S1250-NE/GE/NN, S1600-NE/NN** | Instantaneous type | 100–110V AC | UV80A10NW |
| | | | 115–120V AC | UV80A12NW |
| | | | 200–220V AC | UV80A20NW |
| | | | 230–240V AC | UV80A24NW |
| | | | 380–415V AC | UV80A40NW |
| | | | 440–450V AC | UV80A45NW |
| | | | 24V DC | UV80D02NW |
| | | | 100–120V DC | UV80D10NW |
| | | | 200–240V DC | UV80D20NW |

Note ① : All internal accessories are for lead wire draw-out.

# 10 TemPlug



Proposal for the Rationalisation of Switchboards and Distribution Boards ····· 10-2

*TemPlug70*

1 Features ····· 10-3
2 Outline dimensions ····· 10-4
T2PG05LS (50A Frame) ····· 10-4
T2PG12LS (100, 125A Frame) ····· 10-4
T2PG12S (50, 100, 125A Frame) ····· 10-4
TPPG12S (50, 100, 125A Frame) ····· 10-5
T2PG25LS (225, 250A Frame) ····· 10-5
T2PG25S (225, 250A Frame) ····· 10-6
T2PG40S (400A Frame) ····· 10-6
TPPG40S (400A Frame) ····· 10-7
T2PG63S (600, 630A Frame) ····· 10-7
3 Specifications ····· 10-8
4 Option ····· 10-8
Blank cover ····· 10-8
Busbar support ····· 10-9
Busbar unit ····· 10-10
5 Circuit breaker arrangement example ····· 10-11
6 Order Form ····· 10-12
7 Use case ····· 10-13

# Proposal for the Rationalisation of Switchboards and Distribution Boards

**Switchboard Contractors** | **End Users (including contractors)** | **Design offices**

## Shortening of production time

Eliminates the onerous task of fabricating and installing branching busbars. Can significantly shorten working time and shorten the lead time to the completion of the switchboard.

## Standardisation of switchboards

The size of the main busbar is determined by the power supply capacity, so it is possible to standardize the switchboards with the same capacity.

## Improved safety by separating blocks

With *TemPlug* the busbar block and circuit breaker block can be separated to create a safer switchboard.

∗ A standard busbar support is prepared to keep the assembly accuracy of the busbar.

## Flexibility to change specifications

Even if the frame size or rated current of the circuit breaker is changed, all you have to do is to replace the *TemPlug*


∗ Be sure to turn off the circuit breaker when inserting or removing the *TemPlug*

## Miniaturisation of the switchboard


*TemPlug* plugs directly into the main busbar, so no space is needed for the branching busbar.

## Standardisation of phase order


If the main busbar is R, S, T from the left, the phase order of the load side can be standardized to R, S, T from the top, regardless of the orientation of the circuit breaker installation.




## Standardisation of busbar specifications




Full round shape
R5




Square
R0.9

| | *TemPlug70* ( PG Series ) |
|---|---|
| Busbar thickness (A) | 10mm |
| Busbar type (B) | Full round shape R5 or square R0.9 |
| Interphase pitch (C) | 70±0.5mm |
| Surface treatment | Sn plating or Ag plating |
| Busbar support | We recommend the use of a dedicated support (BST70). |


# TemPlug 70

## PG Series

Simply plug the *TemPlug* into the main busbar to complete the connection !
Aligned with the handle centreline, no need for height adjustment due to standardized depth dimensions.
We can help you miniaturize, standardize, and shorten the production time for 21st century switchboards and distribution boards.


### Miniaturisation and time reduction

Branching busbars do not need to be fabricated and the width of the switchboard can be reduced.




When using *TemPlug*

### Standardisation & Flexibility



The 15mm pitch mounting holes allow the 100AF to 630AF TemPlugs to be mounted in any position.

Standardized mounting pitch
Multiples of 15mm

### Standardisation

The front panel cutout width is standardized to 92mm

* Excludes high-performance electronic circuit breakers and smart circuit breakers.





The front panel and mounting surface height is standardized

### Safety

- Switchboards where the busbar block (primary side) and equipment (secondary side) are separated can be configured.
- Optional items for circuit breaker can be used for the terminal covers and interpole barriers on the load side.


ASL : Arrangement Standard Line
⊢ : Handle Frame Centre Line
℄ : Handle Centre Line


## T2PG05LS, T2PG12LS




### Applicable breakers

| Type of *TemPlug* | MCCB | ELCB |
|---|---|---|
| **T2PG05LS** | S50-SF, S125-SF (15-50A), ZAS125-SF (15-50A)—3P only | ZS50-SF, ZS125-SF (15-50A), ZS100-SM (16-45A) ] 3P only |
| **T2PG12LS** | S125-SF (60-125A), S125-SN, ZAS125-SF (60-125A) ] 3P only | ZS125-SF (60-125A), ZS100-SM (60-100A) ] 3P only |








＊1 See the outline dimensions of the chapter 7 for the load side connection conductor preparation diagram.

＊2 The busbar pitch (70 ± 0.5) and busbar mounting height (27.5 ± 1) are important dimensions.


＊3 If needed please specify front-connected type with extension bar (optional) on the secondary side when ordering.


## T2PG12S




### Applicable breakers

| Type of *TemPlug* | MCCB | ELCB |
|---|---|---|
| **T2PG12S** | ZAS50-GF, ZAS100-GF, ZAS125-GF, S100-GF, S125-GF ] 3P only | ZS100-GF, ZS125-GF ] 3P only |




＊1 See the outline dimensions of the chapter 7 for the load side connection conductor preparation diagram.


＊2 The busbar pitch (70 ± 0.5) and busbar mounting height (27.5 ± 1) are important dimensions.


＊3 If needed please specify front-connected type with extension bar (optional) on the secondary side when ordering.

ASL : Arrangement Standard Line
⊬ : Handle Frame Centre Line
℄ : Handle Centre Line




## TPPG12S





### Applicable breakers

| Type of *TemPlug* | MCCB |
|---|---|
| **TPPG12S** | PS125-NF, PS50-PF, PS125-PF,<br>PS125-NE, PS125-PE, PS125-NN ] 3P only |





Note:Smart circuit breakers have a different panel cutout and are not compatible with panel cutout width 92mm.


＊1 See the outline dimensions of the chapter 7 for the load side connection conductor preparation diagram.

＊2 The busbar pitch (70 ± 0.5) and busbar mounting height (27.5 ± 1) are important dimensions.

＊3 If needed please specify front-connected type with extension bar (optional) on the secondary side when ordering.


## T2PG25LS





### Applicable breakers

| Type of *TemPlug* | MCCB | ELCB |
|---|---|---|
| **T2PG25LS** | E250-SF, S250-SF, S250-SM, S250-SN, ZAE250-SF, ZAS250-SF, PS250-PF, PS250-NE, PS250-PE, PS250-NN | ZE250-SF, ZS250-SF, ZS250-SM |




Note:Smart circuit breakers have a different panel cutout and are not compatible with panel cutout width 92mm.


＊1 See the outline dimensions of the chapter 7 for the load side connection conductor preparation diagram.

＊2 The busbar pitch (70 ± 0.5) and busbar mounting height (27.5 ± 1) are important dimensions.

＊3 If needed please specify front-connected type with extension bar (optional) on the secondary side when ordering.


ASL : Arrangement Standard Line
⊢⊣ : Handle Frame Centre Line
℄ : Handle Centre Line


## T2PG25S




### Applicable breakers

| Type of *TemPlug* | MCCB | ELCB |
|---|---|---|
| **T2PG25S** | ZAS225-GF, ZAS250-GF | ZS225-GF, ZS250-GF |





∗1 See the outline dimensions of the chapter 7 for the load side connection conductor preparation diagram.

∗2 The busbar pitch (70 ± 0.5) and busbar mounting height (27.5 ± 1) are important dimensions.

∗3 If needed please specify front-connected type with extension bar (optional) on the secondary side when ordering.


## T2PG40S


ASL : Arrangement Standard Line
⊢⊣ : Handle Frame Centre Line




### Applicable breakers

| Type of *TemPlug* | MCCB | ELCB |
|---|---|---|
| **T2PG40S** | ZAE400-NF, ZAS400-NF, ZAS400-GF, E400-NF | ZE400-NF, ZS400-NF, ZS400-GF |




Note:High-Performance electronic circuit breakers have a different panel cutout and are not compatible with panel cutout width 92mm.

∗1 See the outline dimensions of the chapter 7 for the load side connection conductor preparation diagram.

∗2 When using a steel plate for the mounting angle, the thickness of the plate should be 3.2t or more.


∗3 Install the guide bolts in this position first and position them.


∗4 The busbar pitch (70 ± 0.5) and busbar mounting height (27.5 ± 1) are important dimensions.

∗5 If needed please specify front-connected type with extension bar (optional) on the secondary side when ordering.

ASL : Arrangement Standard Line
Handle Frame Centre Line
Handle Centre Line

## TPPG40S









### Applicable breakers

| Type of *TemPlug* | MCCB |
|---|---|
| **TPPG40S** | PS400-CF, PS400-NF, PS400-GF, PS400-NE, PS400-GE, PH400-CF①, PH400-CE①, PS400-NN, PS630-CF 500A, PS630-NF 500A, PS630-GF 500A, PS630-NN 500A, PH630-CF 500A① |

Note① : These are special types that can be used. However, due to the limitation of the short-time withstand current of the busbar, they cannot be applied to circuits with a short circuit breaking current exceeding 85kA.









Note:Smart circuit breakers have a different panel cutout and are not compatible with panel cutout width 92mm.

*1 See the outline dimensions of the chapter 7 for the load side connection conductor preparation diagram.
*2 When using a steel plate for the mounting angle, the thickness of the plate should be 3.2t or more.
*3 Install the guide bolts in this position first and position them.
*4 The busbar pitch (70 ± 0.5) and busbar mounting height (27.5 ± 1) are important dimensions.
*5 For 400A frames, if needed please specify front-connected type with extension bar (optional) on the secondary side when ordering.

ASL : Arrangement Standard Line
Handle Frame Centre Line


## T2PG63S





### Applicable breakers

| Type of *TemPlug* | MCCB | ELCB | A (mm) |
|---|---|---|---|
| **T2PG63S** | S630-CF, S630-NF, S630-GN | | 61 |
| | S630-NE, ZAS630-CF, ZAS630-NF | ZS630-CF, ZS630-NF | 63 |




Note:High-Performance electronic circuit breakers have a different panel cutout and are not compatible with panel cutout width 92mm.

*1 When using a steel plate for the mounting angle, the thickness of the plate should be 3.2t or more.
*2 Install the guide bolts in this position first and position them.
*3 The busbar pitch (70 ± 0.5) and busbar mounting height (27.5 ± 1) are important dimensions.

## 100A to 630A Frame

| Plug-in base type *1 | poles | Applicable breakers | | | | | |
|---|---|---|---|---|---|---|---|
| | | Moulded case circuit breakers | Non-automatic trip breakers/ Switch disconnectors (3P only) | Circuit breakers with earth leakage alarm (3P only) | Earth leakage circuit breakers (3P only) | Moulded case circuit breakers for motor protection (3P only) | Earth leakage circuit breakers for motor protection (3P only) |
| T2PG05LS | 2<br>3 | S50-SF,<br>S125-SF (15-50A) | | ZAS125-SF (15-50A) | ZS50-SF,<br>ZS125-SF (15-50A) | | ZS100-SM<br>(16-45A) |
| T2PG12LS | 2<br>3 | S125-SF (60-125A) | S125-SN | ZAS125-SF (60-125A) | ZS125-SF (60-125A) | | ZS100-SM<br>(60-100A) |
| T2PG12S | 2<br>3 | S100-GF,<br>S125-GF | | ZAS50-GF, ZAS100-GF,<br>ZAS125-GF | ZS100-GF,<br>ZS125-GF | | |
| TPPG12S | 2 | PS125-NF,<br>PS50-PF, PS125-PF | | | | | |
| | 3 | PS125-NF,<br>PS50-PF, PS125-PF,<br>PS125-NE*2,<br>PS125-PE*2 | PS125-NN | | | | |
| T2PG25H | 3 | H100-NF*3*4, H125-NF*3*4,<br>H225-NF*3*4 | | | | | |
| T2PG25LS | 3 | E250-SF, S250-SF,<br>PS250-PF, PS250-NE*2,<br>PS250-PE*2 | S250-SN, PS250-NN | ZAE250-SF,<br>ZAS250-SF | ZE250-SF,<br>ZS250-SF | S250-SM | ZS250-SM |
| T2PG25S | 3 | | | ZAS225-GF, ZAS250-GF | ZS225-GF, ZS250-GF | | |
| T2PG40S | 3 | E400-NF | | ZAE400-NF, ZAS400-NF,<br>ZAS400-GF | ZE400-NF,<br>ZS400-NF, ZS400-GF | | |
| TPPG40S | 3 | PS400-CF, PS400-NF,<br>PS400-GF, PH400-CF*3,<br>PS400-NE*2, PS400-GE*2,<br>PH400-CE*2*3,<br>PS630-CF 500A, PS630-NF 500A,<br>PS630-GF 500A, PS630-NN 500A,<br>PH630-CF 500A*3 | PS400-NN,<br>PS630-NN 500A | | | | |
| T2PG63S | 3 | S630-CF, S630-NF,<br>S630-NE*2 | S630-GN | ZAS630-CF,<br>ZAS630-NF | ZS630-CF, ZS630-NF | | |


Use full-round R5 or square R0.9 with a plate thickness of 10mm for the main busbar.
If used in a multi-stack, please consider the temperature of the busbar for a 30K rise under JIS C 4620.

* 1 : The plug-in base is not supplied as a single item. Order together with the circuit breaker.
* 2 : High-performance electronic circuit breakers and smart circuit breakers are not compatible with panel cutout width 92mm.
* 3 : These are special types that can be used. However, due to the limitation of the short-time withstand current of the busbar, they cannot be applied to circuits with a short circuit breaking current exceeding 85kA.
* 4 : Please contact us for the outline dimensions.




## Blank cover for *TemPlug 70*


(Option)



A cover that covers the gap between the *TemPlug* and separates them from the busbar block.
It can be easily divided in 15mm increments, so cut it to fit the gap.

**Type XDI-BCOVER**








| | | |
|---|---|---|
| If folded into 1 in series | A=14.5 | B=0 |
| If folded into 2 in series | A=29.5 | B=15 |
| If folded into 3 in series | A=44.5 | B=30 |
| If folded into 4 in series | A=59.5 | B=45 |
| If folded into 5 in series | A=74.5 | B=60 |
| If folded into 6 in series | A=89.5 | B=75 |
| If folded into 7 in series | A=104.5 | B=90 |
| | A=119 | B=105 for 8 in series |

## Busbar support for *TemPlug 70*


We recommend the use of a busbar support in order to achieve an accurate busbar pitch of 70mm.

**Type BST 70**




### When using *TemPlug 70*

①The recommended values for the busbar support interval to interrupt short-circuit current with an MCCB are as shown in the table below.




For rated breaking capacity 460V AC 50kA


| Busbar size | Busbar support interval L (mm) | | |
|---|---|---|---|
| | 225A | 400A | 600/630A |
| 10t×50w | 585 | 405 | 345 |
| 10t×100w | 735 | 525 | 450 |

For rated breaking capacity 220V AC 85kA

| Busbar size | Busbar support interval L (mm) | | |
|---|---|---|---|
| | 225A | 400A | 600/630A |
| 10t×50w | 690 | 525 | 390 |
| 10t×100w | 885 | 660 | 495 |

②In order to withstand a short-time current of 50kA for 1 second the distance between the busbar supports should be 300mm.

In order to withstand a short-time current of 85kA for 1 second the distance between the busbar supports should be 150mm.




Note1. When using a busbar of 10t × 125w or more, use a bushing type support, too.
Note2. When using a 50w or 75w busbar, the relationship between the busbar and the busbar support mounting hole is the same, and the busbar support can be mounted inversely in the horizontal direction.
Note3. The busbar support should be secured to a strong L-shaped angle or similar.

### *TemPlug 70* confirmation jig

**Type XDI-GAUGE**



*TemPlug 70* confirmation jig is a Go/No Go gauge that determines whether the plug-in base is properly inserted into the busbar.

(Not available for T2PG05LS 3P, T2PG12LS 3P, T2PG12S 2P/3P and TPPG12S 2P/3P.)

## Busbar unit for *TemPlug 70*


We have prepared busbar units to standardize and shorten the production time for switchboards.
Every busbar unit is inspected before shipment for tolerances such as busbar pitch, busbar mounting height, and lateral dimensions of the busbar and plug-in base mounting screw holes, so you can be assured of product quality.

### Slim type branch dedicated type

The branch circuit breaker can be installed on the line side or load side, either on the left or right.

| Type | Rated current | Busbar width (mm) | E (mm) | F (mm) | L (mm) | P (mm) | D (mm) | Short-time current |
|---|---|---|---|---|---|---|---|---|
| BW 9-B-50S | 900A | 50 Fig.① | 52 | — | 1500 | 680 | 200 | 50kA 1sec |
| BW12-B-50S | 1200A | 75 Fig.① | 64.5 | — | | | | |
| BW15-B-50S | 1500A | 100 Fig.② | 52 | 50 | | | | |
| BW 9-B17-50S | 900A | 50 Fig.① | 52 | — | 1700 | 780 | 200 | 50kA 1sec |
| BW12-B17-50S | 1200A | 75 Fig.① | 64.5 | — | | | | |
| BW15-B17-50S | 1500A | 100 Fig.② | 52 | 50 | | | | |
| BW 9-B-85S | 900A | 50 Fig.① | 52 | — | 1500 | 680 | 200 | 85kA 1sec |
| BW12-B-85S | 1200A | 75 Fig.① | 64.5 | — | | | | |
| BW15-B-85S | 1500A | 100 Fig.② | 52 | 50 | | | | |
| BW21-B-85S | 2100A | 150 Fig.③ | 52 | 50 | | | 250 | |
| BW 9-B17-85S | 900A | 50 Fig.① | 52 | — | 1700 | 780 | 200 | 85kA 1sec |
| BW12-B17-85S | 1200A | 75 Fig.① | 64.5 | — | | | | |
| BW15-B17-85S | 1500A | 100 Fig.② | 52 | 50 | | | | |
| BW21-B17-85S | 2100A | 150 Fig.③ | 52 | 50 | | | 250 | |


The outline drawing shows the case of a rated current of 900A and short-time current of 50kA 1sec.



## 100A to 630A Frame



### Circuit breaker mounting drawing





* The busbar pitch (70±0.5) and busbar mounting height (27.5±1) are important dimensions.

### Circuit breaker centre-to-centre pitch

#### For close fitting mounting

(Close fitting is possible in the case of lead wire draw-in. However, circuit breakers with earth leakage alarm except for ZAE250-SF and ZAS250-SF cannot be close fitted.)




**a dimensions**

| Circuit breaker frame size | | 50/100/125AF 2P | 50/100/125AF 3P | 50/100/125AF 3P | 225/250AF 3P | 400AF 3P | 600/630AF 3P |
|---|---|---|---|---|---|---|---|
| | *TemPlug* Type | T2PG05LS 2P T2PG12LS 2P T2PG12S 2P TPPG12S 2P | T2PG05LS 3P T2PG12LS 3P | T2PG12S 3P TPPG12S 3P | T2PG25LS 3P T2PG25S 3P | T2PG40S 3P TPPG40S 3P | T2PG63S 3P |
| 50/100/125AF 2P | T2PG05LS 2P T2PG12LS 2P T2PG12S 2P TPPG12S 2P | 60 | 67.5 | 75 | 90 | 120 | 150 |
| 50/100/125AF 3P | T2PG05LS 3P T2PG12LS 3P | 67.5 | 75 | 82.5 | 97.5 | 127.5 | 157.5 |
| 50/100/125AF 3P | T2PG12S 3P TPPG12S 3P | 75 | 82.5 | 90 | 105 | 135 | 165 |
| 225/250AF 3P | T2PG25LS 3P T2PG25S 3P | 90 | 97.5 | 105 | 120 | 150 | 180 |
| 400AF 3P | T2PG40S 3P TPPG40S 3P | 120 | 127.5 | 135 | 150 | 180 | 210 |
| 600/630AF 3P | T2PG63S 3P | 150 | 157.5 | 165 | 180 | 210 | 240 |

#### When mounting a blank cover

If the circuit breaker has a lead wire terminal block, use about one to three blank covers. (See the figure on the left)

**a dimensions**







| Circuit breaker frame size | | 50/100/125AF 2P | 50/100/125AF 3P | 50/100/125AF 3P | 225/250AF 3P | 400AF 3P | 600/630AF 3P |
|---|---|---|---|---|---|---|---|
| | *TemPlug* type | T2PG05LS 2P T2PG12LS 2P T2PG12S 2P TPPG12S 2P | T2PG05LS 3P T2PG12LS 3P | T2PG12S 3P TPPG12S 3P | T2PG25LS 3P T2PG25S 3P | T2PG40S 3P TPPG40S 3P | T2PG63S 3P |
| 50/100/125AF 2P | T2PG05LS 2P T2PG12LS 2P T2PG12S 2P TPPG12S 2P | 75 | 82.5 | 90 | 105 | 135 | 165 |
| 50/100/125AF 3P | T2PG05LS 3P T2PG12LS 3P | 82.5 | 90 | 97.5 | 112.5 | 142.5 | 172.5 |
| 50/100/125AF 3P | T2PG12S 3P TPPG12S 3P | 90 | 97.5 | 105 | 120 | 150 | 180 |
| 225/250AF 3P | T2PG25LS 3P T2PG25S 3P | 105 | 112.5 | 120 | 135 | 165 | 195 |
| 400AF 3P | T2PG40S 3P TPPG40S 3P | 135 | 142.5 | 150 | 165 | 195 | 225 |
| 600/630AF 3P | T2PG63S 3P | 165 | 172.5 | 180 | 195 | 225 | 255 |

# Order Form

When ordering a *TemPlug*, please specify the "breaker type", "number of poles", "*TemPlug* series abbreviation" and "connection type" (for 2 poles). It is not necessary to fill in the individual type of *TemPlug* (plug-in base type) because we do not supply plug-in bases as a single item.
We will deliver it as a set with the circuit breaker.

| | *TemPlug* series abbreviation |
|---|---|
| *TemPlug70* | PG |

When the number of poles is 2P, the following three types of plug-in base are available, depending on the phase to be connected.
Please specify which connection type.


| Connection type | For ON (line side) left mounting | For ON (line side) right mounting |
|---|---|---|
| A |  R-S(N) phase connection |  T-S(N) phase connection |
| B |  T-S(N) phase connection |  R-S(N) phase connection |
| C |  R-T phase connection |  R-T phase connection |


## Order code

EX. 1
「PS125-NF」+「2P」+「PG」+「A」
EX. 2
「PS250-PF」+「3P」+「PG」

## Use case


# Flexibility to change specifications





The system can easily accommodate changes to the circuit breakers or additions due to changes in load capacity, as well as changes in the use of the circuit breaker.
Note: We recommend turning off the power when replacing circuit breakers for safety. However, in emergencies or when it is impossible to turn off the power, it is possible to replace a circuit breaker when energised, provided that the breaker is turned off and the work is carried out with due consideration for safety.


# Miniaturisation of the switchboard



*TemPlug* plugs directly into the main busbar, so no space is needed for the branching busbar. This makes it possible to reduce the width of the switchboard.

# Standardisation of phase order

R S T R S T R S T



R S T R S T R S T


RST RST

Regardless of the mounting orientation of the circuit breaker, the phase order of the load side can be standardized to R, S, T from the top.

*TemPlug* uses the contact part used in the motor control centre (MCC). Terasaki has developed this technology over many years in our marine switchboards.

- Short circuit test
- Short-time withstand current test
- Vibration test
- Insertion test
- Multi-step temperature test (photo on the right)

We conduct a variety of tests, such as:



Status of multi-step temperature test

# TemCurve Lite

- for windows 7/8/8.1/10 -




## TemCurve Lite

**can carry out the selectivity studies for Terasaki low-voltage air circuit breakers and moulded case circuit breakers very simply and quickly.**


## Comprehensive device database

Included in the software are high-voltage and low-voltage fuses, Terasaki air circuit breakers, Terasaki moulded case circuit breakers, Terasaki miniature breakers for distribution boards and overcurrent relays, etc. Moreover, it is possible to input thermal resistant characteristics of generators if needed, and to have a look at generator protections coordination.



## Time-current curves can be adjusted easily

The time-current curves can be adjusted by choosing different pick-up currents and the operating times. The time-current curves can also be easily adjusted by using the curve drag feature.





Select the value from pull down menu

Drag the characteristic curve with the mouse

## Simple coordination with high-voltage devices


It is possible to coordinate between high-voltage and low-voltage devices by inputting the voltage of the high-voltage side.




Input the circuit voltage


## Output the coordination characteristics curves into CAD

The time-current curves drawn can be output in a DXF format file, and can be used in CAD software. Moreover, you can adjust the scale of the graph for the curves on a horizontal axis (current) and a vertical axis (time). PDF format file also can be output.




## Output single line diagram with the setting values of the devices

Once the time-current curves are drawn, a single line diagram can be printed with individual device settings.




*TemCurve Lite* is the free software for windows 7 / 8 / 8.1/10.
Contact us for details.

【Contact】 E-mail: temcurve@terasaki.co.jp



*TERASAKI ELECTRIC (EUROPE) LTD.*
*FILIAL SVERIGE*
*(Sweden)*



*TERASAKI ELECTRIC (EUROPE) LTD.*
*(United Kingdom)*




*TERASAKI ELECTRIC (EUROPE) LTD.*
*SUCURSAL EN ESPAÑA*
*(Spain)*



*TERASAKI ELECTRIC (EUROPE) LTD.*
*FILIALE ITALIA*
*(Italy)*

# TERASAKI Global Network



*TERASAKI ELECTRIC CO., LTD.*
*(Head Quarters, Japan)*



*TERASAKI ELECTRIC*
*(M) SDN. BHD.*
*(Malaysia)*




*TERASAKI CIRCUIT*
*BREAKERS (S) PTE. LTD.*

*TERASAKI ELECTRIC CO.,*
*(FAR EAST) PTE. LTD.*
*(Singapore)*



*TERASAKI DO BRASIL LTDA.*
*(Brazil)*



*TERASAKI ELECTRIC*
*(SHANGHAI) CO., LTD.*
*(China)*



*TERASAKI ELECTRIC*
*(CHINA) LTD.*
*(China)*

Since 1971 when we established TERASAKI ELECTRIC Europe, our first overseas subsidiary, in the UK, we have assembled a global network of 10 overseas subsidiaries and 72 agents to provide sales and technical supports to customers worldwide.

## ⚠ Safety Notice

Carefully read instruction manual to ensure proper installation, connection, operation, handling and maintenance of the product.


**TERASAKI ELECTRIC CO., LTD.**

Head Office: 6-13-47 Kamihigashi, Hirano-ku, Osaka 547-0002, Japan
Circuit Breaker Division: 6-13-47 Kamihigashi, Hirano-ku, Osaka 547-0002, Japan
TEL +81-6-6791-2763
FAX +81-6-6791-2732
int-sales@terasaki.co.jp
https://www.terasaki.co.jp/



OCT. 2023 Catalogue No. '23-I68E



Ratings and specifications are subject to change without notice.